



# Allied Telesis Gateway Product Family Software Reference Release 4.6

---

Copyright © 2001-2019 Allied Telesis Holdings K. K. - all rights reserved.

Copyright © 2001-2019 Broadcom Corporation.

No part of this publication may be reproduced without prior written permission from Allied Telesis, Inc.

Allied Telesis and the Allied Telesis logo are trademarks of Allied Telesis, Incorporated. All other product names, company names, logos or other designations mentioned herein are trademarks or registered trademarks of their respective owners.

Allied Telesis, Inc. reserves the right to make changes in specifications and other information contained in this document without prior written notice. The information provided herein is subject to change without notice. In no event shall Allied Telesis, Inc. be liable for any incidental, special, indirect, or consequential damages whatsoever, including but not limited to lost profits, arising out of or related to this manual or the information contained herein, even if Allied Telesis, Inc. has been advised of, known, or should have known, the possibility of such damages.

## 2 Setting up the Gateway----- 16

<b>2.1 Getting Started</b>	<b>16</b>
2.1.1 Introduction	16
2.1.2 How to Access the Product	16
2.1.3 TR-069 Management and Scope of Control for the Management Interfaces	17
2.1.4 The Command Interface (CLI)	18
2.1.5 How to Work with Command Modes	21
2.1.6 How to See the Current Configuration (running-config)	26
2.1.7 Default Settings	26
2.1.8 The Default Configuration	27
2.1.9 Defining a User/Password	27
2.1.10 How to Set an IP Address on VLAN 1	27
2.1.11 How to Save and Boot from the Current Configuration	28
2.1.12 How to Return to the Factory Defaults	30
2.1.13 Recovery of Single Image (iMG1400)	31
2.1.14 How to See System Information	31
2.1.15 How to Set System Parameters	32
2.1.16 How to Set the Time and Date	33
2.1.17 How to Add and Remove Users	34
2.1.18 How to Undo Settings and Restore Parameters to Defaults (no option)	35
2.1.19 How to Upgrade the Firmware	36
2.1.20 How to configure Wireless	36
2.1.21 Commands Available in each Mode	37
<b>2.2 Command Syntax Conventions in this Software Reference</b>	<b>38</b>
<b>2.3 Start-up Sequence</b>	<b>39</b>
<b>2.4 CLI Navigation Commands</b>	<b>40</b>
2.4.1 CLI Navigation Commands	41
<b>2.5 User Access Commands</b>	<b>50</b>
2.5.1 User Access Commands	51
<b>2.6 Creating and Managing Configuration Files</b>	<b>66</b>
2.6.1 Introduction	66
2.6.2 Software Updates from TFTP server	66
2.6.3 Listing Configuration Files	67
2.6.4 Creating and Using Configuration Files	68
2.6.5 Creating a configuration file	68
2.6.6 Specifying the start-up configuration script	69
2.6.7 Working with configuration files	70
2.6.8 The configuration file fallback order	70
2.6.9 Copying Files To and From Your Device	71
2.6.10 URL syntax	71
2.6.11 Copying files	71
<b>2.7 File Management Commands</b>	<b>72</b>
2.7.1 File Management Commands	73
<b>2.8 System Configuration and Monitoring Commands</b>	<b>94</b>

2.8.1 System Configuration and Monitoring Commands .....	95
<b>2.9 Software Update .....</b>	<b>114</b>
2.9.1 Introduction .....	114
2.9.2 Software Update Command List .....	114
<b>2.10 Debugging and Logging .....</b>	<b>117</b>
2.10.1 Introduction .....	117
2.10.2 Debugging .....	118
2.10.3 Logging .....	119
<b>2.11 Debugging and Logging Commands .....</b>	<b>120</b>
2.11.1 Debugging and Logging Commands .....	121
<b>2.12 Interfaces .....</b>	<b>128</b>
2.12.1 PPPoE .....	128
2.12.2 HPNA .....	128
<b>2.13 Interface Commands .....</b>	<b>129</b>
2.13.1 Interface Commands .....	130
<b>2.14 Example Configuration .....</b>	<b>144</b>
 <b>3 Routing .....</b>	 <b>146</b>
<b>3.1 Introduction .....</b>	<b>146</b>
3.1.1 Assigning an IP Address .....	146
3.1.2 Static IP addresses .....	146
3.1.3 DHCP dynamic addresses .....	147
<b>3.2 Address Resolution Protocol (ARP) .....</b>	<b>147</b>
<b>3.3 Domain Name System (DNS) .....</b>	<b>147</b>
3.3.1 Domain name parts .....	148
3.3.2 Server hierarchy .....	148
3.3.3 DNS Client .....	148
3.3.4 Dynamic DNS (ddns) .....	149
3.3.5 DHCP options .....	149
<b>3.4 Internet Control Message Protocol (ICMP) .....</b>	<b>149</b>
<b>3.5 Checking IP Connections (ping and traceroute) .....</b>	<b>150</b>
3.5.1 Ping .....	150
3.5.2 Traceroute .....	150
<b>3.6 Multiple IP Addresses on a Subinterface (subvlan) .....</b>	<b>151</b>
3.6.1 Overview .....	151
3.6.2 Creating a sub-vlan .....	152
3.6.3 Features that use subvlans .....	152
<b>3.7 Layer 3 Routing - iMG .....</b>	<b>152</b>
3.7.1 Layer 3 Routing Command List .....	153
<b>3.8 IPv6 .....</b>	<b>174</b>
3.8.1 Overview .....	174
3.8.2 IPv6 Addresses and Prefixes .....	175
3.8.3 Address Types .....	175
3.8.4 IPv6 Headers .....	176
3.8.5 Basic IPv6 Header Structure .....	177
3.8.6 The Internet Control Message Protocol (ICMPv6) .....	178
3.8.7 Stateless Address Autoconfiguration (SLAAC) .....	179



3.8.8 IPv6 Routing - - - - -	180
3.8.9 Integration of IPv4 and IPv6 - - - - -	180
3.8.10 Enabling IPv6 on the iMG - - - - -	180
3.8.11 IPv6 and IPv4 on the iMG - - - - -	181
3.8.12 IPv6 Command List - - - - -	182

## 4 Switching- - - - - 206

<b>4.1 Physical Layer - - - - -</b>	<b>206</b>
4.1.1 Port attributes - - - - -	206
4.1.2 Port Numbering- - - - -	207
4.1.3 Support for using Copper interface as WAN interface - - - - -	208
4.1.4 SFP pluggable models compatibility - - - - -	208
4.1.5 Using Port ranges - - - - -	210
4.1.6 Activating and Deactivating Switch Ports - - - - -	210
4.1.7 Autonegotiation - - - - -	210
4.1.8 Duplex mode - - - - -	210
4.1.9 Speed options - - - - -	211
4.1.10 Port Mirroring - - - - -	211
4.1.11 Quality of Service - - - - -	212
4.1.12 Loop Protection - - - - -	212
4.1.13 Port Security - - - - -	213
4.1.14 Port Security Command List- - - - -	214
4.1.15 HPNA Interface - - - - -	221
4.1.16 Wireless Interface - - - - -	221
4.1.17 The Layer 2 Switching Process - - - - -	222
4.1.18 Switching Command List - - - - -	226
<b>4.2 VLAN - General - - - - -</b>	<b>250</b>
4.2.1 Introduction - - - - -	250
4.2.2 Virtual LANs (VLANs) - - - - -	250
4.2.3 Configuring VLANs- - - - -	251
4.2.4 VLAN Double Tagging (VLAN Stacking) - - - - -	253
4.2.5 How Double-Tagged VLANs Work- - - - -	253
4.2.6 VLAN Rules for Double Tagging - - - - -	253
4.2.7 Restrictions when using Double-Tagged VLANs- - - - -	254
4.2.8 Configuring Double-Tagged VLANs - - - - -	254
<b>4.3 VLAN - iMG - - - - -</b>	<b>255</b>
4.3.1 VLAN Commands - - - - -	258
<b>4.4 PPPoE - - - - -</b>	<b>268</b>
4.4.1 PPPoE Protocol Components - - - - -	268
4.4.2 Automatically populating routing table and DNS server table - - - - -	269
4.4.3 IPv6 Support - - - - -	270
4.4.4 Activating the Feature - - - - -	270
4.4.5 PPPoE Commands - - - - -	271
<b>4.5 HPNA - - - - -</b>	<b>278</b>
4.5.1 HPNA Commands - - - - -	279
<b>4.6 Wireless - - - - -</b>	<b>286</b>
4.6.1 Wireless Commands- - - - -	288

<b>5 Multicast Applications</b>	<b>315</b>
<b>5.1 IGMP Snooping Introduction and Configuration</b>	<b>315</b>
5.1.1 Multicasting overview	315
<b>5.2 IGMP Snooping on iMG</b>	<b>317</b>
5.2.1 IGMP Snoop Only Mode	317
5.2.2 IGMP Proxy Mode	320
5.2.3 IGMP Proxy Routed Mode (Multicast Acceleration)	323
5.2.4 Multicast Command List	326
<b>6 Access and Security</b>	<b>340</b>
<b>6.1 Quality of Service Model</b>	<b>340</b>
6.1.1 Address management	340
6.1.2 Rate limiting support	340
6.1.3 Quality of Service Classification	341
6.1.4 802.1p traffic priority	341
6.1.5 Differentiated services code point (DSCP)	341
6.1.6 QoS Command List	343
<b>6.2 Secure Shell Protocol</b>	<b>354</b>
6.2.1 Introduction	354
6.2.2 Configuring the SSH Server	355
6.2.3 SSH Command List	356
<b>6.3 Security (Trigger, Firewall, Access Control List, Logging)</b>	<b>359</b>
6.3.1 Overview	359
6.3.2 Triggers	359
6.3.3 Firewall	360
6.3.4 Port Filters (using the GUI)	360
6.3.5 Logging Intrusion Attempts	361
6.3.6 Access Control List (ACL)	361
6.3.7 IPv6 Access Lists	362
6.3.8 Protected Ports	362
6.3.9 Security Command List	363
<b>7 Network Management</b>	<b>379</b>
<b>7.1 Network Address Translation (NAT)</b>	<b>379</b>
7.1.1 Introduction	379
7.1.2 NAT on the iMG	379
7.1.3 NAT Command List	380
<b>7.2 Network Time Protocol (NTP)</b>	<b>386</b>
7.2.1 Introduction	386
7.2.2 NTP on the iMG	386
7.2.3 NTP Command List	388
<b>7.3 Dynamic Host Configuration Protocol (DHCP)</b>	<b>393</b>
7.3.1 BOOTP	393
7.3.2 DHCP	393
7.3.3 Configuring the DHCP Server	394
7.3.4 Configuring the DHCP Client	396
7.3.5 DHCP Command list	397

<b>7.4 Simple Network Management Protocol (SNMP)</b>	<b>430</b>
7.4.1 Introduction	430
7.4.2 Network Management Framework	431
7.4.3 Structure of Management Information	432
7.4.4 Names	433
7.4.5 Instances-	433
7.4.6 Syntax	434
7.4.7 Access	434
7.4.8 Status-	434
7.4.9 Description-	434
7.4.10 The SNMP Protocol	434
7.4.11 SNMP Communities (Version v1 and v2c)	437
7.4.12 Configuration Example (SNMPv1 and v2)	438
7.4.13 Object ID (OID) Numbers for iMG Models-	438
7.4.14 The following OIDs are registered for the iMG Models.SNMP Command List	439
<b>7.5 TR69 Configuration</b>	<b>450</b>
7.5.1 Introduction	450
7.5.2 TR69 Command List-	451
7.5.3 Universal Plug and Play	458
<b>8 Voice Management</b>	<b>463</b>
<b>8.1 Voice Service and Protocols</b>	<b>463</b>
8.1.1 Introduction	463
8.1.2 MGCP	463
8.1.3 SIP-	466
8.1.4 Services (Common)	469
8.1.5 Voice Quality Management-	474
<b>8.2 Voice Service Configuration for the iMG</b>	<b>475</b>
8.2.1 Overview	475
8.2.2 Basic Command Sequences for Provisioning	476
<b>8.3 Command Reference</b>	<b>478</b>
8.3.1 Voice Service Logging	479
8.3.2 Voice Service Command List (config-voi-serv)	483
8.3.3 Enable/Disable MGCP Command List (config-serv-mgcp)-	495
8.3.4 Enable/Disable SIP Command List (config-serv-sip)	500
8.3.5 Configure MGCP Protocol Command List (config-mgcp)-	507
8.3.6 Configure SIP Protocol Command List (config-sip-ua)	523
8.3.7 Configuring Voice Prefix Replacement (config-voi-trans-rule)	538
<b>8.4 Configuring Voice Applications on Device and Ports-</b>	<b>541</b>
8.4.1 Access Codes (Supplementary Services) Command list (config-voipapp-fac)	543
8.4.2 Supplementary Service Command list (voipapp-suppl-serv-port)	565
8.4.3 Endpoint Command List (config-voice-port)	575
8.4.4 Configuring Codecs Command List	601
8.4.5 Voice Diagnostic Command List	603
<b>8.5 Configuring Dial Peers</b>	<b>606</b>
8.5.1 Configuring Dial Peers Command List (config-dial-peer)	607
<b>9 Using the GUI Application</b>	<b>616</b>
<b>9.1 Overview</b>	<b>616</b>
9.1.1 Introduction	616

---

<b>9.2 Menu Levels</b>	<b>617</b>
<b>9.3 Split Management</b>	<b>621</b>
<b>10 AMF</b>	<b>623</b>
<b>10.1 AMF Agent Support</b>	<b>623</b>
10.1.1 Introduction	623
10.1.2 AMF Agent Command List	624
<b>11 Sample Command Sequences</b>	<b>627</b>
<b>11.1 Introduction</b>	<b>627</b>
11.1.1 Configuring the iMG (except for Voice Service)	627
11.1.2 Configuring Voice Service (SIP)	630
11.1.3 Configuring Voice Service (MGCP)	631
11.1.4 IPv6 Configuration	633
<hr/>	
<b>Appendix A: Command List 635</b>	
<hr/>	
<b>Appendix B: Windows 7, 8, and 10 Drivers 645</b>	
<b>B.1 Uninstalling the Existing Driver</b>	<b>645</b>
<b>B.2 Installing the Windows 7 (Or 8 or 10) Native Driver</b>	<b>648</b>
<b>B.3 Disabling IPv6 on the USB Interface</b>	<b>654</b>

# I. Preface

## I Introduction

### I.1 Purpose of this manual

The Allied Telesis Gateway product set delivers multiple IP-based broadband services to home over high speed, always-on broadband connection. This Allied Telesis Gateway Product Family of devices enables the delivery of voice, data, and video to customer premises, offering benefits both to service providers and to final users. Service providers can quickly deliver to their customers advanced services such as fast Internet, VoIP, and video on demand in a full scalable way that is remotely manageable. End users get the benefit of a unique device interconnecting all peripherals, computers, and telephones using a single up-link broadband connection.

This manual is the complete reference to the configuration, management, and operation of the Allied Telesis Gateway Product Family of devices. It includes detailed descriptions of all management commands.

It is assumed that the reader is familiar with:

- The topology of the network in which the Intelligent Media Gateway is to be used.
- Basic principles of computer networking, protocols and routing, and interfaces.
- Administration and operation of a computer network.

## II Intended audience

This manual is intended for the system administrators, network designers and field technicians that need to configure and maintain AT-iMG1500, AT-iMG2500, AT-iMG1400 and AT-iMG2400 gateway families.

## III How this Document is Organized

### III.1 Sections

This preface provides an overview of the supported iMG models including the type of Network Interface, Number of Ethernet LAN interfaces and the number and type of Voice ports.

### III.2 Document Issue

An iMG Software release is in the format x-x-xx, for major-minor-point. This manual may or may not be issued for any point release, since some point releases do not affect documentation. Moreover, a document may be re-issued for a point release if further documentation changes are needed. Following is the issue numbering so far for the iMG 4-6 software.

**TABLE 1-1 Document Issue Numbering for Release 4-6**

Release	Issue 1	Issue 2	Notes
			No formal documentation release
4.1	X	X	Golden Master (GM) release
4.1.1	X		General Availability (GA) for 4.1 software release
4.1.2	X	X	Golden Master (GM) release
4-2	X		Golden Master (GM) release
4-2-3	X		General Availability (GA) for 4.2 software release
4-3	X		Golden Master (GM) release
4-3-2	X		General Availability (GA) for 4.3 software release
4-3-3	X		Golden Master (GM) release
4-4	X		General Availability (GA)
4-5	X		General Availability (GA)
4-6	X		General Availability (GA)

## IV Allied Telesis Gateway Family Feature Summary

### IV.I IEEE 802.1Q VLAN SUPPORT AND IP ROUTING

AT-iMG1400, AT-iMG1500, AT-iMG2400 and AT-iMG2500 families support IEEE 802.1Q tagged VLAN operations across all their switch interfaces. Double tagging (also called Q-n-Q) and Port Protected Mode are additional features that extend the iMG flexibility to accommodate business customer scenarios. The powerful combination of wire speed Layer 2 switching between VLANs with high performance Layer 3 routing makes the iMG an highly cost effective unit.

### IV.II QoS

AT-iMG1400, AT-iMG1500, AT-iMG2400 and AT-iMG2500 families support layer 2 QoS operations based on 802.1p priority field, DSCP IP value and ingress port. Up to 4 egress queue can be used to accommodate different service profiles based on QoS classification, making the iMG perfectly able to manage real time applications with different quality of service requirements.

### IV.III PORT RATE LIMITING

In addition to QoS functionalities, AT-iMG1400, AT-iMG1500, AT-iMG2400 and AT-iMG2500 families offer the possibility to limit the egress and ingress bandwidth on each port. This feature allows the service provider to offer differentiated services to each customer and protect its network from malicious packet flooding.

## **IV.IV ROUTING**

AT-iMG1400, AT-iMG1500, AT-iMG2400 and AT-iMG2500 families incorporate a powerful routing engine that allows the iMG to support a variety of routed application contexts. PPPoE and Dynamic Interfaces (DHCP) are supported to communicate with the service provider networks.

## **IV.V NAT AND FIREWALL**

AT-iMG1400, AT-iMG1500, AT-iMG2400 and AT-iMG2500 families integrate a Stateful Inspection Firewall with in addition Network Address Translation (NAT). Each VLAN can be configured to be external or internal interface. With the Virtual Server features, a web or e-mail server can sit beyond the NAT and appear like being on the public interface.

## **IV.VI VOICE OVER IP (VOIP)**

AT-iMG1400, AT-iMG1500, AT-iMG2400 and AT-iMG2500 offer a choice of Voice over IP signaling methods, namely SIP and MGCP including NCS 1.0 profile.

SIP and MGCP are optimized for operation over IP networks. This multiple protocol support provides maximum flexibility for service providers, allowing them to provide an IP telephony service based on cost and feature set, rather than being limited by the protocol used.

Similarly, a choice of different voice and data encoding algorithms is also available comprising G.711 A-law,  $\mu$ -law (64kbps), G.729 (8kbps,) and T.38, so that maximum VoIP interworking is assured with carrier class IP Gateways and network switches.

Quality of Service is provided through mechanisms such as the Type of Service (ToS) field in the IP packet, priority tagging of voice traffic using IEEE 802.1p, as well as silence suppression and local generation of comfort noise - the result is excellent voice quality. Class 5 services are supported and the VoIP interoperability has been certified versus major soft-switch vendors.

## **IV.VII VIDEO STREAMING**

Video Streaming offers unique features to optimize the delivery of Video contents to customers, namely VLAN, IGMP snooping, and proxy.

AT-iMG1400, AT-iMG1500, AT-iMG2400 and AT-iMG2500 support full IGMP snooping capability (v1/v2/v3), and individual LAN ports can receive different Multicast transmissions e.g. different movies or TV channels.

The gateway 'snoops' IGMP packets in-transit, so it knows which port to forward the particular Multicast data to. This results in high quality, high-bandwidth video streaming without affecting Internet surfing or IP telephony on adjacent ports.

The gateway also supports IGMP proxy to allow forwarding of Multicast packets at Layer 3 with or without NAT.

## **IV.VIII MANAGEMENT AND CONFIGURATION**

AT-iMG1400, AT-iMG1500, AT-iMG2400 and AT-iMG2500 are designed for high volume deployment, this is reflected in the Zero Touch Configuration model when using the AlliedView NMS management product whereby no user intervention is required when installing a unit. Refer to the AlliedView NMS Administration Guide for details.

TR69 protocol is supported for remote provisioning via third party ACS systems.

CLI configuration is also supported via Telnet and SSH sessions.

## IV.IX IPv6

AT-iMG1400, AT-iMG1500, AT-iMG2400 and AT-iMG2500 support the following IPv6 functionalities:

- Dual Stack Mode: IPv6 services can run in parallel with legacy IPv4 services sharing the same physical (ports) and logical (vlans) interfaces. IPv6 have a dedicated TCP/IP stack, separated by the IPv4 version, with a proper forwarding/routing/security IPv6 engine.
- IPv6 Routing and IPv6 Firewall: iMG can be used as an IPv6 router being capable to interconnect two or more IPv6 networks. An IPv6 firewall can be configured to protect and control access to the iMG services from the public IPv6 network.
- Transparent IPv6 Bridging: enabled by default on all the iMG next gen. series, allows IPv6 hosts to communicate natively in IPv6 with the service provider network (IPv6).
- Stateless Auto Configuration (SLAAC): IPv6 addresses on the WAN interface can be configured dynamically without any DHCP server on the access network via Router Advertisement for easy plug-and-play operations.
- DHCPv6 stateful configuration: it's a configuration method for WAN interfaces that relies on the presence of a DHCPv6 server in the ISP network from where retrieve IPv6 Global Addresses and other network parameters like Name Servers and search domain string.
- DHCPv6 stateless configuration: it's an hybrid configuration solution for WAN interfaces that makes use of SLAAC for IPv6 Global Address assignments and of a DHCPv6 server in the ISP network for the other network parameters.
- Router Advertisement Daemon (RADV): local hosts connected to the LAN side, can configure their Global IPv6 addresses via SLAAC having the iMG providing them global IPv6 prefixes.
- Prefix Delegation: working in conjunction with Router Advertisement, the iMG requests the list of Public IPv6 Prefixes through DHCPv6 client on the WAN interface and then it propagates this list to the customer's hosts via SLAAC configuration.

## IV.X WIRELESS

Wi-Fi interface is available on the AT-iMG1400 family.

Wi-Fi interface uses a 2x2 MIMO technology that operates on a single band only (2.4GHz) supporting the 802.11 b/g/n modes.

Wi-Fi interface can be configured to belong to any custom VLAN allowing the distribution of different type of service, data voice and even video over the wireless path.

## V Model Gateways Supported

The following table lists the Gateway models that are supported through 4-6.

TABLE 1-2 Models Supported through 4-6

Model Number	Customer Interface <sup>a b c</sup>	WAN Network Interface	4.1.1	4.2	4.3	4.4	4.5	4.6
iMG1405 <sup>d</sup> (indoor)	LAN Ports - 3x10/100/ 1000Mbps + 2x10/100Mbps USB Port Type A USB Port Type B	100/1000Mbps-SFP		X	X	X	X	X



TABLE 1-2 Models Supported through 4-6

Model Number	Customer Interface <sup>a b c</sup>	WAN Network Interface	4.1.1	4.2	4.3	4.4	4.5	4.6
iMG1405W <sup>d</sup> (indoor)	LAN Ports - 3x10/100/ 1000Mbps + 2x10/100Mbps USB Port Type A USB Port Type B Wireless 2.4 GHz 802.11b/g/n	100/1000Mbps-SFP			X	X	X	X
iMG1425 <sup>d</sup> (indoor)	LAN Ports - 3x10/100/ 1000Mbps + 2x10/100Mbps USB Port Type A USB Port Type B FXS Ports - 2	100/1000Mbps-SFP		X	X	X	X	X
iMG1425RF <sup>d</sup> (indoor)	LAN Ports - 3x10/100/ 1000Mbps + 2x10/100Mbps USB Port Type A USB Port Type B FXS Ports - 2 RF CATV	100/1000Mbps-SFP		X	X	X	X	X
iMG1425W <sup>d</sup> (indoor)	LAN Ports - 3x10/100/ 1000Mbps + 2x10/100Mbps USB Port Type A USB Port Type B Wireless 2.4 GHz 802.11b/g/n FXS Ports - 2	100/1000Mbps-SFP			X	X	X	X
iMG1505 (indoor)	LAN Ports - 5x10/100/1000 Mbps USB Port Type A USB Port Type B	100/1000Mbps-BD	X	X	X	X	X	X
iMG1525 (indoor)	LAN Ports - 5x10/100/1000 Mbps USB Port Type A USB Port Type B FXS Ports - 2	100/1000Mbps-BD	X	X	X	X	X	X
iMG1525RF (indoor)	LAN Ports - 5x10/100/1000 Mbps USB Port Type A USB Port Type B FXS Ports - 2 RF CATV	100/1000Mbps-BD	X	X	X	X	X	X

**TABLE 1-2 Models Supported through 4-6**

<b>Model Number</b>	<b>Customer Interface<sup>a b c</sup></b>	<b>WAN Network Interface</b>	<b>4.1.1</b>	<b>4.2</b>	<b>4.3</b>	<b>4.4</b>	<b>4.5</b>	<b>4.6</b>
iMG1525 Version 2 (indoor)	LAN Ports - 5x10/100/1000 Mbps USB Port Type A USB Port Type B FXS Ports - 2	100/1000Mbps-BD					X	X
iMG1525RF Version 2 (indoor)	LAN Ports - 5x10/100/1000 Mbps USB Port Type A USB Port Type B FXS Ports - 2 RF CATV	100/1000Mbps-BD					X	X
iMG2504 (outdoor)	LAN Ports - 4x10/100/1000 Mbps USB Port Type B	1000Mbps-BD	X	X	X	X	X	X
iMG2522 (outdoor)	LAN Ports - 2x10/100/1000 Mbps USB Port Type B FXS Ports - 2	1000Mbps-BD		X	X	X	X	X
iMG2524 (outdoor)	LAN Ports - 4x10/100/1000 Mbps USB Port Type B FXS Ports - 2	1000Mbps-BD	X	X	X	X	X	X
iMG2524F (outdoor)	LAN Ports - 4x10/100/1000 Mbps USB Port Type B FXS Ports - 2	100/1000Mbps-BD	X	X	X	X	X	X
iMG2426F (outdoor)	LAN Ports - 6x10/100/1000 Mbps USB Port Type B FXS Ports - 2	100/1000Mbps-SFP	X	X	X	X	X	X
iMG2524H (outdoor) (HPNA)	LAN Ports - 4x10/100/1000 Mbps USB Port Type B FXS Ports - 2 HPNA 320 Mbps	100/1000Mbps-BD		X	X	X	X	X

a. FXS = Foreign eXchange Subscriber, connection to phone/modem/FAX.

b. USB Type B is used only for management.

c. Ports in 100Mbps mode cannot support Jumbo Frames.

d. For all 1400 series devices, port 1.0.1, port 1.0.2 and port 1.0.5 are 10/100/1000; port 1.0.3, port 1.0.4 are 10/100.

## VI Reason for Update

The following table lists the updates that have occurred for this release, due to hardware, software, and document changes.  
FXS = Foreign exchange Subscriber, connection to phone/modem/FAX.

**TABLE 1-3 Reason for Update - Release 4-5**

Feature	4-5 Level of Support	Source and Reference
Support for new version of iMG I500.	See Table 1-2, "Models Supported through 4-6," on page 12	
Support for AMF Agent on iMG.	See Table 1-2, "Models Supported through 4-6," on page 12	
Support for Native Windows RNDIS Drivers (incl. windows 10).		Appendix B
Auto Propagation of Domain Name and DNS Servers to DHCP Server for IPv6.		Please refer to <a href="#">page 406</a> and <a href="#">page 407</a>

## VII Service and Support

For information about support services for Allied Telesis, contact your Allied Telesis sales representative or visit the website at <http://www.alliedtelesis.com>.

## 2. Setting up the Gateway

---

### 2.1 Getting Started

#### 2.1.1 Introduction

This section and chapter introduces a number of commonly-used management features. Following are the headings:

- [How to Access the Product](#)
- [Command Syntax Conventions in this Software Reference](#)
- [Start-up Sequence](#)
- [CLI Navigation Commands](#)
- [User Access Commands](#)
- [Creating and Managing Configuration Files](#)
- [File Management Commands](#)
- [System Configuration and Monitoring Commands](#)
- [Debugging and Logging](#)
- [Debugging and Logging Commands](#)
- [Interface Commands](#)
- [Example Configuration](#)

#### 2.1.2 How to Access the Product

**Note:** Refer to the iMG Installation Guides for an overview of all ports and powering up the product. These are available at [www.alliedtelesis.com](http://www.alliedtelesis.com).

There are three scenarios for allowing a user to access the product via the AlliedWare Plus command line:

1. The provider has configured the iMG so that a DHCP server allocates an IP address. The user powers up the iMG, and then uses telnet or ssh to gain access at this IP address.
  1. Power up the iMG, with the WAN connection up and running.
  2. The (external) DHCP server may need to be configured in order to provide the server IP address & connection data to the iMG.
  3. Connect a PC to the iMG using an Ethernet cable.
2. Management of the iMG product through the USB-B connection. The user goes to the Allied Telesis website and downloads the appropriate software drivers (needed only for Windows).

**Note:** On Linux installations these drivers are not needed.

1. In case of Windows, follow the normal Windows procedure to install new hardware

**Note:** The first time you go to release 4.1.2 and above, you must delete any existing drivers and install the latest drivers that are available. For Windows 7, see [Appendix B: Windows 7, 8, and 10 Drivers](#) for detailed information on how to remove the previous driver and use the native Windows 7 driver.

**Note:** You may encounter errors depending on the version of Windows you are using, such as the error "Windows found driver software for your device but encountered an error while attempting to install it". The user should first disable IPv6 from the driver connection. Otherwise, the user should delete the version of the driver from the system and download the appropriate software drivers from the Allied Telesis website.

2. In case of Linux, the kernel detects the new USB interface. Configure it in order to retrieve dynamically the IP address from the iMG.
3. Connect a PC to the iMG using a USB-B to USB cable. The IP address 192.168.200.1 is allocated to the iMG.

The user can then access the iMG using the following interfaces

1. telnet or ssh - in the above scenarios, the user can telnet or SSH to either the DHCP-allocated IP address on the iMG (scenario 1) or to 192.168.200.1 (scenario 2). The default administrative login username and password are manager and friend respectively.
2. GUI - On the local pc, bring up a browser and input `http://<iMGIPAddress>` with the IP address identified in either scenario 1 or 2. The default administrative login username and password are manager and friend respectively. For super user and admin/admin for restricted home user account.

**Note:** The majority of this document covers the CLI command set, since the GUI provides a subset of what the CLI provides. Refer to [Using the GUI Application](#) for an overview of the screens and the subset of functions that are available.

**Note:** This product uses the object model for the Broadband Forum TR-069 standard, and so all operations on the product can be performed using a management system (such as AlliedView NMS) that has TR-069 functionality. Refer to the next subsection on activating the Auto Configuration Server (ACS) url.

### 2.1.3 TR-069 Management and Scope of Control for the Management Interfaces

TR-069 is a Broadband Forum standard that defines an application layer protocol for the remote management of end-user devices (which are the iMGs). It is a bi-directional SOAP/HTTP-based protocol that when combined with the different Data Model TRs (such as TR-98 Internet Gateway Device, TR-104 Voip CPE, TR-111 Home Networking Devices), provides a means by which the Auto Configuration Server (ACS) can manage the device. For more details please refer to the Broadband forum web site for the TR content (<http://www.broadband-forum.org>)

TR-069 management can be activated using one of two options:

1. The transmission of option 43 along with the other DHCP options. In this case the vendor specific option would include the ACS URL. Receipt of this option triggers activation of the TR-69 client on the iMG – and it will then inform the ACS of its presence. From this point on, the ACS is able to fully manage the device.
2. Manually configure (using the CLI or a downloaded configuration file) the ACS URL. When this occurs there is same behavior as option 1; the iMG informs the ACS of its presence, and the management of the device proceeds from there.

The following figure shows the relationship between the three methods of accessing and controlling the product:




FIGURE 2-1 Scope of Functions for Management Interfaces

## 2.1.4 The Command Interface (CLI)

### 2.1.4.1 Getting Help

The following kinds of command help are available:

- lists of valid parameters with brief descriptions (the ? key)
- completion of keywords (the Tab key)
- error messages for incomplete or incorrect syntax

### 2.1.4.2 Command Abbreviations

The AlliedWare Plus CLI contains a number of abbreviations for its commands. For example, the show interface command can be entered in the abbreviated form shown below:

Table 2-1: Common Abbreviations

<code>sh in vlan100</code> show interface vlan100
<code>config term</code> configure terminal.

### 2.1.4.3 Viewing a List of Valid Parameters

To get syntax help, type ? (i.e. "space question mark") after:

- the prompt. This will list all commands available in the mode you are in.
- one or more parameters. This will list parameters that can come next in the partial command.
- one or more letters of a parameter. This will list matching parameters.

**Note:** The AlliedWare Plus CLI only displays one screenful of text at a time, with the prompt "--More--" at the end of each screenful. Press the space bar to display the next screenful or the Q key to return to the command prompt.

### 2.1.4.4 Example

To see which commands are available in Privileged Exec Mode, enter ? at the Privileged Exec Mode command prompt:

This results in the following output

```
awplus# ?
clear          Reset functions
configure      Enter configuration mode
copy           Copy from one file to another
debug          Allow debugging commands
delete         Delete a file
dir            List the files on a filesystem
disable        Turn off privileged mode command
echo           Echo a string on the Command Line
enable         Turn on privileged mode command
erase          Erase the system startup configuration
exit           End current mode and down to previous mode
help           Description of the interactive help system
move           Rename or move a file
ping           Send echo messages
reboot         Halt and perform a cold restart
reload         Halt and perform a cold restart
show           Show platform global settings or self-test results
swupdate       Software update
terminal       Configure the terminal
test           Configure test task parameters
traceroute     Show the route packets take to network host
write          Write running configuration to memory, file or terminal
```

To see which commands are available in Configuration mode, enter ? at the Config mode command prompt:

This results in the following output:

```
awplus# configure
Enter configuration commands, one per line.  End with CNTL/Z.
awplus(config)# ?
access-list    Create an access list
boot           Boot configuration
clock          Manage clock
debug          Set application log output level
dial-peer      Dial peer configuration parameters
do             To run exec commands in config mode
enable         Modify enable password parameters
end            End current mode and down to privileged mode
exit           End current mode and down to previous mode
help           Description of the interactive help system
hostname       Set system's network name
interface      Select an interface to configure
ip             Internet Protocol (IP)
ipv6           Internet Protocol version 6 (IPv6)
line           Configure a terminal line
log            Logging control
mac            MAC and MAC address table configuration
mgcp           Enter MGCP protocol configuration mode
mls            Multi-Layer Switch(L2/L3)
no             Negate a command or set its defaults
ntp            Configure NTP
platform       Platform commands
quit           Quit
service        Modify use of network based services
sip-ua         Enter SIP User Agent configuration mode
snmp-server    Enable the snmp agent
swupdate       Software update
tr69-client    Configure TR69 client
username       Establish User Name Authentication
vlan           Configure VLAN parameters
voice          Voice configuration
voice-port     Enter voice port configuration mode
```

```
voipapp      VoIP application configuration parameters
```

To see which show commands that start with "i" are available in Privileged Exec Mode, enter ? after show i:

```
awplus# show i ?
```

This results in the following output:

```
interface      Select an interface to configure
ip             Internet Protocol (IP)
```

### 2.1.4.5 Examples (clock timezone command)

To use the ? help to work out the syntax for the clock timezone command, enter the following sequence of commands:

```
awplus(config)# clock ?
```

```
set           Set the time
summer-time   Manage summer-time
timezone      Set clock timezone
```

```
awplus(config)# clock timezone ?
```

```
<STRING:timezone> Time zone short name (ex: CET for Central European Time)
```

The ? help only indicates what you can type next. For commands that have a series of parameters, the ? help guides the user for the next parameter, and does not indicate the number of parameters needed to complete the command.

### 2.1.4.6 Completing Keywords

To complete keywords, type the Tab key after part of the command.

If only one keyword matches the partial command, the AlliedWare Plus CLI fills in that keyword. If multiple keywords match, it lists them.

### 2.1.4.7 Examples

In this example we use Tab completion in successive steps to build the complete command show ip dhcp server summary. We have included <Tab> to show where to type the Tab key - this is not displayed on screen.

```
awplus# show ip
interface      IP interface status and configuration
name-server    Show DNS server IP address
route          IP routing table
```

### 2.1.4.8 Moving the Cursor around Input Text (Home and End Keys)

The Home and End keys allow the user to go to the beginning or end of a command line, where new text can be inserted.



### 2.1.4.9 Viewing Command Error Messages

The switch displays the following generic error messages about command input:

% Incomplete command—this message indicates that the command requires more parameters. Use the ? help to find out what other parameters are available.

```
awplus# interface
```

```
% Incomplete command.
```

% Invalid input detected at '^' marker—this indicates that the switch could not process the command you entered. The switch also prints the command and marks the first invalid character by putting a '^' under it. Note that you may get this error if you enter a command in the wrong mode, as the following output shows.

```
awplus# interface port1.0.1
```

```
interface port1.0.1
^
% Invalid input detected at '^' marker.
```

% Unrecognized command—when you try to use ? help and get this message, it indicates that the switch can not provide help on the command because it does not recognize it. This means the command does not exist, or that you have entered it in the wrong mode, as the following output shows.

**Note:** The AlliedWare Plus iMG does not tell you when commands are successful. If it does not display an error message, you can assume the command was successful.


```
awplus# interface ?
```

```
% Unrecognized command
```

### 2.1.5 How to Work with Command Modes

The following figure shows the command mode hierarchy and the commands you use to move to lower-level modes.

Multiple users can telnet and issue commands using the User Exec mode and the Privileged Exec Mode. However, only one user is allowed to use the Configure mode at a time. This prevents multiple users from issuing configuration commands simultaneously.

**FIGURE 2-2 AlliedWare Plus CLI modes**

### 2.1.5.1 User Exec mode

User Exec mode is the mode you log into on the switch.

It lets you perform high-level diagnostics (show commands, ping, traceroute etc), start sessions (Telnet, SSH), and change mode.

The default User Exec mode prompt is `awplus>`.

### 2.1.5.2 Privileged Exec Mode

To change from User Exec to Privileged Exec Mode, enter the command:

```
awplus># enable
```

Privileged Exec Mode is the main mode for monitoring—for example, running show commands and debugging. From Privileged Exec Mode, you can do all the commands from User Exec mode plus many system commands.

The default Privileged Exec Mode prompt is `awplus#`.

### 2.1.5.3 Global Configuration mode

To change from Privileged Exec to Global Configuration mode, enter the command:

```
awplus# configure terminal
```

From Global Configuration mode, you can configure most aspects of the switch.

The default Global Configuration mode prompt is `awplus(config)#`.

### 2.1.5.4 Lower-level configuration modes

A number of features are configured by entering a lower-level mode from Global Configuration mode. The following table lists these features.

Table 2-2: Features configured using the lower level modes

Mode	What it configures	Command to access	Default prompt
Interface	Switch ports, VLANs, wireless interface, the management Eth port.	<code>interface &lt;name&gt;</code>	<code>awplus (config-if) #</code>
Line	Console port settings or virtual terminal settings for telnet.	<code>line console 0</code> <code>line vty number</code>	<code>awplus (config-line) #</code>
Voice Service	These are general voice service configuration parameters. Some examples of related data are: - TMF Relay Configuration - RTP QOS Settings - RTCP Enabling/Disabling	<code>voice service voip</code>	<code>awplus (config-voi-srv) #</code>
	This level enables and disables the MGCP protocol service, as well as the links between MGCP and the IP network.	<code>mgcp</code> (from config-voi-srv level)	<code>awplus (config-serv-mgcp) #</code>
	This level enables and disables the SIP protocol service, as well as the links between SIP and the IP network	<code>sip</code> (from config-voi-srv level)	<code>awplus (config-serv-sip) #</code>
MGCP	Configuration that is specific to the MGCP Protocol Service including protocol specific information (timers etc) and references to the Call Agent.	<code>mgcp</code> (from config level)	<code>awplus (config-mgcp) #</code>
SIP	Configuration that is specific to the SIP Protocol Service including protocol specific information (timers etc) and references to the Location Server and Proxy Server.	<code>sip-ua</code> (from config level)	<code>awplus (config-sip-ua) #</code>
Voice Applications (access codes)	Allows specification of the access codes required to enable, disable and program different supplementary services	<code>voipapp feature access code</code>	<code>awplus (config-voiapp-fac) #</code>

Table 2-2: Features configured using the lower level modes

Mode	What it configures	Command to access	Default prompt
Voice Supplementary Services	Allows the enabling of a specific supplementary service on a per port basis – as well as configuration of port specific data – such as forwarded to DN.	voipapp supplementary services	awplus (config-voiapp-supl-serv-port) #
Voice Port	This level enables the configuration of end-point specific data such as gains etc	voice-port tel1/tel2	awplus (config-voiceport) #
Voice Class	This level enables the definition of a set of Codecs – that are then associated with the appropriate Voiceport – thus enabling a fixed set of codecs for that line	voice class codec	awplus (config-voice-class) #
Dial Peer	This can be viewed as an addressable end-point. As such there are really two different varieties of the dial-peer – the incoming dial-peer – against which information is configured that is required to terminate to an associated voiceport – including for example DN – and the outgoing dial-peer – against which information is configured – that enables the system to route a call to an external callagent or softswitch. Especially important here are the destination pattern (or digit map). Note that three dial peers are created automatically when the system is created – dial peer 1 and 2 are incoming dial-peers – and are associated with voice ports tel1 and tel2 respectively. Dial peer 3 is the out-going dial-peer and is only activated when SIP is enabled.	dial peer voice	awplus (config-dial-peer) #
VLAN database	VLANs.	vlan database	awplus (config-vlan) #
DHCP	dhcp server pools and attributes	ip dhcp pool (from config-if access)	awplus (dhcp-config) #
SSID	For configuration of global SSIDs.	dot11 ssid <ssid-name>	awplus (config-if-ssid) #
2.4GHz 802.11 radio	For configuration of 2.4GHz 802.11 radio.	interface dot11radio1.0.1	awplus (config-if-dot11radio) #

### 2.1.5.5 Returning to higher-level modes

The following figure shows the commands to use to move from a lower-level mode to a higher-level mode.

## AlliedWare Plus CLI modes - returning to higher-level modes




FIGURE 2-3 Returning to higher-level modes

### 2.1.5.6 Examples

To go from Interface Configuration to Global Configuration mode:

```
awplus(config-if) # exit
awplus(config) #
```

To go from Interface Configuration to Privileged Exec Mode:

```
awplus(config-if) # end
awplus#
```

To go from Privileged Exec to User Exec (the equivalent to log out):

```
awplus# disable
awplus
```

### 2.1.5.7 Entering Privileged Exec Commands When in a Configuration Mode

As you configure the switch you will be constantly entering various show commands to confirm your configuration. This requires constantly changing between configuration modes and Privileged Exec Mode.

However, you can run Privileged Exec commands without changing mode, by using the command:

```
do <command you want to run>
```

You can use the ? help to find out command syntax when using the **do** command.

To display information about the IP interfaces when in Global Configuration mode, enter the command:

This results in the following output:

```
awplus(config)# do show ip int
```

Interface	IP-Address	Status	Protocol
vlan1	unassigned	admin up	running
vlan2	unassigned	admin up	running

### 2.1.5.8 Main Command Modes Summary

The table below lists the main command modes, how to access each mode, the prompt for each command mode. From any mode, use **exit** to move up a mode, or **end** to move to the Privileged Exec Mode.

Table 2-3: Main command modes and modal prompts

Present Mode	Prompt	Command	New Mode
User Exec	awplus#	enable	Privileged Exec
Privileged Exec	awplus#	configure terminal	Global Configuration
Global Configuration	awplus(config)#	vlan database	VLAN Configuration

### 2.1.6 How to See the Current Configuration (running-config)

The current configuration is called the running-config. To see it, enter the following command in either Privileged Exec Mode or any configuration mode:

```
awplus# show running-config
```

**Note:** The database for the configuration is an xml object model.

### 2.1.7 Default Settings

When the switch first starts up with the AlliedWare Plus CLI, it applies default settings and copies these defaults dynamically into its running-config.

These default settings mean that the AlliedWare CLI:

- encrypts passwords, such as user passwords
- records log message priority in log messages
- turns on the telnet server so that you can telnet to the switch
- enables the switch to look up domain names (but for domain name lookups to work, you have to configure a DNS server)
- starts up in default L2 bridging mode.

- sets all the switch ports to access mode. This means they are untagged ports, suitable for connecting to hosts
- creates untagged VLAN 1 and adds all the switch ports to it
- allows logins on VTY sessions (for telnet etc)
- has switching enabled, so layer 2 traffic is forwarded appropriately without further configuration
- has ports set to autonegotiate their speed and duplex mode
- has copper ports set to auto MDI/MDI-X mode
- disables flow control on WAN, but enables it on LAN interfaces.

### 2.1.8 The Default Configuration

This includes most of the above default settings, which the switch copies to its running-config when it first boots up.

The switch stores a copy of the default configuration in the file, `default.cfg` and uses this as its default start-up file.

For more information about start-up files, see [2.1.11](#).

### 2.1.9 Defining a User/Password

To change the password for an account, the username is deleted and then re-created. This applies to the default user (manager) as well.

```
awplus(config)# username <user> privilege <level> password <password>
```

The password can be up to 23 characters in length and include characters from up to four categories. The password categories are:

- uppercase letters: A to Z
- lowercase letters: a to z
- digits: 0 to 9
- special symbols: all printable ASCII characters not included in the previous three categories. The question mark ? cannot be used as it is reserved for help functionality.

#### 2.1.10 How to Set an IP Address on VLAN 1

This section describes how to set an IP address on the default VLAN (vlan1).

1. If desired, check the current configuration

After logging in, enter Privileged Exec Mode by using the command:

```
awplus# enable (Privileged Exec Mode)
```

Then check the current configuration by using one of the following commands:

```
awplus# show ip interface brief
```

This results in the following output:

Interface	IP-Address	Status	Protocol
vlan1	172.28.8.200	admin up	running

2. Enter Interface Configuration mode for the vlan1 interface

Enter Global Configuration mode and enter the command:

```
awplus(config)# interface vlan1
```

### 3. Enter the IP address and mask

Enter the command:

```
awplus(config-if)# ip address <address/mask>
```


For example, to set the address to 172.28.8.210/16, enter the command:

```
awplus(config-if)# ip address 172.28.8.210/16
```

## 2.1.11 How to Save and Boot from the Current Configuration

This section tells you how to save your configuration and run the saved configuration when the switch starts up.

Refer to [Figure 2-4](#), which shows the basic software file configuration. This figure is used to help describe a number of software configuration scenarios.



**FIGURE 2-4 Basic Software Configuration**

**Table 2-4: Components of Software Configuration**

Area	Purpose	Notes
Configuration Partitions (Mirrored)	All user configuration files are stored here (i.e. all configurations except <code>default.cfg</code> and <code>default_button.cfg</code> ). Whenever a user configuration is changed, the oldest configuration partition is brought up to date with the other one and then the new changes are saved to it. In other words configuration saves, copies, and deletions are made to alternate configuration partitions.  Therefore, if for some reason an error occurs, the other partition contains a known good backup point.	
Default Button Partition	This partition contains a configuration that can be used to override the <code>default.cfg</code> configuration. This enables the service provider to define a baseline configuration that can be recovered for the device if something goes wrong while manipulating the user configurations (or if the user configurations are removed).	It possible to copy a custom configuration into <code>default_button.cfg</code>



Table 2-4: Components of Software Configuration

Area	Purpose	Notes
Image Partition (1 and 2)	Partition 1 contains one complete executable image plus the <code>default.cfg</code> that is guaranteed to be compatible with this image.  Partition 2 contains one complete executable image plus the <code>default.cfg</code> that is guaranteed to be compatible with this image	The <code>default.cfg</code> file is provided with the device with specific attributes; therefore, <code>default.cfg</code> cannot be created, moved, or modified from the CLI.  Note that the file cannot be deleted.  Note that iMG1400 family supports only one image partition.
Boot Partition	This partition contains the bootloader plus device specific configuration parameters – such as Serial Number and MAC Address. This partition is not accessible from the firmware.	
PSP Partition	This small partition contains information required to ensure that the system loads the desired image and configuration. It can be modified via CLI commands.	
startup-config	A shortcut that represents the current boot configuration file. At startup, this is the <code>default.cfg</code> . You can then change the startup-config so that it does not contain the <code>default.cfg</code> ( <code>default.cfg</code> is read-only).	Note that the file can be deleted, with the 'force' option. Refer to <a href="#">“delete”</a>
running-config	A shortcut that represents the current running configuration file. You can you can save this configuration as the startup-config so it will be used when starting up.	

### 2.1.11.1 How to Save the Running Configuration to the current boot file (startup-config)

Enter Privileged Exec Mode and enter the command:

```
awplus# copy running-config startup-config
```

**Note:** If the running configuration is `default.cfg`, the startup-config must first be specified with an alternate filename for this to work as `default.cfg` is a read-only configuration which cannot be modified or deleted.

### 2.1.11.2 How to Create and Use a New Configuration File

1. Copy the current configuration to a new file

Enter Privileged Exec Mode and enter the command:

```
awplus# copy running-config <filename.cfg>
```

### 2.1.11.3 Example

To save the current configuration in a file called `customer_a.cfg`, enter the command

```
awplus# copy running-config customer_a.cfg
```

2. Set the switch to use the new file at startup

To run the new file's configuration when the switch starts up, enter Global Configuration mode and enter the command:

```
awplus(config)# boot config-file customer_a.cfg
```

**Note:** If customer\_a.cfg does not exist it will be created using a copy of the running-config.

For an explanation of the configuration fallback order, see [“The configuration file fallback order”](#).

#### 2.1.11.4 Example

To run the commands in example.cfg on startup, enter the command:

```
awplus(config)# boot config-file customer_a.cfg
```

Display the new settings

To see the files that the switch uses at startup, enter Privileged Exec Mode and enter the command:

```
awplus# show boot
```

The output looks like this:

```
Boot configuration
-----
Current  software   : [partition 1] bcm96368GW_fs_kernel.AtiBcm-4.1_20
Current  boot image : [partition 1] bcm96368GW_fs_kernel.AtiBcm-4.1_20
Backup   boot image : [partition 2] bcm96368GW_fs_kernel.AtiBcm-4.1_20
Default  boot config: default.cfg
Backup   boot config: default_button.cfg (file exists)
Current  boot config: customer_a.cfg (file exists)
```

Continue updating the file when you change the configuration

When you next want to save the current configuration, enter Privileged Exec Mode and enter the command:

```
awplus# copy running-config startup-config
```

#### 2.1.12 How to Return to the Factory Defaults

The switch dynamically adds the default settings to the running-config at start-up if the current boot configuration file is not present. This section describes how to use this feature to return to the factory defaults.

**Note:** After reboot the show running-config output will show the default factory settings for your switch.

Refer to [Start-up Sequence](#) for more information on how the device boots up in various scenarios.

##### 2.1.12.1 Completely restore defaults

To completely remove your configuration and return to the factory default configuration, delete or rename the current boot configuration file and make sure no other file is set as the start-up configuration file.

To find the location of the default boot configuration file, enter Privileged Exec Mode and enter the command:

```
awplus# show boot
```

To delete the current boot configuration, enter Privileged Exec Mode and enter either of the commands:

```
awplus# delete force <filename>
```

or:

```
awplus# erase startup-config
```

**Note:** The wildcard character '\*' is supported, and Configuration files must end with '.cfg', so delete \*.cfg will delete all config files (except default.cfg). Also note that erasing startup-config deletes the current boot configuration file; it does not simply stop the file from being the boot file.

To make sure that no other file is loaded at start-up, enter Global Configuration mode and enter the command:

```
awplus(config)# no boot config-file
```

This will set 'default\_button.cfg' as the startup-config.

### 2.1.13 Recovery of Single Image (iMG I400)

Since the I400 is a single image based device (unlike the I500/2500 devices), if the primary image fails, there is no emergency recovery image available, and so an alternate image needs to be available to bring the board into service so that it can be repaired if necessary. This is done using the following:

- In the event of primary image failure, the iMG can perform a netboot (from a TFTP server).
- The default file name requested in the netboot defaults to a well known filename (the image name from the 4.2 GM release)
- The default TFTP server from which the file should be loaded is the one allocated by the DHCP server.
- The default CRC which is used to validate the incoming file is stored in UB and by default is the CRC of the initial release supporting this device.
- The user can override the following through the application program
  - TFTP filename
  - TFTP server
  - TFTP CRC
- Only CRC validated files will be loaded via netboot during recovery
- CRC can be disabled from the user application

### 2.1.14 How to See System Information

This section describes how to view the following system information:

- overview information
- serial number

#### 2.1.14.1 Viewing Overall System Information

To display an overview of the switch hardware, software, and system settings, enter User Exec or Privileged Exec Mode and enter the command:

```
awplus# show system
```

The output looks like this:

```
awplus> show system
```

```
Switch System Status          Mon Jan 12 12:48:31 1970
Board      ID      Bay      Board Name          Rev      Serial Number
-----
Base              iMG2504              X1        ATNLAB0000001
-----
Memory: DRAM: 125012 kB  Used: 69872 kB  Available: 55140 kB
-----
Environmental Status : Normal
Uptime               : 11 days 12:48:32
Bootloader version   : AtiUboot-1.0_07
VoIP version         : AtiVoip-2.2_32

Current Software      : AT-iMG2500-4.2_60
Software version      : AtiBcm-4.2_60 ALPHA
Build date            : 00:30 14/06/12

Current boot config   : customer_sip.cfg (file exists)
Territory             :

System Name           :
System Contact         :
System Location        :
```

**Note:** For an iMG with an SFP optics, there is also the pluggable parameter. Refer to [show system pluggable](#).

## 2.1.15 How to Set System Parameters

You can set system parameters to personalize the switch and make it easy to identify it when troubleshooting. This section describes how to configure the following system parameters:

- telnet session timeout
- switch name

### 2.1.15.1 How to Change the Telnet Session Timeout

By default, telnet sessions time out after 10 minutes of idle time. If desired, you can change this.

#### 2.1.15.2 Examples

To set the timeout to 30 minutes, enter the command:

```
awplus(config-line)# exec-timeout 30
```

### 2.1.15.3 How to Name the Device

To give the device a name, enter Global Configuration mode and enter the command:

```
awplus(config)# hostname <name>
```

For example, to name the switch “switch1.mycompany.com”:

```
awplus(config)# hostname switch1.mycompany.com
```

The prompt displays the new name:

```
switch1.mycompany.com(config)#
```

The name can contain hyphens, dots, and underscore characters.

However, the name must be a single word, as the following example shows.

```
awplus(config)#hostname switch1.mycompany.com more words
hostname switch1.mycompany.com more words
^
% Invalid input detected at '^' marker.
```

It also cannot be surrounded by quote marks, as the following example shows.

```
awplus(config)#hostname "switch1.mycompany.com more words"
% Please specify string starting with alphabet
```

Also, the prompt has a fixed maximum length, and so the host name in some cases may be truncated. Refer to [hostname](#).

#### 2.1.15.4 Removing the name

To remove the hostname, enter the command:

```
switch1.mycompany.com(config)# no hostname
```

The prompt changes back to the default prompt:

```
awplus(config)#
```

### 2.1.16 How to Set the Time and Date

There are three aspects to setting the time and date:

- setting the current time and date.
- setting the timezone
- configuring the switch to automatically change the time when summer-time begins and ends.

**Note:** Instead of manually setting the time, you can use NTP to automatically get the time from another device. Refer to [Network Time Protocol \(NTP\)](#).

#### 2.1.16.1 How to Show Current Settings

To display the current time, timezone and date, enter Privileged Exec Mode and enter the command:

```
awplus# show clock
```

The output looks like this:

```
Local Time: Fri, 02 Jan 1970 18:57:48 -08:00
UTC Time: Sat, 03 Jan 1970 02:57:48 +00:00
Timezone: PST
Timezone name: Pacific time, Tijuana
Timezone offset: -08:00
Summer time: disabled
```

### 2.1.16.2 How to Set the Time and Date

To set the time and date, enter Privileged Exec Mode and enter the clock set command [clock set](#):

```
clock set <hh:mm> <day> <month> <year>
```

where:

- *hh* is two digits giving the hours in 24-hour format (e.g. 14)
- *mm* is two digits giving the minutes
- *day* is two digits giving the day of the month
- *month* is the first three letters of the month name (e.g. Sep) - The first letter must be capitalized.
- *year* is four digits giving the year

**Note:** The setting of seconds is not supported.

To set the time to 14:00:00 on 25 January 2012, use the command:

```
awplus(config)# clock set 14:00 25 Jan 2012
```

### 2.1.16.3 How to Set the Timezone

To set the timezone, enter Global Configuration mode and enter the clock timezone command [clock timezone](#):

```
clock timezone <timezone-name>
```

The <timezone-name> can be any string up to 6 characters long. Refer to [clock timezone](#) for the list.

To return the timezone to UTC+0, enter the command:

```
awplus(config)# no clock timezone
```

To set the timezone to New Zealand Standard Time, use the command:

```
awplus(config)# clock timezone NZST
```

### 2.1.16.4 How to Configure Summer-time

To enable summer-time management, use the command [clock summer-time](#):

The summer time will be managed automatically, depending on the time zone, without specifying any start or stop date and time.

To disable summer time management, use no [clock summer-time](#)

### 2.1.16.5 How to Configure Summer-time

To configure summer-time, use the following:

```
awplus(config)# clock summer-time
```

## 2.1.17 How to Add and Remove Users

### 2.1.17.1 Adding users

To add a new user with administrative rights, enter Global Configuration mode and enter the command:

```
awplus(config)# username <name> privilege 15 password <password>
```

Both `<name>` and `<password>` can contain any printable character and are case sensitive.

The AlliedWare Plus CLI gives you a choice of 1 or 15 for the privilege level. Level 1 users are limited to User Exec mode so you need to set most users to level 15.

For example, to add user Bob with password 123\$%^, enter the command:

```
awplus(config)# username Bob privilege 15 password 123$%^
```

### 2.1.17.2 Removing users

To remove a user, enter Global Configuration mode and enter the command:

```
no username <name>
```

For example, to remove user Bob, enter the command:

```
awplus(config)# no username Bob
```

Note that you can delete all users, including the user called "manager" and the user you are logged in as. If all privilege 15 user accounts are deleted, a warning message is generated:

```
% Warning: No privileged users exist.
```

**Note:** If all privilege level 15 user accounts are deleted, and there are no other users configured for the device, manager/friend is automatically created.

If there is a user account on the device with a lower privilege level and a password has already been set with the `enable password` command, you can log in and still enter privileged mode. When executing the `enable` command, enter the password created with the `enable password` command. For example, if the password is mypassword:

```
awplus> enable mypassword
awplus#
```

### 2.1.17.3 Displaying users

To list all configured users, enter User Exec or Privileged Exec Mode and enter the command:

```
awplus# show security-password user
```

The output looks like this:

```
Username  Privilege
-----
manager   15
alice     15
guest     1
```

### 2.1.18 How to Undo Settings and Restore Parameters to Defaults (no option)

Using the `no` parameter can accomplish both of these tasks.

To undo most settings, simply re-enter the first parameters of the configuration command with the parameter **no** before them.

You can set the timezone to Eastern Standard Time by entering the command:

```
awplus(config)# clock timezone EST-USA
```

To remove the timezone setting, enter the command:

```
awplus(config)# no clock timezone
```

### 2.1.19 How to Upgrade the Firmware

New releases of the AlliedWare Plus CLI become available regularly. Contact your customer support representative for more information.

1. Put the new release onto your TFTP server. (The iMG software must be extracted from the zipped file).

**Note:** You can use the GUI of the browser to upgrade the firmware, using the Computer Management tab. Refer to [Using the GUI Application](#) for more information on the web-based GUI. The iMG software must be extracted from the zipped file prior to upgrade via webGUI.

2. Copy the new release from your TFTP server onto a switch partition (not the one that will be booted from).

```
awplus# copy tftp://<tftp server address>/
<path>/<filename> <filename>
```

3. Upon successful copy of a firmware upgrade onto the iMG, the new firmware will automatically be marked as bootable.

**Note:** The other partition is deliberately not loaded with the new release, in case the new load is bad.

4. Check the boot settings

Enter Privileged Exec Mode and enter the command:

```
awplus# show boot
```

5. Reboot

Enter Privileged Exec Mode and enter this command and respond to the prompt:

```
awplus# reload
reboot system? (y/n):
```

### 2.1.20 How to configure Wireless

Wireless configuration is a three-step procedure:

1. First the desired VLAN must be associated with the SSID

```
awplus# configure
Enter configuration commands, one per line. End with CNTL/Z.
awplus(config)# vlan
awplus(config-vlan)# vlan 2
awplus(config-vlan)# exit
awplus(config)# do show dot11 bssid
```

Interface	BSSID	Guest	SSID	VLAN
dot11radio1.0.1	e2:0c:25:00:01:6d	Yes	iMG1425W_00_01_6d	Default
dot11radio1.0.1			Guest1	



```
dot11radio1.0.1      Guest2
dot11radio1.0.1      Guest3
```

```
awplus(config)# dot11 ssid iMG1425W_00_01_6d
awplus(config-if-ssid)# vlan 2
awplus(config-if-ssid)# exit
awplus(config)# exit
awplus#
```

**Note:** An SSID may be associated with at most one VLAN at a time.

If an SSID is not associated with a VLAN it will not be shown on the web GUI.

2. The remainder of the wireless configuration can now be completed using the web GUI.
3. Ensure that wireless is enabled. The green wireless LED on the front of the iMG should be lit. If not, press the wireless multi-function button for 3 seconds to hardware-enable wireless. Note that this button acts as a toggle, enabling & disabling wireless (it overrides wireless enabling/disabling functionality available via the CLI & web GUI). Press the wireless button and wait a couple of seconds to enable it. For disabling the wireless function the button needs to be pressed for a longer time (at least 7 seconds).

### 2.1.2.1 Commands Available in each Mode

This appendix lists the commands available in the following command modes:

- User Exec Mode
- Privileged Exec Mode
- Global Configuration Mode

#### 2.1.2.1.1 User Exec Mode

```
awplus> ?
clear      Reset functions
disable    Turn off privileged mode command
enable     Turn on privileged mode command
exit       End current mode and down to previous mode
help       Description of the interactive help system
logout     Exit from the EXEC
show       Show running system information
```

#### 2.1.2.1.2 Privileged Exec Mode

```
awplus# ?
clear      Reset functions
configure  Enter configuration mode
copy       Copy from one file to another
debug      Allow debugging commands
delete     Delete a file
dir        List the files on a filesystem
disable    Turn off privileged mode command
enable     Turn on privileged mode command
erase      Erase the system startup configuration
exit       End current mode and down to previous mode
help       Description of the interactive help system
move       Rename or move a file
ping       Send echo messages
reboot     Halt and perform a cold restart
reload     Halt and perform a cold restart
show       Show platform global settings or self-test results
swupdate   Software update
terminal   Configure the terminal
traceroute Show the route packets take to network host
write      Write running configuration to memory, file or terminal
```

### 2.1.21.3 Global Configuration Mode

```
awplus(config)# ?
access-list  Create an access list
atmf         Enable ATMF functionality
boot         Boot configuration
clock        Manage clock
debug        Set application log output level
dial-peer    Dial peer configuration parameters
do           To run exec commands in config mode
enable       Modify enable password parameters
end          End current mode and down to privileged mode
exit         End current mode and down to previous mode
help         Description of the interactive help system
hostname     Set system's network name
interface    Select an interface to configure
ip           Internet Protocol (IP)
ipv6         Internet Protocol version 6 (IPv6)
line         Configure a terminal line
log          Logging control
mac          MAC and MAC address table configuration
mgcp         Enter MGCP protocol configuration mode
mls          Multi-Layer Switch(L2/L3)
no           Negate a command or set its defaults
ntp          Configure NTP
platform     Platform commands
quit         Quit
service      Modify use of network based services
sip-ua       Enter SIP User Agent configuration mode
snmp-server  Enable the snmp agent
swupdate     Software update
tr69-client  Configure TR69 client
username     Establish User Name Authentication
vlan         Configure VLAN parameters
voice        Voice configuration
voice-port   Enter voice port configuration mode
voipapp      VoIP application configuration parameters
```

## 2.2 Command Syntax Conventions in this Software Reference

The following table describes how command line interface syntax is shown in this Software Reference.

Table 2-5: Syntax Conventions

Syntax element	Example	What to enter in the command line
Keywords are shown in lowercase fixed-width font or bold variable-width font	show memory history or <b>show ip route</b>	Some keywords are required, and others are optional parameters. Type keywords exactly as they appear in the command syntax.
Number ranges are enclosed in angle-brackets < > and separated by a hyphen.	<0-255>	Enter a number from the range. Do not enter the angle brackets.

Table 2-5: Syntax Conventions

Placeholders are shown in lowercase italics within angle-brackets < >, or in uppercase italics	<i>&lt;port-list&gt;</i> or ip dhcp pool <i>NAME</i>	Replace the placeholder with the value you require. The place holder may be an IP address, a text string, or some other value. See the parameter table for the command for information about the type of value to enter. Do not enter the angle-brackets.
Repeats are shown with ellipsis.	param1...	Enter the parameter one or more times.
Optional elements are shown in brackets: [ ]	vlan <i>&lt;vid&gt;</i> [name <i>&lt;vlan-name&gt;</i> ]	If you need the optional parameter, enter it. Do not enter the brackets.
Required choices are enclosed in braces and separated by a vertical bar (pipe): {   }.	show { <i>&lt;filename&gt;</i>   <i>&lt;url&gt;</i> }	Enter one only of the options. Do not enter the braces or vertical bar.
Optional choices are enclosed in or brackets and separated by a vertical bar (pipe): [   ]	[param1   param2]	If needed, enter one only of the options. Do not enter the brackets or vertical bar.
Inclusive options are enclosed in braces, and separated by brackets: { [ ] [ ] }.	{ [param1] [param2] [param3] }	Enter one or more of the options and separate them with a space. Do not enter the braces or brackets.

## 2.3 Start-up Sequence

The start-up sequence for a device running AT-iMG software under normal circumstances will be as seen below - this sequence will be seen when everything loads and runs as expected.

Booting up consists of three major operations:

### 1. Image and configuration Selection

- As the device begins to boot, the bootloader reads the contents of the PSP flash partition which stores the preferred partition to load the image from (partition 1 or partition 2) and the preferred configuration to load. If for some reason the psp is corrupt – or unreadable, the bootloader will always begin the process by attempting to load the image from partition 1 and the default.cfg configuration.
- The boot loader checks to determine whether or not the previous boot process has succeeded. (There is a window of 300 seconds at which a boot process is qualified as a success). If it did not, then the bootloader begins the process with the other partition.
- The bootloader checks to determine that the image is present and valid (e.g. not corrupt). If the image is corrupt, it begins the process with the other partition.
- The bootloader looks to determine if the reset button has been pressed. If it has been pressed, then the bootloader discards any preferred configuration specified, and uses the default\_button.cfg if present (customer default), or default.cfg (generic default).

### 2. Image Loading

- The bootloader then loads the selected image.
- Once the image has loaded, the Application notes that it successfully booted. (There is a window of 300 seconds.)

- If the image boot process fails and the device resets (using for example the watchdog function), then the bootloader will know to use the other image.

### 3. Configuration Loading

- Once the application image has successfully loaded, then configuration loading process begins.
- The device verifies that the selected configuration is acceptable. This implies that:
  - The configuration is valid and compatible with the image.
  - Unknown objects are ignored, and unknown attributes are discarded.
- If the above test fails, then:
  - if the default\_button.cfg exists, it is chosen as the selected configuration and the process is repeated.
  - If the default\_button.cfg does not exist – or is not valid and compatible, then the default.cfg is chosen as the selected configuration and the process is repeated. The default.cfg will always be valid and compatible since it is delivered with the Application image.
- The device then begins to load the configuration
- If there is a failure during the configuration loading process – or up to 300 seconds after that process started, then it is assumed that the configuration is not valid – and the fallback configuration is specified as the preferred configuration to load – and the device restarts.
- Once the configuration is loaded, and 300 seconds has expired, the application notes that it successfully loaded.

**Note:** The 300 second time period is configurable.

---

## 2.4 CLI Navigation Commands

This chapter provides an alphabetical reference for the commands used to navigate between different modes. This chapter also provides a reference for the help and show commands used to help navigate within the CLI.

**Note:** The up-arrow and down-arrow keys can also be used to scroll back and forth through previous commands.

## 2.4.1 CLI Navigation Commands

Table 2-6: CLI Navigation Commands

Commands
<a href="#">configure terminal</a>
<a href="#">disable (Privileged Exec Mode)</a>
<a href="#">do</a>
<a href="#">enable (Privileged Exec Mode)</a>
<a href="#">end</a>
<a href="#">exit</a>
<a href="#">help</a>
<a href="#">logout</a>
<a href="#">show history</a>

## CONFIGURE TERMINAL

<b>Syntax</b>	<code>configure terminal</code>
<b>Description</b>	This command enters the Global Configuration command mode.
<b>Feature</b>	CLI Navigation Commands
<b>Mode</b>	Privileged Exec Mode
<b>Release</b>	4.1
<b>Options</b>	NA
<b>Note</b>	NA
<b>Example</b>	To enter the Global Configuration command mode (note the change in the command prompt), enter the command:

```
awplus# configure terminal
```

```
Enter configuration commands, one per line. End with CNTL/Z.
```

```
awplus(config)#
```

**DISABLE (PRIVILEGED EXEC MODE)**

<i>Syntax</i>	disable
<i>Description</i>	This command exits the Privileged Exec Mode, returning the prompt to the User Exec mode. To end a session, use the exit command.
<i>Feature</i>	CLI Navigation Commands
<i>Mode</i>	Privileged Exec Mode
<i>Release</i>	4.1
<i>Options</i>	NA
<i>Note</i>	NA

**Example** To exit the Privileged Exec Mode, enter the command:

```
awplus# disable
awplus>
```

**DO**

**Syntax**           do <command>

**Description**       This command lets you to run User Exec and Privileged Exec Mode commands when you are in a Configuration mode.

**Feature**           CLI Navigation Commands

**Mode**             Any configuration mode

**Release**          4.1

**Options**

Option	Description	Range	Default Value
<command>	Specify the command and its parameters.	NA	NA

**Note**             NA

**Example**          Here is an example of the do command:

```
awplus> enable
awplus# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
awplus(config)# do ping 192.168.200.1
PING 192.168.200.1 (192.168.200.1): 56 data bytes
56 bytes from 192.168.200.1: icmp_seq=0 ttl=64 time=0.7 ms
56 bytes from 192.168.200.1: icmp_seq=1 ttl=64 time=0.4 ms
56 bytes from 192.168.200.1: icmp_seq=2 ttl=64 time=0.4 ms
56 bytes from 192.168.200.1: icmp_seq=3 ttl=64 time=0.4 ms

--- 192.168.200.1 ping statistics ---
4 packets transmitted, 4 packets received, 0% packet loss
round-trip min/avg/max = 0.4/0.4/0.7 ms
awplus(config)#
```



**ENABLE (PRIVILEGED EXEC MODE)**

**Syntax**            enable

**Description**       This command enters the Privileged Exec Mode.

**Feature**            CLI Navigation Commands

**Mode**              User Exec Mode

**Release**            4.1

**Options**            NA

**Note**               NA

**Example**            The following example shows the use of the **enable** command to enter the Privileged Exec Mode (note the change in the command prompt)

```
awplus# enable
awplus#
```

**END**

**Syntax**           end

**Description**       This command returns the prompt to the Privileged Exec command mode from any other advanced command mode.

**Feature**           CLI Navigation Commands

**Mode**             All command modes

**Release**           4.1

**Options**           NA

**Note**             NA

**Example**           The following example shows the use of the end command to return to the Privileged Exec Mode directly from Interface mode.

```
awplus# enable
awplus# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
awplus(config)# interface vlan1
awplus(config-if)# end
awplus#
```

**EXIT**

**Syntax**            exit

**Description**       This command exits the current mode, and returns the prompt to the mode at the previous level. When used in User Exec mode, the exit command terminates the session.

**Feature**            CLI Navigation Commands

**Mode**               All command modes.

**Release**            4.1

**Options**            NA

**Note**               NA

**Example**            The following example shows the use of exit command to exit Interface mode:

```
awplus(config-if)# end
awplus# exit
awplus#
AlliedWare Plus CLI has terminated. Have a nice day!!!
```

Connection to host lost.

**HELP**

<b>Syntax</b>	help
<b>Description</b>	This command displays a description of the AT-IMG CLI help system.
<b>Feature</b>	NA
<b>Mode</b>	All command modes
<b>Release</b>	4.1
<b>Options</b>	NA
<b>Note</b>	NA
<b>Example</b>	To display a description on how to use the system help, use the command

```
awplus> enable
awplus# help
```

When you need help at the command line, press '?'.

If nothing matches, the help list will be empty. Delete characters until entering a '?' shows the available options.

Enter '?' after a complete parameter to show remaining valid command parameters (e.g. 'show ?').

Enter '?' after part of a parameter to show parameters that complete the typed letters (e.g. 'show ip?').

```
awplus#
```

**LOGOUT**

<i><b>Syntax</b></i>	logout
<i><b>Description</b></i>	This command exits the User Exec or Privileged Exec Modes and ends the session.
<i><b>Feature</b></i>	CLI Navigation Commands
<i><b>Mode</b></i>	User Exec Mode
<i><b>Release</b></i>	4.1
<i><b>Options</b></i>	NA
<i><b>Note</b></i>	NA
<i><b>Example</b></i>	To exit the User Exec mode, use the command:

```
awplus> logout
awplus>
AlliedWare Plus CLI has terminated. Have a nice day!!!
```

**SHOW HISTORY**

**Syntax**            `show history`

**Description**        This command lists the commands entered in the current session. The history buffer is cleared automatically upon reboot. Also, note that identical commands entered consecutively appear as single entry.

The output lists all command line entries, including commands that returned an error.

**Feature**            CLI Navigation Commands

**Mode**              User Exec and Privileged Exec

**Release**           4.1.2

**Options**           NA

**Note**              In this release, an incomplete command that is entered does not show up in the command list.

**Example**            To display the commands entered during the current session, use the command:

```
awplus# show history
```

```
awplus# show history
 1 enable
 2 config
 3 show history
 4 quit
 5 show history
awplus#
```

---

## 2.5 User Access Commands

## 2.5.1 User Access Commands

This chapter provides an alphabetical reference of commands used to configure user access.

Table 2-7: User Access Commands

Commands
<a href="#">enable password</a>
<a href="#">exec-timeout</a>
<a href="#">service http</a>
<a href="#">service ssh</a>
<a href="#">service telnet</a>
<a href="#">show exec-timeout</a>
<a href="#">show exec-timeout</a>
<a href="#">show http</a>
<a href="#">show security-password user</a>
<a href="#">show ssh</a>
<a href="#">show ssh server</a>
<a href="#">show telnet</a>
<a href="#">terminal length</a>
<a href="#">username</a>

## ENABLE PASSWORD

**Syntax**            `enable password <password>`

**Description**        This command sets a local password to control access to various privilege levels. Use the enable password command to modify or create a password to be used, and use the no enable password command to remove the password.

This also enables the Network Administrator to set a password for entering the enable mode. There are three methods to enable a password. In the examples below, for each method, the configuration is different: the configuration file output is different, but the password string to be used to enter the enable mode is the same (mypasswd).

A user can have an intermediate CLI security level set with this command for privilege level 7 to access all the show commands in Privileged Exec Mode and all the commands in User Exec mode, but not any configuration commands in Privileged Exec Mode.

**Feature**            User Access Commands

**Mode**              Global Configuration Mode

**Release**           4.1

**Options**

Option	Description	Range	Default Value
<plain>	Specifies the unencrypted password.	NA	NA

**Note**                Do not use encrypted passwords for GUI users. The GUI requires unencrypted user passwords only - not encrypted user passwords. Do not use option 8 for GUI users.

**Example**            The plain password is encrypted in the configuration files (part of xml attributes).

```
awplus# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
awplus(config)# enable password mypasswd
awplus(config)# end
```



## EXEC-TIMEOUT

**Syntax**            `exec-timeout {<minutes>}`  
                     `no exec-timeout`

**Description**        This command sets the interval your device waits for user input from either a console or VTY connection. Once the timeout interval is reached, the connection is dropped. This command sets the time limit when the console or VTY connection automatically logs off after no activity. The no variant of this command removes a specified timeout and resets to the default timeout (10 minutes). This command is used set the time the telnet session waits for an idle VTY session, before it times out. An `exec-timeout 0 0` setting will cause the telnet session to wait indefinitely. The command `exec-timeout 0 0` is useful while configuring a device, but reduces device security. If no input is detected during the interval then the current connection resumes. If no connections exist then the terminal returns to an idle state and disconnects incoming sessions..

**Feature**            User Access Commands

**Mode**              Line Configuration

**Release**            4.3.2

**Options**

Option	Description	Range	Default Value
<minutes>	Required integer timeout value in minutes	<0-35791>	10
<seconds>	Required integer timeout value in seconds	<0-2147483>	0

**Note**                When setting 0 minutes and 0 seconds the console session waits indefinitely

**Example**            To set connections to timeout after 2 minutes and 30 seconds if there is no response from the user, use the following commands

```
awplus# configure terminal
awplus(config)# line console 0
awplus(config-line)# exec-timeout 2 30
```

**Example**            To reset the console connection to the default timeout of 10 minutes if there is no response from the user, use the following commands:

```
awplus# configure terminal
awplus(config)# line console 0
awplus(config-line)# no exec-timeout
```

**SERVICE HTTP**

**Syntax**            `service http`  
                  `no service http`

**Description**        This command enables the HTTP (Hypertext Transfer Protocol) service. The HTTP service is enabled by default on a Java enabled browser.

The no service http command disables the HTTP feature.

The HTTP service is enabled by default.

**Feature**            User Access Commands

**Mode**              Global Configuration Mode

**Release**           4.1

**Options**           NA

**Note**              NA

**Example**           To disable the HTTP service, use the command.

```
awplus> enable
awplus# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
awplus(config)# no service http
awplus(config)#
```

**Example**           To re-enable the HTTP service, use the command.

```
awplus(config)# service http
awplus(config)#
```

## SERVICE SSH

**Syntax**            `service ssh`  
                  `no service ssh`

**Description**        This command enables the Secure Shell server on the device. Once enabled, connections coming from SSH clients are accepted.

The no variant of this command disables the Secure Shell server. When the Secure Shell server is disabled, connections from SSH clients are not accepted. This command does not affect existing SSH sessions. To terminate existing sessions, use the clear ssh command.

By default, this command enables the IPv4 Secure Shell server.

**Feature**            SSH Commands

**Mode**              Global Configuration Mode

**Release**           4.1

**Options**           NA

**Note**              NA

**Example**           To enable the Secure Shell server, use the commands:

```
awplus(config)# service ssh
```

**Example**           To disable the IPv4 and telnet servers, use the following commands:

```
awplus(config)# no service ssh
```

## SERVICE TELNET

**Syntax**            `service telnet`  
                     `no service telnet`

**Description**      This command enables the telnet server. The server is enabled by default. Enabling the telnet server starts the switch listening for incoming telnet sessions on the configured port.

The server listens on port 23, unless you have changed the port by using the privilege level command.

Use the no variant of this command to disable the telnet server. Disabling the telnet server will stop the switch listening for new incoming telnet sessions. However, existing telnet sessions will still be active.

The IPv4 telnet servers are enabled by default.

**Feature**            User Access Commands

**Mode**              Global Configuration Mode

**Release**           4.1

**Options**           NA

**Note**               NA

**Example**           To enable the IPv4 telnet servers, use the following commands:

```
awplus(config)# service telnet
```

**Example**           To disable the IPv4 and telnet servers, use the following commands:

```
awplus(config)# no service telnet
```

**SHOW HTTP**

<i>Syntax</i>	show http
<i>Description</i>	This command shows the status of the HTTP server.
<i>Feature</i>	User Access Commands
<i>Mode</i>	Global Configuration Mode
<i>Release</i>	4.1
<i>Options</i>	NA
<i>Note</i>	NA
<i>Example</i>	

```
awplus# configure terminal
awplus(config)# show http

awplus(config)# show http

Http Server Configuration
-----

Http Server: enabled
```

**SHOW EXEC-TIMEOUT**

<i>Syntax</i>	show line
<i>Description</i>	This command shows the interactive timeout setting.
<i>Feature</i>	User Access Commands
<i>Mode</i>	Global Configuration Mode
<i>Release</i>	4.4
<i>Options</i>	NA
<i>Note</i>	See setting for exec-timeout
<i>Example</i>	

```
awplus# show line
```

```
awplus# show line
```

```
Serial, Telnet, SSH or USB configuration:  
Interactive timeout: 10 minutes 0 seconds
```

```
or (after modify exec-timeout 1 1)
```

```
awplus# show line
```

```
Serial, Telnet, SSH or USB configuration:  
Interactive timeout: 1 minute 1 second
```

**SHOW LINE**

<i>Syntax</i>	show line
<i>Description</i>	This command shows the interactive timeout setting.
<i>Feature</i>	User Access Commands
<i>Mode</i>	Global Configuration Mode
<i>Release</i>	4.4
<i>Options</i>	NA
<i>Note</i>	See setting for exec-timeout
<i>Example</i>	

```
awplus# configure terminal
```

```
awplus(config)# show line
```

```
awplus(config)# show line
```

```
Serial, Telnet, SSH or USB configuration:  
Interactive timeout: 10 minutes 0 seconds
```

**SHOW SECURITY-PASSWORD USER**

**Syntax**            `show security-password user`

**Description**      This command displays user account and password information for all users.

**Feature**            User Access Commands

**Mode**              Privileged Exec Mode

**Release**           4.1

**Options**            NA

**Note**               NA

**Example**            To enable the IPv4 telnet servers, use the following commands:

```
awplus# show security-password user
User account and password information
UserName  Privilege
manager   15
alice     15
bob       15
guest     1
```



**SHOW SSH**

**Syntax**            `show ssh server`

**Description**      This command displays the active SSH sessions on the device, both incoming and outgoing.

**Feature**            SSH Commands

**Mode**              Privileged Exec Mode

**Release**           4.1

**Options**           NA

**Note**              NA

**Example**           To display the current SSH status on the device, use the command:

```
awplus# show ssh
SSH Server Configuration
-----
SSH Server: enabled
```

## SHOW SSH SERVER

**Syntax**            show ssh server

<b>Description</b>	This command displays the status of the SSH server.
--------------------	---

<i>Feature</i>	SSH Commands
----------------	--------------

<i>Mode</i>	Privileged Exec Mode
-------------	----------------------

Release 4.1

<i>Options</i>	NA
----------------	----

<i>Note</i>	NA
-------------	----

**Example** To display the current SSH status on the device, use the command:

```
awplus# show ssh server
```

## Secure Shell Server Configuration

```
SSH Server      : Enabled
```

**SHOW TELNET**

**Syntax**            `show telnet`

**Description**      This command shows the Telnet server settings.

**Feature**            User Access Commands

**Mode**              Privileged Exec Mode

**Release**           4.1

**Options**           NA

**Note**              NA

**Example**           To show the Telnet server settings, use the command:

```
awplus# show telnet
```

```
awplus# show telnet
```

```
Telnet Server Configuration
```

```
-----  
Telnet server                                : Enabled
```

## TERMINAL LENGTH

**Syntax**      `terminal length <length>`  
                 `terminal no length`

**Description**      Use the terminal length command to specify the number of rows of output that the device will display before pausing, for the currently-active terminal only. Use the terminal no length command to remove the length specified by this command. The default length will apply unless you have changed the length for some or all lines by using the **length (console display)** command.

**Feature**          User Access Commands

**Mode**            Privileged Exec Mode

**Release**        4.3.2

### Options

Option	Description	Range	Default Value
<length>	Number of rows that the device will display on the currently-active terminal before pausing. Value 0 means no pause.	<0-512>	24

**Note**            Use 0 for no pausing

**Example**        The following example sets the number of lines to 15.

```
awplus# terminal length 15
```

**Example**        The following example removes terminal length set previously.

```
awplus# terminal no length
```

**USERNAME**

**Syntax**      `username <name> privilege <0-15> password <password>`  
                  `no username <name>`

**Description**      This command creates or modifies a user.

**Feature**            User Access Commands

**Mode**                Global Configuration mode

**Release**            4.1

**Options**

Option	Description	Range	Default Value
<name>	The login name for the user. Do not use punctuation marks, such as single quotes ('), double quotes (""), or colons (:) with the user login name.	NA	NA
privilege	The user's privilege level. Use the privilege levels to set the access rights for each user. The range is <1-15>. A privilege level: Values from 1 to 9 assign complete CLI access protected by privilege password. WEB pages are restricted to show only basic system information. Values from 10 to 14 assign complete CLI access protected by privilege password. WEB pages are fully available. Value of 15 assign complete CLI access without requiring any privilege password. WEB pages are fully available.	NA	NA
password	A password that the user must enter when logging in. Note that the user enters the plain-text version of the password when logging in <password> The user's password. The password can be up to 23 characters in length and include characters from up to four categories. The password categories are: uppercase letters: A to Z lowercase letters: a to z digits: 0 to 9 functionality. special symbols: all printable ASCII characters not included in the previous three categories. The question mark ? cannot be used as it is reserved for help	NA	NA

**Note**                NA

**Example**            To create the user bob with a privilege level of 15, and the password bobs\_secret, use the commands:

```
awplus(config)# username bob privilege 15 password bobs_secret
```

---

## 2.6 Creating and Managing Configuration Files

### 2.6.1 Introduction

This chapter provides information on:

- Files that are part of the automatic file download from a TFTP server
- Creating and Using Configuration Files
- Copying Files To and From Your Device

### 2.6.2 Software Updates from TFTP server

There is a client *software update module* running on the gateway that contacts a TFTP server and retrieves from it the required software or support files.

The *software update module* retrieves the TFTP Server address from the value of a specific dhcp option (option 66 'tftp-server-name' and option 67 for the path) passed by the external DHCP server to the gateway IP interface. It then uses the path and filename string to navigate into the TFTP server.

In order to distinguish the correct DHCP Offer (in case more than one DHCP server is present in the network), the gateway will consider only DHCP Offers that include the option 60, which is sent in the Discover & Request - and expected to be received in the Offer and the Ack. (If option 43 is received, the process stops.)

If multiple leases with Option 60 are received (on different VLANs), the last one received is the one used.


The class-id that identifies the specific device ('dhcp-class-identifier') can have one of the following possible values, depending on the product code:

- iMG1405
- iMG1425W
- iMG1425
- iMG1505
- iMG1525
- iMG1425
- iMG1425W
- iMG1525RF
- iMG2504
- iMG2522
- iMG2524
- iMG2524F
- iMG2524H

**Note:** The *software update module* is designed to download only the files that differ or are not already present in the file-system.

**Note:** On dual image devices, one image is updated, and then the system restarts. The process is then repeated, and the second image is updated.

**Note:** It is possible to disable the TFTP trigger during the boot phase by setting a parameter value only accessible via CWMP/TR69:  
InternetGatewayDevice.X\_BROADCOM\_COM\_AppCfg.X\_ALLIEDTELESIS\_COM\_SwupdateCfg.DhcpTriggerEnable



**FIGURE 2-5 Normal Automatic Update Operation Mode**

In order to inform the *software update module* about which files it must download from the TFTP server, a special file named **MD5SUM** must be created on the TFTP server.

When the *software update module* connects to the TFTP server, it retrieves immediately this file and then downloads each file reported in this list.

The MD5SUM file is a list of filenames where each file name has the associated MD5 value.

**Note:** The filename (MD5SUM) is fixed.

To create the MD5SUM file it is possible use the md5sum command available under standard Linux platforms (free md5sum applications are available also under *Windows™ Operating System*).

If a file reported in the MD5SUM list is already present into the gateway file-system with the same MD5 value, the *software update module* will skip the download of this file; otherwise it will download it.

Two files with special names are processed as follows:

- default\_button.cfg - This is placed in a special partition. Refer to [2.1.11](#).
- bootstrap.cfg - This automatically becomes the startup-config. Refer to [2.1.11](#).

### 2.6.3 Listing Configuration Files

To list the .cfg files and their size in bytes, enter Privileged Exec Mode and enter the command:

```
awplus# dir
```

The output lists files and directories in order of modification date, descending. It looks like this:

```
9748 default.cfg
13320 default_button.cfg
13320 test.cfg

awplus#
```

## 2.6.4 Creating and Using Configuration Files

This section provides instructions on:

- Creating a configuration file
- Specifying the start-up configuration script
- Working with configuration files

**Note:** Configuration files must end with '.cfg'.

## 2.6.5 Creating a configuration file

A *configuration file* is a text file that contains a sequence of standard cli commands or an xml file. Configuration files have a .cfg extension. Your device has a default configuration script called *default.cfg*.

```
awplus# show file default.cfg
username manager privilege 15 password friend
username admin privilege 9 password admin
interface vlan1
ip address dhcp
exit
service http
service telnet
service ssh
```

When the device starts by using a boot cli command, a file named cli\_boot\_result.txt is created in order to debug errors in the configuration file. (This file is also present in tech-support)

The default\_button.cfg could also be saved in a cli format.

Please note that cli files are “read only” (it is not possible to edit a cli file from a device). To modify a cli file it is necessary to import a new modified cli file.

If you try to save a boot cli file via WEB/tr69, a file named unnamed.cfg in xml format will be saved.

You can create and edit configuration files on your device by:

- saving the dynamic configuration on the device, known as the *running-config* (see [Working with configuration files](#)). Use the command:

```
awplus# copy running-config <filename.cfg>
```

Where <filename.cfg> specifies a file in Flash.

- creating a file on a remote PC, then copying it to onto your device. See [Copying files](#) for more information about using the copy commands.

Once you have created a configuration file, you can use it as the *startup-config* file. See [Specifying the start-up configuration script](#) for more information.



**Note:** You cannot edit a configuration file.

**Note:** Configurations are created for a particular device-type, and can only be loaded on devices of that type.

**Note:** Any configuration file written as a CLI sequence of commands **MUST** include the following:

```
service telnet
service http
service ssh
```

## 2.6.6 Specifying the start-up configuration script

When you restart your device, or when it automatically restarts, it loads the config known as the *boot config* or *startup-config* file.

When you first start your device, the script set as the startup-config file is *default.cfg*. If desired, you can overwrite *default.cfg* with another configuration. Alternatively, you can change the startup-config by specifying a new file as the startup-config. Use the command:

```
awplus(config)# boot config-file <filename.cfg>
```

where filename.cfg specifies the name and location of a configuration file. At the next restart, the device loads the config in the specified file.

You can change the content of the file set as the startup-config file by:

- entering commands directly into the CLI, then saving this configuration using the command:

```
awplus# copy running-config startup-config
```

This command saves the device's dynamic configuration into the file that is currently configured as the startup-config file.

- writing commands into a configuration file (see [Creating a configuration file](#) below), then using the command:

```
awplus# copy SOURCE-URL startup-config
```

This command saves the script from the source file into the file that is currently configured as the startup-config file.

To display the name of the configuration file that is set to execute when the device restarts, enter the command:

```
awplus# show boot
```

To see the config in the startup-config file, use the command:

```
awplus# show startup-config
```

To erase the file set as the startup-config file, use the command:

```
awplus# erase startup-config
```

At the next restart that occurs, the device will first attempt to load default\_button.cfg. If that is not present it will then fall-back to default.cfg. See section [“Start-up Sequence”](#).

**Note:** When configuring the device using the Web GUI or a TR-069 tool, each configuration action results in a save. If the startup configuration is the default.cfg, then a new config is created named unnamed.cfg and that is set as the startup configuration. If the unnamed.cfg file is present and is a CLI file, Web GUI and TR-069 cannot be saved.

## 2.6.7 Working with configuration files

When you use the CLI or GUI to configure your device, it stores this dynamic configuration called the *running-config*. To view the device's running-config, use the command:

```
awplus# show running-config
```

If you turn off the device or restart it, any unsaved changes to the running-config are lost. To save the running-config as a configuration script, use the command:

```
awplus# copy running-config <filename>.cfg
```

You may have many configuration files. Storing them on a device allows you to keep a backup device with configuration scripts for every device in the network to speed up network recovery time.

## 2.6.8 The configuration file fallback order

The configuration fallback order is:

- configuration file
- default button configuration file
- the factory default configuration.

It is important to note there is a distinction in system behavior between these when writing to the startup-config file and when the system boots up.

When you copy a configuration script from a source file into the startup-config file the system will write to the specified startup config. (The user must specify the startup config.)

At system startup the device goes through the fallback sequence until it finds a file that exists and is valid. For example, if the configuration file is not found then the backup configuration file becomes the current boot configuration, or startup-config, and so on. In the output displayed by the show boot command, the Current boot config parameter shows the startup-config file that the switch will load during the next boot cycle. The fallback sequence when configuration files are deleted is shown below in output from the show boot command.

In the example output below, the current boot configuration file, test.cfg, is set. This is the startup-config file that the device loads at the next boot cycle.

```
awplus# show boot
Boot configuration
-----
Current software : [partition 2] AT-iMG2500-4.3_112
Current boot image : [partition 2] AT-iMG2500-4.3_112 (AtiBcm-4.3_112)
Backup boot image : [partition 1] AT-iMG2500-4.2.3 (AtiBcm-4.2.3)
Default boot config: default.cfg
Backup boot config: default_button.cfg (file exists)
Current boot config: 3play-sip.cfg (file exists)
```

Reset startup-config (which was test.cfg) to the backup configuration file (default\_button.cfg). Note that test.cfg is not deleted – it is simply no longer marked as the startup-config.

```
awplus# do show boot
Boot configuration
-----
Current software : [partition 2] AT-iMG2500-4.3_112
Current boot image : [partition 2] AT-iMG2500-4.3_112 (AtiBcm-4.3_112)
Backup boot image : [partition 1] AT-iMG2500-4.2.3 (AtiBcm-4.2.3)
Default boot config: default.cfg
Backup boot config: default_button.cfg (file exists)
Current boot config: 3play-sip.cfg (file exists)
```

At system startup the switch will load the default button or the default configuration file as the startup-config.

## 2.6.9 Copying Files To and From Your Device

This section provides instructions on:

- URL syntax
- Copying files

### 2.6.10 URL syntax

Many of the file management commands use the placeholder "URL" to represent the name and location of the file that you want to act on. The following table explains the syntax of this URL for each different type of file location.

**Note:** Only the tftp:// URL type is supported.

Table 2-8: Location of Common Files

When you copy a file...	Use this syntax:
Copying with Trivial File Transfer Protocol (TFTP)	tftp://LOCATION/[DIRECTORY]/]FILENAME

### 2.6.11 Copying files

To copy files, use the copy commands. These commands allow you to copy files:

To copy a file, enter Privileged Exec Mode and enter the command:

```
awplus# copy <source-filename>
          <destination-filename>
```

If the file already exists, the user must delete the file before trying again.

**Note:** There is no file system; there is a single directory where all files reside.

#### 2.6.11.1 Copying with Trivial File Transfer Protocol (TFTP)

TFTP runs over User Datagram Protocol (UDP). It is simpler and faster than FTP but has minimal capability, such as no provisions for user authentication. Two examples on how to copy a configuration file from the TFTP server to the iMG and how to copy a show-tech report file from the iMG to a TFTP server are the following:

To copy a config file from a TFTP server to the iMG, enter Privileged Exec Mode and enter the command:

```
awplus# copy tftp://<server address>/[server path/]
        <serverfilename>.cfg <localfilename>.cfg
```

To copy a show-tech file from the iMG to a TFTP server, enter Privileged Exec Mode and enter the command:

```
awplus# copy <show-techfilename> tftp://<server address>/
        [server path/]<servershow-techfilename>
```

---

## 2.7 File Management Commands

## 2.7.1 File Management Commands

This chapter provides an alphabetical reference of commands used for file management.

**Note:** Many of the commands in this chapter use the placeholder "URL" to represent the name and location of the file that you want to act on. The following table explains the syntax of this URL for each different type of file location

Table 2-9: URL Syntax and Keyword Usage

When you copy a file...	Use this syntax:
In local memory	FILENAME
Using Hypertext Transfer Protocol (HTTP)	http[ : / / ] [ [ USERNAME : PASSWORD ] @ ] { HOSTNAME   HOST-IP } [ / FILEPATH ] / FILENAME
Using Trivial File Transfer Protocol (TFTP)	tftp : // LOCATION / [ DIRECTORY / ] FILENAME

Table 2-10: User Access Commands

Commands
boot config-file
boot default button
boot system
boot system recovery crc
boot system recovery filename
boot system recovery server
copy
copy running-config
copy startup-config
delete
dir
erase startup-config
move
show boot
show file
show running-config
show startup-config
show version

## BOOT CONFIG-FILE

**Syntax**            `boot config-file <filename>`  
                     `no boot config-`

**Description**      This command sets the configuration file to use during the next boot cycle.

Use the no variant of this command to set the boot configuration file to default. If the configuration file does not exist, the file is automatically created.

For an explanation of the configuration fallback order, see [2.6.8](#).

**Feature**            File Management Commands

**Mode**                Global Configuration Mode

**Release**            4.1

**Options**

Option	Description	Range	Default Value
<filename>	Valid configuration files must have a .cfg extension.	NA	NA

**Note**                NA

**Example**            To run the configuration file `branch.cfg` stored on the switch's Flash filesystem the next time the device boots up, use the commands:

```
awplus(config)# boot config-file branch.cfg
```

## BOOT DEFAULT BUTTON

<b>Syntax</b>	<pre>awplus(config)# boot default-button awplus(config)# no boot default-button</pre>
<b>Description</b>	<p>This command enables the support for default button. If a user keeps pressed the reset button for more than 10 seconds, the iMG will restart and will execute the configuration showed in the file named default-button configuration.</p> <p>The no variant of the command disables the support for the reset of the default button.</p>
<b>Feature</b>	File Management Commands
<b>Mode</b>	Privileged Exec Mode
<b>Release</b>	4.3.2
<b>Options</b>	NA
<b>Note</b>	For single image devices (i.e. iMG I400 family), there is no backup boot image.
<b>Example</b>	<p>To enable the current boot configuration, use the command:</p> <pre>awplus(config)# boot default-button</pre>

## BOOT SYSTEM

**Syntax**            `boot system partition [1|2]`  
                     `boot system <filename>`

**Description**        This command sets the release file to load during the next boot cycle. The user can specify the file name as well as the partition. To know the name of the release file use the show boot command.

**Feature**            File Management Commands

**Mode**                Global Configuration Mode

**Release**            4.1

**Options**

Option	Description	Range	Default Value
<i>partition</i>	Where all user configuration files are stored.	NA	NA

**Note**                NA

**Example**            To run the appload in the other partition, use the commands:

```
awplus(config)# boot system partition 1
```



## BOOT SYSTEM RECOVERY CRC

**Syntax**            `boot system recovery crc <hex>`  
                     `no boot system recovery crc <hex>`

**Description**        This command sets the value (if set not equal to zero) that enables CRC validation of the image once it is downloaded. This only applies to the system recovery process, and not normal firmware updates. Refer to [boot system recovery server](#). The no command restores the value to the default (0)

**Description**

**Description**        see boot recovery server description

**Feature**            File Management Commands

**Mode**                Global Configuration Mode

**Release**            4.2

**Options**

Option	Description	Range	Default Value
hex	value that enables CRC validation of the image once it is downloaded.	NA	0x00

**Note**                The CRC value for each image can be found in the Release Notes. This command applies only to single image devices (i.e. IMG1400).

**Example**            To set the hex value, use the commands:

```
awplus(config)# boot system recovery crc 04c2cddFF
```

## BOOT SYSTEM RECOVERY FILENAME

**Syntax**            `boot system recovery filename <filename>`  
                     `no boot system recovery filename <filename>`

**Description**      This command sets the image filename that is requested from the server for recovery. The no command restores the filename to the default.

**Feature**            File Management Commands

**Mode**              Global Configuration Mode

**Release**            4.2

### Options

Option	Description	Range	Default Value
filename	The filename for the image.	NA	AT-iMG1400-4.2

**Note**                This command applies only to I400 series devices (single image).

**Example**            To set the tftp ip address, use the commands:  
`awplus(config)# boot system recovery filename AT-iMG1400-4.2`

## BOOT SYSTEM RECOVERY SERVER

**Syntax**            `boot system recovery server <IP_address>`  
                     `no boot system recovery server <IP_address>`

**Description**      This command sets the IP address where the TFTP request is sent for emergency recovery of a single image device. The no command restores the value to the default, i.e. the IP address of the DHCP server where the iMG is connected.

**Feature**            File Management Commands

**Mode**              Global Configuration Mode

**Release**            4.2

**Options**

Option	Description	Range	Default Value
IP_address	The IP address for the TFTP request.	NA	IPaddress of the DHCP server

**Note**                This command applies only to I 400 series devices (single image).

**Example**            To set the tftp ip address, use the commands:

```
awplus(config)# boot system recovery server 10.52.208.1
```

**COPY**

**Syntax**

```
copy <source-url> <destination-file>
copy <source-file> <destination-file>
copy <source-file> <destination-url>
```

**Description** This command may be used to copy configuration files from a remote tftp server onto the iMG, from the iMG to a remote tftp server, or simply to make a local copy of a configuration file already present on the iMG

This command can also be used to copy tech-support .txt files from the iMG to a remote tftp server (see the [show tech-support](#) command).

**Feature** File Management Commands

**Mode** Privileged Exec Mode

**Release** 4.1

**Options**

Option	Description	Range	Default Value
<source-file>	The name of an existing configuration file on the iMG.	NA	NA
<destination-file>	The name of the new configuration file that you would like to create on the iMG	NA	NA
<source-url>	The tftp URL of a configuration file. The file pointed by the url must be a valid configuration file with a .cfg file-name extension.	NA	NA
<destination-url>	The tftp URL of the destination configuration file.	NA	NA

**Note** It is not possible to use both <source-url> and <destination-url> together in the same copy command.

**Example** The following commands show an example for each syntax listed above:

```
awplus# copy tftp://alpha.myplace.com/newconfig.cfg newconfig.cfg
awplus# copy oldconfig.cfg backup_oldconfig.cfg
awplus# copy oldconfig.cfg tftp://alpha.myplace.com/backup_config.cfg
```

## COPY RUNNING-CONFIG

**Syntax**            `copy running-config <destination-tftp-url>`  
                     `copy running-config startup-config`

**Description**       This command copies the running-config to a destination file.

**Feature**            File Management Commands

**Mode**              Privileged Exec Mode

**Release**            4.1

**Options**

Option	Description	Range	Default Value
<destination-url>	The tftp URL where you would like the current running-config saved. This command creates a file if no file exists with the specified filename. If a file already exists, then the CLI prompts you before overwriting the file.	NA	NA
startup-config	Copies the running-config into the file set as the current startup-config file.	NA	NA

**Note**               NA

**Example**            To copy the running-config into the startup-config, use the command:

```
awplus# copy running-config startup-config
```

**Example**            To use tftp to copy the running-config as current.cfg, use the command:

```
awplus# copy running-config tftp://server/config_files/current.cfg
```

## COPY STARTUP-CONFIG

**Syntax**            `copy <source-url> startup-config`  
                     `copy startup-config <destination-url>`

**Description**       This command copies the startup-config script into a destination file, or alternatively copies a configuration script from a source file into the startup-config file.

**Feature**            File Management Commands

**Mode**               Privileged Exec Mode

**Release**            4.1

### Options

Option	Description	Range	Default Value
<source-url>	The tftp URL of a configuration file. This must be a valid configuration file with a .cfg filename extension. Specify this to copy the script in the file into the startup-config file. Note that this does not make the copied file the new startup file, so any further changes made in the configuration file are not added to the startup-config file unless you reuse this command.	NA	NA
<destination-url>	The destination and filename that you are saving the startup-config as. This command creates a file if no file exists with the specified filename. If a file already exists, then the CLI prompts you before overwriting the file.	NA	NA

**Note**                NA

**Example**            To copy the file Layer3.cfg to the startup-config, use the command:  
`awplus# copy Layer3.cfg startup-config`

**Example**            To copy the startup-config as the file oldconfig.cfg use the command:  
`awplus# copy startup-config oldconfig.cfg`

## DELETE

**Syntax** `delete [force] <name>`

**Description** This command deletes configuration files and text files like the tech support file.

The use of wildcards is allowed here so commands such as these are allowed:

- `awplus# delete *.cfg`
- `awplus# delete test*.cfg`
- `awplus# delete *.txt`
- `awplus# delete tech*.txt`

**Feature** File Management Commands

**Mode** Privileged Exec Mode

**Release** 4.1.2

**Options**

Option	Description	Range	Default Value
force	Don't prompt with individual file names before deletion. This option can also be used to force deletion of the current startup configuration."	NA	NA
<name>	Name of the config file to delete.	NA	NA

**Note** When the user inputs delete with a wildcard, a prompt message appears for each file to be deleted; Deletion is done for the selected files at the end of **all** the requests. Also, to allow the deletion of the startup config, the `force` option must be used.

**Example** To delete the file `temp.cfg` from the current directory, use the command:

```
awplus# delete temp.cfg
```

**Example** To delete the file `tech-support-00700001-000229.txt` from the current directory, use the command

```
awplus# delete tech-support-00700001-000229.txt
```

**DIR**

**Syntax**            dir

**Description**      This command lists the config and text files on the iMG, preceded by their size in bytes.

**Feature**            File Management Commands

**Mode**              Privileged Exec Mode

**Release**            4.1

**Options**            NA

**Note**               NA

**Example**            To list the files in the current working directory, use the command:

```
awplus# dir
 9748 default.cfg
346545 tech-support-00700001-000229.txt
13418 a1.cfg
```



**ENABLE DEFAULT BUTTON CONFIGURATION**

<i><b>Syntax</b></i>	<code>awplus(config)# boot default-button</code>
<i><b>Description</b></i>	This command is for enabling the default button configuration.
<i><b>Feature</b></i>	File Management Commands
<i><b>Mode</b></i>	Privileged Exec Mode
<i><b>Release</b></i>	4.3.2
<i><b>Options</b></i>	NA
<i><b>Note</b></i>	For single image devices (i.e. iMG I400 family), there is no backup boot image.
<i><b>Example</b></i>	To enable the current boot configuration, use the command: <code>awplus(config)# boot default-button</code>

**ERASE STARTUP-CONFIG**

<i>Syntax</i>	erase startup-config
<i>Description</i>	This command deletes the file that is set as the startup-config file, which is the configuration file that the system runs when it boots up. Note that startup-config is not changed, so at the next restart, the device will attempt to load the (now deleted) file pointed to by startup-config, and will then fall-back the configuration as described in <a href="#">Start-up Sequence</a> .
<i>Feature</i>	File Management Commands
<i>Mode</i>	Privileged Exec Mode
<i>Release</i>	4.1
<i>Options</i>	NA
<i>Note</i>	NA
<i>Example</i>	To delete the file currently set as the startup-config, use the command:  awplus# erase startup-config

**MOVE**

**Syntax**            `move <source-file> <destination-file>`

**Description**      This command may be used to move (i.e. rename) a configuration file.

**Feature**            File Management Commands

**Mode**                Privileged Exec Mode

**Release**            4.1

**Options**

Option	Description	Range	Default Value
<source-file>	The name of an existing configuration file on the iMG.	NA	NA
<destination-file>	The new name that you would like give to the configuration file.	NA	NA

**Note**                NA

**Example**            To use the move command to rename a file as a backup file:

```
awplus# move oldconfig.cfg backup_oldconfig.cfg
```

## SHOW BOOT

**Syntax**            `show boot`

**Description**      This command displays the current boot configuration.

**Feature**            File Management Commands

**Mode**              Privileged Exec Mode

**Release**           4.1

**Options**            NA

**Note**              For single image devices (i.e. iMG 1400 family), there is no backup boot image.

**Example**            To show the current boot configuration, use the command:

```
awplus# show boot
```

Boot configuration

```
-----  
Current  software   : AT-iMG1400-4.3.2_23  
Current  boot image : AT-iMG1400-4.3.2_23 (AtiBcm-4.3.2_23)  
Default  boot config: default.cfg  
Backup   boot config: default_button.cfg (file not found)  
Current  boot config: unnamed.cfg (file exists)  
Default  button     : disabled
```

OR

```
awplus# show boot
```

Boot configuration

```
-----  
Current  software   : AT-iMG1400-4.3.2_23  
Current  boot image : AT-iMG1400-4.3.2_23 (AtiBcm-4.3.2_23)  
Default  boot config: default.cfg  
Backup   boot config: default_button.cfg (file not found)  
Current  boot config: unnamed.cfg (file exists)  
Default  button     : enabled
```

**SHOW FILE**Table 2-11: Parameters in the output of the **show boot** command

Parameter	Description
Current software	The current software release that the device is using.
Current boot image	The boot image currently configured for use during the next boot cycle.
Backup boot image	The boot image to use during the next boot cycle if the device cannot load the main image.
Default boot config	The default startup configuration file. The device loads this configuration script if no file is set as the startup-config file.
Backup boot config	The backup boot configuration – default_button.cfg
Current boot config	The configuration file currently configured as the startup-config file. The device loads this configuration file during the next boot cycle if this file exists.

**Syntax** `show file {<config.cfg> | <filename.txt>}`

**Description** This command displays the contents of a configuration file or of a technical support file.

**Feature** File Management Commands

**Mode** Privileged Exec Mode

**Release** 4.1

**Options**

Option	Description	Range	Default Value
<filename>	Name of a configuration file or name of tech-support file	NA	NA

**Note** NA

**Example** To display the contents of the file `customer_sip.cfg`, which is in the current directory, use the command:

```
awplus# show file customer_sip.cfg
<?xml version="1.0"?>
<DslCpeConfig version="3.0">
  <InternetGatewayDevice>
    <LANDeviceNumberOfEntries>5</LANDeviceNumberOfEntries>
    <WANDeviceNumberOfEntries>1</WANDeviceNumberOfEntries>
    <DeviceInfo>
      <FirstUseDate>0001-01-01T00:00:00Z</FirstUseDate>
      <VendorConfigFile nextInstance="33" ></VendorConfigFile>
    </DeviceInfo>
    <X_BROADCOM_COM_EthernetSwitch>
      <NumberOfVirtualPorts>5</NumberOfVirtualPorts>
      <EnableVirtualPorts>TRUE</EnableVirtualPorts>
      <IfName>(null)</IfName>
      <X_ALLIEDTELESIS_COM_DscpMapping instance="1">
        <X_ALLIEDTELESIS_COM_DscpValue>45</X_ALLIEDTELESIS_COM_DscpValue>
        <X_ALLIEDTELESIS_COM_EgressQueue>3</X_ALLIEDTELESIS_COM_EgressQueue>
      </X_ALLIEDTELESIS_COM_DscpMapping>
    </X_BROADCOM_COM_EthernetSwitch>
  </InternetGatewayDevice>
</DslCpeConfig>
```

```
</X_ALLIEDTELESIS_COM_DscpMapping>  
<X_ALLIEDTELESIS_COM_DscpMapping instance="2">  
  <X_ALLIEDTELESIS_COM_DscpValue>35</X_ALLIEDTELESIS_COM_DscpValue>  
  <X_ALLIEDTELESIS_COM_EgressQueue>2</X_ALLIEDTELESIS_COM_EgressQueue>
```

**SHOW RUNNING-CONFIG**

**Syntax**            show running-config

**Description**       This command displays the current configuration of the device. The output includes all non-default configuration; default settings are not displayed.

You can control the output in any one of the following ways:

(Display filtering is not supported in this release.)

- 'q' will abort the output.
- Pressing 'enter' or the space bar will advance the output by one line.
- 'r' will show all remaining output.

**Feature**            File Management Commands

**Mode**               All command modes

**Release**            4.1

**Options**            NA

**Note**               NA

**Example**            To display the current dynamic configuration of your device, use the command:

```
awplus# show running-config
<?xml version="1.0"?>

<DslCpeConfig version="3.0">
  <InternetGatewayDevice>
    <LANDeviceNumberOfEntries>1</LANDeviceNumberOfEntries>
    <WANDeviceNumberOfEntries>1</WANDeviceNumberOfEntries>
    <DeviceInfo>
      <FirstUseDate>0001-01-01T00:00:00Z</FirstUseDate>
      <VendorConfigFile nextInstance="4" ></VendorConfigFile>
    </DeviceInfo>
    <Layer2Bridging>
      <BridgeNumberOfEntries>1</BridgeNumberOfEntries>
      <FilterNumberOfEntries>6</FilterNumberOfEntries>
      <MarkingNumberOfEntries>0</MarkingNumberOfEntries>
      <AvailableInterfaceNumberOfEntries>6</AvailableInterfaceNumberOfEntries>
      <Bridge instance="1">
        <BridgeKey>1</BridgeKey>
        <BridgeEnable>TRUE</BridgeEnable>
        <BridgeName>Default</BridgeName>
        <VLANID>1</VLANID>
      </Bridge>
      <Bridge nextInstance="2" ></Bridge>
      <Filter instance="1">
        <FilterKey>1</FilterKey>
      </Filter>
    </Layer2Bridging>
  </InternetGatewayDevice>
</DslCpeConfig>
--More-- (6% of 13326 bytes)
```

**SHOW STARTUP-CONFIG**

**Syntax**            show startup-config

**Description**      This command displays the contents of the start-up configuration file, which is the file that the device runs on start-up.

**Feature**            File Management Commands

**Mode**              Privileged Exec Mode

**Release**            4.1

**Options**            NA

**Note**              NA

**Example**            To display the contents of the current start-up configuration file, use the command:

```
awplus# show startup-config
<?xml version="1.0"?>
<DslCpeConfig version="3.0">
  <InternetGatewayDevice>
    <LANDeviceNumberOfEntries>1</LANDeviceNumberOfEntries>
    <WANDeviceNumberOfEntries>1</WANDeviceNumberOfEntries>
    <DeviceInfo>
      <FirstUseDate>0001-01-01T00:00:00Z</FirstUseDate>
      <VendorConfigFile nextInstance="4" ></VendorConfigFile>
    </DeviceInfo>
    <Layer2Bridging>
      <BridgeNumberOfEntries>1</BridgeNumberOfEntries>
      <FilterNumberOfEntries>6</FilterNumberOfEntries>
      <MarkingNumberOfEntries>0</MarkingNumberOfEntries>
      <AvailableInterfaceNumberOfEntries>6</AvailableInterfaceNumberOfEntries>
      <Bridge instance="1">
        <BridgeKey>1</BridgeKey>
        <BridgeEnable>TRUE</BridgeEnable>
        <BridgeName>Default</BridgeName>
        <VLANID>1</VLANID>
      </Bridge>
      <Bridge nextInstance="2" ></Bridge>
      <Filter instance="1">
        <FilterKey>1</FilterKey>
      </Filter>
    </Layer2Bridging>
  </InternetGatewayDevice>
</DslCpeConfig>
--More-- (6% of 13326 bytes)
```



**SHOW VERSION**

**Syntax**            `show version [abbreviated]`

**Description**      This command displays the version number and copyright details of the current application build (name, date and type) with the indication of AlliedWare Plus CLI, VoIP and Uboot version, your device is running, and an extended list of all copyrights of application tools used.

For information on output options, see Controlling Command Output.

**Feature**            File Management Commands

**Mode**              User Exec and Privileged Exec Mode

**Release**           4.2

**Options**           NA

**Note**              CLI and UBoot version information is added in 4.2

**Example**           To display the version details of your currently installed software, use the command:

```
awplus # show version
```

```
AT-IMG1400 4.3 GM 11/04/13 14:05
```

```
Application Build name : AT-IMG1400-4.3
```

```
Application Build date : 14:05 11/04/13
```

```
Application Build type : GM
```

```
802.11 radio version   : 0.9.17.1/v1.0
```

```
VoIP version           : AtiVoip-2.3_37
```

```
CLI version            : AtiAwpCli-1.3_93
```

```
Uboot version          : AtiUboot-1.0_23
```

```
Uboot build date       : Sep 26 2012 10:42:19
```

```
Uboot script version   : 1.0.8
```

```
CFE version            : 1.0.38 for BCM96828 (32bit,SP,BE)
```

```
CFE build date         : Wed Sep 26 10:42:31 EDT 2012
```

```
Copyright (c) 2001-2013 Allied Telesis Holdings K. K. - all rights reserved.
```

```
Copyright (c) 2001-2011 Broadcom Corporation.
```

```
=====
The following portions of this product are covered by the GNU GPLv2,
```

```
Source code may be downloaded from:
```

```
http://www.alliedtelesis.co.nz/support/gpl/awp.html
```

```
The license text can be found at:
```

```
http://www.gnu.org/licenses/gpl-2.0.html
```

```
...
```

**Example**           To display the abbreviated listing, use the command:

```
awplus# show version abbreviated
```

```
AT-IMG1400 4.3 GM 11/04/13 14:05

Application Build name : AT-IMG1400-4.3
Application Build date : 14:05 11/04/13
Application Build type : GM

802.11 radio version   : 0.9.17.1/v1.0

VoIP version           : AtiVoip-2.3_37
CLI version            : AtiAwpCli-1.3_93

Uboot version          : AtiUboot-1.0_23
Uboot build date       : Sep 26 2012 10:42:19
Uboot script version   : 1.0.8

CFE version            : 1.0.38 for BCM96828 (32bit,SP,BE)
CFE build date         : Wed Sep 26 10:42:31 EDT 2012
awplus#
```

---

## 2.8 System Configuration and Monitoring Commands

## 2.8.1 System Configuration and Monitoring Commands

This chapter provides an alphabetical reference of commands for configuring and monitoring the system.

Table 2-12: System Configuration and Monitoring Commands

Commands
<a href="#">clock set</a>
<a href="#">clock summer-time</a>
<a href="#">clock timezone</a>
<a href="#">hostname</a>
<a href="#">psu-management</a>
<a href="#">show clock</a>
<a href="#">show cpu</a>
<a href="#">show memory shared</a>
<a href="#">show system</a>
<a href="#">show system pluggable</a>
<a href="#">show system psu</a>
<a href="#">show tech-support</a>
<a href="#">terminal monitor</a>

## CLOCK SET

**Syntax** `clock set <hh:mm> <day> <month> <year>`

**Description** This command sets the time and date for the system clock.

Configure the timezone before setting the local time. Otherwise, when you change the timezone, the device applies the new offset to the local time. Note that in 4.1 seconds is always set at 00.

**Feature** System Configuration and Monitoring Commands

**Mode** Global Configuration Mode

**Release** 4.1

**Options**

Option	Description	Range	Default Value
<hh:mm>	Local time in 24-hour format	NA	NA
<day>	Day of the current month <1-31>	NA	NA
<month>	The first three letters of the current month. The first letter must be capitalized.	NA	NA
<year>	Current year <2000-2035>	NA	NA

**Note** If Network Time Protocol (NTP) is enabled, then you cannot change the time or date using this command. NTP maintains the clock automatically using an external time source. If you wish to manually alter the time or date, you must first disable NTP.

**Example** To set the time and date on your system to 2pm on the 3rd of November 2011, use the command:

```
awplus(config)# clock set 14:00 03 Nov 2011
```

## CLOCK SUMMER-TIME

**Syntax**            `clock summer-time`  
                  `no clock summer-time`

**Description**        This command enables the management of the daylight saving time. Once this command has been typed, the summertime will start and stop automatically, depending on the time zone set via [clock timezone](#) (see next pages). The no variant of this command disables the summertime management and returns to the default.

By default, the device has summertime management disabled.

**Feature**            System Configuration and Monitoring Commands

**Mode**              Global Configuration Mode

**Release**           4.1

**Options**           NA

**Note**              NA

**Example**           To start summertime management, use the command:

```
awplus(config)# clock summer-time
```

**Example**           To stop summertime management, use the command:

```
awplus(config)# no clock summer-time
```

**CLOCK TIMEZONE**

**Syntax**      `clock timezone <timezone-name>`  
                  `no clock timezone`

**Description**      This command defines the device's clock timezone. The timezone is set as an offset to the UTC.

The no variant of this command resets the time zone to UTC (+00:00).

By default, the system time is set to UTC.

Configure the timezone before setting the local time. Otherwise, when you change the timezone, the device applies the new offset to the local time.

If summertime management is enabled, the summertime will follow the rules applied in the time zone set, without the need to specify them.

In the table below, the available time zones are listed. Note that 'Abbreviation' corresponds to the parameter <timezone-name>. The offset is not needed since the abbreviation has the built-in Offset value.

Table 2-13: Time Zones Available

Abbreviation	Name	UTC Offset
AFT	Afghanistan Time	+04:30
AKST	Alaska Standard Time	-09:00
AMT	Armenia Time	+04:00
ART	Argentina Time	-03:00
AST	Atlantic Standard Time	-04:00
AST-Arabia	AST-Arabia	+03:00
AZOT	Azores Time	-01:00
BOT	Bolivia Time	-04:00
BRT	Brasilia Time	-03:00
BST	Bangladesh Standard Time	+06:00
CAT	Central Africa Time	+02:00
CDT	Central Daylight Time	-06:00
CEST	Central European Summer Time	+02:00
CET	Central European Time	+01:00
CLT	Chile Standard Time	-04:00
COT	Colombia Time	-05:00
CST-Australia	Australia Central Standard Time	+09:30
CST-China	China Standard Time	+08:00
CST-USA	USA Central Standard Time	-06:00

Table 2-13: Time Zones Available

Abbreviation	Name	UTC Offset
CVT	Cape Verde Time	-01:00
EEST	Eastern European Summer Time	+03:00
EET	Eastern European Time	+02:00
EST-Australia	Australia Eastern Standard Time	+10:00
EST-USA	USA Eastern Standard Time	-05:00
FJT	Fiji Time	+12:00
GMT	Greenwich Mean Time	+00:00
GST	Gulf Standard Time	+04:00
HAST	Hawaii-Aleutian Standard Time	-10:00
IRST	Iran Standard Time	+03:30
IST-India	India Standard Time	+05:30
IST-Israel	Israel Standard Time	+02:00
JST	Japan Standard Time	+09:00
KRAT	Krasnoyarsk Time	+07:00
KST	Korea Standard Time	+09:00
MAGT	Magadan Time	+11:00
MDT	Mountain Daylight Time	-07:00
MMT	Myanmar Time	+06:30
MSK	Moscow Standard Time	+03:00
MST	Mountain Standard Time	-07:00
MTZ	Mountain Time Zone	-07:00
NOVT	Novosibirsk Time	+06:00
NPT	Nepal Time	+05:45
NST	Newfoundland Standard Time	-03:30
NZST	New Zealand Standard Time	+12:00
O	Oscar Time Zone	-02:00
PGT	Papua New Guinea Time	+10:00
PST	Pacific Standard Time	-08:00
SBT	Solomon Islands Time	+11:00
SGT	Singapore Time	+08:00
ULAT	Ulaanbaatar Time	+08:00

Table 2-13: Time Zones Available

Abbreviation	Name	UTC Offset
UTC	Universal Time Clock	+00:00
UZT	Uzbekistan Time	+05:00
VLAT	Vladivostok Time	+10:00
WAT	West Africa Time	+01:00
WET	Western European Time	+00:00
WGT	West Greenland Time	-03:00
WIB	Western Indonesian Time	+07:00
WST-Australia	Australia Western Standard Time	+08:00
WST-Samoa	West Samoa Time	-11:00
Y	International Date Line West	-12:00
YAKT	Yakutsk Time	+09:00
YEKT	Yekaterinburg Time	+05:00

**Feature** System Configuration and Monitoring Commands

**Mode** Global Configuration Mode

**Release** 4.2

**Options**

Option	Description	Default Value	Default Value
<timezone-name>	The abbreviation of the timezone, up to 6 characters long.	NA	NA

**Note** NA

**Example** To set the timezone to New Zealand Standard Time, use the command:

```
awplus(config)# clock timezone NZST
```

**Example** To set the time zone to Eastern Standard Time in the USA, use the command:

```
awplus(config)# clock timezone EST-USA
```



## HOSTNAME

**Syntax**           hostname <hostname>  
                  no hostname

**Description**       This command sets the name applied to the device as shown at the prompt. The hostname is:

- displayed in the output of the [show system](#) command
- displayed in the CLI prompt so you know which device you are configuring
- stored in the MIB object sysName

Use the no variant of this command to reset the hostname to the default value (awplus).

The prompt has a fixed maximum length. If the hostname is too long to be fully displayed within the prompt it will be truncated and have ".." appended to indicate this. The CLI submode will always be displayed in full - so the degree of truncation of the hostname will vary between submodes. Refer to the example below.

To specify or modify the host name, use the hostname global configuration command. The host name is used in prompts and default configuration filenames.

The name must also follow the rules for ARPANET host names. The name must start with a letter, end with a letter or digit, and use only letters, digits, and hyphens, and contain no spaces. Refer to RFC 1035.

**Feature**           System Configuration and Monitoring Commands

**Mode**             Global Configuration Mode

**Release**          4.1

**Options**

Option	Description	Range	Default Value
<hostname>	Specifies the network name of the system.	NA	awplus.

**Note**             NA

**Example**         To set the system name to HQ-Sales, use the command:

```
awplus(config)# hostname HQ-Sales
HQ-Sales(config)#
```

## PSU-MANAGEMENT

**Syntax**           psu-management  
                  no psu-management

**Description**     The first one enables the PSU Management System, the second one disables it.

**Feature**          System Configuration and Monitoring Commands

**Mode**            User Exec and Privileged Exec Mode

**Release**         4.3.1

**Options**         NA

**Note**            When enabling the PSU management runtime, battery traps are sent so to inform about the battery status, exactly like at startup.

**Example**         To display the PSU Management System use the command:

```
awplus(config)# do show system psu
```

```
System PSU Status
PSU Management System      : running
```

```
Alarm Status:
PSU Battery Missing        : alarm present!
PSU Replace Battery        : alarm present!
PSU Battery Low            : alarm present!
PSU on Battery             : alarm present!
awplus(config)# no psu-management
awplus(config)# do show system psu
```

```
System PSU Status
PSU Management System      : not running
```

```
Alarm Status:
PSU Battery Missing        : alarm present!
PSU Replace Battery        : alarm present!
PSU Battery Low            : alarm present!
PSU on Battery             : alarm present!
awplus(config)# psu-management
awplus(config)# do show system psu
```

```
System PSU Status
PSU Management System      : running
```

```
Alarm Status:
PSU Battery Missing        : alarm present!
PSU Replace Battery        : alarm present!
PSU Battery Low            : alarm present!
PSU on Battery             : alarm present!
awplus(config)#
```

## SHOW CLOCK

**Syntax**            `show clock`

**Description**       This command displays the system's current configured local time and date. It also displays other clock related information such as timezone and summertime configuration.

**Feature**            System Configuration and Monitoring Commands

**Mode**              User Exec and Privileged Exec Mode

**Release**            4.1

**Options**            NA

**Note**               NA

**Example**           To display the system's current local time, use the command:

```
awplus# show clock
Local Time: Mon, 29 Aug 2011 13:56:06 +1200
UTC Time: Mon, 29 Aug 2011 01:56:06 +0000
Timezone: NZST
```

```
Timezone name: Auckland, Wellington
Timezone offset: +12:00
Summer time : disabled
```

Table 2-14: Parameters in the output of the **show clock** command

Parameter	Description
Local Time	Current local time.
UTC Time	Current UTC time.
Timezone	The current configured timezone acronym.
Timezone Name	The current configured timezone name.
Timezone Offset	Number of hours offset to UTC.
Summer time	Specify if daylight saving time is running or not

**SHOW CPU****Syntax** show cpu**Description** This command displays a list of running processes with their CPU utilization.**Feature** System Configuration and Monitoring Commands**Mode** User Exec and Privileged Exec Mode**Release** 4.1**Options** NA**Note** NA**Example** To show the cpu utilization of current processes, sorting them by the number of threads the processes are using, use the command:

```
awplus# show cpu
System load averages:
 1 minute: 0.00, 5 minutes: 0.00, 15 minutes: 0.00
```

user processes

=====

pid	name	thrds	cpu%	pri	state	sleep%	runtime
216	(sh)	1	0.00	15	sleep	N/A	490
324	(swmdk)	3	3.13	15	sleep	N/A	1425839
338	(smd)	1	0.00	15	sleep	N/A	98108
354	(syslogd)	1	0.00	15	sleep	N/A	20
355	(klogd)	1	0.00	15	sleep	N/A	4
356	(dnsproxy)	1	0.00	15	sleep	N/A	2
646	(dhcpc)	1	0.00	15	sleep	N/A	9
670	(cli_bep)	1	0.00	15	sleep	N/A	1103
671	(usbconsole)	1	0.00	15	sleep	N/A	59
9924	(telnetd)	1	0.00	15	sleep	N/A	10
9925	(awp_cli)	1	3.13	15	run	N/A	36

Kernel Threads

=====

pid	name	cpu%	pri	state	sleep%	runtime
1	(init)	0.00	15	sleep	N/A	89
2	(kthreadd)	0.00	10	sleep	N/A	0
3	(sirq-high/0)	0.00	15	sleep	N/A	0
4	(sirq-timer/0)	0.00	15	sleep	N/A	69
5	(sirq-net-tx/0)	0.00	15	sleep	N/A	461
6	(sirq-net-rx/0)	0.00	15	sleep	N/A	1325
7	(sirq-block/0)	0.00	15	sleep	N/A	0
8	(sirq-tasklet/0)	0.00	15	sleep	N/A	2821
9	(sirq-sched/0)	0.00	15	sleep	N/A	0
10	(sirq-hrtimer/0)	0.00	15	sleep	N/A	0
11	(sirq-rcu/0)	0.00	15	sleep	N/A	51
12	(events/0)	0.00	10	sleep	N/A	2
13	(khelper)	0.00	10	sleep	N/A	669
16	(async/mgr)	0.00	10	sleep	N/A	0
68	(kblockd/0)	0.00	10	sleep	N/A	0
77	(khubd)	0.00	10	sleep	N/A	0
108	(pdflush)	0.00	15	sleep	N/A	0
110	(kswapd0)	0.00	25	sleep	N/A	0
112	(crypto/0)	0.00	10	sleep	N/A	0
172	(mtddblockd)	0.00	10	sleep	N/A	264

---

293	(bcmsh)	0.00	15	sleep	N/A	0
294	(bcmsh_timer)	0.00	15	sleep	N/A	0
339	(ssh)	0.00	15	sleep	N/A	2084
653	(snmpd)	0.00	15	sleep	N/A	22
667	(cmfd)	0.00	15	sleep	N/A	12
674	(ati_voice)	0.00	15	sleep	N/A	30
707	(udhcpd)	0.00	15	sleep	N/A	0

**SHOW MEMORY SHARED****Syntax** `show memory shared`**Description** This command displays basic shared memory and heap memory usage statistics present in tech-support**Feature** System Configuration and Monitoring Commands**Mode** User Exec and Privileged Exec Mode**Release** 4.2**Options** NA**Note** NA**Example** To display shared memory allocation used on the switch, use the command:

```
awplus# show memory shared
Total MDM Shared Memory Region : 416KB
Shared Memory Usable           : 000338KB
Shared Memory in-use           : 000077KB
Shared Memory free             : 000260KB
Shared Memory allocs           : 077545
Shared Memory frees            : 076109
Shared Memory alloc/free delta : 001436
```

```
Heap bytes in-use      : 000016
Heap allocs           : 000037
Heap frees            : 000036
Heap alloc/free delta : 000001
```

**Output**Table 2-15: Parameters in the output of the **show cpu** command

Parameter	Description
System load averages	The average number of processes waiting for CPU time for the periods stated.
Current CPU load	Current CPU utilization specified by load types.
CPU averages	Average CPU utilization for the periods stated.
pid	Identifier number of the process.
name	A shortened name for the process
thrds	Number of threads in the process.
cpu%	Percentage of CPU utilization that this process is consuming.
pri	Process priority state.
state	Process state; one of "run", "sleep", "zombie", and "dead".
sleep%	Percentage of time that the process is in the sleep state.

Table 2-15: Parameters in the output of the **show cpu** command (Continued)

Parameter	Description
runtime	The time that the process has been running for, measured in jiffies. A jiffy is the duration of one tick of the system timer interrupt.

**SHOW SYSTEM****Syntax**      `show system`**Description**      This command displays general system information about the device, including the hardware installed, memory, and software versions loaded. It also displays location and contact details when these have been set.**Feature**      System Configuration and Monitoring Commands**Mode**      User Exec and Privileged Exec Mode**Release**      4.1.2**Options**      NA**Note**      NA**Source****Example**      To display the system information, use the command:

```
awplus# show system
Switch System Status                               Sun Jan 25 01:43:32 1970
Board      ID   Bay   Board Name                      Rev      Serial Number
-----
Base                               iMG2504                          X1       ATNLAB0000001
-----
Memory: DRAM:  123680 kB  Used: 57652 kB  Available: 66028 kB
-----
Environmental Status : Normal
Uptime               : 24 days 01:43:32
Bootloader version   : AtiUboot-1.0_07
VoIP version         : AtiVoip-2.0_110

Current Software     : AT-iMG2500-4.1
Software version     : AtiBcm-4.1 GM
Build date           : 22:33 03/08/11

Current boot config  : unnamed.cfg (file exists)
Territory            :

System Name          :
System Contact       :
System Location      :
awplus#
```



## SHOW SYSTEM PLUGGABLE

**Syntax**      show system pluggable [diagnostics]

<b>Description</b>	This command displays information about the pluggable transceivers, such as SFPs, which are currently installed in your switch.
--------------------	---

Feature	System Configuration and Monitoring Commands
---------	--

<i>Mode</i>	User Exec and Privileged Exec Mode
-------------	------------------------------------

Release 4.2

## Options

Option	Description	Range	Default Value
diagnostics	Shows digital diagnostic information retrieved from the SFP EEPROM. Only SFP modules that implement "internal" calibration show this output.	NA	NA

<i>Note</i>	NA
-------------	----

*Source*

**Example** To display the system information on the power, use the command:

```
awplus# show system pluggable
Port1.0.6
=====
Vendor Name:                ATI
Device Name:                AT-SPBD10-13
Device Type:               BASE-BX10
Serial Number:             A03243R124300045
Manufacturing Datecode:    12102501      <<<<<<<<<<<
SFP Laser Wavelength:     1310nm
Link Length Supported
   Single Mode Fiber :      10Km
   OM1 (62.5um) Fiber:    -
   OM2 (50um) Fiber  :    -
Diagnostic Calibration:    -
```

**SHOW SYSTEM PSU**

**Syntax**            `show system psu`

**Description**      This command displays general system information about the power system and if any alarms are present.

**Feature**            System Configuration and Monitoring Commands

**Mode**              User Exec and Privileged Exec Mode

**Release**            4.1.2

**Options**            NA

**Note**               NA

**Source**

**Example**            To display the system information for power, use the command:

```
awplus# show system psu
```

```
PSU Management System      : running
```

```
Alarm Status:
```

```
PSU Battery Missing        : alarm present!
```

```
PSU Replace Battery        : alarm present!
```

```
PSU Battery Low            : alarm present!
```

```
PSU on Battery              : alarm present!
```

```
awplus#
```

## SHOW TECH-SUPPORT

**Syntax** `show tech-support [all]`

**Description** This command generates system and debugging information for the switch and saves it to a file.

The command generates a large amount of output and the output is saved into a file. The output file name is written once the command has been completed. The name is 'tech-support-' followed by date and time; the extension is .txt (an example could be: tech-support-00700001-000037.txt).

If all is specified the command captures the full list of information of the device.

The show tech-support command is useful for collecting a large amount of information about your switch for troubleshooting purposes. The output of this command can be provided to technical support representatives when reporting a problem.

The output of the command 'show tech-support' includes all these sections. Each one is the output of the command having the same name, unless specified differently below (in this case the Example shows the output):

- show clock (just the current date and time)
- show system
- show version abbreviated
- show boot
- show security-password
- dir
- show system psu
- show system pluggable
- show system pluggable diagnostics
- show hpna stations
- show test
- show vlan
- etc.

The output of the command 'show tech-support all' includes the same sections plus few additional ones.

### Options

Option	Description	Range	Default Value
all	Output full troubleshooting information for all protocols and the device	NA	NA

**Feature** System Configuration and Monitoring Commands

**Mode** Privileged Exec Mode

**Release** 4.2

**Note** In 4.2, the output has been expanded to include additional show commands, including those for IPv6.

**Example** To capture the basic set of show output for the technical support, use the command:

```
awplus# show tech-support
```

Generating output ....

Generated output to tech-support-20130520-095529.txt <<<<

```
awplus# show file tech-support-20130520-095529.txt
```

```
.....SHOW_TECH_SUPPORT
```

```
=====
```

```
.....System-Level-Information
```

```
-----clock-----
```

```
....
```

**TERMINAL MONITOR**

**Syntax**            terminal monitor  
                     terminal no monitor

**Description**      This command displays debugging output on a terminal. Note that logs continue to be sent to the syslog system; this allows the user to view the logs as they are produced.

To display the cursor after a line of debugging output, press the Enter key.

Use the command terminal no monitor to stop displaying debugging output on the terminal, or use the timeout option to stop displaying debugging output on the terminal after a set time.

By default displaying debug out is disabled.

**Feature**            System Configuration and Monitoring Commands

**Mode**                Privileged Exec Mode

**Release**            4.1

**Options**            NA

**Note**                NA

**Example**            To display debugging output on a terminal, enter the command:

```
awplus# terminal no monitor
```

```
awplus# Aug  7 15:09:59 (none) user.info awp_cli: User manager executed "end". Returned
CPARSER_OK.
Aug  7 15:10:08 (none) user.notice syslog: Got a new message  66
Aug  7 15:10:08 (none) user.notice syslog: IGMP Pkt Rcvd from src 0xc0a8640c and dst 0xe-
002023f with
Aug  7 15:10:08 (none) user.notice syslog: mcpd_group_rep_update_switch_ati:282: echo
"L:mmac add 0 2
Aug  7 15:10:13 (none) user.notice syslog: Got a new message  66
Aug  7 15:10:13 (none) user.notice syslog: IGMP Pkt Rcvd from src 0xc0a8640c and dst 0xe-
10a0a0a with
Aug  7 15:10:13 (none) user.notice syslog: mcpd_group_rep_update_switch_ati:282: echo
"L:mmac add 0 2
Aug  7 15:10:24 (none) user.notice syslog: Got a new message  66
Aug  7 15:10:24 (none) user.notice syslog: IGMP Pkt Rcvd from src 0xac2005fe and dst
0xe0000001 with
Aug  7 15:10:24 (none) user.notice syslog: MCPD_IGMP_MEMBERSHIP_QUERY  75
Aug  7 15:10:25 (none) user.notice syslog: Got a new message  66
Aug  7 15:10:25 (none) user.notice syslog: IGMP Pkt Rcvd from src 0xc0a8640c and dst 0xe-
10a0a0a with
Aug  7 15:10:26 (none) user.notice syslog: mcpd_group_rep_update_switch_ati:282: echo
"L:mmac add 0 2
```

**Example**            To stop displaying debugging output on the terminal, use the command:

```
awplus# terminal no monitor
```

## 2.9 Software Update

### 2.9.1 Introduction

The iMG supports several different means of software update:

- The CLI copy command may be used to download a specific software image from a remote tftp server using a tftp://<path/filename> URI. See section [How to Upgrade the Firmware](#).
- The TR-69 Download method may be invoked by an ACS to force the iMG to download a specific software image. Refer to your ACS documentation.
- The iMG can be configured to check a remote tftp server for updated software and/or configuration files whenever a DHCP lease is obtained or renewed.
- The CLI swupdate command can be used to check a remote ftp server for updated software and/or configuration files.

This section describes the swupdate command. This command allows the user to configure & initiate the downloading of updated software and/or configurations from a remote ftp server by means of a list file containing file names & corresponding MD5 checksums.

When the `swupdate now` command is invoked, the iMG attempts to download a file named MD5SUM from the ftp server. The contents of this file is then used to determine which (if any) software and/or configuration files available on the ftp server are not already present on the iMG, and then those files not already present are downloaded.

### 2.9.2 Software Update Command List

Table 2-16: Software Update Commands

Commands
<code>show swupdate</code>
<code>swupdate</code>
<code>swupdate now</code>

## SHOW SWUPDATE

<i>Syntax</i>	show swupdate
<i>Description</i>	This command shows the configuration of the iMG swupdate client
<i>Feature</i>	Update Commands
<i>Mode</i>	Privileged Exec Mode
<i>Release</i>	4.1
<i>Options</i>	NA
<i>Note</i>	NA

*Example* See the example output below:

```
awplus# show swupdate
-----
Software Update Configuration
-----
FTP server name/address      : beethoven.atg.lc
FTP Server path              : decomposing/composer
FTP server username          : manager
FTP server password          : friend
```

**SWUPDATE**

**Syntax**      `swupdate {password <password> | username <username> | server {<ipaddress> | <domain>} | server-path <pathname>}`  
                  `no swupdate {password | username | server | server-path}`

**Description**      This command configures the iMG software update client.  
                  Use the no variant of this command to remove configured options.

**Feature**          Update Commands

**Mode**            Global Configuration Mode

**Release**        4.1

**Options**

Option	Description	Default Value	Default Value
<password>	A string of up to 64 characters. May not include white-space.	NA	manager
<username>	A string of up to 64 characters. May not include white-space.	NA	friend
<ipaddress>	A valid dotted-numeric IPv4 address	NA	NA
<domain>	A valid IP domain name	NA	NA
<pathname>	A string of up to 64 characters. May not include white-space and must contain valid path-name syntax for the remote ftp server.	NA	NA

**Note**            NA

**Example**        To configure the iMG software update client, use the commands:

```
awplus(config)# swupdate server aladdins-cave.com
awplus(config)# swupdate server-path jewellery_box
awplus(config)# swupdate password open_sesame
awplus(config)# swupdate username treasure_trove
```



**SWUPDATE NOW**

**Syntax**            `swupdate now [noreboot]`

**Description**      This command invokes the swupdate client which will attempt to download software and configurations not already present on the iMG.

**Feature**            Update Commands

**Mode**                Privileged Exec & Global Configuration

**Release**            4.1

**Options**

Option	Description	Range	Default Value
noreboot	Prevents the iMG from automatically rebooting if one or more files have been downloaded.	NA	NA

**Note**

- If the swupdate now command downloads a configuration file named 'bootstrap.cfg', this file will be set as the startup-config (i.e. it will be the configuration loaded when the iMG is restarted).
- If the swupdate now command downloads one or more files - on completion of the download the iMG will by default reboot. You can use the swupdate now noreboot variant to prevent this automatic reboot. If no new software or configurations are downloaded no reboot will occur.
- The swupdate client will download a maximum of one software image per-invocation (this constraint does not apply to configuration files). If you wish to upgrade both image partitions you should invoke the swupdate now command twice (allowing the iMG to reboot between invocations).
- If a voice call is in progress and this command is entered, the device performs the upgrade but not the restart until the call is taken down.

**Example**            To download the software and prevent the automatic reboot, use the following commands:

```
awplus(config)# swupdate now noreboot
Downloading MD5SUM
Downloading AT-iMG2500-4.1.1_04
Downloading test_config.cfg
Starting image flash write of AT-iMG2500-4.1.1_04. This may take several minutes - please
be patient
Starting flash write of user configuration files
awplus(config)#
```

## 2.10 Debugging and Logging

### 2.10.1 Introduction

The AT iMG software has a comprehensive debugging and logging facility in various subsystems and components. This chapter describes how to start/stop debugging and logging.

**Warning:** At the Privileged Exec Mode, the User can enter a proprietary debug level via the “debug” command – and gain access to a lower level command set. Only use this command when instructed to do so by Allied Telesis personnel.

## 2.10.2 Debugging

Many subsystems have debug commands. Debug commands, used with parameters, log subsystem-specific information at a specific severity level.

The system is always writing logs at the error severity level for all subsystems, and is the default log stream. On using a debug command, another stream is added to this default log stream, and this stream continues to generate output until the no parameter is used with the command.

**Note:** Log generation is always on, and by default all logs are error.

**Note:** It is possible to change some logs to notice or debug; no debug all restores all to the default level of error.

**Note:** With voice logs, specific subsystems are enabled individually, while the overall log level is controlled as above. Prior to setting the voip log level to debug or notice, it is recommended to disable all voip subsystems, and then enable the specific underlying one that you want --- i.e.

```
no debug voip
```

```
debug voip category aep
```

**Note:** To specify where logging output is sent, use the log commands, explained below.

To turn on debugging for a subsystem at a specified severity level, use the command `debug`. For example;

```
awplus(config)# debug igmp level notice
```

The subsystems that are available are:

- access                      Intrusion attempt of a not permitted host
- all                          All applications
- atmf                        Enable logging for Allied Telesis Management Framework (ATMF)
- hpna                        Home Phoneline Networking Alliance (HPNA)
- httpd                      Hypertext Transfer Protocol (HTTP)
- igmp                        Internet Group Management Protocol (IGMP)
- looproot                   Loop-protection
- pppoe                      Point-to-Point Protocol over Ethernet (PPPoE)
- snmpd                      Simple Network Management Protocol (SNMP)
- sshd                        Secure Shell Server
- swupdate                   Software Update Application
- telnetd                    Terminal Emulation Server
- tr69                        Broadband Forum TR-69 Remote Management Protocol (TR-69)
- upnp                        Enable logging for Universal Plug and Play (UPnP)
- voip                        Voice over IP (VOIP)

Also included is access, for attempted intrusions. This is not specifically a subsystem but deals with security.

The severity **levels** in order are as follows. (The error set is the smallest, with notice including error and debug including notice.)

- error
- notifications (notice)
- debugging (debug)

To turn off debugging, use the `no debug` command. When a subsystem is specified with the `no debug` command, debugging is stopped for the specified subsystem. To stop all debugging except for the default stream, use the `all` parameter.

```
awplus(config)# no debug all
```

### 2.10.3 Logging

The log messages as they are processed can be sent to a log server or to the terminal. (In a future release, the log messages can be sent to a host based on the subsystem and severity level.)

The following types of logging output are available:

- terminal
- host

**Note:** Terminal log and console log cannot be set at the same time. If console logging is enabled then the terminal logging is turned off.

The buffered log is a file stored in persistent memory on the device. Because it is stored in RAM its content will survive (or **persist**) a restart, but will **not** survive a power cycle of the device. A device can only have one instance of the buffered log. The buffered log is enabled by default and has a filter to include messages with a severity level of 'notifications' and above.

#### 2.10.3.1 Example - Creating a Log Stream that includes igmp and is displayed at the terminal monitor

1. Turn on the debug options by using the relevant debug command at the config level.

```
awplus(config)# debug igmp level debug
```

2. Run the terminal monitor command to send output to the terminal

```
awplus# terminal monitor
```

This is a sample output of the debug igmp events command displayed on the terminal:

```
awplus#terminal monitor
Dec  2 16:41:49 localhost IGMP[6518]: IGMP: IGMP message sent to 10.10.23.60/32 via interface
vlan2
Dec  2 16:41:57 localhost IGMP[6518]: IGMP: Received an IGMP message of type IGMP Reservation
from 192.168.0.60 via interface vlan2
Dec  2 16:41:57 localhost IGMP[6518]: IGMP: Received a IGMP message from 10.10.23.60/32
```

#### 2.10.3.2 Logging of Executed Commands (Info level)

To track command input, each executed command is logged as an Info level log (although they are not true Info level logs), and includes the user-id of the user who executed the command. Also included is the command's status value (whether the command succeeded).

**Note:** These executed commands are always created, and are not affected by the log level.

An example of this log is as follows;

```
Jan  1 00:00:45 (none) user.info awp_cli: User manager executed "enable".
Returned CPARSER_OK. 100
Jan  1 00:00:52 (none) user.info awp_cli: User manager executed "terminal
monitor ". Returned CPARSER_OK. 111
```

For reboots, the log shows that the reboot was caused by a command, but not the user-id.

**Note:** For reboots the log can show the source of the reboot, which may not be with a command. Sources can be:

- CLI command

- WEB command
- TR69 command
- SWUPDATE command
- Voice command

### 2.10.3.3 Duplicate Logs Suppressed

When a duplicate log is produced, it is suppressed and counted until a different message is received. When there is a new message, "Previous message duplicated x times" is printed. Following is an example:

```
Dec 1 11:04:33 (none) user.info awp_cli: User manager executed "hostname
pippol". Returned CPARSER_OK. 109
Dec 1 11:04:39 (none) user.info Previous message duplicated 3 times 74
```

**Note:** Timestamps are ignored in the string comparison. Also, the last digit is the length of the log message and is not part of the log.

### 2.10.3.4 Logging of voip Subsystem

For the voip subsystem, there are several categories (mgcp, aep, etc.). By default, all the voip logs are enabled at the error level. To control the voip logging, the user should disable all voip logs and enable them selectively at the appropriate level. Refer to [Voice Service Logging](#).

### 2.10.3.5 Host log

A host log sends log messages to a remote syslog server. A device may have many syslog hosts configured. To configure or remove a host use the commands:

```
log host <ip_address>
no log host
```

where <ip-addr> is the IP address of the remote syslog server.

It is not possible to view the log messages sent to this type of output as they are not retained on the device. They must be viewed on the remote device. The other host log commands are:

```
show log config
```

which shows what is on the syslog server.

---

## 2.11 Debugging and Logging Commands

### 2.11.1 Debugging and Logging Commands

This chapter provides an alphabetical reference of commands for debugging and logging.

Table 2-17: Logging Commands

Commands
<code>clear log</code>
<code>debug</code>
<code>log host</code>
<code>show log</code>
<code>show log config</code>

**CLEAR LOG**

**Syntax**            `clear log`

**Description**      This command removes the contents of the logs that are persistent memory.

**Feature**            Logging Commands

**Mode**                Privileged Exec Mode

**Release**            4.1.2

**Options**            NA

**Note**                This command clears all logs: in the iMG there is no concept of buffered versus permanent logs (and therefore no separate commands to delete the two types).

**Example**            To delete the contents of the logs, input:

```
awplus# clear log
```

**DEBUG**

**Syntax** `debug <subsystem> level <error-level>`

**Description** This command defines a stream of error logs in addition to the default stream.

**Feature** Logging Commands

**Mode** Configuration Mode

**Release** 4.1

**Options**

Option	Description	Range	Default Value
subsystem	The subsystem that will have logs created. Refer to <a href="#">Debugging</a> for the subsystems supported.	NA	NA
error-level	The level of log. Levels are: <ul style="list-style-type: none"><li>- debug (includes notice and error)</li><li>- notice (includes error)</li><li>- error</li></ul>	NA	NA

**Note** NA

**Example** To define a subsystem and severity level, input:

```
awplus (config)# debug igmp level error
```

## LOG HOST

**Syntax**            `log host <ip-addr>`  
                     `no log host`

**Description**        This command configures the device to send log messages to a remote syslog server via UDP port 514. The IP address of the remote server must be specified. All logs are sent; there is no filtering. Logging is allowed only to a single syslog server at a time.

**Feature**            Logging Commands

**Mode**              Global Configuration Mode

**Release**            4.1

**Options**

Option	Description	Range	Default Value
<ip-addr>	The IP address of a remote syslog server in dotted decimal format A.B.C.D	NA	NA

**Note**              NA

**Example**            To configure the device to send log messages to a remote syslog server with IP address 10.32.16.99 use the following commands:

```
awplus(config)# log host 10.32.16.99
```

**Example**            To stop the device from sending log messages to the remote syslog server with IP address 10.32.16.99 use the following commands:

```
awplus(config)# no log host
```



**SHOW LOG**

**Syntax** `show log [tail [<10-250>]]`

**Description** This command displays the contents of the buffered log.

By default the entire contents of the buffered log is displayed.

If the optional tail parameter is specified only the latest 10 messages in the buffered log are displayed. A numerical value can be specified after the tail parameter to select how many of the latest messages should be displayed.

**Feature** Logging Commands

**Mode** Privileged Exec Mode and Global Configuration Mode

**Release** 4.1

**Options**

Option	Description	Range	Default Value
tail	Display only the latest log entries	NA	NA
<10-250>	Specify the number of log entries to display	NA	10

**Note** NA

**Example** To display the contents of the buffered log use the command:

```
awplus# show log
content: '0' 147
Jan 1 01:12:20 (none) daemon.debug syslog: snmpd:340.426:read_nvram_param:101:Read file: /
proc/gpio/AtiGpioBatteryLow and cooked content: '0' 148
Jan 1 01:12:20 (none) daemon.debug syslog: snmpd:340.428:read_nvram_param:101:Read file: /
proc/gpio/AtiGpioBatteryMissing and cooked content: '0' 152
Jan 1 01:12:20 (none) daemon.debug syslog: snmpd:340.428:read_nvram_param:101:Read file: /
proc/gpio/AtiGpioBatteryReplace and cooked content: '0' 152
Jan 1 01:12:20 (none) daemon.debug syslog: snmpd:340.428:cmsLck_releaseLock-
Traced:139:lock hold time=2ms, acquiring lock callerFuncName checkBatteryTraps; releasing
lock callerFuncName checkBatteryTraps; 210
Jan 1 01:12:24 (none) daemon.debug syslog: snmpd:344.437:cmsLck_acquireLockWithTimeout-
Traced:94:acquired lock. callerFuncName checkBatteryTraps; timeout 60000 milliseconds 178
Jan 1 01:12:24 (none) daemon.debug syslog: snmpd:344.437:read_nvram_param:101:Read file: /
proc/gpio/AtiGpioBatteryOn and cooked content: '0' 147
Jan 1 01:12:24 (none) daemon.debug syslog: snmpd:344.437:read_nvram_param:101:Read file: /
proc/gpio/AtiGpioBatteryLow and cooked content: '0' 148
Jan 1 01:12:24 (none) daemon.debug syslog: snmpd:344.439:read_nvram_param:101:Read file: /
proc/gpio/AtiGpioBatteryMissing and cooked content: '0' 152
Jan 1 01:12:24 (none) daemon.debug syslog: snmpd:344.439:read_nvram_param:101:Read file: /
proc/gpio/AtiGpioBatteryReplace and cooked content: '0' 152
Jan 1 01:12:24 (none) daemon.debug syslog: snmpd:344.441:cmsLck_releaseLock-
Traced:139:lock hold time=4ms, acquiring lock callerFuncName checkBatteryTraps; releasing
lock callerFuncName checkBatteryTraps; 210
Jan 1 01:12:28 (none) daemon.debug syslog: snmpd:348.450:cmsLck_acquireLockWithTimeout-
Traced:94:acquired lock. callerFuncName checkBatteryTraps; timeout 60000 milliseconds 178
Jan 1 01:12:28 (none) daemon.debug syslog: snmpd:348.450:read_nvram_param:101:Read file: /
proc/gpio/AtiGpioBatteryOn and cooked content: '0' 147
Jan 1 01:12:28 (none) daemon.debug syslog: snmpd:348.450:read_nvram_param:101:Read file: /
proc/gpio/AtiGpioBatteryLow and cooked content: '0' 148
```

```

Jan  1 01:12:28 (none) daemon.debug syslog: snmpd:348.452:read_nvram_param:101:Read file: /
proc/gpio/AtiGpioBatteryMissing and cooked content: '0' 152
Jan  1 01:12:28 (none) daemon.debug syslog: snmpd:348.452:read_nvram_param:101:Read file: /
proc/gpio/AtiGpioBatteryReplace and cooked content: '0' 152
Jan  1 01:12:28 (none) daemon.debug syslog: snmpd:348.454:cmsLck_releaseLock-
Traced:139:lock hold time=4ms, acquiring lock callerFuncName checkBatteryTraps; releasing
lock callerFuncName checkBatteryTraps; 210
Jan  1 01:12:32 (none) daemon.debug syslog: snmpd:352.463:cmsLck_acquireLockWithTimeout-
Traced:94:acquired lock. callerFuncName checkBatteryTraps; timeout 60000 milliseconds--
More-- (1% of 261971 bytes)

```

**Example** To display the most recent contents of the buffered log use the command:

```

awplus# show log tail 15
Jan  1 00:00:25 (none) user.info kernel: Broadcom PLOAM Driver version: v0.8 Aug  3 2011
22:30:50 103
Jan  1 00:00:25 (none) user.warn kernel: dgas: kerSysRegisterDyingGaspHandler: gpon0 reg-
istered 103
Jan  1 00:00:25 (none) user.info kernel: Broadcom OMCI Driver (Aug  3 2011 22:30:53) 90
Jan  1 00:00:25 (none) user.info kernel: Broadcom 802.1Q VLAN Interface, v0.1 83
Jan  1 00:00:25 (none) user.err kernel: usb 2-2: device not accepting address 4, error -62
96
Jan  1 00:00:25 (none) user.info kernel: usb 2-2: new full speed USB device using ohci_hcd
and address 5 110
Jan  1 00:00:25 (none) user.err kernel: usb 2-2: device not accepting address 5, error -62
96
Jan  1 00:00:25 (none) user.err kernel: hub 2-0:1.0: unable to enumerate USB device on port
2 99
Jan  1 00:00:25 (none) user.info kernel: ip_tables: (C) 2000-2006 Netfilter Core Team 91
Jan  1 00:00:25 (none) user.warn kernel: Netfilter messages via NETLINK v0.30. 84
Jan  1 00:00:26 (none) user.warn kernel: nf_conntrack version 0.5.0 (2040 buckets, 8160
max) 98
Jan  1 00:00:30 (none) user.info kernel: monitor task is initialized pid= 339 84
Jan  1 00:00:31 (none) daemon.debug syslog: tr64_main: entry 67
Jan  1 00:00:31 (none) daemon.debug syslog: init_event_queue (queueCount 40) 83
Jan  1 00:00:31 (none) daemon.debug syslog: pTr64Data 48ace0 67

```

**SHOW LOG CONFIG****Syntax**            show log config**Description**      This command displays information about the logging system. This includes the subsystems included and the severity level for the subsystems. By default the error level is included for all subsystems. VoIP has a subset and these are enabled by default.**Feature**            Logging Commands**Mode**              Privileged Exec Mode and Global Configuration Mode**Release**           4.1**Options**           NA**Note**              NA**Example**           To display the logging configuration use the command:

show log config

Permanent Log:

Status ..... Enabled

Filters:

Level ..... debug

Program .....

Level ..... notices

Program .....

Level ..... errors

Program ..... httpd sshd telnetd swupdate snmpd igmp pppoe tr69 access voip hpna

Under Voip subcategory:

The verbosity is: Medium

aep ..... Enabled

ca ..... Enabled

config ..... Enabled

drv ..... Enabled

drvtones ..... Enabled

gwa ..... Enabled

mep ..... Enabled

mgcp ..... Enabled

mgcpEvent ..... Enabled

mgcpMsg ..... Enabled

sdp ..... Enabled

sep ..... Enabled

sigcon ..... Enabled

sip ..... Enabled

sipevent ..... Enabled

sipMsg ..... Enabled

vrg ..... Enabled

awplus#

## 2.12 Interfaces

### 2.12.1 PPPoE

The Point-to-Point Protocol (PPP), as defined in RFC 1661, allows data transmission over serial (point-to-point) connections. A common use for PPP is for ISPs to provide dial-up access for their customers to the internet. Authentication is through user id/password.

To control this point-to-point connection, PPP uses a set of symmetric peer-to-peer protocols, including:

- Link Control Protocol (LCP) - This is used to initiate and terminate connections, and allows the peers to negotiate connection options.
- Network Control Protocol (NCP) - This is used after LCP has successfully set up a connection and is used to negotiate network layer information.

The iMG supports PPP over Ethernet (PPPoE) - RFC 2516 defines how PPPoE allows connection of a network of hosts over a layer 2 access device to a remote Access Concentrator. Generally speaking, PPPoE is used to assign IP addresses to clients based on the user authentication as opposed to open connections where static IP addresses or DHCP are used. To provide the point-to-point connection over Ethernet, each PPP session must learn the Ethernet address of the remote peer, as well as establish a unique Session Identifier.


Refer to [PPPoE](#) for more information.

### 2.12.2 HPNA

The AT-iMG2524H model is designed to support HPNA interface v3.1 (12-44 MHz) in Master Mode.

Up to 8 HPNA stations can be managed by the master node on iMG2524H.

The following is a typical application scenario where HPNA is used



**FIGURE 2-6 HPNA Sample Configuration**

From a CLI configuration point of view, HPNA interface is managed as the other WAN/LAN copper/fiber interfaces.

Only one hpna interface exists in the system and it is referred in CLI commands as hpna1.0.1.

HPNA interface supports trunk or access switch modes but does not support rate limiting and qos settings.

Specific test and provisioning commands are available for `hpna l.0.l` interface to list the attached HPNA stations and performance capabilities.

---

## 2.13 Interface Commands

## 2.13.1 Interface Commands

This chapter provides an alphabetical reference of commands used to configure and display interfaces.

Table 2-18: Interface Commands

Commands
<a href="#">interface port</a>
<a href="#">interface catv</a>
<a href="#">interface vlan</a>
<a href="#">show catv</a>
<a href="#">show catv diagnostics</a>
<a href="#">show interface</a>
<a href="#">show interface brief</a>
<a href="#">show interface status</a>
<a href="#">show interface switchport</a>
<a href="#">shutdown (config-if)</a>
<a href="#">shutdown (config-if-catv)</a>

## INTERFACE PORT

**Syntax** `interface <port-list>`

**Description** This command selects one or more physical interfaces to configure.

The port can be a physical interface on the device - such as the Ethernet port - in which case it is possible to configure information specific to the devices - such as flowcontrol, protected mode, rate limiting, etc.

For ports, the interfaces are defined as follows.

Device	Port range	Notes
iMG1500	port1.0.1 to port1.0.6	port1.0.6 is the WAN port
iMG2500	port1.0.1 to port1.0.5 hpnal.0.1	port1.0.5 is the WAN port
iMG1400	port1.0.1, port1.0.2 and ,port1.0.5 are 10/100/1000. port1.0.3 and port1.0.4 are 10/100.	port1.0.6 is the WAN port

**Feature** Interface Commands

**Mode** Global Configuration Mode

**Release** 4.1

**Options**

Option	Description	Range	Default Value
<interface-list>	The interfaces or ports to configure. An interface-list can be: - a switch port or ports, separated by a comma or dash, such as port1.0.1, port1.0.2 and port1.0.1-port1.0.5 - a catv connection. (Refer to catv commands.) The specified interfaces must exist.	ALL	ALL

**Note**

**Example** The following example shows how to enter Interface mode to configure a port interface and the feature options in bold.

```
awplus(config)# interface port1.0.5 (this is the WAN port)
awplus(config-if)# ?
do                               To run exec commands in config mode
duplex                          Set duplex modes on the interface
egress-rate-limit              Limit the amount of traffic egressing the interface
end                               End current mode and down to privileged mode
exit                             End current mode and down to previous mode
flowcontrol                   IEEE 802.3x Flow Control
help                             Description of the interactive help system
ingress-rate-limit            Limit the amount of traffic ingressing the interface
interface                     Select an interface to configure
mirror                        Port mirroring command
```

jumbo-frame	Enable jumbo frame support (1000 Mbps speed only)
<b>mls</b>	Multi-Layer Switch(L2/L3)
no	Negate a command or set its defaults
quit	End current mode and down to previous mode
<b>shutdown</b>	Shutdown the selected interface
<b>speed</b>	Set the link speed of an interface
<b>switchport</b>	Set the switching characteristics of the Layer2 interface



**INTERFACE CATV**

**Syntax**            `interface catv`

**Description**      This command is used to enter the cable tv (catv) interface for the RF iMG models.

**Feature**            Interface Commands

**Mode**              Interface catv Configuration

**Release**            4.2

**Options**            NA

**Note**               NA

**Example**            To enter the catv mode use the commands:

```
awplus(config)# interface catv
awplus(config_if_catv)#
```

**INTERFACE VLAN**

**Syntax** `interface <vlan-list>`

**Description** This command selects one or more vlans to configure.

The vlan list can be one or more vlans in which case it is possible to manipulate information such as the IP Address or the state of the DHCP Client.

**Feature** Interface Commands

**Mode** Global Configuration Mode

**Release** 4.1

**Options**

Option	Description	Range	Default Value
<interface-list>	The interfaces to configure. An interface-list can be: - an interface (e.g. vlan2) - a sub-interface (e.g. vlan2.1)	NA	NA

**Note** NA

**Example** The following example shows how to enter Interface mode to configure vlan1 and the featureoptions in bold.

```
awplus(config)# interface vlan1
awplus(config-if)# ?
access-group   Add an access list to the VLAN access group
do              To run exec commands in config mode
end            End current mode and down to privileged mode
exit          End current mode and down to previous mode
help          Description of the interactive help system
interface      Select an interface to configure
ip            Internet Protocol (IP)
no            Negate a command or set its default
quit         End current mode and down to previous mode

awplus(config-if)# ip ?
address      IP address configuration commands
dhcp         Configure DHCP
igmp         Internet Group Management Protocol (IGMP)
```

**SHOW CATV****Syntax**            show catv**Description**       This command displays catv interface status.**Feature**            Interface Commands**Mode**               Interface catv Configuration**Release**            4.2**Note**               NA**Example**            To display configuration and status information for catv on iMG1525RF use the command

```
awplus# show catv
RF Output:                    Enabled
```

```
awplus# show catv diagnostics
Alarm State:                 Off
```

```
awplus(config)# interface catv
awplus(config-if-catv)# ?
do            To run exec commands in config mode
end           End current mode and down to privileged mode
exit          End current mode and down to previous mode
help          Description of the interactive help system
no            Negate a command or set its defaults
quit          End current mode and down to previous mode
shutdown     Disable cable TV RF interface
```

**Example**            To display configuration and status information for catv on iMG1425RF and iMG1405RF use the command

```
awplus# show catv
RF Output:                    Enabled
Receive Signal:              Not Detected
Vendor Name:                  Optomedia
Device Name:                  OND-5JA1-001
Device Revision:              02
Serial Number:                201S010516
Manufacturing Datecode:      12011900
Transceiver Type:             CATV
RF Bandwidth:                47 - 1000 MHz
RF Receiver Wavelength:      1550 nm
Responsivity:                1.00 mA/mW
Min RF Tx Power:              -
Max Optical Rx Power:        0.00 dBm
Min Optical Rx Power:        -10.00 dBm
```

```
awplus# show catv diagnostics
```

	Status		Alarms		Warnings		
	Reading	Alarm	Max	Min	Warn	Max	Min
Temp: (Degrees C)	60.273	-	80.000	-0.004	-	75.000	-0.004
Vcc: (Volts)	11.666	-	13.196	10.799	-	12.596	11.399
PD Mon: (Volts)	0.014	Low	2.235	0.088	Low	1.775	0.112
RF Mon: (Volts)	0.779	Low	2.047	1.256	Low	1.916	1.387

**SHOW CATV DIAGNOSTICS**

**Syntax**            `show catv diagnostics`

**Description**      This command displays catv interface status.

**Feature**            Interface Commands

**Mode**              Interface catv Configuration

**Release**            4.2

**Note**               NA

**Example**            To display configuration and status information for catv use the command

```
awplus# show catv diagnostics
```

	Status		Alarms			Warnings	
	Reading	Alarm	Max	Min	Warn	Max	Min
Temp: (Degrees C)	-24.996	Low	80.000	-0.004	Low	75.000	-0.004
Vcc: (Volts)	3.374	Low	3.441	3.155	Low	3.393	3.298
PD Mon: (Volts)	1.072	Low	1.191	0.953	Low	1.144	1.001
RF Mon: (Volts)	1.311	Low	1.430	1.191	Low	1.382	1.239

**SHOW INTERFACE**

**Syntax** `show interface [<interface-list>]`

**Description** This command displays interface configuration and status.

**Feature** Interface Commands

**Mode** User Exec and Privileged Exec Mode

**Release** 4.2

**Options**

Option	Description	Range	Default Value
<interface-list>	The interfaces to display information about. An interface list can be a switch port (e.g. port1.0.4)	ALL	ALL

**Note** This command now includes the HPNA port. Refer to the examples.

**Example** To display configuration and status information for interfaces port1.0.1 through port1.0.5, use the command:

```
awplus# show interface port1.0.1-port1.0.5
Interface port1.0.1
  Link is DOWN, administrative state is UP
  Address is 000c.2503.9a14
  Description:
    index 1 mtu N/A
    flowcontrol disabled, configured duplex auto, configured speed auto
    jumbo frame support is disabled
    SNMP link-status traps: Disabled (Suppressed in 0 sec.)
  Bandwidth Unknown
    input packets 0, bytes 0, dropped 0, multicast packets 0
    output packets 0, bytes 0, multicast packets 0 broadcast packets 0
Interface port1.0.2
  Link is DOWN, administrative state is UP
  Address is 000c.2503.9a14
  Description:
    index 2 mtu N/A
    flowcontrol disabled, configured duplex full, configured speed 1000
    jumbo frame support is disabled
    SNMP link-status traps: Disabled (Suppressed in 0 sec.)
  Bandwidth Unknown
    input packets 0, bytes 0, dropped 0, multicast packets 0
    output packets 0, bytes 0, multicast packets 0 broadcast packets 0
Interface port1.0.3
  Link is DOWN, administrative state is UP
  Address is 000c.2503.9a14
  Description:
    index 3 mtu N/A
    flowcontrol disabled, configured duplex auto, configured speed auto
    jumbo frame support is disabled
    SNMP link-status traps: Disabled (Suppressed in 0 sec.)
  Bandwidth Unknown
    input packets 0, bytes 0, dropped 0, multicast packets 0
    output packets 0, bytes 0, multicast packets 0 broadcast packets 0
Interface port1.0.4
```

```
Link is DOWN, administrative state is UP
Address is 000c.2503.9a14
Description:
index 4 mtu N/A
flowcontrol disabled, configured duplex auto, configured speed auto
jumbo frame support is disabled
SNMP link-status traps: Disabled (Suppressed in 0 sec.)
Bandwidth Unknown
  input packets 0, bytes 0, dropped 0, multicast packets 0
  output packets 0, bytes 0, multicast packets 0 broadcast packets 0
Interface port1.0.5
Link is UP, administrative state is UP
Address is 000c.2503.9a14
Description:
index 5 mtu N/A
current duplex full, current speed 1000, polarity N/A, flowcontrol both
jumbo frame support is disabled
configured duplex auto, configured speed auto
SNMP link-status traps: Disabled (Suppressed in 0 sec.)
Bandwidth Unknown
  input packets 54153, bytes 3969372, dropped 0, multicast packets 2091
  output packets 3170, bytes 385951, multicast packets 0 broadcast packets 311
```

**Example** To view the attributes for the HPNA port, input the following commands:

```
awplus# show interface hpna1.0.1

Interface hpna1.0.1
Link is UP, administrative state is UP
Address is 000c.2503.9a57
Description:
index 31 mtu N/A
current duplex N/A, current speed N/A, polarity N/A, flowcontrol both
configured duplex auto, configured speed auto
jumbo frame support is disabled
Protected switching mode is disabled
SNMP link-status traps: Disabled (Suppressed in 0 sec.)
Bandwidth Unknown
  input packets 5415, bytes 770961, dropped 0, multicast packets 3476
  output packets 288908693, bytes 1313253283, multicast packets 288897392 broadcast packets 9641
```

**Example** To view the attributes for the Wireless interface, input the following commands:

```
awplus# show interface dot11radio1.0.1

Interface dot11radio1.0.1
Link is UP, administrative state is UP
SSID1:
  MAC address is e2:0d:da:0e:8c:00
  IEEE 802.11n SSID:"iMG1405W-192"
  Channel 11 (2.462 Ghz)
  Bit Rate:144.4 Mbit/s
  Rx packets 2034, bytes 176287, errors 0, dropped 0
  Tx packets 1803, bytes 200018, errors 0, dropped 0
SSID2:
  MAC address is f2:0d:da:0e:8c:00
```

```
IEEE 802.11n  SSID:"Guest1-192"  
Channel 11 (2.462 Ghz)  
Bit Rate:144.4 Mbit/s  
Rx packets 0, bytes 0, errors 0, dropped 0  
Tx packets 1089, bytes 102454, errors 0, dropped 0  
SSID3:  
MAC address is 02:0d:da:0e:8c:00  
IEEE 802.11n  SSID:"Guest2-192"  
Channel 11 (2.462 Ghz)  
Bit Rate:144.4 Mbit/s  
Rx packets 4634, bytes 396854, errors 0, dropped 0  
Tx packets 2635127, bytes 2147483647, errors 0, dropped 0  
SSID4:  
MAC address is 12:0d:da:0e:8c:00  
IEEE 802.11n  SSID:"Guest3-192"  
Channel 11 (2.462 Ghz)  
Bit Rate:144.4 Mbit/s  
Rx packets 0, bytes 0, errors 0, dropped 0  
Tx packets 0, bytes 0, errors 0, dropped 0
```

**SHOW INTERFACE BRIEF**

**Syntax**            `show interface brief`

**Description**      This command displays brief interface, configuration, and status information, including provisioning information.

**Feature**            Interface Commands

**Mode**              User Exec and Privileged Exec Mode

**Release**           4.1

**Options**            NA

**Note**               NA

**Example**           Example output from the `show interface brief` command

```
awplus# show interface brief
Interface          Status             Protocol
port1.0.1          admin up           down
port1.0.2          admin up           down
port1.0.3          admin up           down
port1.0.4          admin up           down
port1.0.5          admin up           up
```

Table 2-19: Parameters in the output of the **show interface brief** command

Parameter	Description
Interface	The name or type of interface.
Status	The administrative state. This can be either admin up or admin down
Protocol	The link state. This can be either down, running, or provisioned



**SHOW INTERFACE STATUS**

**Syntax** `show interface [<port-list>] status`

**Description** This command displays the status of the specified interface or interfaces. Note that when no interface or interfaces are specified then the status of all interfaces on the switch are shown.

**Feature** Interface Commands

**Mode** Global Configuration Mode

**Release** 4.1

**Options**

Option	Description	Range	Default Value
<port-list>	The ports to display information about. The port list can be separated by commas for each port or a dash (-) for a range of ports.	NA	NA

**Note** NA

**Example** To display the status of ports 1.0.1 to 1.0.5, use the commands:

```
awplus# show interface port1.0.1-1.0.5 status
```

Port	Name	Status	Vlan	Duplex	Speed	Type
port1.0.1		notconnect	1	auto	auto	1000BASE-T
port1.0.2		notconnect	1	auto	auto	1000BASE-T
port1.0.3		notconnect	1	auto	auto	1000BASE-T
port1.0.4		notconnect	1	auto	auto	1000BASE-T
port1.0.5		notconnect	1	auto	auto	1000BASE-T

## SHOW INTERFACE SWITCHPORT

**Syntax**            show interface switchport

**Description**       This command displays the interface status of the switchports. This includes the mode (access or trunk) and the VLAN configuration. Refer to Section 2 for more information.

**Feature**            Interface Commands

**Mode**                Global Configuration Mode

**Release**            4.1

**Options**            NA

**Note**                NA

**Example**            To display the status of interface for all switchports, use the command:

```
awplus# show interface switchport
Interface name : port1.0.1
Switchport mode : access
Ingress filter : enable
Acceptable frame types : all
VLAN stacking port mode : customer
Default Vlan : 100
Configured Vlans : 100
```

```
Interface name : port1.0.5
Switchport mode : access
Ingress filter : enable
Acceptable frame types : all
VLAN stacking port mode : customer
Default Vlan : 100
Configured Vlans : 100
```

```
Interface name : port1.0.6
Switchport mode : trunk
Ingress filter : enable
Acceptable frame types : all
VLAN stacking port mode : customer
Default Vlan : 0
Configured Vlans : 202 203 204 205
awplus#
```

## SHUTDOWN (CONFIG-IF)

**Syntax**            shutdown  
                  no shutdown

**Description**        This command shuts down the selected interface. This administratively disables the link and takes the link down at the physical (electrical) layer.

Use the no variant of this command to disable this function and therefore to bring the link back up again.

**Feature**            Interface Commands

**Mode**                Interface Configuration

**Release**            4.2

**Options**            NA

**Note**                The catv interface is added in 4.2

**Example**            The following example shows the use of the shutdown command to shut down port1.0.20.

```
awplus# configure terminal
awplus(config)# interface port1.0.20
awplus(config-if)# shutdown
```

**Example**            The following example shows the use of the no shutdown command to bring up port1.0.12.

```
awplus(config)# interface port1.0.12
awplus(config-if)# no shutdown
```

**Example**            The following example shows the use of the no shutdown command to bring up the catv interface on an iMG 1400.

```
awplus(config)# interface catv
awplus(config-if-catv)# no shutdown
```

## SHUTDOWN (CONFIG-IF-CATV)

**Syntax**            shutdown  
                     no shutdown

**Description**        This command shuts down the selected catv interface.  
  
                     Use the no variant of this command to disable this function and therefore to bring the catv interface into service

**Feature**            Interface Commands

**Mode**                Interface catv Configuration

**Release**            4.1.1

**Options**            NA

**Note**                NA


**Example**            The following example shows the use of the no shutdown command to enable the catv interface.

```
awplus(config)# interface catv
awplus(config-if-catv)# no shutdown
```

## 2.14 Example Configuration

By following this section, the user should be able to start up the iMG and input commands at the various levels. The remaining sections of this document describe how Layer 2 and Layer 3 are configured for the iMG, as well as IGMP, Security, Network Management, and Voice Management.

To help the user work through these sections, the following figure shows the iMG2500 and iMG1500 in an example configuration that has data and video services. When appropriate, this example will be followed throughout the rest of this document for both example configurations and command examples.



**FIGURE 2-7 Example Configuration - iMG2500 and iMG1500**

## 3. Routing

The Layer3 functionality of the iMG includes the following:

- [Introduction](#)
- [Address Resolution Protocol \(ARP\)](#)
- [Domain Name System \(DNS\)](#)
- [Dynamic DNS \(ddns\)](#)
- [Internet Control Message Protocol \(ICMP\)](#)
- [Checking IP Connections \(ping and traceroute\)](#)
- [Layer 3 Routing Command List](#)
- [IPv6](#)
- [IPv6 Command List](#)

---

### 3.1 Introduction

This chapter describes how to configure IPv4 addressing and the protocols used to help IP function on your network.

As well as the familiar Internet, with uppercase "I", the term internet (with lowercase "i") can refer to any network (Local [LAN] or wide area network [WAN]) that uses the Internet protocol. This chapter concentrates on this definition—a generalized network that uses IP as its transport protocol.

#### 3.1.1 Assigning an IP Address

To configure your device to perform IP routing (for example, to access the Internet) you need to configure IP. You also need to configure IP if you want to manage your device from any IP-based management process (such as SSH, Telnet, or SNMP).

Add an IP address to each of the interfaces that you want to process IP traffic.

You can configure an interface on your device with a static IP address, or with a dynamic IP address assigned using your device's DHCP client. Moreover, you can provision subinterfaces, allowing additional addressable entities. Both static and dhcp apply to these interfaces.

#### 3.1.2 Static IP addresses

To add a static IP address to an interface, enter interface mode for the interface that you want to configure, then use the command:

```
awplus(config-if)# ip address <ip-addr/prefix-length>
```

where <ip-address/m> the IP address followed by a slash then the prefix length. Note that you cannot specify the mask in dotted decimal notation in this command.

For example, to give the interface vlan1 an address of 192.168.10.10, with a class C subnet mask, use the command:

```
awplus (config)# interface vlan1
awplus(config-if)# ip address 192.168.10.10/24
```

### 3.1.3 DHCP dynamic addresses

When you use the DHCP client, it obtains the IP address and subnet mask for the interface, and other IP configuration parameters, from a DHCP server. To configure an interface to gain its IP configuration using the DHCP client, use the command:

```
awplus(config-if)# ip address dhcp
```

If an IP interface is configured to get its IP address and subnet mask from DHCP, the interface does not take part in IP routing until the IP address and subnet mask have been set by DHCP.

If you need to make a static entry in your DHCP server for the device, you need your device's MAC address, which you can display by using the command:

```
awplus# show interface
```

---

## 3.2 Address Resolution Protocol (ARP)

Address Resolution Protocol (ARP) is used by your device to dynamically learn the layer 2 address of devices in its networks. Most hosts also have a MAC physical address in addition to the assigned IP address. For Ethernet, this is a 6-byte, globally unique number. ARP enables your device to learn the physical address of the host that has a given IP address.

When your device needs to forward packets to a destination that it does not know the layer 2 address of, it broadcasts an ARP request to determine where to send the packet. The ARP request is a broadcast packet and includes the target IP address. All stations on the LAN receive this broadcast but only one host recognizes its own IP address. It replies, thereby giving your device its physical address.

Your device creates a dynamic ARP entry in its ARP cache, to record the IP address to physical address mapping (also called a binding). It uses that ARP entry to forward further packets to that address.

The ARP protocol is described in RFC 826, An Ethernet Address Resolution Protocol—or—Converting Network Protocol Addresses to 48 bit Ethernet Address for Transmission on Ethernet Hardware.

---

## 3.3 Domain Name System (DNS)

The Domain Name System allows you to access remote systems by entering human-readable device host names rather than IP addresses. DNS works by creating a mapping between a device name, such as “www.alliedtelesis.com”, and its IP address. These mappings are held on DNS servers. The benefits of DNS are that domain names:

- can map to a new IP address if the host's IP address changes
- are easier to remember than an IP address
- allow organizations to use a domain name hierarchy that is independent of any IP address assignment

### 3.3.1 Domain name parts

Domain names are made up of a hierarchy of two or more name segments. Each segment is separated by a period. The format of domain names is the same as the host portion of a URL (Uniform Resource Locator). The first segment from the left is unique to the host, with each following segment mapping the host in the domain name hierarchy. The segment on the far right is a top-level domain name shared by many hosts.

### 3.3.2 Server hierarchy

A network of domain name servers maintains the mappings between domain names and their IP addresses. This network operates in a hierarchy that is similar to the structure of the domain names. When a local DNS server cannot resolve your request it sends the request to a higher level DNS server.

For example, to access the site “alliedtelesis.com”, your PC sends a DNS query to its local DNS server asking for the IP address matching alliedtelesis.com. If this address is already locally cached (following its recent use), the DNS server returns the IP address that matches alliedtelesis.com. If the DNS server does not have this address cached, it forwards the request upwards through the hierarchy of DNS servers until a DNS server can resolve the mapping. This means an often-used domain name is resolved quickly, while an uncommon or nonexistent domain may take longer to resolve or fail.

As well as the hierarchy of domain name servers accessible through the Internet, you can operate your own DNS server to map to private IP addresses within your network.

### 3.3.3 DNS Client

The Allied Telesis Gateway has a DNS Client that is enabled automatically when you add a DNS server to your device. This client allows you to use domain names instead of IP addresses when using commands on your device.

To add a DNS server to the list of servers that the device sends DNS queries to, use the command:

```
awplus(config)# ip name-server (IPv4)
```

To check the list of servers that the device sends DNS queries to, use the command:

```
awplus# show ip name-server (ipv4)
```

To add a default domain name used to append to DNS requests, use the command:

```
awplus(config)# ip domain-name <domain-name>
```

For example, to use DNS to match hostnames to your internal network “example.net”, use the command:

```
awplus(config)# ip domain-name example.net
```

If you then use the command `ping host2`, your device sends a DNS request for `host2.example.net`. To check the domain name configured with this command, use the command:

```
awplus# show ip domain-name
```

Alternatively you can create a list of domain names that your device will try in turn by using the command:

```
awplus(config)# show ip domain-list <domain-name>
```

For example, to use DNS to match incomplete hostnames to the top level domains “.com”, and “.net”, use the commands:

```
awplus(config)# ip domain-list .com
```

```
awplus(config)# ip domain-list .net
```

If you then use the command `ping alliedtelesis`, your device sends a DNS request for `alliedtelesis.com` and if no match was found your device would then try `alliedtelesis.net`. To check the entries in the domain list, use the command:

```
awplus# show ip domain-list
```

To check the status of the DNS Client on your device, and the configured servers and domain names, use the command:



```
awplus# show hosts
```

### 3.3.4 Dynamic DNS (ddns)

Dynamic DNS (ddns) is a feature that allows remote hosts to connect to your home web server (such as a game server). This feature works with ddns providers (tzo and dyndds), which have the ip address/domain name association. (They are not limited to these two.) Whenever the IP address changes, the iMG informs the provider of this change. The provider then updates their dns servers; the remote hosts have their associations updated and can then access the (same) domain name using the new ip address.

**Note:** The ddns feature can be placed on a subvlan as well. Refer to [Multiple IP Addresses on a Subinterface \(subvlan\)](#).

### 3.3.5 DHCP options

When your device is using its DHCP client for an interface, it can receive the following DHCP options from the DHCP server:

Option 6 - a list of DNS servers. This list appends to the DNS servers set on your device with the `ip name-server` command.

Option 3 - routers

Option 15 - a domain name used to resolve host names. This option replaces the domain name set with the `ip domain-name` command.

Option 43 - ACS-TR-069 - This is for vendor-specific information, and contains the url for remote management.

Option 61 - This is the default client-id and is a combination of mac and vlan.

Refer to [Dynamic Host Configuration Protocol \(DHCP\)](#) for more information.

To configure DHCP client id option with a free form string, use the command:

```
awplus(config-if)# ip dhcp client client-id
```

To configure DHCP client id option with IAID-RFC3315, use the command:

```
awplus(config-if)# ip dhcp client client-id IAID F0F0ABC
```

To configure DHCP client request options, use the command:

```
awplus(config-if)# ip dhcp client request 6
```

## 3.4 Internet Control Message Protocol (ICMP)

The Internet Control Message Protocol (ICMP) allows networking devices to send information and control messages to other devices or hosts. Your device implements all non-obsolete ICMP functions.

The following table lists the ICMP messages implemented by your device.

Table 3-1: ICMP Messages

ICMP Message Type	Device Response
Echo reply (0)	This is used to implement the ping command. Your device sends out an echo reply in response to an echo request.
Destination unreachable (3)	This message is sent when your device drops a packet because it did not have a route to the destination.
Redirect (5)	Your device issues this message to inform a local host that its target is located on the same LAN (no routing is required) or when it detects a host using a non-optimal route (usually because a link has failed or changed its status).  For example, if your device receives a packet destined to its own MAC address, but with a destination IP address of another host in the local subnet, it returns an ICMP redirect to the originating host.  ICMP redirects are disabled on interfaces on which local proxy ARP is enabled.
Echo request (8)	This is related to echo replies. If your device receives an echo request, it sends an echo reply. If you enter the ping command, your device generates echo requests.
Time to Live Exceeded (11)	If the TTL field in a packet falls to zero, your device sends this message. This occurs when there are too many hops in the path that a packet is traversing.

ICMP messages are enabled on all interfaces by default. You can control the flow of ICMP messages across different interfaces using the [Access Control List \(ACL\)](#).

## 3.5 Checking IP Connections (ping and traceroute)

To verify connections between networks and network devices, use the ping (Packet Internet Groper) and trace route functions on your device.

### 3.5.1 Ping

Ping tests the connectivity between two network devices to determine whether each network device can “see” the other device. Echo request packets are sent to the destination addresses and responses are displayed on the console.

If you can ping the end destination, then the physical, Layer 2 and Layer 3 links are functioning, and any difficulties are in the network or higher layers.

If pinging the end destination fails, use traceroute to discover the point of failure in the route to the destination.

To ping a device, use the command [ping \(ipv4\)](#). Note that this command has options for IPv6 (refer to [IPv6](#)).

### 3.5.2 Traceroute

You can use traceroute to discover the route that packets pass between two systems running the IP protocol. Traceroute sends an initial UDP packets with the Time To Live (TTL) field in the IP header set starting at 1. The TTL field is increased by one for every subsequent packet sent until the destination is reached. Each hop along the path between two systems responds with a TTL exceeded packet (ICMP type 11) and from this the path is determined.

To use traceroute, use the command:

```
awplus# traceroute {<hostname>|<ipaddr>}
```

**Note:** This command has options for IPv6 (refer to [traceroute ipv6](#)).

## 3.6 Multiple IP Addresses on a Subinterface (subvlan)

### 3.6.1 Overview

The iMG can be configured in different ways to match the requirements of a service provider (or providers). The different services (voice, data, video, mgmt) usually exist on different subnets and are configured so that there is one VLAN/IP address per service. (This model is used in the configuration example in [Example Configuration](#).)

There is also the case where a provider wishes to have only one vlan interface for all services. To make this possible, the network interface can have one VLAN (such as vlan1), with its associated IP address, and a sub-vlan interface, with each subvlan having its own IP address. These sub-vlan interfaces are named as vlan1.1, vlan1.2, etc. up to vlan1.31.

Refer to the following figure.

Note that for certain services are based on a single interface and so cannot use sub-vlans:

- IGMP
- NAT/Firewall
- Access List




FIGURE 3-1 Example Configuration using sub-vlans

### 3.6.2 Creating a sub-vlan

After creating the sub-vlan, the user inputs the interface command using the sub-vlan, and enters the (config-subif) level. Once at this level, the same types of commands are available as at the interface level. Following is an example sequence.

```
awplus(config-if)# interface vlan1.1 (vlan1 exists, creates additional ip interface)
awplus(config-subif)# ip address dhcp (command is at the config-subif level)
awplus(config-subif)# ip dhcp client request 3
```

### 3.6.3 Features that use subvlans

It is possible to use subinterfaces with the following features:

- IP Address management
- DHCP
- DDNS
- ping
- Route Tables
- TR69
- Voip
- Telnet/SSH/http

The following features do not use subinterfaces (main interface only):

- IGMP
- NAT/Firewall and access lists (are all based on base interface)

The commands include subinterface parameters and outputs when they can be used.

---

## 3.7 Layer 3 Routing - iMG

### 3.7.1 Layer 3 Routing Command List

Following is an alphabetical reference of commands used to configure the following protocols:

- Address Resolution Protocol (ARP)
- Domain Name Service (DNS)

Table 3-2: Routing Commands

Commands
add provider
add url
http
ip address
ip ddns update hostname
ip ddns update method
ip domain-name
ip name-server (IPv4)
ip route
ping (ipv4)
remove provider
remove url
show hosts
show ip ddns
show ip domain-list
show ip domain-name
show ip interface brief
show ip name-server (ipv4)
show ip route
show ip sockets
traceroute

## ADD PROVIDER

**Syntax**            `add provider {tzo | dyndns} username <username> password <password>`

**Description**      This command selects the ddns provider and sets the username and password that is used to access the provider when the ip address for the domain name has been updated.

**Feature**            IP Addressing and Protocol Commands

**Mode**              Interface Configuration for a VLAN interface

**Release**            4.2

**Options**

Option	Description	Range	Default Value
tzo   dyndns	The ddns providers. Refer to <a href="http://www.tzo.com">http://www.tzo.com</a> and <a href="http://dyn.com/dns/">http://dyn.com/dns/</a>	NA	NA
username	User-defined name to access the provider. Refer to the ddns providers for conventions.	NA	NA
password	User-defined password to access the provider. Refer to the ddns providers for conventions.	NA	NA

**Note**                NA

**Example**            To add the ddns provider, use the following commands:

```
awplus# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
awplus(config)# awplus(config)# ip ddns update method tzo-method
awplus(DDNS-update-method)#http
awplus(DDNS-HTTP)# add provider tzo username my_name password my_password
```

**ADD URL**

**Syntax**            add <url>

**Description**       This command adds the url that is created for the ddns service contact.

**Feature**            IP Addressing and Protocol Commands

**Mode**               Interface Configuration for a VLAN interface or a local loopback interface.

**Release**            4.2

**Options**            NA

**Note**               NA

**Example**            To use this command, refer to the example

```
awplus# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Awplus(config)# ip ddns update method tzo_method
Awplus(DDNS-update-method)# http
Awplus(DDNS-HTTP)# add http://myurl.com
```

## HTTP

<i>Syntax</i>	http
<i>Description</i>	This command sets the protocol as http when associating a ddns method with a ddns provider.
<i>Feature</i>	IP Addressing and Protocol Commands
<i>Mode</i>	Interface Configuration for a VLAN interface or a local loopback interface.
<i>Release</i>	4.2
<i>Options</i>	NA
<i>Note</i>	NA

**Example** To use this command, refer to the example

```
awplus# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Awplus(config)# ip ddns update method tzo-method
Awplus(DDNS-update-method)# http
Awplus(DDNS-HTTP)# add provider tzo username my_host password my_password
```



## IP ADDRESS

**Syntax**

```
ip address <ip-addr/prefix-length>
no ip address dhcp
no ip address
```

**Description** This command sets a static IP address on an interface. To set the primary IP address on the interface, specify only `ip address <ip-address/m>`. This overwrites any configured primary IP address.

The `no` variant of this command removes the IP address from the interface. You cannot remove the primary address when a secondary address is present.

**Feature** IP Addressing and Protocol Commands

**Mode** Interface Configuration for a VLAN interface or a local loopback interface.

**Release** 4.1

**Options**

Option	Description	Range	Default Value
<code>&lt;ip-addr/prefix-length&gt;</code>	The IPv4 address and prefix length you are assigning to the interface.	NA	NA

**Note** Only one method is allowed per interface.

**Example** To add the primary IP address 10.10.10.50/24 to the interface `vlan7`, use the following commands:

```
awplus# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
awplus(config)# interface vlan7
awplus(config-if)# ip address 10.10.10.50/24
```

## IP DDNS UPDATE HOSTNAME

**Syntax**            `ip ddns update hostname <hostname>`  
                     `no ip ddns update hostname <hostname>`

**Description**        This command creates a user-defined hostname for the ddns provider. the ddns method. The command is also used when attaching the hostname to a (sub)interface.

The no variant of this Command deletes the hostname. This command will work only if the hostname is not associated with a (sub) interface.

**Feature**            IP Addressing and Protocol Commands

**Mode**                Interface Configuration for a VLAN interface or a local loopback interface.

**Release**            4.2

### Options

Option	Description	Range	Default Value
<hostname>	User-defined hostname that is sent to the ddns provider. This hostname is used by remote hosts when they wish to access the local server.	NA	NA

**Note**                NA

**Example**            To create and attach a hostname to a (sub)interface, use the following commands.

```
awplus# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
awplus(config)# interface vlan1.1
awplus(config-subif)# ip ddns update method tzo_method
awplus(config-subif)# ip ddns update hostname example.name.com
```

```
awplus(config-subif)# do show ip ddns update
```

```
DDNS Update Method  tzo_method  >> Disabled
```

```
-----
Provider             None
User Name            (null)
URL(non-specific)    (null)
Interface            brv1.1:1
Hostname             example.name.com
```

## IP DDNS UPDATE METHOD

**Syntax**

```
ip ddns update method <method_name>
ip ddns update hostname <hostname>
no ip ddns update method <method_name>
```

**Description** This command creates a user-defined name for the ddns method. The command is also used when attaching the method name and hostname to a (sub)interface.

The no variant of this command deletes the method. This command will work only if the method is **not** associated with a (sub) interface.

**Feature** IP Addressing and Protocol Commands

**Mode** Interface Configuration for a VLAN interface or a local loopback interface.

**Release** 4.2

### Options

Option	Description	Range	Default Value
method_name	User-defined name for the ddns method. This name method must be associated with a (sub) interface to be activated.	NA	NA
hostname	User-defined hostname for the (sub)vlan	NA	NA

**Note** NA

**Example** To create a method name, use the following commands. Note that the CLI is placed in the DDNS-update-method level.

```
awplus# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
awplus(config)# ip ddns update method tzo_method
awplus(DDNS-update-method)#
```

**Example** To attach a method to a (sub)interface a method name, use the following commands.

```
awplus# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
awplus(config)# interface vlan1.1
awplus(config-subif)# ip ddns update method tzo_method
awplus(config-subif)# ip ddns update hostname example.name.com
```

```
awplus(config-subif)# do show ip ddns update
```

```
DDNS Update Method  tzo_method  >> Disabled
```

```
-----
Provider           None
User Name          (null)
URL(non-specific)  (null)
Interface          brv1.1:1
Hostname           example.name.com
```

## IP DOMAIN-NAME

**Syntax**            `ip domain-name <domain-name>`  
                      `no ip domain-name`

**Description**        This command sets a default domain for the DNS. The DNS client appends this domain to incomplete host-names in DNS requests.

If there are no domains in the DNS list (created using the `ip domain-list` command) then your device uses the domain specified with this command. If any domain exists in the DNS list, then the device does not use the domain configured with this command.

When your device is using its DHCP client for an interface, it can receive Option 15 from the DHCP server. This option replaces the domain name set with this command. See Dynamic Host Configuration Protocol (DHCP) Introduction for more information about DHCP and DHCP options.

The `no` variant of this command removes the domain-name previously set by this command

**Feature**            IP Addressing and Protocol Commands

**Mode**              Global Configuration Mode

**Release**            4.1

**Options**

Option	Description	Range	Default Value
<domain-name>	Domain string, for example "company.com".	NA	NA

**Note**                NA

**Example**            To configure the domain name, enter the following commands:

```
awplus# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
ip domain-name company.com
```

## IP NAME-SERVER (IPv4)

**Syntax**

```
ip name-server <ip-addr>  
no ip name-server <ip-addr>
```

**Description** This command adds the IP address of a DNS server to the device's list of servers. The DNS client on your device sends DNS queries to devices on this list when trying to resolve a DNS hostname. Your device cannot resolve a hostname until you have added at least one server to this list. The iMG can support a maximum of 2 concurrent IPv4 DNS server addresses.

When your device is using its DHCP client for an interface, it can receive Option 6 from the DHCP server. This option appends the name server list with more DNS servers. See Dynamic Host Configuration Protocol (DHCP) Introduction for more information about DHCP and DHCP options.

The no variant of this command removes the DNS server from the list of servers.

**Feature** IP Addressing and Protocol Commands

**Mode** Global Configuration Mode

**Release** 4.1

### Options

Option	Description	Range	Default Value
<ip-addr>	The IP address to be advertised with the specified preference value.	NA	NA

**Note** NA

**Example** To allow your device to send DNS queries to a DNS server at 10.10.10.5, use the commands

```
awplus# configure terminal  
Enter configuration commands, one per line. End with CNTL/Z.  
ip name-server 10.10.10.5
```

## IP ROUTE

**Syntax**      `ip route <subnet&mask> {<gateway-ip>|<interface>} [<1-255>]`  
`no ip route <subnet&mask> {<gateway-ip>|<interface>} [<1-255>]`

**Description**      This command adds a static route to the Routing Information Base (RIB). If this route is the best route for the destination, then your device adds it to the Forwarding Information Base (FIB). Your device uses the FIB to advertise routes to neighbors and forward packets.

The no variant of this command removes the static route from the RIB and FIB. The no variant of this command removes the DNS server from the list of servers.

**Feature**      Routing Commands

**Mode**      Global Configuration Mode

**Release**      4.1

### Options

Option	Description	Range	Default Value
<sub-net&mask>	The IPv4 address of the destination prefix with either a prefix length or a separate mask specified in one of the following formats:  The IPv4 subnet address in dotted decimal notation followed by the subnet mask in dotted decimal notation.  The IPv4 subnet address in dotted decimal notation followed by a forward slash, then the prefix length.	NA	NA
<gateway-ip>	The IPv4 address of the gateway device.	NA	NA
<interface>	The interface that connects your device to the network. Enter the name of the VLAN or its VID.	NA	NA
<1-255>	The administrative distance for this route. For more information about setting administrative distances.	NA	NA

**Note**      NA

**Example**      To add the destination 192.168.3.0 with the mask 255.255.255.0 as a static route available through the device at "10.10.0.2", use the command:

```
awplus# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
ip route 192.168.3.0/24 10.10.10.2
```

**PING (IPv4)**

**Syntax** ping [ip] <hostname> [interface <vlan> | <vlansub>]

**Default** This command sends a query to another IPv4 host (send Echo Request messages). The user can also specify which interface the ping requests should be sent on.

**Feature** IP Addressing and Protocol Commands

**Mode** User Exec and Privileged Exec Mode

**Release** 4.2

**Options**

Option	Description	Range	Default Value
ip	Specifies that IPv4 addresses are being used.	NA	NA
hostname	The destination IP address or hostname. For IPv4 the format is A.B.C.D	NA	NA
interface	The vlan or vlan sub-interface (range)	NA	NA

**Note** The ping command may take some time to complete. It can be interrupted at any time by pressing ctrl-c.

**Example** To ping a host, input the following:

```
awplus# ping 192.168.200.1
PING 192.168.200.1 (192.168.200.1): 56 data bytes
56 bytes from 192.168.200.1: icmp_seq=0 ttl=64 time=0.6 ms
56 bytes from 192.168.200.1: icmp_seq=1 ttl=64 time=0.4 ms
56 bytes from 192.168.200.1: icmp_seq=2 ttl=64 time=0.4 ms
56 bytes from 192.168.200.1: icmp_seq=3 ttl=64 time=0.4 ms
```

```
--- 192.168.200.1 ping statistics ---
4 packets transmitted, 4 packets received, 0% packet loss
round-trip min/avg/max = 0.4/0.4/0.6 ms
```

```
awplus# ping www.apple.com
PING www.apple.com (2.17.109.15): 56 data bytes
64 bytes from 2.17.109.15: seq=0 ttl=57 time=4.532 ms
64 bytes from 2.17.109.15: seq=1 ttl=57 time=3.690 ms
64 bytes from 2.17.109.15: seq=2 ttl=57 time=3.746 ms
64 bytes from 2.17.109.15: seq=3 ttl=57 time=3.631 ms
```

```
--- www.apple.com ping statistics ---
4 packets transmitted, 4 packets received, 0% packet loss
round-trip min/avg/max = 3.631/3.899/4.532 ms
```

## REMOVE PROVIDER

**Syntax**            `remove provider`

**Description**       This command removes the ddns service contact that was previously created.

**Feature**            IP Addressing and Protocol Commands

**Mode**              Interface Configuration for a VLAN interface or a local loopback interface.

**Release**            4.2

**Options**            NA

**Note**               NA

**Example**            To use this command, refer to the example

```
awplus# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Awplus(config)# ip ddns update method tzo_method
Awplus(DDNS-update-method)# http
Awplus(DDNS-HTTP)# remove provider
```



## REMOVE URL

**Syntax**            `remove url`

**Description**       This command removes the url that was previously created for the ddns service contact.

**Feature**            IP Addressing and Protocol Commands

**Mode**              Interface Configuration for a VLAN interface or a local loopback interface.

**Release**            4.2

**Options**            NA

**Note**               NA

**Example**            To use this command, refer to the example

```
awplus# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Awplus(config)# ip ddns update method tzo_method
Awplus(DDNS-update-method)# http
Awplus(DDNS-HTTP)# remove url
```

## SHOW HOSTS

**Syntax**            `show hosts`

**Description**      This command shows the default domain, domain list, and name servers configured on your device.

**Feature**            IP Addressing and Protocol Commands

**Mode**              Privileged Exec Mode

**Release**           4.1

**Options**           NA

**Note**              NA

**Example**           To display the default domain, use the command:

```
awplus# show hosts
awplus# show hosts
DNS default domain:  AlliedTelesis
DNS domain list:  company.com
domain Home
```

```
DNS Name Servers:
172.0.0.1
```

**SHOW IP DDNS**

**Syntax**            show ip ddns [update]

**Description**      This command shows the ddns configuration and whether any of the methods are attached to (sub)interfaces.

**Feature**            IP Addressing and Protocol Commands

**Mode**              Privileged Exec Mode

**Release**            4.2

**Options**

Option	Description	Range	Default Value
update	In the output, displays the ddns attributes by method	NA	NA

**Note**                NA

**Example**            To display the ddns attributes, use the commands:

```
awplus# show ip ddns
IP interface: vlan1
-----
    DDNS is disabled

IP interface: vlan1.1
-----
    Update Method is tzo_method
    Provider      None
    Username
    Hostname      example.name.com

IP interface: vlan2
-----
    DDNS is disabled

IP interface: vlan7
-----
    DDNS is disabled

awplus# show ip ddns update

DDNS Update Method  tzo_method  >> Disabled
-----
    Provider          None
    User Name         (null)
    URL(non-specific) (null)
    Interface         brv1.1:1
    Hostname          example.name.com
```

**SHOW IP DOMAIN-LIST**

**Syntax**            `show ip domain-list`

**Description**      This command shows the domains configured in the domain list. The DNS client uses the domains in this list to append incomplete hostnames when sending a DNS enquiry to a DNS server.

**Feature**            IP Addressing and Protocol Commands

**Mode**              Privileged Exec Mode

**Release**            4.1

**Options**            NA

**Note**               NA

**Example**            To display the list of domains in the domain list, use the command

```
awplus# show ip domain-list
DNS domain list:
domain Home
```

**SHOW IP DOMAIN-NAME**

**Syntax**            `show ip domain-name`

**Description**       This command shows the default domain configured on your device. When there are no entries in the DNS list, the DNS client appends this domain to incomplete hostnames when sending a DNS enquiry to a DNS server.

**Feature**            IP Addressing and Protocol Commands

**Mode**              Privileged Exec Mode

**Release**            4.1

**Options**            NA

**Note**               NA

**Example**            To display the list of domains in the domain list, use the command

```
awplus# show ip domain-name
DNS default domain  Allied Telesis
```

**SHOW IP INTERFACE BRIEF**

**Syntax**            show ip interface brief

**Description**      This command displays brief information about interfaces and the IP addresses assigned to them.

**Feature**            IP Addressing and Protocol Commands

**Mode**              Privileged Exec Mode

**Release**            4.2

**Options**            NA

**Note**               NA

**Example**            To show the IP addresses assigned to the device, use the command

```
awplus# show ip interface brief
```

Interface	IP-Address	Status	Protocol
vlan1	unassigned	admin up	down
vlan1.1	unassigned	admin up	down
vlan2	unassigned	admin up	running
vlan7	unassigned	admin up	down
vlan10	unassigned	admin up	down
vlan20	unassigned	admin up	down
vlan40	unassigned	admin up	down

**SHOW IP NAME-SERVER (IPv4)**

**Syntax**            `show ip name-server`

**Description**        This command displays the list of DNS servers your device sends DNS requests to. On the iMG these server addresses can be set statically using the [ip name-server \(IPv4\)](#) command, or dynamically using the DHCP option 6.

The iMG supports up to 2 concurrent IPv4 and 2 concurrent IPv6 DNS server addresses (so a combined maximum of 4). Note that setting a static server address discards any dynamically set DNS server addresses. So this command will show either static or dynamic DNS server addresses - but not both at once

**Feature**            IP Addressing and Protocol Commands

**Mode**              Privileged Exec Mode

**Release**            4.1

**Options**            N/A

**Note**                NA

**Example**            To display the list of DNS servers that your device sends DNS requests to, use the command

```
awplus# show ip name-server
DNS Name Servers:
 172.0.01
```

## SHOW IP ROUTE

**Syntax** `show ip route`

**Description** This command shows the ip route to display the current state of the routing table.

Typically, route entries are composed of the following elements

- \* code
- \* a second label indicating the sub-type of the route
- \* network or host ip address
- \* administrative distance and metric
- \* nexthop ip address
- \* outgoing interface name
- This route is the same as the other OSPF route explained above; the main difference is that it is a Type 2 External OSPF route.

**Feature** Routing Commands

**Mode** Privileged Exec Mode

**Release** 4.1

**Options** NA

**Note** NA

**Example** To display the OSPF routes in the FIB, use the command. If any VRF is configured, it will display routes defined for that VRF.:

```
awplus# show ip route ospf
```

**Example** To display the routes in the context of a VRF instance "red" in the FIB, use the command:

```
awplus# show ip route vrf red
```

**Example** To display all routes in the FIB, including routes for all VRF instances if any VRF is configured, use the command:

```
awplus# show ip route
```

Destination	Mask	NextHop	Interface	Protocol
172.0.0.0	255.255.0.0	0.0.0.0	vlan1	INTERFACE
0.0.0.0	0.0.0.0	172.0.0.1	vlan1	DHCP



**SHOW IP SOCKETS**

**Syntax**            show ip sockets

**Description**      This command displays informations about the IP sockets that are present on the device. It includes TCP, UDP listen sockets, displaying associated IP address and port. When a TCP session is established this is displayed including the remote IP address and port and the state of the session.

**Feature**            Routing Commands

**Mode**              Privileged Exec Mode

**Release**            4.2

**Options**            NA

**Note**               NA

**Example**            To display the IP sockets, use the command:

```
awplus # show ip sockets
Active Internet connections (servers and established)
Proto Recv-Q Send-Q Local Address           Foreign Address          State
tcp        0      0 127.0.0.1:54321         0.0.0.0:*                LISTEN
tcp        0      0 0.0.0.0:44401           0.0.0.0:*                LISTEN
tcp        0      0 0.0.0.0:30005           0.0.0.0:*                LISTEN
tcp        0      0 :::80                   :::*                      LISTEN
tcp        0      0 :::22                   :::*                      LISTEN
tcp        0      0 :::23                   :::*                      LISTEN
tcp        0      0 ::ffff:172.32.4.203:22  ::ffff:10.17.90.132:3905
ESTABLISHED
udp        0      0 0.0.0.0:161             0.0.0.0:*
udp        0      0 0.0.0.0:162             0.0.0.0:*
udp        0    480 172.32.3.203:50606       0.0.0.0:*
udp    50688      0 172.32.3.203:50607       0.0.0.0:*
udp        0      0 0.0.0.0:67              0.0.0.0:*
udp        0      0 172.32.3.203:5060        0.0.0.0:*
udp        0      0 127.0.0.1:53201          0.0.0.0:*
udp        0      0 :::54274                :::*
udp        0      0 :::53                   :::*
udp        0      0 :::19401                 :::*
raw        0      0 0.0.0.0:2               0.0.0.0:*                2
```

## TRACEROUTE

**Syntax** `traceroute {<ip-addr>|<hostname>}`

**Description** This command traces the route to the specified IPv4 host.

**Feature** IP Addressing and Protocol Commands

**Mode** User Exec and Privileged Exec Mode

**Release** 4.1

**Options**

Option	Description	Range	Default Value
<ip-addr>	The destination IPv4 address. The IPv4 address uses the format A.B.C.D.	NA	NA
<hostname>	The destination hostname.	NA	NA

**Note** The traceroute command may take some time to complete. It can be interrupted at any time by pressing ctrl-c.

**Example**

```
awplus# traceroute 10.10.0.5
```

## 3.8 IPv6

### 3.8.1 Overview

IPv6 is the next generation of the Internet Protocol (IP). It has primarily been developed to solve the problem of the eventual exhaustion of the IPv4 address space, but also offers other enhancements. IPv6 addresses are 16 bytes long, in contrast to IPv4's 4 byte addresses. Other features of IPv6 include:

- Address structure improvements:
  - globally unique addresses with more levels of addressing hierarchy to reduce the size of routing tables
  - autoconfiguration of addresses by hosts
  - improved scalability of Multicast routing by adding a "scope" field to Multicast addresses
- Removes the need for packet fragmentation en-route, by dynamic determination of the largest packet size that is supported by every link in the path. A link's MTU (Maximum Transmission Unit) must be at least 1280 bytes, compared with 576 bytes for IPv4.
- Includes a Traffic Class that allow packets to be labeled with an appropriate priority. If the network becomes congested, the lowest priority packets are dropped.
- Includes Flow labels that indicate to intermediate switches and routers that packets are part of a flow, and that a particular flow requires a particular type of service. This feature enables, for example, real-time processing of data streams. It also increases routing speed because the forwarding router need only check the flow label, not the rest of the header. The handling indicated by the flow label can be done by the IPv6 Hop-by-Hop header, or by a separate protocol such as RSVP.
- Mandatory authentication and data integrity protocols through IPsec. IPsec is optional in IPv4.

### 3.8.2 IPv6 Addresses and Prefixes

IPv6 addresses are hexadecimal, and are made up of eight pairs of octets separated by colons. An example of a valid address is 2001:0db8:0000:0000:0260:0000:97ff:64aa. In the interests of brevity, addresses can be abbreviated in two ways:

- Leading zeros can be omitted, so this address can be written as 2001:db8:0:0:260:0:97ff:64aa.
- Consecutive zeros can be replaced with a double colon, so this address can be written as 2001:db8::260:0:97ff:64aa. Note that a double colon can replace any number of consecutive zeros, but an address can contain only one double colon.

Like IPv4 addresses, a proportion of the left-most bits of the IPv6 address can be used to indicate the subnet, rather than a single node. This part of the address is called the prefix. Prefixes provide the equivalent functionality to a subnet mask in IPv4, allowing a subnet to be addressed, rather than a single node. If a prefix is specified, the IPv6 address is followed by a slash and the number of bits that represent the prefix. For example, 2001::/16 indicates that the first 16 bits (2001) of the address 2001:0:0:0:0:0:0:0 represent the prefix.

Like IPv4 addresses, IPv6 addresses are attached to interfaces.

### 3.8.3 Address Types

IPv6 supports the following address types:

- unicast
- Multicast
- Anycast

#### 3.8.3.1 Unicast Addresses

A unicast address is attached to a single interface and delivers packets only to that interface. The following special addresses have been defined:

- IPv4-compatible and IPv4-mapped addresses. IPv4-compatible addresses are used to tunnel IPv6 packets across an IPv4 network. IPv4-mapped addresses are used by an IPv6 host to communicate with an IPv4 host. The IPv6 host addresses the packet to the mapped address.
- Link-local addresses can be used on the local network on which the interface is attached. The link-local prefix is fe80::/10. Different interfaces on a device may have the same link-local address. The iMG will automatically generate a link-local address for all interfaces that are using IPv6. Commands entered to configure link-local addresses that match any automatically generated link-local addresses by the switch will not be executed.
- Site-local - These are the equivalent of IPv4 private addresses. These cannot transmit from one site to another site without the use of a global IPv6 address.
- Global - These are the equivalent of public IPv4 addresses. Global addresses can be routed publicly in the Internet. Any device or site that wishes to transmit packets to another site must be uniquely identified with a global address.

#### 3.8.3.2 Multicast Addresses

IPv6 Multicast addresses provide the equivalent functionality to broadcast addresses in IPv4. Broadcast addresses are not supported in IPv6. A Multicast address identifies a group of interfaces, and packets are sent to all interfaces in that group.

Among the special addresses that have been defined are addresses that allow Multicasting to:

- All interfaces on a particular host (ff01::1)
- All nodes on a local network (ff01::2)
- All routers on the local link (ff02::2)
- All routers on the local site (ff05::2).

### 3.8.3.3 Anycast Addresses

An anycast address is a unicast address that is attached to more than one interface. If a packet is sent to an anycast address it is delivered to the nearest interface with that address, with the definition of “nearest” depending on the protocol used for routing. If the protocol is RIPv6, the nearest interface is the one that is the shortest number of hops away.

Anycast addresses can be assigned to routers only, and packets cannot originate from an anycast address. A router must be configured to know that it is using an anycast address because the address format cannot be distinguished from that of a unicast address.

Only one anycast address has been predefined: the subnet-router address. The subnet-router address sends messages to the nearest router on a subnet and consists of the subnet’s prefix followed by zeros.

**Note:** Assignment of anycast addresses is not supported in 4.2.

### 3.8.4 IPv6 Headers

The basic unit of data sent through an internet is called a packet in IPv6. A packet consists of a header followed by the data. The following table lists the IPv6 fields.

Table 3-3: IPv6 Field Descriptions

Field	Function
Ver	Version of the IP protocol that created the packet. For IPv6, this field has a value of 6.
Differentiated Services	8-bit value that contains the 6-bit DSCP and is used to prioritize traffic as part of a Quality of Service system. For more information, see “Differentiated Services Architecture” on page 60.4. Additional information can be found in RFC 2474, Definition of the Differentiated Services Field (DS Field) in the IPv4 and IPv6 Headers.
Flow Label	20-bit value that indicates the data flow to which this packet belongs. This flow may be handled in a particular way.
Payload Length	Length of the user data portion of the packet. If the data payload is larger than 64 kB, the length is given in the optional “Jumbo Payload” header and the Payload Length header is given a value of zero.
Next Header	Number that indicates the type of header that immediately follows the basic IP header. This header type may be an optional IPv6 extension header, a relevant IPv4 option header, or another protocol, such as TCP or ICMPv6. The IPv6 extension header values are: <ul style="list-style-type: none"> <li>- 0 (Hop-by-Hop Options Header)</li> <li>- 43 (IPv6 Routing Header)</li> <li>- 44 (IPv6 Fragment Header)</li> <li>- 50 (Encapsulating Security Payload)</li> <li>- 51 (IPv6 Authentication Header)</li> <li>- 59 (No Next Header)</li> <li>- 60 (Destination Options Header)</li> </ul>
Hop Limit	Field that is the equivalent of the IPv4 Time To Live field, measured in hops.
Source IP address	128-bit IPv6 address of the sender.

Table 3-3: IPv6 Field Descriptions

Field	Function
Destination IP address	128-bit IPv6 address of the recipient.
Optional extension headers	Headers for less-frequently used information.
User data	Payload.

### 3.8.5 Basic IPv6 Header Structure

The headers contain information necessary to move the packet across the internet. They must be able to cope with missing and duplicated packets as well as possible fragmentation (and reassembly) of the original packet.

IPv6 headers are twice as long as IPv4 headers (40 bytes instead of 20 bytes) and contain four times the address space size (128 bits instead of 32 bits).

They no longer contains the header length, identification, flags, fragment offset, and header checksum fields. Some of these options are placed in extension headers. The Time To Live field is replaced with a hop limit, and the IPv4 Type of Service field is replaced with a Differentiated Services field. The Differentiated Services field contains the DSCP bits, used in a Quality of Service (QoS) regime. The following table explains IPv4 header fields that changed in IPv6.

Table 3-4: IPv6 Header Structure

Field	Function
Type of Service	The type of service that a connection should receive is indicated in IPv6 by the Flow Label field in the IPv6 header.
Fragmentation information (the Identification field, the Flags field and the Fragment Offset field)	In most cases fragmentation does not occur in IPv6. If it does, packets are fragmented at their source and not en route. Therefore, the fragmentation information is contained in an extension header to reduce the size of the basic IPv6 header.
Header Checksum	This option has not been provided in IPv6. This is because transport protocols implement checksums and because of the availability of the IPsec authentication header (AH) in IPv6.
Options	Extension headers handle all the optional values associated with IPv6 packets. The biggest advantage of this scheme is that the size of the basic IP header is a constant.

#### 3.8.5.1 Extension Headers

IPv6 implements many of the less commonly used fields in the IPv4 header (or their equivalents) as extension headers, which are placed after the basic IPv6 header. The length of each header must be a multiple of 8 bytes.

The first extension header is identified by the Next Header field in the basic IPv6 header. Any subsequent extension headers are identified by an 8-bit “Next Header” value at the beginning of the preceding extension header.

IPv6 nodes that originate packets are required to place extension headers in a specific order:

1. The basic IPv6 header. This must come immediately before the extension headers.
2. The Hop-by-Hop header. This specifies options that must be examined by every node in the routing path.
3. A Destination Options header. This is used to specify options to be processed by the first destination or final destination. The destination options header is the only extension header that may be present more than once in the IPv6 packet.

4. The Routing header. This enables a static path to be specified for the packet, if the dynamically-determined path is undesirable.
5. The Fragment header. This indicates that the source node has fragmented the packet, and contains information about the fragmentation.
6. The Authentication header (AH). This verifies the integrity of the packet and its headers
7. The Encapsulating Security Payload (ESP) header. This encrypts a packet and verifies the integrity of its contents.
8. The Upper Layer Protocol header. This indicates which protocol a higher layer (such as the transport layer) is to process the packet with (for example, TCP).

### 3.8.6 The Internet Control Message Protocol (ICMPv6)

The Internet Control Message Protocol, ICMPv6, provides a mechanism for error reporting and route discovery and diagnostics. It also conveys information about Multicast group membership, a function that is carried out by the Internet Group Management Protocol (IGMP) in IPv4, and performs address resolution, which the Address Resolution Protocol (ARP) performs in IPv4.

Significant aspects of ICMPv6 include neighbor discovery, which enables one device in a network to find out about other nearby devices; and stateless address autoconfiguration, which allows a device to dynamically determine its own IPv6 address.

ICMPv6 is also used to support the Ping v6 (Packet Internet Groper) and Trace route v6 functions that are used to verify the connections between networks and network devices. Ping is used to test the connectivity between two network devices to determine whether each network device can “see” the other device. Trace route is used to discover the route used to pass packets between two systems running the IP protocol.

Both of these functions operate almost identically in IPv4 and IPv6. Refer to the [ping ipv6](#) command.

#### 3.8.6.1 Neighbor Discovery

Neighbor discovery is an ICMPv6 function that enables a router or a host to identify other devices on its links. This information is then used in address autoconfiguration, to redirect a node to use a more appropriate router if necessary, and to maintain reach ability information with its neighbors.

The IPv6 Neighbor Discovery protocol is similar to a combination of the IPv4 protocols ARP, ICMP Router Discovery and ICMP Redirect.

The following table describes packet types involved with neighbor discovery.

Table 3-5: IPv6 Neighbor Discovery Packet Types

Packet Type	Description
router solicitation	Packet in which a host sends out a request for routers to generate advertisements.
router advertisement	Allows routers to advertise their presence and other network parameters. A router sends an advertisement packet in response to a solicitation packet from a host.
neighbor solicitation	Packet in which a node sends a packet to determine the link layer address of a neighbor or to verify that a neighbor is still active.
neighbor advertisement	A response to a neighbor solicitation packet. These packets are also used to notify neighbors of link layer address changes.
redirect	Informs hosts of a better first hop.

To comply with Section 6.2.1 of RFC 2461, IPv6 Neighbor Discovery, the router does not generate router advertisements by default. The following table explains packet types and services.

Table 3-6: IPv6 Neighbor Discovery Packet Types

Packet Type	Description
address resolution	A method for carrying out address autoconfiguration, and is achieved using the Neighbor Solicitation Message and the Neighbor Advertisement Message.
router and prefix discovery	On connection to a link, a node needs to know the address of a router that the node can use to reach the rest of the world. The node also needs to know the prefix (or prefixes) that define the range of IP addresses on its link that it can reach without going through a router.  Routers use ICMP to convey this information to hosts, by means of router advertisements. The message may have an option attached (the source link address option), which enables the receiving node to respond directly to the router, without performing a neighbor solicitation.
immediate information	The configuration of a router includes a defined frequency at which unsolicited advertisements are sent. If a node wants to obtain information about the nearest router immediately, rather than waiting for the next unsolicited advertisement, the node can send a router solicitation message.  Each router that receives the solicitation message sends a router advertisement specifically to the node that sent the solicitation.
redirection	If a node is aware of more than one router that it can use to connect to wider networks, the router to which it sends packets by default does not always represent the most desirable route. ICMPv6 uses the redirect packet to communicate a more effective path to the node.
Neighbor Unreachability Detection (NUD)	A node may issue solicitation requests to determine whether a path is still viable, or may listen in on acknowledgement packets of higher layer protocols, such as TCP. If the node determines that a path is no longer viable, it attempts to establish a new link to the neighbor, or to re-establish the previous link. NUD can be used between any two devices in the network, independent of whether the devices are acting as hosts or routers.

### 3.8.7 Stateless Address Autoconfiguration (SLAAC)

Stateless address autoconfiguration allows an IPv6-aware device to be plugged into a network without manual configuration with an IP address. This plug and play functionality results in networks that are easier to set up and modify, and simplifies the process of shifting to use a new Internet Service Provider (ISP).

Stateless address autoconfiguration is achieved in a series of steps. Routers and hosts perform the first three steps, which auto configure a link-local address. A global address is auto configured in the last three steps, which only hosts perform.

### 3.8.7.1 On the Router or Host

1. During system start-up, the iMG begins autoconfiguration by generating a link-local address for the interface. A link-local address is formed by adding the interface ID to the link-local prefix fe80::/10 (reference RFC 3513).

**Note:** Different interfaces on an iMG may have the same link-local address. The switch will automatically generate a link-local address for all interfaces that are using IPv6. Commands entered to configure link-local addresses that match any automatically generated link-local addresses by the switch will not be executed. Enter the [show ipv6 interface brief](#) command to display automatically generated link-local addresses. Automatically generated link-local addresses contain the last six hexadecimal numbers of the MAC address for a given interface.

2. The node then transmits a neighbor solicitation message to this address. If the address is already in use, the node that the address belongs to replies with a neighbor advertisement message. The autoconfiguration process stops and manual configuration of the node is then required.

3. If no neighbor advertisement is received, the node concludes that the address is available and assigns it to the chosen interface.

### 3.8.7.2 On the Host

1. The node then sends one or more router solicitations to detect if any routers are present. Any routers present responds with a router advertisement.

If no router advertisement is received, the node tries to use DHCP to obtain an address and other configuration information. If no DHCP server responds, the node continues using the link-level address.

If a router advertisement is received, this message informs the node how to proceed with the auto configuration process. The prefix from the router advertisement, if received, is added to the link-level address to form the global unicast IP address.

2. This address is then assigned to the network interface.

If routers are present, the node continues to receive router advertisements. The node updates its configuration when there are changes in the router advertisements.

## 3.8.8 IPv6 Routing

Routing in IPv6 is almost identical to IPv4 routing under CIDR, except that the addresses are 128-bit IPv6 addresses instead of 32-bit IPv4 addresses.

## 3.8.9 Integration of IPv4 and IPv6

IPv6 has been designed in such a way that a smooth transition from IPv4 is possible. The most effective way to ensure this is to use a dual IP stack. A node configured as a dual stack system has both a 128-bit IPv6 address and a 32-bit IPv4 address, and so can communicate with nodes running IPv4 and those running IPv6.

### 3.8.10 Enabling IPv6 on the iMG

This section describes the iMG's support for IPv6, and how to configure IPv6 on the iMG.

#### 3.8.10.1 Enabling IPv6

The iMG's implementation of IPv6 is disabled by default on all interfaces. To enable IPv6 on an interface, use the [ipv6 enable \(config-if\)](#) or [ipv6 address \(config-if\)](#) command. To display information about IPv6 settings, use the [show ipv6 interface brief](#) command. Because the iMG implements IPv6 as a dual stack, implementing IPv6 does not affect IPv4 functionality.

IPv6 packet forwarding is also disabled by default. To enable IPv6 packet forwarding, use the [ipv6 forwarding \(config\)](#) command.



### 3.8.10.2 IPv6 Stateless Address Autoconfiguration (SLAAC)

The iMG's implementation of IPv6 supports SLAAC. To enable IPv6 SLAAC on an interface, use the [ipv6 address \(config-if\)](#) command with the autoconfig option. SLAAC uses the EUI-64 algorithm to populate the least significant 64 bits of the global unicast address. `ipv6 address autoconfig` automatically configures both an IPv6 link-local address and an IPv6 global unicast address, and also enables IPv6 processing on the interface.

### 3.8.10.3 IPv6 Link-local Addresses

The iMG's implementation of IPv6 supports enabling of IPv6 on an interface with only an IPv6 link-local addresses (i.e. no global unicast address) for communications within the local subnetwork. Routers do not forward packets to link-local addresses. To enable this mode, use the `IPv6 enable (config-if)` command. `ipv6 enable` automatically configures an IPv6 link-local address on the interface and enables IPv6 processing on the interface.

## 3.8.11 IPv6 and IPv4 on the iMG

In 4.2 both IPv4 and IPv6 can be configured on the iMG. The services each can support are as follows:

- Management of the iMG (using ssh, telnet, SNMP, HTTP and TR69) is by means of **IPv4 only**.
- VoIP support is by means of **IPv4 only**. (The SIP & MGCP applications do not currently support IPv6).
- Streaming video is by means of **IPv4 (using IGMP) only**.
- Routed IPv4 data, i.e. IPv4 internet using NAT.
- Routed IPv6 data, i.e. IPv6 internet using GUAs (globally unique addresses) on all interfaces. Note that IPv6 NAT is not supported on the iMG.
- Bridged data (layer 2). In this case the iMG is used simply as a layer 2 switch, and layer 3 (IPv4 and/or IPv6) packets are switched transparently by the iMG.

### 3.8.12 IPv6 Command List

Table 3-7: IPv6 Commands

Commands
ipv6 address (config-if)
ipv6 enable (config-if)
ipv6 forwarding (config)
ip name-server (config) - IPv6
ipv6 nd dad-attempts (config-if)
ipv6 nd managed-config-flag (config-if)
ipv6 nd minimum-ra-interval (config-if)
ipv6 nd other-config-flag (config-if)
ipv6 nd ra-interval (config-if)
ipv6 nd rs-attempts (config-if)
ipv6 nd rs-delay (config-if)
ipv6 nd rs-interval (config-if)
ipv6 nd suppress-ra (config-if)
ipv6 route (config)
ping ipv6
show ip name-server (ipv6)
show ipv6 forwarding
show ipv6 general-prefix
show ipv6 interface brief
show ipv6 interface verbose
show ipv6 neighbors
show ipv6 route
traceroute ipv6

**IPv6 ADDRESS (CONFIG-IF)**

**Syntax**

```

ipv6 address <delegated-prefix-name> 0:0:0:<bits>::/<dp-len> eui-64
ipv6 address <ipv6-prefix>/<prefix-len> eui-64 [default]
ipv6 address <ipv6-addr>/<prefix-len> [default]
ipv6 address autoconfig [default]
no ipv6 address <delegated-prefix-name> 0:0:0:<bits>::/<dp-len> eui-64
no ipv6 address <ipv6-prefix>/<prefix-len> eui-64 [default]
no ipv6 address <ipv6-addr>/<prefix-len> [default]
no ipv6 address autoconfig [default]

```

**Description** Use this command to set the IPv6 address of a VLAN interface and enable IPv6 on the interface. Use the no variant of this command to remove the address assignment.

**Feature** IPv6 Commands

**Mode** Interface Mode

**Release** 4.2

**Options**

Option	Description	Range	Default Value
delegated-prefix-name	Name of the delegated prefix from which to derive the dp-len high-order bits of the address prefix (high-order 64 bits of the address).	NA	NA
bits	The low-order bits of the address prefix (high-order 64 bits of the address).	0-FFFF	NA
dp-len	The length of delegated prefix delegated-prefix-name	1-64	NA
eui-64	The EUI-64 algorithm will be used to derive the low-order 64 bits of the IPv6 address from the interface MAC address.	NA	NA
ipv6-prefix	An IPv6 address prefix of the form X:X:X::	NA	NA
ipv6-addr	An IPv6 address of the form X:X:X::X	NA	NA
prefix-len	Prefix length of the address. For Ethernet interfaces this should always be 64.	64	NA
default	Indicates that this interface will be used to derive the default IPv6 route dynamically from RA (router advertisement) messages.	NA	NA

**Note** All interfaces default to IPv6-disabled with no IPv6 address.  
If the 'default' option is specified on multiple IPv6 interfaces, the last interface so specified is used for the default route.  
The 'default' option cannot be specified if a static IPv6 default route has been configured on the iMG.

**Example**

```

awplus(config)# interface vlan1
awplus(config-if)# ipv6 address 2001:0db8::a2/64

```

**IPv6 ENABLE (CONFIG-IF)**

<b>Syntax</b>	ipv6 enable no ipv6 enable
<b>Description</b>	Use this command to enable an IPv6 interface with only a link local address.
<b>Feature</b>	IPv6 Commands
<b>Mode</b>	Interface Config
<b>Release</b>	4.2
<b>Options</b>	NA
<b>Note</b>	All interfaces default to IPv6 disabled with no IPv6 address.

**Example**

```
awplus(config)# interface vlan1  
awplus(config-if)# ipv6 enable
```

## IPv6 FORWARDING (CONFIG)

<b>Syntax</b>	ipv6 forwarding no ipv6 forwarding
<b>Description</b>	Use this command to enable IPv6 packet forwarding on the iMG. Use the no variant of this command to disable IPv6 packet forwarding.
<b>Feature</b>	IPv6 Commands
<b>Mode</b>	Global Configuration mode
<b>Release</b>	4.2
<b>Options</b>	NA
<b>Note</b>	NA

### Example

```
awplus(config)# ipv6 forwarding
```

## IP NAME-SERVER (CONFIG) - IPV6

**Syntax**

```
ip name-server <ipv6-addr>  
no ip name-server <ipv6-addr>
```

**Description** This command adds the IPv6 address of a DNS server to the iMG's list of DNS servers. The DNS client on your iMG sends DNS queries to servers in this list when trying to resolve a DNS hostname. Your device cannot resolve a hostname until you have added at least one server to this list. The iMG can support a maximum of 2 concurrent IPv6 DNS server addresses.

The no variant of this command removes the DNS server from the list of servers.

**Feature** IP Addressing and Protocol Commands

**Mode** Interface Mode

**Release** 4.2

### Options

Option	Description	Range	Default Value
ipv6-addr	The DNS server IPv6 address to be added to the iMG list of DNS servers.	NA	NA

**Note** NA

**Example** To allow your device to send DNS queries to a DNS server at 2001:db8::1, use the commands

```
awplus# configure terminal  
Enter configuration commands, one per line. End with CNTL/Z.  
ip name-server 2001:db8::1
```

**IPv6 ND DAD-ATTEMPTS (CONFIG-IF)**

**Syntax**            `ipv6 nd dad-attempts <value>`  
                     `no ipv6 nd dad-attempts`

**Description**      Use this command to specify the number of DAD (duplicate address detection) attempts. Use the `no` parameter with this command to reset the value to the default.

**Feature**            IPv6 Commands

**Mode**              Interface Mode

**Release**            4.2

**Options**

Option	Description	Range	Default Value
dad-attempts	Number of DAD attempts that will be performed when attempting to assign an IPv6 address to an interface	0-600	3

**Note**                NA

**Example**

```
awplus(config)# interface vlan1
awplus(config-if)# ipv6 nd dad-attempts 20
```

## IPv6 ND MANAGED-CONFIG-FLAG (CONFIG-IF)

<b>Syntax</b>	<code>ipv6 nd managed-config-flag</code> <code>no ipv6 nd managed-config-flag</code>
<b>Description</b>	<p>Used to configure the Managed Config Flag in RA (Router Advertisement) messages. Setting this flag indicates to hosts on the subnet that a stateful autoconfiguration protocol such as DHCPv6 should be used for address configuration. An unset flag indicates that hosts may use the SLAAC autoconfiguration mechanism to derive IPv6 addresses. The default is flag unset.</p> <p>Use the no variant of this command to reset this command to its default of flag unset.</p>
<b>Feature</b>	IPv6 Commands
<b>Mode</b>	Interface Mode
<b>Release</b>	4.2
<b>Options</b>	NA
<b>Note</b>	Router Advertisements will not be transmitted unless you have applied the <code>no ipv6 nd suppress-ra</code> command. This step is included in the example below

### Example

```
awplus(config)# interface vlan2

awplus(config-if)# ipv6 nd managed-config-flag

awplus(config-if)# no ipv6 nd suppress-ra
```



**IPv6 ND MINIMUM-RA-INTERVAL (CONFIG-IF)**

**Syntax**            `ipv6 nd minimum-ra-interval <seconds>`  
                     `no ipv6 nd minimum-ra-interval`

**Description**      Use this command to specify the minimum interval between IPv6 Router Advertisements (RA) transmissions. Use the `no` option with this command to reset the value to default.

**Feature**            IPv6 Commands

**Mode**              Interface Mode

**Release**            4.2

**Options**

Option	Description	Range	Default Value
seconds	Specifies the number of seconds between IPv6 router advertisements. Valid values are from 4 to 1800 seconds.	3-3150	3

**Note**                Router Advertisements will not be transmitted unless you have applied the `no ipv6 nd suppress-ra` command. This step is included in the example below

**Example**

```
awplus(config)# interface vlan4
awplus(config-if)# ipv6 nd minimum-ra-interval 60
awplus(config-if)# no ipv6 nd suppress-ra
```

## IPv6 ND OTHER-CONFIG-FLAG (CONFIG-IF)

**Syntax**            `ipv6 nd other-config-flag`  
                     `no ipv6 nd other-config-flag`

**Description**       Use this command to set the other stateful configuration flag (contained within the router advertisement field) to be used for IPv6 address auto-configuration. This flag is used to request the router to provide information in addition to providing addresses. Use the `no` variant of this command to reset the value to default.

Used to configure the Other Config Flag in RA (Router Advertisement) messages. Setting this flag indicates to hosts on the subnet that they may use DHCPv6 to obtain stateless configuration information (such as DNS server addresses, domain search list, etc).

**Feature**            IPv6 Commands

**Mode**               Interface Mode

**Release**            4.2

**Options**            NA

**Note**               Router Advertisements will not be transmitted unless you have applied the `no ipv6 nd suppress-ra` command. This step is included in the example below.

### Example

```
awplus(config)# interface vlan4

awplus(config-if)# ipv6 nd other-config-flag

awplus(config-if)# no ipv6 nd suppress-ra
```

**IPv6 ND RA-INTERVAL (CONFIG-IF)**

**Syntax**            `ipv6 nd ra-interval <seconds>`  
                     `no ipv6 nd ra-interval`

**Description**      Use this command to specify the interval between IPv6 Router Advertisement (RA) transmissions. Use the `no` option with this command to reset the value to default.

**Feature**            IPv6 Commands

**Mode**              Interface Mode

**Release**            4.2

**Options**

Option	Description	Range	Default Value
<seconds>	Specifies the number of seconds between IPv6 router advertisements. Valid values are from 4 to 1800 seconds.	4-1800	600

**Note**                Router Advertisements will not be transmitted unless you have applied the `no ipv6 nd suppress-ra` command. This step is included in the example below.

**Example**            To set a router advertisement interval of 800 seconds on `vlan4`, use the following commands:

```
awplus(config)# interface vlan4

awplus(config-if)# ipv6 nd ra-interval 800

awplus(config-if)# no ipv6 nd suppress-ra
```

**IPv6 ND RS-ATTEMPTS (CONFIG-IF)**

**Syntax**            `ipv6 nd rs-attempts <attempts>`  
                     `no ipv6 nd rs-attempts`

**Description**       This command sets the maximum number of RS (Router Solicitation) attempts that will be sent when attempting to locate routers on the subnet. Use the `no` parameter with this command to reset the value to the default.

**Feature**            IPv6 Commands

**Mode**               Interface Config

**Release**            4.2

**Options**

Option	Description	Range	Default Value
attempts	Sets the maximum number of attempts	0-600	3

**Note**                NA

**Example**            To set the number of attempts to 60, use the following command:  
`awplus(config-if)# ipv6 nd rs-attempts 60`

## IPv6 ND RS-DELAY (CONFIG-IF)

**Syntax**            `ipv6 nd rs-delay <seconds>`  
                     `no ipv6 nd rs-delay`

**Description**       This command sets the maximum extent for the random time delay that will be applied before performing RS (Router Solicitation). Use the `no` parameter with this command to reset the value to the default

**Feature**            IPv6 Commands

**Mode**              Interface Mode

**Release**            4.2

### Options

Option	Description	Range	Default Value
seconds	Sets the maximum number of attempts	1-600	1

**Note**                NA

**Example**            To set the delay to 10 seconds, use the following command:

```
awplus(config-if)# ipv6 nd rs-delay 10
```

**IPv6 ND RS-INTERVAL (CONFIG-IF)**

**Syntax**            `ipv6 nd rs-interval <seconds>`  
                     `no ipv6 nd rs-interval`

**Description**       This command sets the interval in seconds between RS (Router Solicitation) retries. Use the `no` parameter with this command to reset the value to the default.

**Feature**            IPv6 Commands

**Mode**               Interface mode

**Release**            4.2

**Options**

Option	Description	Range	Default Value
seconds	Sets the interval between each solicitation message	1-600	4

**Note**                NA

**Example**            To set the delay to 5 seconds, use the following command:

```
awplus(config-if)# ipv6 nd rs-interval 5
```

### IPv6 ND SUPPRESS-RA (CONFIG-IF)

**Syntax**            `ipv6 nd suppress-ra`  
                     `no ipv6 nd suppress-ra`

**Description**      Use this command to inhibit IPv6 Router Advertisement (RA) transmission for the current interface. Router advertisements are used when applying IPv6 stateless auto-configuration. Use no parameter with this command to enable Router Advertisement transmission. The default state is suppression of RA messages.

**Feature**            IPv6 Commands

**Mode**              Interface mode

**Release**            4.2

**Options**            NA

**Note**               Router Advertisement (RA) transmission is suppressed by default.

**Example**            To enable the transmission of router advertisements from interface vlan4 on the switch, use the following commands:

```
awplus(config)# interface vlan4
```

```
awplus(config-if)# no ipv6 nd suppress-ra
```

## IPv6 ROUTE (CONFIG)

**Syntax**

```

ipv6 route {<dest-prefix/length> | <dest-addr/length>} <gateway-addr> [vlan]
ipv6 route {<dest-prefix/length> | <dest-addr/length>} vlan
no ipv6 route {<dest-prefix/length> | <dest-addr/length>} <gateway-addr>
[vlan]
no ipv6 route {<dest-prefix/length> | <dest-addr/length>} vlan

```

**Description** Use this command to add IPv6 static routes. Use the no variant of this command to remove static routes

**Feature** IPv6 Commands

**Mode** Global Configuration mode

**Release** 4.2

### Options

Option	Description	Range	Default Value
dest-prefix/ length	Specifies a prefix as the route destination. The prefix must be of the form X:X:X::/prefix-length. The pre-fix-length is between 0 and 64, or has the value 128.	0-64	NA
dest-addr/ length	Specifies a host address as the route destination. The host address must be of the form X:X::X:X/128.	128	NA
gateway-addr	Specifies the gateway IPv6 address using the form X:X::X:X. The prefix length is usually set between 0 and 64, or has the value 128.	NA	NA
vlan	Specifies the outgoing interface to be used for the route in the form vlannn.	NA	NA

**Note** A static default route can be configured by using the unspecified address '::'. A maximum of one default route can be configured at a time,

### Example

```

awplus# configure terminal
awplus(config)# ipv6 route 2001:0db8::1/128 2001:2:3::1

```



## PING IPV6

**Syntax** `ping ipv6 <destination> [interface <vlan-id>]`

**Description** This command sends a query to another IPv6 host (send Echo Request messages). The user can also specify which interface the ping requests should be sent on.

**Feature** IPv6 Commands

**Mode** Privileged Exec mode

**Release** 4.2

### Options

Option	Description	Range	Default Value
destination	The destination IP address or hostname.	NA	NA
Vlan-id	The outgoing interface to use.	NA	NA

**Note** When the destination is a link-local address the outgoing interface must be specified.  
The ping command may take some time to complete. It can be interrupted at any time by pressing ctrl-c

### Example

```
aawplus# ping ipv6 www.ipv6.apple.com
PING www.ipv6.apple.com (2001:41a8:24:4::c316:c8d2): 56 data bytes
64 bytes from 2001:41a8:24:4::c316:c8d2: seq=0 ttl=56 time=73.852 ms
64 bytes from 2001:41a8:24:4::c316:c8d2: seq=1 ttl=56 time=73.511 ms
64 bytes from 2001:41a8:24:4::c316:c8d2: seq=2 ttl=56 time=73.346 ms
64 bytes from 2001:41a8:24:4::c316:c8d2: seq=3 ttl=56 time=73.667 ms
```

```
--- 2001:41a8:24:4::c316:c8d2 ping statistics ---
4 packets transmitted, 4 packets received, 0% packet loss
round-trip min/avg/max = 73.346/73.594/73.852 ms
```

## SHOW IP NAME-SERVER (IPv6)

**Syntax**            `show ip name-server`

**Description**        This command displays the list of DNS servers your device sends DNS requests to. On the iMG these server addresses can be set statically using the [ip name-server \(config\) - IPv6](#) command, or dynamically using the ipv6 DHCP option 24 in the `ipv6 dhcp client request domain-name-servers` command.

The iMG supports up to 2 concurrent IPv4 and 2 concurrent IPv6 DNS server addresses (so a combined maximum of 4). Note that setting a static server address discards any dynamically set DNS server addresses. So this command will show either static or dynamic DNS server addresses - but not both at once.

**Feature**            IP Addressing and Protocol Commands

**Mode**              Privileged Exec Mode

**Release**           4.2

**Options**           N/A

**Note**               NA

**Example**           To display the list of DNS servers that your device sends DNS requests to, use the command

```
awplus# show ip name-server
DNS Name Servers:
2001:5c0:1000:11::2
```

## SHOW IPV6 FORWARDING

<i>Syntax</i>	ping ipv6 [<host> <ipv6-address>]
<i>Description</i>	Use this command to display IPv6 forwarding status.
<i>Feature</i>	IPv6 Commands
<i>Mode</i>	Privileged Exec mode
<i>Release</i>	4.2
<i>Options</i>	NA
<i>Note</i>	NA

### Example

```
awplus# show ipv6 forwarding
ipv6 forwarding is on
```

## SHOW IPV6 GENERAL-PREFIX

<i>Syntax</i>	show ipv6 general-prefix
<i>Description</i>	Use this command to display IPv6 general prefix information.
<i>Feature</i>	IPv6 Commands
<i>Mode</i>	Privileged Exec mode
<i>Release</i>	4.2
<i>Options</i>	NA
<i>Note</i>	NA

### Example

```
awplus# show ipv6 general-prefix
IPv6 Prefix my-prefix, acquired via DHCP PD
2001:5c0:1515:3afc::/63 Valid lifetime 2592000, preferred lifetime 604800
  brv11.11 (Address command)
  brv33.33 (Address command)
```

## SHOW IPV6 INTERFACE BRIEF

**Syntax**            `show ipv6 interface brief`

**Description**      Use this command to display summary information about IPv6 interfaces.

**Feature**            IPv6 Commands

**Mode**              Privileged Exec mode

**Release**           4.2

**Options**           NA

**Note**              NA

### Example

```
awplus# show ipv6 interface brief
```

Interface	IPv6-Address	Status	Protocol
vlan1	fe80::20c:25ff:fe03:9a18/64	admin up	down
vlan7	unassigned	admin down	down
vlan10	unassigned	admin down	down
vlan20	unassigned	admin down	down
vlan40	unassigned	admin down	down

## SHOW IPV6 INTERFACE VERBOSE

**Syntax** `show ipv6 interface verbose <vlan_ID>`

**Description** Use this command to display comprehensive information for a specific IPv6 interface.

**Feature** IPv6 Commands

**Mode** Privileged Exec mode

**Release** 4.2

**Options**

Option	Description	Range	Default Value
vlan_ID	The interface of interest.	NA	NA

**Note** NA

**Example**

```
awplus# show ipv6 interface verbose vlan11
```

```
vlan11 is admin up, line protocol is down
IPv6 is enabled, link-local address is fe80::20d:ff:fe0a:109/64
Global unicast address(es):
  2001:5c0:1515:3afc:20d:ff:fe0a:109/64
RA router advertisements: enabled
RA router advertisements are sent every: 600 seconds
RA router advertisement minimum interval: 3 seconds
RA managed config flag: disabled
RA other config flag: enabled
ND number of DAD attempts: 3
ND number of router solicitation attempts: 3
ND router solicitation delay: 1 second
ND router solicitation interval: 4 seconds
```

## SHOW IPV6 NEIGHBORS

<i>Syntax</i>	show ipv6 neighbors
<i>Description</i>	Use this command to display IPv6 neighbor information.
<i>Feature</i>	IPv6 Commands
<i>Mode</i>	Privileged Exec mode
<i>Release</i>	4.2
<i>Options</i>	NA
<i>Note</i>	NA

### Example

```
awplus# show ipv6 neighbors
```

IPv6 Address	MAC Address	State	Interface	
fe80::20c:25ff:fe01:801	00:0c:25:01:08:01	STALE	brv11.11	router
fe80::210:18ff:feaf:216d	00:10:18:af:21:6d	REACHABLE	brv2.2	router

## SHOW IPV6 ROUTE

<b>Syntax</b>	show ipv6 route
<b>Description</b>	Use this command to display the IPv6 routing table.
<b>Feature</b>	IPv6 Commands
<b>Mode</b>	Privileged Exec mode
<b>Release</b>	4.2
<b>Options</b>	NA
<b>Note</b>	NA

### Example

```
awplus# show ipv6 route
```

Destination	NextHop	Interface	Protocol
2001:5c0:1515:3a00::/64	::	vlan2	INTERFACE
2001:5c0:1515:3a30::/64	::	vlan11	INTERFACE
2001:5c0:1515:3a40::/64	::	vlan22	INTERFACE
2001:5c0:1515:3a50::/64	::	vlan33	INTERFACE
2001:5c0:1515:3a30::/60	2001:5c0:1515:3a00::43	vlan2	STATIC
2001:5c0:1515:3a50::/60	::	vlan33	STATIC
::/0	fe80::210:18ff:feaf:216d	vlan2	RADV



## TRACEROUTE IPV6

**Syntax** `traceroute ipv6 <destination>`

**Description** Use this command to trace the route to the specified IPv6 host.

**Feature** IPv6 Commands

**Mode** Privileged Exec mode

**Release** 4.2

### Options

Option	Description	Range	Default Value
destination	A hostname or IPv6 numeric address	NA	NA

**Note** The traceroute command may take some time to complete. It can be interrupted at any time by pressing ctrl-c.

### Example

```
awplus# traceroute ipv6 www.ipv6.apple.com
traceroute to www.ipv6.apple.com (2001:41a8:24:4::c316:c8d2), 30 hops max, 16 byte packets
 1  2001:5c0:1515:3a00::1 (2001:5c0:1515:3a00::1)  0.546 ms  0.493 ms  0.410 ms
 2  2001:5c0:1400:b::be56 (2001:5c0:1400:b::be56)  47.592 ms  47.733 ms  47.880 ms
 3  2001:4de0:1000:a22::1 (2001:4de0:1000:a22::1)  44.493 ms  51.578 ms  47.388 ms
 4  2001:4de0:a::1 (2001:4de0:a::1)  84.620 ms  44.451 ms  52.668 ms
 5  2001:7f8:1::a500:6939:1 (2001:7f8:1::a500:6939:1)  49.058 ms  50.635 ms  48.767 ms
 6  2001:7f8:1::a500:6762:1 (2001:7f8:1::a500:6762:1)  48.066 ms  49.778 ms  45.612 ms
 7  2001:41a8:24:4::1 (2001:41a8:24:4::1)  76.000 ms  77.965 ms  129.501 ms
 8  * 2001:41a8:24:4::c316:c8d2 (2001:41a8:24:4::c316:c8d2)  92.070 ms  87.653 ms
```

## 4. Switching

This section gives an overview about iMG physical interfaces and Layer 2 switching functionalities.

---

### 4.1 Physical Layer

#### 4.1.1 Port attributes

Each physical data interface is univocally identified by a port number.

The software supports a number of features at the physical level that allow it to be connected in a variety of physical networks. Depending on the type of the physical interface there are a set of attributes that can be unique or common to each interface.

The following is an abstract of the attributes supported by each interface type:

Port Type	Attributes Supported
LAN (copper)	<ul style="list-style-type: none"><li>• Enabling/Disabling</li><li>• Fixed speed: 10/100/1000</li><li>• Fixed duplex: half/full</li><li>• Speed Autonegotiation</li><li>• Flow Control</li><li>• Egress/ingress rate limiting</li><li>• Default CoS value</li><li>• QoS method: CoS/ToS</li><li>• Protected/Unprotected</li><li>• Jumbo Frame</li><li>• Q-n-Q</li><li>• Mirror</li><li>• Loop Protection</li></ul>

Port Type	Attributes Supported
WAN (fiber)	<ul style="list-style-type: none"> <li>• Enabling/Disabling</li> <li>• Fixed speed: 100/1000</li> <li>• Speed Autonegotiation</li> <li>• Flow Control</li> <li>• Egress/ingress rate limiting</li> <li>• Default CoS value</li> <li>• QoS method: CoS/ToS</li> <li>• Protected/Unprotected</li> <li>• Jumbo Frame</li> <li>• Q-n-Q</li> <li>• Mirror</li> </ul>
HPNA	<ul style="list-style-type: none"> <li>• Enabling/Disabling</li> <li>• Loop Protection</li> </ul>
Wi-Fi	<ul style="list-style-type: none"> <li>• Enabling/Disabling</li> <li>• Authentication &amp; Encryption</li> </ul>

#### 4.1.2 Port Numbering

Ports are numbered using a 3 digit format x.y.z where x is the device number (within a stacked configuration), y is the module number within the device, and z is the port number within the module. Ports connected directly to the switch chassis (rather than a pluggable module) are given the module number 0. In an unstacked configuration all device numbers are 1. For example, port number 1.0.6 represents device 1, module 0, port 6.

**Note:** On the iMG the device is always 1 and the module is always 0. The port numbering starts at 1, with the upper number depending on the number of ports. Therefore, on the iMG1505 the port range is port 1.0.1 - port 1.0.6, while on the 2505 it is port 1.0.1 - port 1.0.5.

Depending on the interface type we may have different port prefixes that are used to identify the port within the family:

- WAN/LAN interfaces (copper or active fiber) are referred as portX.Y.Z
- HPNA interfaces are referred as hpnaX.Y.Z
- GPON interfaces (for future) are referred as gponX.Y.Z
- Wi-Fi interfaces (radio interfaces) are referred as dot11radioX.Y.Z

The following table gives the current port names and port index ranges for the existing iMG models

iMG Family	iMG Models	LAN Port Names	WAN Port Names
iMG1500	iMG1505 iMG1525 iMG1525RF	port1.0.1 to port1.0.5	Port1.0.6

iMG Family	iMG Models	LAN Port Names	WANSFPPortName	Wi-Fi Port
iMG1400	iMG1405 iMG1425 iMG1425RF	port1.0.1 to port1.0.5	Port1.0.6	None
	iMG1405VW iMG1425VW	port1.0.1 to port1.0.5	Port1.0.6	dot11radio1.0.1

iMG Family	iMG Models	LAN Port Names	WAN Port Names	HPNA Port
iMG2500	iMG2522	port1.0.1 to port1.0.2	Port1.0.3	None
	iMG2504 iMG2524 iMG2524F	port1.0.1 to port1.0.4	Port1.0.5	None
	iMG2524H	port1.0.1 to port1.0.4	Port1.0.5	hpna1.0.1

iMG Family	iMG Models	LAN Port Names	WANSFPPortName
iMG2400	iMG2426F	port1.0.1 to port1.0.6	Port1.0.7

### 4.1.3 Support for using Copper interface as WAN interface

Starting from Version 4.3.1 it will be possible to use also Copper as a WAN interface. (For example on Port 1.0.1)

### 4.1.4 SFP pluggable models compatibility

Starting from software release 4.3.2, the iMG models that are designed with WAN SFP (i.e. iMG1400 and iMG2400) have introduced a compatibility check function on the SFP module. Only SFP modules that are labeled Allied Telesis are allowed to be plugged in the SFP slot. In case a module is not recognized as belonging to the supported module list, a warning message is prompted any time a user logs in and the same warning message is also tracked in the syslog file.

The following tables list the SFP modules supported by the iMG2426F model and the iMG1400 family:

iMG Model	SFPs		
iMG2426F	AT-SPFXBD-LC-13 AT-SPTX, AT-SPBD10-13, AT-SPBD20-13/I, AT-TN-P015-A, AT-SPBD20EPON-13 AT-SPFX/2 AT-SPFX/15 AT-SPBD40-15/I AT-SPBD40-13/I 1000SFP59B120L-H 1000SFP49B120L-H	AT-SPBD40-1270LU AT-SPBD40-1290LU AT-SPBD40-1310LU AT-SPBD40-1330LU AT-SPBD40-1350LU AT-SPBD40-1370LU AT-SPBD40-1390LU AT-SPBD40-1410LU AT-SPBD40-1430LU AT-SPBD40-1450LU AT-SPBD40-1470LU AT-SPBD40-1490LU AT-SPBD40-1510LU AT-SPBD40-1530LU AT-SPBD40-1550LU AT-SPBD40-1570LU AT-SPBD40-1590LU AT-SPBD40-1610LU	AT-SPBD40-1610HU AT-SPBD40-1270HU AT-SPBD40-1290HU AT-SPBD40-1310HU AT-SPBD40-1330HU AT-SPBD40-1350HU AT-SPBD40-1370HU AT-SPBD40-1390HU AT-SPBD40-1410HU AT-SPBD40-1430HU AT-SPBD40-1450HU AT-SPBD40-1470HU AT-SPBD40-1490HU AT-SPBD40-1510HU AT-SPBD40-1530HU AT-SPBD40-1550HU AT-SPBD40-1570HU AT-SPBD40-1590HU

iMG Family	SFPs		
iMG1400	AT-SPFXBD-LC-13 AT-SPTX, AT-SPBD10-13, AT-SPBD20-13/I, AT-TN-P015-A, AT-SPFX/2 AT-SPFX/15 1000SFP59B120L-H 1000SFP49B120L-H		

For units that have been produced before release 4.3.2 and that are going to be upgraded, the existing SFPs will continue to work even if they are not Allied Telesis or their model is not in the above list. In this case only the warning message is printed but the SFP is not disabled.

### 4.1.5 Using Port ranges

When entering configuration commands it's possible to refer to more than one physical interface in the same command.

Two port syntax are supported:

- Continuous range

To configure a continuous range of ports at the same time, enter the range in the format:

```
portx.y.z-portx.y.z
```

For example, to configure the same interface setting on switch ports 1-3, enter the Global Configuration mode command:

```
awplus(config)#interface port1.0.1-port1.0.3
```

- Non-continuous

To configure a non-continuous set of ports at the same time, enter a comma-separated list:

```
portx.y.z,portx.y.z
```

For example, to configure the same interface setting on base switch ports 1 and 5, enter the Global Configuration mode command:

```
awplus(config)#interface port1.0.1,port1.0.5
```

It is possible to combine a hyphen-separated range and a comma-separated list. To configure the same setting on base switch ports 1-3 and 5, enter the Global Configuration mode command:

```
awplus(config)#interface port1.0.1-port1.0.3,port1.0.5
```

### 4.1.6 Activating and Deactivating Switch Ports

An active switch port is one that is available for packet reception and transmission. By default ports and VLANs are activated. To shutdown a port or VLAN use the shutdown command. Use the no variant of this command to reactivate it.

### 4.1.7 Autonegotiation

Autonegotiation lets the port adjust its speed and duplex mode to accommodate the device connected to it.

When the port connects to another autonegotiating device, they negotiate the highest possible speed and duplex mode for both of them.

By default, all ports autonegotiate. Setting the port to a fixed speed and duplex mode may be necessary when connecting to a device that cannot autonegotiate.

### 4.1.8 Duplex mode

Ports can operate in full duplex or half duplex mode depending on the type of port it is.

When in full duplex mode, a port transmits and receives data simultaneously.

When in half duplex mode, the port transmits or receives but not both at the same time.

You can set a port to use either of these options, or allow it to autonegotiate the duplex mode with the device at the other end of the link. To configure the duplex mode, use these commands:

```
awplus# configure terminal
awplus(config)# interface port1.0.1
awplus(config-if)# duplex {auto|full|half}
```

### 4.1.9 Speed options

Before configuring a port's speed, check the hardware limit for the particular port type. The following list can be used as a guide:

- RJ-45 copper switch ports: 10, 100 or 1000 Mbps
- supported dual-speed copper SFPs: 100 or 1000 Mbps
- fiber SFPs

For the latest list of approved SFP transceivers either contact your authorized distributor or reseller, or visit <http://www.alliedtelesis.com>

You can set a port to use one of these speed options, or allow it to autonegotiate the speed with the device at the other end of the link.

Most types of switch port can operate in either full duplex or half duplex mode. In full duplex mode a port can transmit and receive data simultaneously. In half duplex mode the port can either transmit or receive, but not at the same time.

Make sure that the configuration of the switch matches the configuration of the device at the far end of the link.

In particular, avoid having one end autonegotiate duplex mode while the other end is fixed.

For example, if you set one end of a link to autonegotiate and fix the other end at full duplex, the autonegotiating end cannot determine that the fixed end is full duplex capable.

Therefore, the autonegotiating end selects half-duplex operation. This results in a duplex mismatch and packet loss.

To avoid this, either fix the mode at both ends, or use auto-negotiation at both ends.

For example to set the port speed to 1000 kbps on port1.0.1:

```
awplus# configure terminal
awplus(config)# interface port1.0.1
awplus(config-if)# speed 1000
```

### 4.1.10 Port Mirroring

Port mirroring enables traffic being received and transmitted on a switch port to be sent to another switch port, the mirror port, usually for the purposes of capturing the data with a protocol analyzer.

The mirror port is the only switch port that does not belong to a VLAN, and therefore does not participate in any other switching. Before the mirror port can be set, it must be removed from all trunk groups and all VLANs except the default VLAN.

**Note:** Due to the internal hardware properties of the switch, frames that are destined to leave the mirrored port untagged (i.e. will have their VLAN tag removed on egress) will be received by the mirror port with the tag retained.

Consequently, if frames were being transmitted by the mirror port (into the network) at wire speed, then the mirror port might be unable to accept all the frames supplied to it.

The following example sets port 1.0.2 to mirror the incoming and outgoing traffic on port 1.0.1:

```
awplus# configure terminal
awplus(config)# interface port1.0.2
awplus(config-if)# mirror interface port1.0.1
```

#### 4.1.11 Quality of Service

Quality of Service (QoS) enables you to both prioritize traffic and limit its available bandwidth. The concept of QoS is a departure from the original networking protocols, in which all traffic on the Internet or within a LAN had the same available bandwidth.

Without QoS, all traffic types are equally likely to be dropped if a link becomes oversubscribed. This approach is now inadequate in many networks, because traffic levels have increased and networks often carry time-critical applications such as streams of real-time video data.

QoS also enables service providers to easily supply different customers with different amounts of bandwidth.

In this release the iMG support port-based QoS, and P-Bit to DSCP Value queue mapping on the switch.

Key capabilities are:

- P-Bit to Queue Mapping
- DSCP Value to Queue Mapping
- P-Bit setting of incoming untagged traffic.

In a future release, there will be more control about traffic flows.

Configuring Quality of Service involves two separate stages:

1. Classifying traffic into flows, according to a wide range of criteria. Classification is performed by the switch's class maps.
2. Acting on these traffic flows.

The switch's QoS functionality includes the following:

- policies, to provide a QoS configuration for a port or ports
- traffic classes, for bandwidth limiting and user prioritization
- maximum bandwidth limiting on a traffic class
- flow groups within traffic classes, for user prioritization
- control of the egress scheduling algorithm
- priority re-labelling of frames, at Layer 2, by replacing the VLAN tag User Priority field
- class of service re-labelling of frames, at Layer 3, by replacing the DSCP (DiffServ Code Point) or the TOS precedence
- value in the IP header's Type of Service (TOS) field.

#### 4.1.12 Loop Protection

Loop Protection is a feature designed to detect the packet loop caused by the network fault, and once a suspected loop-back condition has been detected, the software will attempt to remove the loop by disabling a switch port involved in the loop.

Loop detection works by sending Loop Detection Frames (LDFs) out from the switch ports.

The LDF is a layer 2 LLC frame with a unique MAC address of a non-existent end station.

If the switch receives the LDF it generated on the same VLAN that the LDF was originally transmitted on, then a loop must exist somewhere in the network that includes the ports of the switch.



Loop detection can be enabled and disabled, and on a per-port basis. The feature is disabled by default.

LDFs will be transmitted at a user configurable rate LDFInterval.

For the security, LDFs have an identifier field that is a randomly generated identifier code.

Loop detection validates the field in received LDF (for VLAN, each identifier will be kept for validation) is accepted and anything else is discarded. This prevents denial of service attacks.

Loop detection must be enabled and configured at global level by entering the following commands:

```
awplus# configure terminal
awplus(config)# loop-protection loop-detect
awplus(config-if)# loop-protection loop-detect ldf-interval 20
```

Then it must be enabled on port interfaces:

```
awplus# configure terminal
awplus(config)# interface port1.0.1-port1.0.4
awplus(config)# loop protection
```

### 4.1.13 Port Security

Port security is available on iMG2400, iMG2500 and iMG1500V2 devices.

Port Security is a feature designed to limit access to the network to either, a set number of devices per port, or a specific device on a port by screening traffic based on the source MAC Address. This is done by limiting the number of MAC Addresses on a specific port – or it is possible to actually configure a specific MAC Address to be allowed on a port.

```
awplus(config)# interface port1.0.4
awplus(config)# switchport port-security
awplus(config)# mac address-table static <mac address> interface <port>
```

When this feature is enabled on a port all received traffic is forwarded to the CPU so that the MAC Address can be learned and populated against that specific port. From that point on, traffic received from that MAC Address is forwarded as normal. By default the port will allow up to five MAC addresses per port (there is a limit of 20 per device). This limit can be adjusted via cli.

```
awplus(config)# switchport port-security maximum <int 1-5>
```

By default the MAC address learned is static and persists thru restarts. This ensures that only a fixed set of devices that remain the same can transmit over that port. If instead, the intent is just to limit the number of devices that can be used, it is possible to enable Aging which will remove the MAC Addresses from the list – once they age out of the FDB.

```
awplus(config)# switchport port-security aging
```

Finally, the action taken when a device is detected that exceeds the specified limits can be specified. By default the mode is “protect” that means that the system logs the fact that the MAC address was detected and blocked, adds that MAC to the intrusion list and discards incoming traffic from that device. It is also possible to perform more drastic actions shutdown the port. Recovering a port that has been shut down due to violations requires manual interventions. Allowing access for a MAC that has been detected and placed in the Intrusion list requires that the intrusion list be cleared.

#### 4.1.14 Port Security Command List

This chapter provides an alphabetical reference of configure, clear, and show commands related to Port Security.

Table 4-1: Port Security Commands

Commands
<code>clear port-security intrusion interface</code>
<code>show port-security interface</code>
<code>show port-security intrusion</code>
<code>switchport port-security</code>
<code>switchport port-security aging</code>
<code>switchport port-security maximum</code>
<code>switchport port-security violation</code>

**CLEAR PORT-SECURITY INTRUSION INTERFACE**

**Syntax** `clear port-security intrusion interface <port | port range>`

**Description** This command clears the set of MAC Addresses that have been detected as outside the limits – and enables them to be considered for valid devices. This can be useful if the maximum MAC Address limit has been increased.

**Feature** Switching Commands

**Mode** User Exec and Privileged Exec

**Release** 4.6

**Options**

Option	Description	Range	Default Value
<port>	The switch port (e.g. port1.0.1)	NA	NA
<port range>	The set of switch ports to display information for. (e.g. port1.0.1-4)	NA	NA

**Note** This feature is not supported on HPNA or Wireless interfaces.

**Example** To clear the list if MAC blocked on a port by port-security:

```
awplus# show port-security intrusion interface port1.0.1
```

```
Interface port1.0.1
```

```
Intrusions:
```

```
EC:CD:6D:DC:85:8B
00:0C:25:23:C0:06
00:0C:25:23:C0:00
00:0D:DA:0B:87:19
00:0C:25:03:87:24
00:0D:DA:0C:FD:27
00:0C:25:27:AB:B1
00:0C:25:29:03:42
00:04:23:5F:EB:27
00:0D:DA:0E:72:3D
```

```
awplus# clear port-security intrusion interface port1.0.1
```

```
awplus# show port-security intrusion interface port1.0.1
```

```
Interface port1.0.1
```

```
Intrusions:
```

## SHOW PORT-SECURITY INTERFACE

**Syntax** `show port-security interface <port | port range>`

**Description** This command displays the port security configuration and status on the associated port.

**Feature** Switching Commands

**Mode** User Exec and Privileged Exec

**Release** 4.6

**Options**

Option	Description	Range	Default Value
<port>	The switch port (e.g. port1.0.1)	NA	NA
<port range>	The set of switch ports to display information for. (e.g. port1.0.1-4)	NA	NA

**Note** This feature is not supported on HPNA or Wireless interfaces.

**Example** To display the port security status and configuration on a particular port:

```
awplus# show port-security interface port1.0.1
Interface port1.0.1
  Enable:          TRUE
  Aging:           FALSE
  Maximum:         2
  Violation Action: Protect
  MAC Address list
    Number of entries: 1
  1)00:0C:25:03:9A:14 (learned)
```

## SHOW PORT-SECURITY INTRUSION

**Syntax** `show port-security intrusion <port | port range>`

**Description** This command displays the MAC Addresses that were detected on a port for which traffic is blocked.

**Feature** Switching Commands

**Mode** User Exec and Privileged Exec

**Release** 4.6

**Options**

Option	Description	Range	Default Value
<port>	The switch port (e.g. port1.0.1)	NA	NA
<port range>	The set of switch ports to display information for. (e.g. port1.0.1-4)	NA	NA

**Note** This feature is not supported on HPNA or Wireless interfaces.

**Example** To display the port security status and configuration on a particular port:

```
awplus# show port-security intrusion interface port1.0.1
```

```
Interface port1.0.1
```

```
Intrusions:
```

```
EC:CD:6D:DC:85:8B
00:0C:25:23:C0:06
00:0C:25:23:C0:00
00:0D:DA:0B:87:19
00:0C:25:03:87:24
00:0D:DA:0C:FD:27
00:0C:25:27:AB:B1
00:0C:25:29:03:42
00:04:23:5F:EB:27
00:0D:DA:0E:72:3D
```

## SWITCHPORT PORT-SECURITY

**Syntax**            `switchport port-security`  
                     `no switchport port-security`

**Description**       This command enables port security on the associated port.

Use the no variant of this command to disable the feature.

Traffic is only forwarded for devices whose MAC Address is known to the system. By default the number of MAC Addresses is limited to 5 and they are learned as new source MAC addresses are detected on the port. The learning process by default is static and survives restarts so that it is not possible to for the customer to change to a different device without manual intervention. By default the behavior when exceeding the number of allowed MAC Addresses – is to discard any traffic from additional devices.

**Feature**            Switching Commands

**Mode**              Interface Configuration

**Release**            4.6

**Options**            NA

**Note**               This feature is not supported on HPNA or Wireless interfaces.

**Example**            To enable port security on a particular port:

```
aawplus(config)# interface port1.0.1
awplus(config-if)# switchport port-security
```

```
awplus(config-if)# do show port-security interface port1.0.1
```

```
Interface port1.0.1
  Enable:                TRUE
  Aging:                 FALSE
  Maximum:               2
  Violation Action:      Protect
  MAC Address list
    Number of entries: 1
    1) 00:0C:25:03:9A:14 (learned)
```

```
awplus(config)# interface port1.0.1
awplus(config-if)# no switchport port-security
```

## SWITCHPORT PORT-SECURITY AGING

**Syntax**            switchport port-security aging  
                      no switchport port-security aging

**Description**      This command activates Port Security aging of learned MAC Addresses.

Use the no variant of this command to disable aging.

By default the MAC Addresses are learned statically so it is not possible to switch out devices. By enabling Aging, the Port Security feature ages out the learned entries in a similar manner as the MAC Address table. Enabling Aging also causes any learned MAC Addresses to be flushed upon a restart.

**Feature**            Switching Commands

**Mode**              Interface Configuration

**Release**            4.6

**Options**            NA

**Note**                NA

**Example**            To enable port security aging on a particular port:

```
awplus(config)# interface port1.0.1
awplus(config-if)# switchport port-security aging

awplus(config-if)# do show port-security interface port1.0.1
```

```
Interface port1.0.1
  Enable:                TRUE
  Aging:                  TRUE
  Maximum:                2
  Violation Action:      Protect
  MAC Address list
    Number of entries: 1
    1) 00:0C:25:03:9A:14 (learned)
```

```
awplus(config)# interface port1.0.1
awplus(config-if)# no switchport port-security aging
```

**SWITCHPORT PORT-SECURITY MAXIMUM**

**Syntax**            switchport port-security maximum <1-5>  
                      no switchport port-security maximum

**Description**       This command Controls the number of MAC Addresses that the Port Security feature will allow on a port.

Use the no variant of this command to reset to the default (5).

**Feature**            Switching Commands

**Mode**               Interface Configuration

**Release**            4.6

**Options**

Option	Description	Range	Default Value
<1-5>	The number of MAC Addresses to allow on a port.	1 - 5	5

**Note**                NA

**Example**            To enable port security aging on a particular port:

```
awplus(config)# interface port1.0.1
awplus(config-if)# switchport port-security maximum 3

awplus(config-if)# do show port-security interface port1.0.1

Interface port1.0.1
  Enable:                TRUE
  Aging:                  FALSE
  Maximum:                3
  Violation Action:      Protect
  MAC Address list
    Number of entries: 1
    1) 00:0C:25:03:9A:14 (learned)

awplus(config)# interface port1.0.1
awplus(config-if)# no switchport port-security maximum
```



## SWITCHPORT PORT-SECURITY VIOLATION

**Syntax**      `switchport port-security violation [protect | shutdown]`  
`no switchport port-security violation`

**Description**      This command Controls the Port Security behavior when a source MAC Address is detected beyond those allowed.

Use the no variant of this command to reset to the default (protect).

Regardless of the violation mode a the MAC is added to the intrusion list (limited to 10 instances) and a log is generated recording the MAC Address that was rejected. If a MAC Address is added to the Intrusion list, a manual action is required to remove it. If a port is shut down, a manual action is required to bring it back into service.

**Feature**      Switching Commands

**Mode**      Interface Configuration

**Release**      4.6

### Options

Option	Description	Range	Default Value
protect	Traffic from any MAC Address outside the limits is discarded.	NA	NA
shutdown	When a MAC Address outside the limits is detected, the port is shutdown.	NA	NA

**Note**      In all cases, when a violation is detected, a log is generated and the MAC Address is added to the Intrusion list.

**Example**      To enable port security shutdown on a particular port:

```
awplus(config)# interface port1.0.1
awplus(config-if)# switchport port-security violation shutdown

awplus(config-if)# do show port-security interface port1.0.1
Interface port1.0.1

  Enable:                TRUE
  Aging:                 FALSE
  Maximum:               1
  Violation Action:      Shutdown
  MAC Address list
    Number of entries: 1
    1) 00:0C:25:03:9A:14 (learned)
```

### 4.1.15 HPNA Interface

In release 4.2 the iMG2524H model is introduced that includes an HPNA interface. Refer to Interfaces for a list of features.

### 4.1.16 Wireless Interface

In release 4.3 the iMG1425W model is introduced which includes an IEEE 802.11 wireless interface. Refer to Interfaces for a list of features.

### 4.1.17 The Layer 2 Switching Process

The Layer 2 switching process comprises these related but separate processes:

- The Ingress Rules
- The Learning Process
- The Forwarding Process
- The Egress Rules

Ingress rules admit or discard frames based on their VLAN tagging.

The Learning process learns the MAC addresses and VLAN membership of frames admitted on each port.

The Forwarding process determines which ports the frames are forwarded to, and the Quality of Service priority with which they are transmitted.

Finally, Egress rules determine for each frame whether VLAN tags are included in the Ethernet frames that are transmitted.

These processes assume that each station on the extended LAN has a unique data link layer address, and that all data link layer frames have a header which includes the source (sender's) MAC address and destination (recipient's) MAC address.

#### 4.1.17.1 The Ingress Rules

All frames, tagged and untagged, that a VLAN-aware switch receives must be classified into a VLAN.

Each received frame is mapped to exactly one VLAN.

If an incoming frame is tagged with a valid VLAN identifier (VID) then that VID is used.

If an incoming frame is untagged or is priority tagged (a tagged frame with a VID of all zeros), then the switch uses internal VLAN association rules to determine the VLAN it belongs to.

The default setting for the ingress rules is to Admit All Frames.

Ingress Filtering is always disabled.

Every port belongs to one or more VLANs so every incoming frame has a VID to show which VLAN it belongs.

The final part of the Ingress Rules is Ingress Filtering, which is always disabled; frames are admitted even if they have a VID of a VLAN to which the port not belongs but that exists in the system VLAN database.

Each port on the switch can be configured to be one of two modes:

- only untagged frames - access mode
- tagged & untagged frames - trunk mode

#### 4.1.17.2 Access Mode

This mode can be used to connect to VLAN unaware devices. Frames to and from access mode ports carry no VLAN tagging information.

#### 4.1.17.3 Trunk Mode

This mode is used to connect VLAN capable devices. All devices that connect using trunk mode ports must be VLAN aware.

#### 4.1.17.4 The Learning Process

- The learning process uses an adaptive learning algorithm, sometimes called backward learning, to discover the location of each station on the extended LAN.

All frames admitted by the ingress rules on any port are passed on to the forwarding process when they are for destinations in the same VLAN.

Frames destined for other VLANs are passed to a Layer 3 protocol, such as IP.

For every frame admitted, the frame's source MAC address and VID are compared with entries in the forwarding database for the VLAN (also known as a MAC Address table) maintained by the switch.

When the frame's source address is not in the forwarding database for the VLAN, the address is added and an ageing timer for that entry is started.

When the frame's source address is already in the forwarding database, the ageing timer for that entry is restarted.

By default, switch learning is enabled.

Switch Learning can be disabled with:

```
no mac address-table acquire
```

and re-enabled using:

```
mac address-table acquire.
```

If the ageing timer for an entry in the forwarding database expires before another frame with the same source address is received, the entry is removed from the forwarding database.

This prevents the forwarding database from being filled with information about stations that are inactive or have been disconnected from the network.

It also ensures that entries for active stations are kept alive in the forwarding database.

By default, the ageing timer is enabled with a default ageing-time.

The ageing timer can be reset to the default with the command:

```
no mac address-table ageing-time
```

The ageing timer can be increased or decreased using:

```
mac address-table ageing-time
```

If switch learning is disabled and the ageing timer has aged out all dynamically learned filter entries, only statically entered MAC source addresses decide the packets to forward or discard.

When the switch finds no matching entries in the forwarding database during the forwarding process, all switch ports in the VLAN are flooded with the packet, except the port that received it.

The default value for the mac address-table ageing-time is 300 seconds (5 minutes).

To set the mac address-table ageing-time to 1000 seconds:

```
awplus# configure terminal
awplus(config)# mac address-table ageing-time 1000
```

To display the settings for switch learning and the switch ageing timer, use the command:

```
awplus# show mac address-table ageing-time
MAC address learning is enabled.
Ageing time is 300 seconds.
```

#### 4.1.17.5 The Forwarding Process

After a VID is assigned to a frame using the ingress rules, the switch forwards it to the destination MAC address specified in the frame.

To do this the switch must learn which MAC addresses are available on each port for each VLAN.

When the destination MAC address is not found, the switch floods the frame on all ports that are members of the VLAN except the port on which the frame was received.

The forwarding database (also known as the MAC Address table) determines the egress port on which the destination MAC address has been learned.

MAC addresses are learned dynamically as part of the layer two switching process.

The forwarding database is ordered according to MAC address and VLAN identifier.

This means a MAC address can appear more than once in the forwarding database having been learned on the same port but for different VLANs.

This could occur if the IP address of an end station is changed thereby moving the end station to a different IP subnet-based VLAN while still connected to the same switch port.

When the forwarding database ageing process is enabled, old entries in the forwarding database are deleted after a user-configurable period.

#### 4.1.17.6 The Egress Rules

After the forwarding process has determined from which ports and transmission queues to forward a frame, the egress rules for each port determine whether the outgoing frame is VLAN-tagged with its numerical VLAN identifier (VID).

A port must belong to a VLAN at all times unless the port has been set as the mirror port for the switch.

A port can transmit VLAN-tagged frames for any VLAN to which the port belongs. A port can transmit untagged frames for any VLAN for which the port is configured, e.g. IP subnet-based or protocol-based, unless prevented by the port-based VLAN egress rules.

A port that belongs to a port-based VLAN can transmit untagged packets for only one VLAN.

#### 4.1.17.7 Layer 2 Filtering

The switch has a forwarding database (also known as the MAC address table) whose entries determine whether frames are forwarded or discarded over each port.

Entries in the forwarding database are created dynamically by the learning process.

A dynamic entry is automatically deleted from the forwarding database when its ageing timer expires.

The forwarding database supports queries by the forwarding process as to whether frames with given values of the destination MAC address field should be forwarded to a given port.

For each VLAN, the destination MAC address of a frame to be forwarded is checked against the forwarding database.

If there is no entry for the destination address and VLAN, the frame is transmitted on all ports in the VLAN that are in the forwarding or disabled state, except the port on which the frame was received. This process is referred to as flooding.

If an entry is found in the forwarding database but the entry is not marked forwarding or the entry points to the same port the frame was received on, the frame is discarded. Otherwise, the frame is transmitted on the port specified by the forwarding database.

#### 4.1.17.8 Ingress Filtering

Each port on the switch belongs to one or more VLANs. Since ingress filtering is always enabled, any frame received on the specified port is only admitted if its VID matches one for which the port is tagged.

Any frame received on the port is discarded if its VID does not match one for which the port is tagged. Untagged frames are admitted and are assigned the VLAN Identifier (VID) of the port's native VLAN.

#### **4.1.17.9 IGMP Snooping**

IGMP (Internet Group Management Protocol) is used by IP hosts to report their multicast group memberships to routers and switches.

IP hosts join a multicast group to receive broadcast messages directed to the multicast group address. IGMP is an IP-based protocol and uses IP addresses to identify both the multicast groups and the host members.

For a VLAN-aware devices, this means multicast group membership is on a per-VLAN basis.

If at least one port in the VLAN is a member of a multicast group, by default multicast packets will be flooded onto all ports in the VLAN.

IGMP snooping enables the switch to forward multicast traffic intelligently on the switch.

The switch listens to IGMP membership reports, queries and leave messages to identify the switch ports that are members of multicast groups.

Multicast traffic will only be forwarded to ports identified as members of the specific multicast group.

IGMP snooping is performed at Layer 2 on VLAN interfaces automatically.

By default, the switch will forward traffic only from those ports with multicast listeners, therefore it will not act as a simple hub and flood all multicast traffic out all ports.

IGMP snooping is independent of the IGMP and Layer 3 configuration, so an IP interface does not have to be attached to the VLAN, and IGMP does not have to be enabled or configured.

IGMP snooping is disabled by default.

Refer to IGMP Snooping Introduction and Configuration for more information and commands.

### 4.1.18 Switching Command List

This subsection provides an alphabetical reference for commands used to configure the Forwarding Database (FDB).

Table 4-2: Switching Commands

Commands
<a href="#">clear mac address-table dynamic</a>
<a href="#">clear mac address-table static</a>
<a href="#">clear port counter</a>
<a href="#">description</a>
<a href="#">duplex</a>
<a href="#">flowcontrol</a>
<a href="#">jumbo-frame</a>
<a href="#">loop-protection action link-down</a>
<a href="#">loop-protection loop-detect</a>
<a href="#">loop-protection timeout</a>
<a href="#">mac address-table acquire</a>
<a href="#">mirror interface</a>
<a href="#">platform vlan-stacking-tpid</a>
<a href="#">show interface switchport</a>
<a href="#">show loop-protection</a>
<a href="#">show mac address-table</a>
<a href="#">show mirror</a>
<a href="#">show platform</a>
<a href="#">show platform port counters</a>
<a href="#">show storm-control</a>
<a href="#">speed</a>
<a href="#">storm-control</a>
<a href="#">switchport block</a>

## CLEAR MAC ADDRESS-TABLE DYNAMIC

**Syntax** `clear mac address-table dynamic [vlan <vid>|interface <port>]`

**Description** This command clears from the filtering database of all the dynamic MAC entries learned for a selected interface or VLAN.

Use this command with options to clear the filtering database of all the dynamic entries learned for a given interface or VLAN. Use this command without options to clear any learned entries. Compare this usage and operation with the [clear mac address-table static](#) command.

**Feature** Switching Commands

**Mode** Privileged Exec

**Release** 4.1.2

**Options**

Option	Description	Range	Default Value
<vid>	Only dynamic entries matching the selected VID are removed from the database.	1-4094	NA
<port>	The port from which address entries will be cleared. This will be a single port, (e.g. port1.1.4),	NA	NA

**Note** NA

**Example** This example shows how to clear all dynamically learned filtering database entries for all interfaces and VLANs:

```
awplus# clear mac address-table dynamic
```

## CLEAR MAC ADDRESS-TABLE STATIC

**Syntax** `clear mac address-table static [vlan <vid>|interface <port>]`

**Description** Use this command with options to clear the filtering database of all the static entries for an interface or VLAN. Compare this usage with [clear mac address-table dynamic](#).

**Feature** Switching Commands

**Mode** Privileged Exec

**Release** 4.1.2

**Options**

Option	Description	Range	Default Value
<vid>	Only static entries matching the selected VID are removed from the database.	NA	NA
<port>	The port from which address entries will be cleared. This will be a single port, (e.g. port1.1.4),	NA	NA

**Note** Note that static MAC entries are managed by the IGMP process and it is recommended not to purge the static database to avoid issues with multicast signalling handling.

**Example** This example shows how to clear all filtering database entries configured through the CLI.

```
awplus# clear mac address-table static
```

**Example** This example shows how to clear all filtering database entries for a given interface configured through the CLI.

```
awplus# clear mac address-table static interface port1.0.1
```



**CLEAR PORT COUNTER**

**Syntax** `clear port counter [<port>]`

**Description** This command clears the packet counters of the port.

**Feature** Switching Commands

**Mode** Privileged Exec Mode

**Release** 4.1

**Options**

Option	Description	Range	Default Value
<port>	The port number or range	NA	NA

**Note** NA

**Example** To clear the packet counter for port1.0.1

```
awplus# clear port counter port1.0.1
```

**DESCRIPTION**

**Syntax** `description <string_description>`

**Description** This command specifies the description for one interface. The “no description” command restores the default value “” (empty string).

**Feature** Switching Commands

**Mode** Interface Configuration Mode

**Release** 4.3.3

**Options**

Option	Description	Range	Default Value
description	Specified description for one interface. The string can contain “space”.	1-18	Empty string

**Note** NA

**Example**

```
awplus(config)# interface port1.0.1
awplus(config-if)# description test iMG1400
```

```
awplus(config-if)# do show interface port1.0.1-port1.0.7 status
```

Port	Name	Status	Vlan	Duplex	Speed	Type
port1.0.1	test iMG1400	down	2	auto	auto	N/A
port1.0.2		down	2	auto	auto	N/A
port1.0.3		down	2	auto	auto	N/A
port1.0.4		down	2	auto	auto	N/A
port1.0.5		down	2	auto	auto	N/A
port1.0.6		down	2	auto	auto	N/A
port1.0.7		up	trunk	full	auto	N/A

## DUPLEX

**Syntax** duplex {auto|full|half}

**Description** This command changes the duplex mode for the specified port.

By default, ports auto-negotiate duplex mode (except for 100Base-FX ports which do not support auto-negotiation, so default to full duplex mode).

To see the currently-negotiated duplex mode for ports whose links are up, use [show interface](#).

**Feature** Switching Commands

**Mode** Interface Configuration

**Release** 4.1

**Options**

Option	Description	Range	Default Value
auto	Auto-negotiate duplex mode.	NA	NA
full	Operate in full duplex mode only	NA	NA
half	Operate in half duplex mode only.	NA	NA

**Note** NA

**Example** To specify full duplex for port1.0.4, enter the following commands:

```
awplus(config)# interface port1.0.4
awplus(config-if)# duplex full
```

**Example** To specify half duplex for port1.0.4, enter the following commands:

```
awplus(config)# interface port1.0.4
awplus(config-if)# duplex half
```

**Example** To auto-negotiate duplex mode for port1.0.4, enter the following commands:

```
awplus(config)# interface port1.0.4
awplus(config-if)# duplex auto
```

## FLOWCONTROL

**Syntax**           flowcontrol both  
                  no flowcontrol

**Description**     This command enables flow control, and configures the flow control mode for the switch port.

Use the no variant of this command to disable flow control for the specified switch port.

By default, flow control is enabled on all LAN ports, and disabled on the WAN interface.

The flow control mechanism specified by 802.3x is only for full duplex links. It operates by sending PAUSE frames to the link partner to temporarily suspend transmission on the link

Flow control enables connected Ethernet ports to control traffic rates during congestion by allowing congested nodes to pause link operation at the other end. If one port experiences congestion, and cannot receive any more traffic, it notifies the other port to stop sending until the condition clears. When the local device detects congestion at its end, it notifies the remote device by sending a pause frame. On receiving a pause frame, the remote device stops sending data packets, which prevents loss of data packets during the congestion period.

**Feature**           Switching Commands

**Mode**             Interface Configuration

**Release**          4.1

**Options**

Option	Description	Range	Default Value
both	Use this parameter to specify send and receive flow control for the port.	NA	NA

**Note**             NA

**Example**          To enable flow control for both send and receive, enter the following commands:

```
awplus(config)# interface port1.0.2
awplus(config-if)# flowcontrol both
```

```
awplus(config)# interface port1.1.2
awplus(config-if)# no flowcontrol
```

## JUMBO-FRAME

<b>Syntax</b>	jumbo-frame no jumbo frame
<b>Description</b>	This command is used to enable jumbo frame support for a port. Use the no form of this command to disable the jumbo-frame feature.
<b>Feature</b>	Interface Commands
<b>Mode</b>	Global Configuration Mode
<b>Release</b>	4.1.2
<b>Options</b>	NA
<b>Note</b>	Jumbo Frame can be enabled for 1000 Mbps interfaces. Maximum Frame size is 9726 bytes. Jumbo frames are not forwarded to the CPU point.
<b>Example</b>	To activate jumbo-frame support use the commands:  awplus(config)# interface port1.0.5 awplus(config_if)# jumbo-frame

## LOOP-PROTECTION ACTION LINK-DOWN

<b>Syntax</b>	<code>loop-protection action link-down</code> <code>no loop-protection action link-down</code>
<b>Description</b>	This command enables loop protection on the selected interface. In order to have loop protection working in the interface it's necessary also to enable loop-protection at global level. Use the no version of the command to disable loop-protection on the selected interface.
<b>Feature</b>	Switching Commands
<b>Mode</b>	Privileged Exec
<b>Release</b>	4.3
<b>Options</b>	NA
<b>Note</b>	NA
<b>Example</b>	<p>In this example loop-protection is enabled on port1.0.1:</p> <pre>awplus(config)# loop-protection loop-detect awplus(config)# interface port1.0.1 awplus(config-if)# loop-protection action link-down</pre>

## LOOP-PROTECTION LOOP-DETECT

**Syntax**      `loop-protection loop-detect { ldf-interval <loopInterval>}`  
`no loop-protection loop-detect { ldf-interval }`

**Description**      This command when entered without the option ldf-interval enables loop protection at system level. Use the optional parameter ldf-interval to control the interval for sending LDF frames. Use the no version of the command to disable loop-protection or to return the LDF interval to the default value.

**Feature**      Switching Commands

**Mode**      Privileged Exec

**Release**      4.3

**Options**

Option	Description	Range	Default Value
loopInterval	The interval in seconds between loop detection frames	5-600 secs	30

**Note**      NA

**Example**      In this example loop-protection is enabled and LDF interval is configured to 20 seconds:

```
awplus(config)# loop-protection loop-detect
awplus(config)# loop-protection loop-detect ldf-interval 20
```

## LOOP-PROTECTION TIMEOUT

**Syntax**            `loop-protection timeout <time>`  
                     `no loop-protection timeout`

**Description**       This command specifies the duration the port will be disabled when a loop is detected. After the port timeout expires the port is re-enabled and LDF frames are transmitted again. Use the no version of the command to return the timeout interval to the default value.

**Feature**            Switching Commands

**Mode**               Privileged Exec

**Release**            4.3

**Options**

Option	Description	Range	Default Value
time	The duration in seconds the port is kept disabled before LDF frames are retransmitted.	0-86400 secs	10

**Note**                This becomes the generic Timeout value, but it will not be applied to each port until that port has loop detect reconfigured - or the system is restarted.

**Example**            In this example loop-protection is enabled and LDF interval is configured to 15 seconds:

```
awplus(config)# loop-protection timeout 15
```



## MAC ADDRESS-TABLE ACQUIRE

<b>Syntax</b>	<code>mac address-table acquire</code> <code>no mac address-table acquire</code>
<b>Description</b>	Use this command to enable or disable MAC address learning on the device. To disable learning, use the no variant of this command.
<b>Feature</b>	Switching Commands
<b>Mode</b>	Global Configuration Mode
<b>Release</b>	4.1.2
<b>Options</b>	NA
<b>Note</b>	Learning is enabled by default.
<b>Example</b>	The following example shows disabling MAC address learning:  <code>awplus#(config)# no mac address-table acquire</code>

## MAC ADDRESS-TABLE AGEING-TIME

**Syntax**            `mac address-table ageing-time <ageing-timer>`  
                     `no mac address-table ageing-time`

**Description**        This command specifies an ageing-out time for a learned MAC address. The learned MAC address will persist for at least the specified time.

The no variant of this command will reset the ageing-out time back to the default value of 300 seconds (5 minutes).

**Feature**            Switching Commands

**Mode**                Global Configuration Mode

**Release**            4.1.2

**Options**

Option	Description	Range	Default Value
<ageing-timer>	The number of seconds of persistence.	<1-1000000>	300

**Note**                NA

**Example**            The following examples show specifying the time-out for learned MAC addresses:

```
awplus#(config)# mac address-table ageing-time 1000
awplus#(config)# no mac address-table ageing-time
```

## MIRROR INTERFACE

**Syntax** `mirror interface <source-port-list> direction both`

**Description** This command defines a mirror port and mirrored (monitored) ports. The port for which you enter interface mode will be the mirror port.

Use this command to send traffic to another device connected to the mirror port for monitoring.

This command can only be applied to a single mirror (destination) port, not to a range of ports. One interface may have multiple monitored interfaces.

The destination port is removed from all VLANs, and no longer participates in other switching.

Use the no variant of this command to disable port mirroring by the destination port on the specified source port.

**Feature** Switching Commands

**Mode** Interface Configuration

**Release** 4.1

**Options**

Option	Description	Range	Default Value
<source-port-list>	The source ports to mirror. A port-list can be: a port (e.g. port1.2.12) a continuous range of ports separated by a hyphen, e.g. port1.0.1-1.0.24 or port1.1.1-port1.1.24 a comma-separated list of ports and port ranges, e.g. port1.0.1,port1.1.1-1.2.24.	NA	NA
direction	Specifies whether to mirror traffic that the source port receives, transmits, or both.	NA	both

**Note** NA

**Example** To mirror traffic received and transmitted on port1.1.4 and port1.1.5 to destination port1.1.3, use the commands:

```
awplus#(config)# interface port1.1.3
awplus#(config)# mirror interface port1.1.4,port1.1.5 direction both
```

## PLATFORM VLAN-STACKING-TPID

**Syntax**            platform vlan-stacking-tpid <tpid>  
                     no platform vlan-stacking-tpid <tpid>

**Description**       This command specifies the Tag Protocol Identifier (TPID) value that applies to all frames that are carrying double tagged VLANs. All nested VLANs must use the same TPID value. (This feature is sometimes referred to as VLAN stacking or VLAN double-tagging.)

Use the no variant of this command to revert to the default TPID value (0x8100).

**Feature**            Switching Commands

**Mode**               Global Configuration Mode

**Release**            4.1.2

**Options**

Option	Description	Range	Default Value
<tpid>	The Ethernet type of the tagged packet, as a two byte hexadecimal number.	NA	8100

**Note**                The TPID value also applies to all frames carrying single tagged VLANs. Changing the TPID value may affect customer services and iMG management.

**Example**            To set the VLAN stacking TPID value to 0x9100, use the following commands:

```
awplus#(config)# platform vlan-stacking-tpid 0x9100
```

**Example**            To reset the VLAN stacking TPID value to the default (0x8100), use the following commands:

```
awplus#(config)# no platform vlan-stacking-tpid
```

## SHOW INTERFACE SWITCHPORT

**Syntax**            show interface switchport

**Description**      This command shows VLAN information about each switch port.

**Feature**            Switching Commands

**Mode**              User Exec and Privileged Exec

**Release**           4.1.2

**Options**           NA

**Note**              NA

**Example**           To display VLAN information about each switch port, refer to these commands, which show VLAN stacking enabled and then disabled, with Provider port1.0.6:

```
awplus(config)# int port1.0.6
awplus(config-if)# switchport vlan-stacking provider-port
awplus(config-if)# do show int switchport
```

```
Interface name : port1.0.5
Switchport mode : trunk
Ingress filter : enable
Acceptable frame types : all
VLAN stacking port mode : customer
Default Vlan : 1
Configured Vlans : 1 142
```

```
Interface name : port1.0.6
Switchport mode : trunk
Ingress filter : enable
Acceptable frame types : all
VLAN stacking port mode : provider
Default Vlan : 1
Configured Vlans : 1 142
```

```
awplus(config-if)# no switchport vlan-stacking
awplus(config-if)# do show int switchport
```

```
Interface name : port1.0.5
Switchport mode : trunk
Ingress filter : enable
Acceptable frame types : all
VLAN stacking port mode : customer
Default Vlan : 1
Configured Vlans : 1 142
```

```
Interface name : port1.0.6
Switchport mode : trunk
Ingress filter : enable
Acceptable frame types : all
VLAN stacking port mode : customer
Default Vlan : 1
Configured Vlans : 1 142
awplus(config-if)#
```

## SHOW LOOP-PROTECTION

**Syntax**            show loop-protection

**Description**      This command displays the loop-protection configuration and it's status at system and interface level.

**Feature**            Switching Commands

**Mode**              Privileged Exec

**Release**            4.3

**Options**            NA

**Note**               NA

**Example**            In this example loop-protection is enabled on all interfaces and detected on port1.0.2:

```
awplus# show loop-protection
```

```
Loop-Detection:      enabled
```

```
LDF Interval:        30 [sec]
```

```
Link Down Timeout:   10 [sec]
```

```
Interface:            port1.0.1
```

```
  Action:              none
```

```
  Status:              Normal
```

```
Interface:            port1.0.2
```

```
  Action:              linkdown
```

```
  Status:              Loop protection active - no traffic
```

```
Interface:            port1.0.3
```

```
  Action:              linkdown
```

```
  Status:              Normal
```

```
Interface:            port1.0.4
```

```
  Action:              none
```

```
  Status:              Normal
```

```
Interface:            port1.0.5
```

```
  Action:              none
```

```
  Status:              Normal
```

## SHOW MAC ADDRESS-TABLE

**Syntax** `show mac address-table [acquire|ageing-time|dynamic|interface|static|vlan]`

**Description** This command displays attributes of the mac address-table for layer 2 switched traffic.

**Feature** Switching Commands

**Mode** User Exec and Privileged Exec

**Release** 4.1.2

**Note** Wireless output only present on wireless-equipped models.

**Example** See the below sample output captured when there was no traffic being switched:

```
awplus# show mac address-table
VLAN Port      mac          type
202  Port1.0.5    000d.da06.13dd forward dynamic
202  Port1.0.5    000d.da00.0299 forward dynamic
202  Port1.0.5    000d.da01.37f9 forward dynamic
202  Port1.0.5    000c.2515.7008 forward dynamic
202  dot11radio1.0.1 b8d9.cefe.ddc0 forward dynamic
```

**SHOW MIRROR**

**Syntax**            `show mirror`

**Description**      This command displays the status of all mirrored ports.

**Feature**            Switching Commands

**Mode**              Privileged Exec Mode

**Release**           4.1

**Options**           NA

**Note**              If no ports are mirrored, nothing will be displayed.

**Example**           To display the status of all mirrored ports, use the following command:

```
awplus# show mirror
Mirror Test Port Name: port1.0.1
Mirror option: Enabled
Mirror direction: both
Monitored Port Name: port1.0.2
```



---

**SHOW PLATFORM**

**Syntax**            `show platform`

**Description**      This command displays the settings configured using the platform commands

**Feature**            Switching Commands

**Mode**              Privileged Exec

**Release**           4.1.2

**Options**           NA

**Note**              The output shows the TPID used for the VLAN stacking feature. Refer to [VLAN Double Tagging \(VLAN Stacking\)](#).

**Example**           To check the settings configured with platform commands on the switch, use the following command:

```
awplus# show platform
Vlan-stacking TPID                    0x8100
```

**SHOW PLATFORM PORT COUNTERS**

**Syntax** show platform <port> counters

**Description** This command displays extended counters for the selected interface. To clear the port counters use the clear port counter <port> command

**Feature** Switching Commands

**Mode** User Exec and Privileged Exec

**Release** 4.2.3

**Syntax** <port>

**Description** This switch port statistics on WAN interface for iMG1425

**Options**

Option	Description	Range	Default Value
port	The switch port (e.g. port1.0.1) to which retrieve counters information	NA	NA

**Note** N/A

**Example** To show port statistics on WAN interface for iMG1425:

```
awplus# show platform port port1.0.6 counters
VSwitch Port Counters
```

```
-----

Port 1.0.6      Ethernet MAC counters:
Combined receive/transmit packets by size (octets) counters:
  64              72206 512 - 1023              0
  65 - 127        17003 1024 - MaxPktSz          0
  128 - 255        1602
  256 - 511        31440

General counters:
Receive          Transmit
Octets           17249641 Octets           319681
Pkts             122251 Pkts             486
CRCErrors        0
UnicastPkts      1721 UnicastPkts        357
MulticastPkts    7648 MulticastPkts       12
BroadcastPkts    112882 BroadcastPkts     117
FlowCtrlFrms     0 FlowCtrlFrms          0
OversizePkts     0
Fragments        0
Jabbers          0
UpsupportOpcode  0
UndersizePkts    0
                  Collisions              0
                  LateCollisions          0
                  ExcessivCollsns         0

Miscellaneous counters:
MAC TxErr        0
MAC RxErr        0
Drop Events      0
-----
```

**SHOW STORM-CONTROL**

<b>Syntax</b>	show storm-control
<b>Description</b>	This command shows broadcast and multicast rates for each switch interface.
<b>Feature</b>	Switching Commands
<b>Mode</b>	User Exec and Privileged Exec
<b>Release</b>	4.3.3
<b>Options</b>	NA
<b>Note</b>	NA
<b>Example</b>	To display the storm-control, refer to this command:

```
awplus# show storm-control
```

Port	BcastLevel	McastLevel
port1.0.1	100.0%	100.0%
port1.0.2	100.0%	100.0%
port1.0.3	100.0%	100.0%
port1.0.4	100.0%	100.0%
port1.0.5	100.0%	100.0%
port1.0.6	100.0%	100.0%
port1.0.7	100.0%	100.0%

**SPEED**

**Syntax** speed <speed>

**Description** This command changes the speed of the specified port. To see the configured speed and the currently-negotiated speed for ports whose links are up, use the [show interface](#) command.

By default, ports autonegotiate speed, except for the WAN interfaces on iMG2504 and iMG2524 (iMG2500, iMG2524, iMG2524F, iMG2524H and iMG2426F do support autonegotiate).

**Feature** Switching Commands

**Mode** Interface Configuration

**Release** 4.1

**Options**

Option	Description	Range	Default Value
speed	Fixed speed rate for the selected interface or out for autonegotiation.	auto, 10, 100, 1000	auto

**Note** Note that if multiple speeds are specified after the auto option to autonegotiate speeds, then only those speeds specified are attempted for autonegotiation.

**Example** To set the speed of a tri-speed port to 100Mbps, enter the following commands:

```
awplus#(config)# interface port1.0.4
awplus#(config-if)# speed 100
```

**Example** To return the port to auto-negotiating its speed, enter the following commands:

```
awplus#(config)# interface port1.0.4
awplus#(config-if)# speed auto
```

## STORM-CONTROL

**Syntax** `storm-control {multicast|broadcast} level <value>`

**Description** This command limits the maximum broadcast and multicast traffic admitted at the ingress of an interface. Broadcast and multicast rate controls share the same system resource therefore setting the broadcast rate control results on setting also the multicast rate control to the same value. If rates for broadcast and multicast differ, the lowest setting is applied.

**Feature** Switching Commands

**Mode** Interface Configuration

**Release** 4.3.3

**Options**

Option	Description	Range	Default Value
value	The maximum multicast or broadcast rate in link percentage.	0-100	100

**Note** Note that if multiple speeds are specified after the auto option to autonegotiate speeds, then only those speeds specified are attempted for autonegotiation.

**Example** To set maximum broadcast rate at 15% of link speed:  
awplus#(config)# interface port1.0.1  
awplus#(config-if)# storm-control broadcast level 15

## SWITCHPORT BLOCK

**Syntax**            `switchport block {multicast|unicast}`  
                     `no switchport block {multicast|unicast}`

**Description**      This command restricts flooding of unknown unicast or multicast packets.

**Feature**            Switching Commands

**Mode**              Interface Configuration

**Release**           4.4

Option	Description	Range	Default Value
multicast	Restricts flooding of unknown multicast on this port(s).	NA	NA
unicast	Restricts flooding of unknown unicast on this port(s).	NA	NA

**Note**                To display information about the following setting see section SHOW INTERFACE

**Example**            Note that if multiple speeds are specified after the auto option to autonegotiate speeds, then only to restrict flooding of unknown multicast and unicast incoming traffic on port 1.0.1:

**Example**            `awplus # configure terminal`  
                     `awplus (config)# interface port1.0.1`  
                     `awplus (config-if)# no switchport block multicast`  
                     `awplus (config-if)# no switchport block unicast`  
                     `awplus (config-if)# end`

## 4.2 VLAN - General

### 4.2.1 Introduction

This chapter describes Virtual LANs (VLAN), VLAN features and configuration on the switch. For detailed descriptions of commands used to configure VLANs, see VLAN Commands.

### 4.2.2 Virtual LANs (VLANs)

A Virtual LAN (VLAN) is a logical, software-defined subnetwork. It allows similar devices on the network to be grouped together into one broadcast domain, irrespective of their physical position in the network. Multiple VLANs can be used to group workstations, servers, and other network equipment connected to the switch, according to similar data and security requirements.

Decoupling logical broadcast domains from the physical wiring topology offers several advantages, including the ability to:

- Move devices and people with minimal, or no, reconfiguration
- Change a device's broadcast domain and access to resources without physically moving the device, by software reconfiguration or by moving its cable from one switch port to another
- Isolate parts of the network from other parts, by placing them in different VLANs
- Share servers and other network resources without losing data isolation or security
- Direct broadcast traffic to only those devices which need to receive it, to reduce traffic across the network
- Connect 802.1Q-compatible switches together through one port on each switch

Devices that are members of the same VLAN only exchange data with each other through the switch's layer 2 switching capabilities. To exchange data between devices that are located in different VLANs, the switch's layer 3 (routing) capabilities are used. The switch passes VLAN status information to the Internet Protocol (IP) module that indicates whether a VLAN is up or down. This information is used to determine route availability.

The device supports up to 4094 VLANs (the maximum allowed by the VID field in the 802.1Q tag). On some devices a few of these VLANs may be reserved for management purposes. When the switch is first powered up (and therefore unconfigured), it creates a default VLAN with a VID of 1 and an interface name of `vlan1`. In this initial condition, the switch attaches all its ports to this default VLAN. The default VLAN cannot be deleted, and ports can only be removed from it if they also belong to at least one other VLAN. If all the devices on the physical LAN belong to the same logical LAN, that is, the same broadcast domain, then the default settings will be acceptable, and no additional VLAN configuration is required.

## 4.2.3 Configuring VLANs

### 4.2.3.1 Defaults

By default, all switch ports are in access mode, are associated with the default VLAN (`vlan1`), and have ingress filtering on. You cannot delete `vlan1`.

### 4.2.3.2 VLAN names

When you create a VLAN (`vlan` command), you give it a numerical VLAN Identifier (VID)—a number from 2 to 4094, which is included in VLAN-tagged Ethernet frames to and from this VLAN. You may also give it an arbitrary alphanumeric name containing a meaningful description, which is not transmitted to other devices.

When referring to a VLAN, some commands require the VLAN to be specified by its VID while some commands require it to be specified by its interface name: `vlan<VID>`. In command output, the VLAN may be referred to by its VID, its interface name (`vlan<VID>`), or its VLAN name (the arbitrary alphanumeric string).

You can name a VLAN with a string containing "vlan" and its VLAN Identifier (VID). To avoid confusion, we recommend not naming it "vlan" followed by any number different from its VID.

### 4.2.3.3 Access mode

A switch port in access mode sends untagged Ethernet frames, that is, frames without a VLAN tag. Each port is associated with one VLAN (the port-based VLAN, by default, `vlan1`), and when it receives untagged frames, it associates them with the VID of this VLAN. You can associate the port with another VLAN created by the `vlan` command, and this removes it from the default VLAN (`switchport access vlan` command).

Use access mode for any ports connected to devices that do not use VLAN tagging, for instance PC workstations.

### 4.2.3.4 Trunk mode

A switch port in trunk mode is associated with one or more VLANs for which it transmits VLAN-tagged frames, and for which it identifies incoming tagged frames with these VIDs.

To allow a switch port to distinguish and identify traffic from different VLANs, put it in trunk mode (`switchport mode trunk` command), and add the VLANs (`switchport trunk allowed vlan` command). Use trunk mode for ports connected to other switches which send VLAN-tagged traffic from one or more VLANs.

A trunk mode port may also have a native VLAN (by default `vlan1`), for which it transmits untagged frames, and with which it associates incoming untagged frames (`switchport trunk native vlan` command).

### 4.2.3.5 VLANs

All the ports in a channel group must have the same VLAN configuration: they must belong to the same VLANs and have the same tagging status, and can only be operated on as a group.

Table 4-3: Configuration procedure for VLANs

Create VLANs	
<pre>awplus# configure terminal</pre>	Enter Configuration mode.
<pre>awplus(config)# vlan database</pre>	Enter VLAN Configuration mode.
<pre>awplus(config-vlan)# &lt;vlan &lt;vid&gt; name &lt;name&gt; or vlan &lt;vid-range&gt;</pre>	Create VLANs.
Associate switch ports with VLANs	
<pre>awplus(config-vlan)# interface &lt;port-list&gt;</pre>	Associate switch ports in access mode with VLANs:
<pre>awplus(config-if)# switchport access vlan &lt;vlan-id&gt;</pre>	Enter Interface Configuration mode for the switch ports that will be in access mode for a particular VLAN. Associate the VLAN with these ports in access mode. Repeat for other VLANs and ports in access mode.
<pre>awplus(config-if)# interface &lt;port-list&gt;</pre>	Associate switch ports in trunk mode with VLANs. Enter Interface Configuration mode for all the switch ports that will be in trunk mode for a particular set of VLANs.
<pre>awplus(config-if)# switchport mode trunk</pre>	Set these switch ports to trunk mode.
<pre>awplus(config-if)# switchport trunk allowed vlan all or switchport trunk allowed vlan add &lt;vid-list&gt;</pre>	Allow these switch ports to trunk this set of VLANs.
<pre>awplus(config-if)# switchport trunk native vlan {&lt;vid&gt; none}</pre>	By default, a trunk mode switch port's native VLAN—the VLAN that the port uses for untagged packets—is VLAN 1. Some control packets are untagged, including MSTP CIST BPDUs.  If required, change the native VLAN from the default. The new native VLAN must already be allowed for this switch port.
<pre>awplus(config-if)# exit</pre>	Return to Global Configuration mode.



Table 4-3: Configuration procedure for VLANs

<pre>awplus(config) # exit</pre>	Return to Privileged Exec Mode.
<pre>awplus# show vlan &lt;1-4094&gt;}</pre>	Confirm VLAN configuration.

#### 4.2.4 VLAN Double Tagging (VLAN Stacking)

VLAN double tagging, also known as VLAN Stacking, Nested VLANs, or Q-in-Q VLANs, are used to operate a number of private Layer 2 networks within a single public Layer 2 network. This feature provides simple access infrastructure for network service providers to operate Metropolitan Area Networks (MANs) as commercial value-added networks.

A double-tagging implementation consists of the following port types:

- Provider ports - these connect to a service provider's Layer-2 network
- Customer edge ports - these connect to a customer's private Layer-2 network

**Note:** It is possible to configure a LAN interface as a Provider port, such as allowing one of the copper interfaces to connect to the provider's network, or daisy chaining the iMG with another device. Refer to [switchport vlan-stacking \(double tagging\)](#), [show platform](#), and [show interface switchport](#).

#### 4.2.5 How Double-Tagged VLANs Work

In a double-tagging VLAN environment VLAN tagging exists at two levels:

- client or customer tagging (C-Tag)
- service provider tagging (S-Tag)

When double-tagging is enabled, the service provider assigns to each of its clients an individual 12 bit customer VID called an S-Tag. The S-Tag field has an identical structure to a conventional VLAN tag field.

The S-Tag is expected to be attached to the packet as it enters the service provider network.

When the packet is forwarded to the customer edge-port, the S-Tag is removed, and is transmitted as it was received from the customer network. (The packet can be tagged, or not, and the management of this is up to the end customer.)

When the packet is on ingress from a customer-edge port, the S-Tag is added to the packet and the default priority associated with that port is set on the S-tag which is used for switching as described above.

#### 4.2.6 VLAN Rules for Double Tagging

When double-tagged VLANs are created on the switch:

- An S-tagged VLAN belongs to only one customer and can have multiple customer-edge ports.
- A port must be either a customer-edge port or a provider port, but cannot be both.
- Double-tagging is either on or off for the entire device.

A service provider port:

- accepts only tagged packets
- transmits only tagged packets
- can be in many double-tagged VLANs

A customer edge port:

- accepts both tagged (C-Tag) and untagged packets, and adds the S-Tag on ingress (upstream)

- transmits both tagged (C-Tag) and untagged packets, and strips the S-Tag on egress (downstream)
- can be a member of only one double-tagged VLAN

### 4.2.7 Restrictions when using Double-Tagged VLANs

Restrictions when double-tagged VLANs are implemented are:

- Ethernet bridging is based on the S-Tag VID instead of the packet C-Tag VID. The packets C-Tag VID does not change
- The p-bit to queue mapping is based on the S-VID (outer VLAN).
- Be sure to coordinate the iMG Provider port and interfaces to upstream devices. As long as the TPID value match, the upstream device will only see the S-VID and pass it up through the network.

**Caution:** The TPID value also applies to all frames carrying single tagged VLANs. Changing the TPID value may affect customer services and iMG management.

- The TPID can be changed by the user but is set by default at 0x8100.
- The Service Provider port uses the TPID to determine if a packet is tagged. (The Customer port assumes the packet is untagged.)
- Traffic that is sent to the CPU (Mgmt and Voice VLAN) must be configured as single-tagged only.

### 4.2.8 Configuring Double-Tagged VLANs

1. Create, and enable, service provider VLANs 20, 40, 50, and 60.

```
awplus# configure terminal
awplus(config)# vlan database
awplus(config-vlan)# vlan 20,40,50,60
awplus(config-vlan)# exit
```

2. Configure ports 1.0.5 as a provider-port members of VLAN 20, 40, 50, and 60.

```
awplus(config)# interface port1.0.5
awplus(config-if)# switchport mode trunk
awplus(config-if)# switchport trunk allowed vlan add 20,40,50,60
awplus(config-if)# switchport trunk native vlan none
(In a true double-tagging configuration, there are no untagged packets.)
awplus(config-if)# exit
```

3. Configure the customer ports with default VLANs, with port 1.0.1 a member of VLAN 20 and ports 1.0.2 and 1.0.3 members of VLAN 40. Also, set two tagged VLANs on the CPU port (50 and 60)

```
awplus(config)# interface port1.0.1
awplus(config-if)# switchport mode access
awplus(config-if)# switchport access vlan 20
awplus(config-if)# interface port1.0.2
awplus(config-if)# switchport mode access
awplus(config-if)# switchport access vlan 40
awplus(config-if)# interface port1.0.3
awplus(config-if)# switchport mode access
```

```
awplus(config-if)# switchport access vlan 40
awplus(config-if)# exit
awplus(config)# interface vlan 50
awplus(config-if)# ip address dhcp
awplus(config-if)# interface vlan 60
awplus(config-if)# ip address dhcp
awplus(config-if)# exit
```

#### 4. Set the Tag Protocol Identifier (TPID).

If you need to change the Tag Protocol Identifier (TPID) from its default (for VLAN stacking) of 0x8100 (specified as hex notation), use the following command. This example changes the TPID to 0x9100:

```
awplus(config)# platform vlan-stacking-tpid 0x9100
```

**Caution:** The TPID value also applies to all frames carrying single tagged VLANs. Changing the TPID value may affect customer services and iMG management

#### 5. Enable the stacking feature on port1.0.5, since this is the provider port.

```
awplus(config)# interface port1.0.5
awplus(config-if)# switchport vlan-stacking provider-port
```

The nested `tpid` parameter specifies the Ethernet type of the tagged packet. This is set to 0x8100 by default.

Note that this command specifies the TPID value that applies to all VLANs used for double-tagged VLANs (stacked VLANs). You cannot set individual TPID values for different VLANs within a multi double tagged VLAN network.

---

## 4.3 VLAN - iMG

The following figure shows the sample VLAN configuration, followed by the commands that are used to set up the VLANs and their interfaces.




FIGURE 4-1 Sample Configuration - VLANs and Interfaces

```
awplus> enable
awplus# configure
awplus(config)# vlan database
<cr>
awplus(config)# vlan database
awplus(config-vlan)# vlan 7
awplus(config-vlan)# vlan 10
awplus(config-vlan)# vlan 40
awplus(config-vlan)# exit
awplus(config)# interface port1.0.1-port1.0.5
awplus(config-if)# switchport mode access
awplus(config-if)# exit
awplus(config)# interface port1.0.1
awplus(config-if)# switchport access vlan 10
awplus(config-if)# exit
awplus(config)# interface port1.0.2-port1.0.3
awplus(config-if)# switchport access vlan 40
awplus(config-if)# exit

----- On the iMG1500 (WAN port) -----
awplus(config)# interface port1.0.6
awplus(config-if)# switchport mode trunk
awplus(config-if)# switchport trunk allowed vlan add 7,10,40
```

```
awplus(config)# do show vlan
```

VLAN ID	Name	Type	State	Member ports
(u)-Untagged, (t)-Tagged				
1	Default	STATIC	ACTIVE	port1.0.4(u) port1.0.5(u) port1.0.6(u)
7	VLAN0007	STATIC	ACTIVE	port1.0.6(t)
10	VLAN0010	STATIC	ACTIVE	port1.0.1(u) port1.0.6(t)
40	VLAN0040	STATIC	ACTIVE	port1.0.2(u) port1.0.3(u) port1.0.6(t)

```
----- On the IMG2500 (WAN port) ----- awplus(config)# interface port1.0.5 awplus(config-if)# switchport mode trunk
```

```
awplus(config-if)# switchport trunk allowed vlan add 7,10,40
```

```
awplus(config)# do show vlan
```

VLAN ID	Name	Type	State	Member ports
(u)-Untagged, (t)-Tagged				
1	Default	STATIC	ACTIVE	port1.0.4(u) port1.0.5(u) port1.0.6(u)
7	VLAN0007	STATIC	ACTIVE	port1.0.5(t)
10	VLAN0010	STATIC	ACTIVE	port1.0.1(u) port1.0.5(t)
40	VLAN0040	STATIC	ACTIVE	port1.0.2(u) port1.0.3(u) port1.0.5(t)

```
awplus(config)# interface vlan7
```

```
awplus(config-if)# ip address dhcp
```

```
awplus(config-if)# exit
```

```
awplus(config)# interface vlan40
```

```
awplus(config-if)# ip address dhcp
```

```
awplus(config-if)# exit
```

```
awplus(config)# do show ip interface
```

Interface	IP-Address	Status	Protocol
vlan1	172.0.0.103/16	admin up	running
vlan7	10.0.0.251/16	admin up	running
vlan10	unassigned	admin up	running
vlan40	10.1.0.254/16	admin up	running

```
awplus(config)# interface vlan40
```

```
awplus(config-if)# ip igmp snooping
```

```
awplus(config-if)#
```

### 4.3.1 VLAN Commands

This subsection provides an alphabetical reference for commands used to configure the Forwarding Database (FDB)..

Table 4-4: VLAN Commands

Commands
<a href="#">show vlan</a>
<a href="#">switchport access vlan</a>
<a href="#">switchport mode access</a>
<a href="#">switchport mode trunk</a>
<a href="#">switchport trunk allowed vlan</a>
<a href="#">switchport trunk native vlan</a>
<a href="#">switchport vlan-stacking (double tagging)</a>
<a href="#">vlan</a>
<a href="#">vlan database</a>

## SHOW VLAN

**Syntax**            show vlan

**Description**      This command displays information about all the VLANs configured.

**Feature**            VLAN Commands

**Mode**              Privileged Exec Mode

**Release**            4.1

**Options**            NA

**Note**              Wireless output only present on wireless-equipped models

**Example**            To display information about VLAN 2, use the command:

```
awplus# show vlan 2
VLAN ID  Name                Type      State    Member ports
              (u)-Untagged, (t)-Tagged
=====
2         VLAN0002           STATIC    ACTIVE   port1.0.5(u) port1.0.6(u) port1.0.7(u)
              port1.0.8(u)port1.0.7(u)
              dot11radio1.0.1(u)
```

## SWITCHPORT ACCESS VLAN

**Syntax**

```
switchport access vlan <vlan-id>
no switchport access vlan
show interface switchport
```

**Description**

This command changes the port-based VLAN of the current port.

Use the no variant of this command to change the port-based VLAN of this port to the default VLAN, *vlan1*.

Any untagged frame received on this port will be associated with the specified VLAN.

**Feature** VLAN Commands

**Mode** Interface Configuration

**Release** 4.1

**Options**

Option	Description	Range	Default Value
<vlan-id>	<1-4094> The port-based VLAN ID for the port.	NA	NA

**Note** NA

**Example**

To change the port-based VLAN to VLAN 3 for port1.0.2, use the commands:

```
awplus#(config)# interface port1.0.2
awplus#(config-if)# switchport access vlan 3
```

**Example**

To reset the port-based VLAN to the default VLAN 1 for port1.0.2, use the commands:

```
awplus#(config)# interface port1.0.2
awplus#(config-if)# no switchport access vlan
```



## SWITCHPORT MODE ACCESS

**Syntax**            `switchport mode access`

**Description**        This command sets the switching characteristics of the port to access mode. Received frames are classified based on the VLAN characteristics, then accepted or discarded based on the specified filtering criteria.

By default, ports are in access mode with ingress filtering on.

Use access mode to send untagged frames only.

**Feature**            VLAN Commands

**Mode**                Interface Configuration

**Release**            4.1

**Options**            NA

**Note**                NA

**Example**            To set the access, mode use the following commands:

```
awplus#(config)# interface port1.0.2
awplus#(config-if)# switchport mode access
```

## SWITCHPORT MODE TRUNK

<b>Syntax</b>	<code>switchport mode trunk</code> <code>show interface switchport</code>
<b>Description</b>	<p>This command sets the switching characteristics of the port to trunk. Received frames are classified based on the VLAN characteristics.</p> <p>By default, ports are in access mode, are untagged members of the default VLAN (vlan 1), and have ingress filtering on.</p> <p>A port in trunk mode can be a tagged member of multiple VLANs, and an untagged member of one native VLAN.</p>
<b>Feature</b>	VLAN Commands
<b>Mode</b>	Interface Configuration
<b>Release</b>	4.1
<b>Options</b>	NA
<b>Note</b>	To configure which VLANs this port will trunk for, use the <a href="#">switchport trunk allowed vlan</a> command
<b>Example</b>	

```
awplus#(config)# interface port1.1.3
awplus#(config-if)# switchport mode trunk
```

**SWITCHPORT TRUNK ALLOWED VLAN**

**Syntax**

```
switchport trunk allowed vlan none
switchport trunk allowed vlan add <vid-list>
switchport trunk allowed vlan remove <vid-list>
no switchport trunk
```

**Description** This command adds VLANs to be trunked over this switch port. Traffic for these VLANs can be sent and received on the port.

The all parameter sets the port to be a tagged member of all the VLANs configured on the device. The none parameter removes all VLANs from the port's tagged member set. The add and remove parameters will add and remove VLANs to and from the port's member set.

Use the no variant of this command to reset switching characteristics of a specified interface to negate a trunked configuration specified with switchport trunk allowed vlan command.

By default, ports are untagged members of the default VLAN (vlan 1).

**Feature** VLAN Commands

**Mode** Interface Configuration

**Release** 4.2.3

**Options**

Option	Description	Range	Default Value
none	Allow no VLANs to transmit and receive through the port.	NA	NA
add	Add a VLAN to transmit and receive through the port.	NA	NA
remove	Remove a VLAN from transmit and receive through the port.	NA	NA
<vid-list>	<p>&lt;2-4094&gt; The ID of the VLAN or VLANs that will be added to, or removed from, the port. A single VLAN, VLAN range, or comma-separated VLAN list can be set.</p> <p>For a VLAN range, specify two VLAN numbers: lowest, then highest number in the range, separated by a hyphen.</p> <p>For a VLAN list, specify the VLAN numbers separated by commas.</p> <p>Do not enter spaces between hyphens or commas when setting parameters for VLAN ranges or lists.</p>	NA	1

**Note** NA

**Example** The following shows adding a single VLAN to the port's member set.

```
awplus#(config)# interface port1.0.2
awplus#(config-if)# switchport trunk allowed vlan add 2
```

**Example** The following shows adding a range of VLANs to the port's member set.

```
awplus#(config)# interface port1.0.2
awplus#(config-if)# switchport trunk allowed vlan add 2-4
```

**Example** The following shows adding a list of VLANs to the port's member set.

```
awplus#(config)# interface port1.0.2  
awplus#(config-if)# switchport trunk allowed vlan add 2,3,4
```

**SWITCHPORT TRUNK NATIVE VLAN**

**Syntax**            `switchport trunk native vlan {<vid>|none}`  
                      `no switchport trunk native vlan`

**Description**      This command configures the native VLAN for this port. The native VLAN is used for classifying the incoming untagged packets.

Use the no variant of this command to revert the native VLAN to the default VLAN ID 1. Command negation removes tagged VLANs, and sets the native VLAN to the default VLAN.

**Feature**            VLAN Commands

**Mode**                Interface Configuration

**Release**            4.1

**Options**

Option	Description	Range	Default Value
<vid>	<2-4094> The ID of the VLAN that will be used to classify the incoming untagged packets. The VLAN ID must be a part of the VLAN member set of the port.	NA	NA
none	No native VLAN specified. This option removes the native VLAN from the port and sets the acceptable frame types to vlan-tagged only.  Note: Use the no variant of this command to revert to the default VLAN 1 as the native VLAN for the specified interface switchport - not none.	NA	NA

**Note**                NA

**Example**            The following commands show configuration of VLAN 2 as the native VLAN for interface port1.0.2:

```
awplus#(config)# interface port1.0.2
awplus#(config-if)# switchport trunk native vlan 2
```

**Example**            The following commands show the removal of the native VLAN for interface port1.0.2:

```
awplus#(config)# interface port1.0.2
awplus#(config-if)# switchport trunk native vlan none
```

**Example**            The following commands revert the native VLAN to the default VLAN 1 for interface port 1.0.2:

```
awplus#(config)# interface port1.0.2
awplus#(config-if)# no switchport trunk native vlan
```

## SWITCHPORT VLAN-STACKING (DOUBLE TAGGING)

**Syntax**            `switchport vlan-stacking provider-port`  
                      `no switchport vlan-stacking`

**Description**        This command enables VLAN stacking on a port and set it to be the provider-port. This is sometimes referred to as VLAN double-tagging, nested VLANs, or QinQ.

Use no parameter with this command to disable double tagging on an interface.

By default, ports are not VLAN stacking ports.

Traffic with two vlan tags can only be bridged, from the service provider to customer ports. All traffic that terminates on the device, whether being routed, used for management, etc. can have only one tag.

**Feature**            VLAN Commands

**Mode**              Interface Configuration

**Release**            4.1.2

**Options**

Option	Description	Range	Default Value
provider-port	Set the port to be a provider port. This port must already be in trunk mode.	NA	NA

**Note**                Usually the WAN port is the provider port, since it interfaces the service provider's network. However, other ports (LAN) can be configured to be a Provider port, such as when daisy-chaining with another device. (The traffic still goes upstream to the Provider's network.)

**Example**            To enable VLAN stacking, enter the following commands:

```
awplus#(config)# interface port1.0.2
awplus#(config-if)# switchport vlan-stacking provider-port
```

## VLAN

**Syntax**

```
vlan <vid> [name <vlan-name>]  
no vlan {<vid>|<vid-range>}
```

**Description**

This command creates VLANs, assigns names to them, and enables or disables them.

The no variant of this command destroys the specified VLANs.

By default, VLANs are enabled when they are created, and are always enabled.

**Feature** VLAN Commands

**Mode** VLAN Configuration

**Release** 4.1

**Options**

Option	Description	Range	Default Value
<vid>	The VID of the VLAN that will be enabled or disabled <2-4094>.	NA	NA
<vlan-name>	The ASCII name of the VLAN. Maximum length: 32 characters.	NA	NA
<vid-range>	Specifies a range of VLAN identifiers.	NA	NA

**Note** NA

**Example** To create a VLAN, enter the following commands:

```
awplus#(config)# vlan database  
awplus#(config-if)# vlan 45 name accounts
```

## VLAN DATABASE

**Syntax**            `vlan database`

**Description**        This command enters the VLAN Configuration mode.

This command enters the VLAN configuration mode. You can then add or delete a VLAN, or modify its values.

**Feature**            VLAN Commands

**Mode**              Global Configuration Mode

**Release**            4.1

**Options**            NA

**Note**                NA

**Example**            In the following example, note the change to VLAN configuration mode from Configure mode:

```
awplus#(config)# vlan database
awplus#(config-vlan)#
```

## 4.4 PPPoE

### 4.4.1 PPPoE Protocol Components

PPPoE has two distinct stages, Discovery and Session, as described below.

When a Host wishes to initiate a PPPoE session, it must first perform Discovery to identify the Ethernet MAC address of the peer and establish a PPPoE SESSION\_ID. While PPP defines a peer-to-peer relationship, Discovery is inherently a client-server relationship. In the Discovery process, a Host (the client) discovers an Access Concentrator (the server). Based on the network topology, there may be more than one Access Concentrator that the Host can communicate with. The Discovery stage allows the Host to discover all Access Concentrators and then select one. When Discovery completes successfully, both the Host and the selected Access Concentrator have the information they will use to build their point-to-point connection over Ethernet.

There are four steps in the Discovery stage. When complete, both peers know the PPPoE Session ID and the peer's Ethernet Address - **These together are what uniquely define each PPPoE session.** The four packet types are described below, as well as the fifth packet type (Terminate).

Table 4-5: PPPoE Packet Type Sequence for Discovery (and Termination)

Packet Type <sup>a</sup>	Sender	Description
PADI (Initiation)	host	A broadcast packet that to discover the Access Concentrator. It includes the type of service the host is trying to get access to.
PADO (Offer)	Access Concentrator (AC)	The AC offers its MAC address if it can offer the type of service the host has asked for. One or more ACs may send this packet. The PADO packet is sent to the Unicast address of the PPPoE client.



Table 4-5: PPPoE Packet Type Sequence for Discovery (and Termination)

Packet Type <sup>a</sup>	Sender	Description
PADR (Request)	host	Confirms the choice of the AC for this type of service. This packet is sent to the Unicast address of the Access Concentrator. The client may receive multiple PADO packets, but the client responds to the first valid PADO that the client received. If the initial PADI packet had a blank "service-name" field filled, the client populates the "service-name" field of the PADR packet with the first service name that had been returned in the PADO packet.
PADS (Session Confirmation)	AC	When the PADR is received, the Access Concentrator generates unique session identification (ID) for the Point-to-Point Protocol (PPP) session and returns this ID to the PPPoE client in the PADS packet. This packet is sent to the Unicast address of the client.  When this process has completed, the client is aware of the address of the Access Concentrator and a session ID has been established. At this point, a normal PPP session begins.
PADI(Terminate)	host or AC	Optional packet to terminate the PPPoE session. The session ID is discarded, and the host must begin the Discovery process again.

a. PAD for all packet types = PPPoE Active Discovery. Word in parentheses is for final letter in acronym)

Once the session begins, the PPP data is sent as in any other PPP encapsulation, with all Ethernet packets Unicast. Note that the session\_ID must be the value assigned during Discovery, and it must not change during the session. When the LCP terminates, the host and access concentrator must stop using that PPPoE session, and the discovery process begins again.

#### 4.4.2 Automatically populating routing table and DNS server table

During the PPP connection establishment, the Network Control Protocol called PPP **Internet Protocol Control Protocol** (IPCP) is called to negotiate the IP address of the local end of the link and to retrieve the Default Route and a list of DNS server ip addresses.

The negotiated local IP address is used to assign the IP address to the VLAN interface. In this case when the PPP session is established, the VLAN interface changes from having a null IP address to the new negotiated IP address and every time the PPP session is closed, the IP interface will revert back to having a null IP address.

The PPPoE connection has the capability to set the CPE's default route. To enable setting the CPE's default route use the following command in VLAN interface sub-mode:

```
ppp ipcp default route
```

Use the no version of this command to prevent PPP from setting the default route.

**Note:** If more than one PPPoE connection is configured to support setting the default route and multiple PPPoE connections receive a default route from server, the setting of the default route will be determined by the order of the PPPoE link establishment.

The PPPoE transport object is also able to set automatically the primary and secondary DNS servers. Use the following command to enable setting of Primary and Secondary DNS servers:

```
ppp ipcp dns request
```

Use the no version of this command to prevent PPP from setting the DNS servers.

**Note:** If more than one PPPoE connection is configured to support setting the DNS server and multiple PPPoE connections receive a DNS server from server - the setting of the DNS server will be indeterminate depending on order of the PPPoE link establishment.

### 4.4.3 IPv6 Support

Supporting IPv6 over PPPoE does not require additional ppp configuration. All that is required is the normal IPv6 Configuration for the IP interface.

The most common ip addressing mode is SLAC – activated via the “IP Address Autoconfig default” command.

Allocation of additional info is managed via the DHCPv6 Client configuration rather than the PPP client – allowing the use of Prefix Delegation or the dynamic configuration of attributes such as the Domain-name-server or the domain-search-list.

- `ipv6 dhcp client pd TEST_PD_NAME`
- `ipv6 dhcp client request domain-name-servers`
- `ipv6 dhcp client request domain-search-list`

For more information please see the IPv6 Manual section.

### 4.4.4 Activating the Feature

The system is designed to implement more than one embedded PPPoE clients to be able to connect to external Access Concentrators. One PPPoE client may be configured per VLAN; a PPPoE connection is configured on the VLAN interface.

The configuration of a PPPoE connection is as follows:

1. Enter interface command submode for vlan:

```
interface vlan123
```

2. Set authentication protocol:

```
ppp authentication pap OR
```

```
ppp authentication chap
```

3. Set the username/password:

```
ppp sent-username <username> password <password>
```

4. Enable pppoe on vlan interface:

```
pppoe enable
```

5. Disable pppoe on vlan interface:

```
no pppoe enable
```

### 4.4.5 PPPoE Commands

This subsection provides an alphabetical reference for commands used to configure PPPoE.

Table 4-6: PPPoE Commands

Commands
<a href="#">ppp authentication</a>
<a href="#">ppp ipcp default route</a>
<a href="#">ppp ipcp dns request</a>
<a href="#">ppp sent-username</a>
<a href="#">pppoe enable</a>
<a href="#">show pppoe</a>

## PPP AUTHENTICATION

**Syntax** `ppp authentication {chap | pap | auto}`

**Description** This command sets the authentication method as either:

Password Authentication Protocol (PAP) - provides a simple method for a remote node to establish its identity using a two-way handshake. After the PPP link establishment phase is complete, a username and password pair is repeatedly sent by the remote node across the link (in clear text) until authentication is acknowledged, or until the connection is terminated. PAP is not a secure authentication protocol. Passwords are sent across the link in clear text and there is no protection from playback or trail-and-error attacks. The remote node is in control of the frequency and timing of the login attempts

CHAP - The Challenge Handshake Authentication Protocol (CHAP) verifies the identity of the peer by means of a three-way handshake. The connection is verified by comparing calculated values. Otherwise the connection is dropped.

**Feature** PPP

**Mode** VLAN Configuration Mode

**Release** 4.1.2

**Options**

Option	Description	Range	Default Value
chap	Challenge Handshake Authentication Protocol; the server sends an authentication request to the remote user dialing in. PAP passes the encrypted username and password and identifies the remote end	NA	NA
pap	Password Authentication Protocol; the server sends and authentication request to the remote user dialing in. PAP passes the unencrypted username and password and identifies the remote end.	NA	NA
auto	The authentication protocol used by the remote PPP server is discovered and used.	NA	NA

**Note** NA

**Example** In the following example, note the change to VLAN configuration mode from Configure mode:

```
awplus#(config)# interface vlan4
awplus#(config-if)# ppp authentication pap
```

## PPP IPCP DEFAULT ROUTE

<b>Syntax</b>	<code>ppp ipcp default route</code> <code>no ppp ipcp default route</code>
<b>Description</b>	This command is used to allow ppp to the CPE's default route. The no form of this command disallows the configuration of a default route via pppoe.
<b>Feature</b>	PPP
<b>Mode</b>	VLAN Configuration Mode
<b>Release</b>	4.1.2
<b>Options</b>	NA
<b>Note</b>	NA
<b>Example</b>	In the following example, :  <pre>awplus#(config)# interface vlan4 awplus#(config-if)# ppp ipcp default route</pre>

## PPP IPCP DNS REQUEST

<b>Syntax</b>	<code>ppp ipcp dns request</code> <code>no ppp ipcp dns request</code>
<b>Description</b>	This command is used to allow the configuration of dns servers through PPP. The no form of this command to prevent PPP from setting the dns servers.
<b>Feature</b>	PPP
<b>Mode</b>	VLAN Configuration Mode
<b>Release</b>	4.1.2
<b>Options</b>	NA
<b>Note</b>	NA
<b>Example</b>	Refer to the following example,  <pre>awplus#(config)# interface vlan4 awplus#(config-if)# ppp ipcp dns request</pre>

## PPP SENT-USERNAME

**Syntax** `ppp sent-username pppUsername=<username> password=<password>`

**Description** This command sets the username and password. This command must be input so that the PPPoE connection can be completed.

**Feature** PPP

**Mode** VLAN Configuration Mode

**Release** 4.1.2

**Options**

Option	Description	Range	Default Value
pppUsername	Sets the user name. Maximum length is 64 characters	NA	NA
password	Sets the password.	NA	NA

**Note** NA

**Example** In the following example, note the change to VLAN configuration mode from Configure mode:

```
awplus#(config)# interface vlan4
awplus#(config-if)# ppp sent-username user1 password jcp1klkX
```

## PPPOE ENABLE

**Syntax**           pppoe enable  
                  no pppoe enable

**Description**       This command enable the PPPoE feature and is the last command used to implement the PPPoE feature. The no form of this command disables the feature.

**Feature**           PPP

**Mode**             VLAN Configuration Mode

**Release**          4.1.2

**Options**          NA

**Note**             NA

**Example**          In the following example, :

```
awplus#(config)# interface vlan4
awplus#(config-if)# pppoe enable
```



## SHOW PPPOE

<b>Syntax</b>	show pppoe no show pppoe
<b>Description</b>	This command displays configuration and status information about the IPv4 and IPv6 PPPoE Interfaces.
<b>Feature</b>	PPP
<b>Mode</b>	Privileged Exec iMode
<b>Release</b>	4.2
<b>Options</b>	NA
<b>Note</b>	NA

**Example** To display ppp information:

```
awplus# show pppoe
```

```
Vlan: 1
```

```
-----
```

```
PPPOE/IPv4 is disabled
```

```
PPPOE/IPv6 is disabled
```

```
Vlan: 2
```

```
-----
```

```
PPPOE/IPv4 is disabled
```

```
PPPOE/IPv6 is disabled
```

```
Vlan: 152
```

```
-----
```

```
PPPOE/IPv4 is enabled
```

```
Status: Connected
```

```
Username: PPP_2426F_Regr
```

```
Protocol: AUTO_AUTH
```

```
Setting Default routes: Enabled
```

```
Setting DNS servers: Enabled
```

```
Vlan: 152
```

```
-----
```

```
PPPOE/IPv6 is enabled
```

```
Interface: ppp0.152
```

```
Status: Connected
```

```
IPv6CP: up
```

```
Global (SLAAC): 2620:ba:8000:2:6526:ac5e:82f1:f42e/64
```

```
Link Local-Local: fe80::6526:ac5e:82f1:f42e
```

```
Link Local-Remote: fe80::0000:0000:00f0:0313
```

```
Prefix Delegation:
```

```
  Name: TEST_PD_NAME
```

```
  IPv6 prefix: 2620:ba:dead:1::/64
```

```
  Preferred lifetime: 233280
```

```
  Valid lifetime: 259200
```

```
DNS:
```

```
  DNS Server: 2001:4680:4680::8888
```

```
  Domain Search List: (null)
```

## 4.5 HPNA

Since multiple features include provisioning at the interface (and subinterface) level, multiple commands are affected as well. The following table lists these commands. The commands listed in [HPNA Commands](#) are specifically for the HPNA interface.

Table 4-7: Commands affected by the HPNA Interface

Command	Effect	Notes
<a href="#">show vlan</a>	HPNA port can be included if using the iMG2524H	
<a href="#">show vlan</a>	Output includes HPNA port	
<a href="#">interface hpna 1.0.1</a>	Supports the following sub-commands <ul style="list-style-type: none"><li>- <a href="#">switchport mode access</a></li><li>- <a href="#">switchport mode trunk</a></li><li>- <a href="#">switchport access vlan</a></li><li>- <a href="#">switchport trunk allowed vlan</a></li><li>- <a href="#">switchport trunk native vlan</a></li></ul>	
<a href="#">show mac address-table</a>	Can include interface hpna 1.0.1	
<a href="#">clear mac address-table dynamic</a>	Can include interface hpna 1.0.1	
<a href="#">clear mac address-table static</a>	Can include interface hpna 1.0.1	

### 4.5.1 HPNA Commands

This chapter provides an alphabetical reference of commands used to configure and display interfaces.

Table 4-8: HPNA Commands

Commands
<code>interface hpna 1.0.1</code>
<code>clear hpna counters</code>
<code>show hpna counters</code>
<code>show hpna stations</code>
<code>show test</code>
<code>test interface hpna 1.0.1</code>

**INTERFACE HPNA1.0.1**

**Syntax**            `interface hpna1.0.1`

**Description**      This command access the interface level for the HPNA interface. For release 4.2 the number is always 1.0.1, but will change when there is more than one HPNA port.

**Feature**            Switching Commands

**Mode**              Global Configuration Mode

**Release**            4.2

**Options**            NA

**Note**                NA

**Example**            The following example shows the command to enable the hpna interface.

```
awplus(config)# interface hpna1.0.1
awplus(config-if-hpna)# no shutdown
```

## CLEAR HPNA COUNTERS

**Syntax** `clear hpna counters [ <station MAC address> ]`

**Description** Use this command to clear statistic counters for hpna stations.

**Description** If the command is entered while there is a test running a warning message is returned.

**Feature** Switching Commands

**Mode** Global Configuration Mode

**Release** 4.2

**Options**

Option	Description	Range	Default Value
MAC	The MAC address of the HPNA station where the statistics are cleared.	NA	NA

**Note** The command returns an error message if the hpna interface is disabled.

**Example** The following example shows what is displayed

```
awplus(config)# interface hpna1.0.1
awplus(config-if-hpna)# do clear hpna counters
```

## SHOW HPNA COUNTERS

**Syntax** show hpna counters [ <station MAC address> ]

**Description** Use this command to clear statistic counters for hpna stations.

**Feature** Switching Commands

**Mode** Global Configuration Mode

**Release** 4.2

### Options

Option	Description	Range	Default Value
station MAC address	The MAC address of the HPNA station where the statistics are retrieved	NA	NA

**Note** The command returns an error message if the hpna interface is disabled.

**Example** The following example shows what is displayed

```
awplus(config)# interface hpna1.0.1
```

```
awplus(config-if-hpna)# do show hpna counters
```

```
awplus# show hpna counters
```

```
Counters for 00:0d:da:0d:97:55
```

Counter	Value	Description
txPkt	1177	Total (good and bad) transmitted packets
txByte	91026	Total (good and bad) transmitted bytes
rxPkt	1020	Total (good and bad) received packets
rxByte	73278	Total (good and bad) received bytes
txBroadcast	160	Transmitted broadcast packets
rxBroadcast	0	Received broadcast packets
txMulticast	0	Transmitted multicast packets
rxMulticast	0	Received multicast packets
rxCrc	1	Packets received with CRC error(s)
rxHostCrc	1	Packets with CRC errors sent to the host
rxShort	0	Received short packets
txShort	0	Short packets received from the host
txDropped	0	Packets from host dropped due to lack of HPNA resources
rxDropped	0	Received packets dropped due to lack of HPNA resources
ctlReqPkt	840	Control requests from local host (CERT/stats/FW loading)
ctlReplPkt	840	Control replies to local host (CERT/stats/FW loading)
ctlRemoteReqPkt	0	Control requests from remote HPNA host (CERT/Mgmt/FW)
ctlRemoteReplPkt	0	Control replies to remote host (CERT/stats/FW loading)
txPercentPerCycle	2.41	% time HPNA transmitter is busy per HPNA time cycle
idlePercentPerCycle	97.39	% time HPNA media is idle per HPNA time cycle
txPercentAvg	3.62	% time HPNA transmitter is busy on average
idlePercentAvg	95.04	% time HPNA media is idle on average

**SHOW HPNA STATIONS**

**Syntax** show hpna stations [MAC]

**Description** Use this command to display the HPNA stations connected to the HPNA interface. If the command is entered while there is a test still running a warning message is returned

**Feature** Switching Commands

**Mode** Global Configuration Mode

**Release** 4.2

**Note**

Option	Description	Range	Default Value
MAC	The MAC address of the HPNA station	NA	NA

**Note** The command cannot be executed if the hpna interface is disabled

**Example** The following example shows what is displayed

```
awplus(config)# interface hpna1.0.1
awplus(config-if-hpna)# do show hpna stations
```

Idx	MAC Address	Link	Sync	Master	Firmware Version	HW Profile
0	00:0d:da:0d:97:55	Yes	Yes	Yes (local device)	CG3210H 1.9.4	Coax 12-44
1	00:01:40:25:98:eb	Yes	Yes	No	CG3010H 1.9.4	Coax 12-28
2	00:01:40:25:98:e6	Yes	Yes	No	CG3010H 1.9.4	Coax 12-28
3	00:01:40:25:98:d1	Yes	Yes	No	CG3010H 1.9.4	Coax 12-28
4	00:01:40:25:99:c5	Yes	Yes	No	CG3010H 1.9.4	Coax 12-28
5	00:01:40:25:98:c9	Yes	Yes	No	CG3010H 1.9.4	Coax 12-28
6	00:01:40:25:aa:34	Yes	Yes	No	CG3010H 1.9.4	Coax 12-28

**SHOW TEST****Syntax** show test**Description** Use this command to display the latest CERT test results. If the command is entered while there is a test running a warning message is returned**Feature** Switching Commands**Mode** Global Configuration Mode**Release** 4.2**Options** NA**Note** The command returns an error message if the hpna interface is disabled**Example** The following example shows what is displayed

```
awplus(config)# interface hpna1.0.1
awplus(config-if-hpna)# test interface hpna1.0.1
awplus(config-if-hpna)# do show test
```

MAC		Frames						
Source	Destination	Xmtd	Rcvd	%	SNR	Rate	Rx Power	
00:0d:da:0d:97:55	00:01:40:25:98:eb	1000	1000	100.00	41.56	112 Mbps	-8.89	
00:0d:da:0d:97:55	00:01:40:25:98:e6	1000	1000	100.00	40.93	112 Mbps	-9.08	
00:0d:da:0d:97:55	00:01:40:25:98:c9	1000	1000	100.00	38.75	112 Mbps	-15.99	
00:0d:da:0d:97:55	00:01:40:25:99:c5	1000	1000	100.00	39.37	112 Mbps	-9.14	
00:0d:da:0d:97:55	00:01:40:25:98:d1	1000	1000	100.00	40.00	112 Mbps	-16.15	
00:0d:da:0d:97:55	00:01:40:25:aa:34	1000	1000	100.00	39.37	112 Mbps	-13.02	
00:01:40:25:98:eb	00:0d:da:0d:97:55	1000	1000	100.00	41.25	128 Mbps	-7.20	
00:01:40:25:98:eb	00:01:40:25:98:e6	1000	1000	100.00	37.81	112 Mbps	-29.66	
00:01:40:25:98:eb	00:01:40:25:98:c9	1000	1000	100.00	37.81	112 Mbps	-36.75	
00:01:40:25:98:eb	00:01:40:25:99:c5	1000	1000	100.00	38.12	112 Mbps	-30.84	
00:01:40:25:98:eb	00:01:40:25:98:d1	1000	1000	100.00	36.56	96 Mbps	-37.11	
00:01:40:25:98:eb	00:01:40:25:aa:34	1000	1000	100.00	38.12	112 Mbps	-33.40	
00:01:40:25:98:e6	00:0d:da:0d:97:55	1000	1000	100.00	41.25	128 Mbps	-7.35	
00:01:40:25:98:e6	00:01:40:25:98:eb	1000	1000	100.00	39.06	112 Mbps	-30.07	
00:01:40:25:98:e6	00:01:40:25:98:c9	1000	1000	100.00	37.81	112 Mbps	-36.89	
00:01:40:25:98:e6	00:01:40:25:99:c5	1000	1000	100.00	38.75	112 Mbps	-29.97	
00:01:40:25:98:e6	00:01:40:25:98:d1	1000	1000	100.00	36.56	112 Mbps	-37.18	
00:01:40:25:98:e6	00:01:40:25:aa:34	1000	1000	100.00	37.81	112 Mbps	-33.55	
00:01:40:25:98:d1	00:0d:da:0d:97:55	1000	1000	100.00	41.56	128 Mbps	-14.12	
00:01:40:25:98:d1	00:01:40:25:98:eb	1000	1000	100.00	36.87	112 Mbps	-37.05	
00:01:40:25:98:d1	00:01:40:25:98:e6	1000	1000	100.00	37.50	112 Mbps	-36.91	
00:01:40:25:98:d1	00:01:40:25:98:c9	1000	1000	100.00	38.43	112 Mbps	-35.32	
00:01:40:25:98:d1	00:01:40:25:99:c5	1000	1000	100.00	36.56	112 Mbps	-37.25	
00:01:40:25:98:d1	00:01:40:25:aa:34	1000	1000	100.00	35.93	96 Mbps	-39.59	
00:01:40:25:99:c5	00:0d:da:0d:97:55	1000	1000	100.00	41.25	128 Mbps	-7.34	
00:01:40:25:99:c5	00:01:40:25:98:eb	1000	1000	100.00	37.18	112 Mbps	-31.06	
00:01:40:25:99:c5	00:01:40:25:98:e6	1000	1000	100.00	39.06	112 Mbps	-29.47	
00:01:40:25:99:c5	00:01:40:25:98:c9	1000	1000	100.00	36.25	112 Mbps	-36.39	
00:01:40:25:99:c5	00:01:40:25:98:d1	1000	1000	100.00	36.87	112 Mbps	-36.63	
00:01:40:25:99:c5	00:01:40:25:aa:34	1000	1000	100.00	38.12	112 Mbps	-33.25	
00:01:40:25:98:c9	00:0d:da:0d:97:55	1000	1000	100.00	41.56	128 Mbps	-14.14	
00:01:40:25:98:c9	00:01:40:25:98:eb	1000	1000	100.00	36.25	112 Mbps	-36.93	
00:01:40:25:98:c9	00:01:40:25:98:e6	1000	1000	100.00	35.93	112 Mbps	-36.79	
00:01:40:25:98:c9	00:01:40:25:99:c5	1000	1000	100.00	37.50	112 Mbps	-36.74	
00:01:40:25:98:c9	00:01:40:25:98:d1	1000	1000	100.00	37.50	112 Mbps	-35.33	
00:01:40:25:98:c9	00:01:40:25:aa:34	1000	1000	100.00	35.93	112 Mbps	-39.41	



---

00:01:40:25:aa:34	00:0d:da:0d:97:55	1000	1000	100.00	41.56	128	Mbps	-10.70
00:01:40:25:aa:34	00:01:40:25:98:eb	1000	1000	100.00	37.81	112	Mbps	-33.50
00:01:40:25:aa:34	00:01:40:25:98:e6	1000	1000	100.00	37.18	112	Mbps	-33.09
00:01:40:25:aa:34	00:01:40:25:98:c9	1000	1000	100.00	35.31	96	Mbps	-39.33
00:01:40:25:aa:34	00:01:40:25:99:c5	1000	1000	100.00	37.18	112	Mbps	-33.15
00:01:40:25:aa:34	00:01:40:25:98:d1	1000	1000	100.00	34.68	96	Mbps	-39.59

## TEST INTERFACE HPNA1.0.1

**Syntax** `test interface hpna1.0.1 [to [MAC]] [frames <numframes>]`

**Description** Use this command to start CERT tests on HPNA interface. CLI prompt is immediately returned after the command is entered even if CERT tests are not terminated yet. To display the CERT tests results use the command `show test cert`.

**Feature** Switching Commands

**Mode** Global Configuration Mode

**Release** 4.2

**Options**

Option	Description	Range	Default Value
to MAC	The MAC address of the HPNA station	NA	NA
frames	The number of frames to use during the HPNA CERT	1-99999	NA

**Note** The command cannot be executed if the hpna interface is disabled.

**Example** The following example shows what is displayed

```
awplus(config)# interface hpna1.0.1
awplus(config-if-hpna)# test interface hpna1.0.1
HPNA CERT test started
```

## 4.6 Wireless

Table 2-8 below lists existing commands that are affected by the inclusion of wireless, while table 2-9 documents new commands added specifically for wireless.

Table 4-9: Commands affected by the Wireless Interface

Command	Effect	Notes
<a href="#">interface port</a>	Supports additional 'dot11radio1.0.1' sub-mode & associated commands as described in table 2-9 below	
<a href="#">show interface</a>	Supports additional 'dot11radio1.0.1 [status]' sub-commands as described in table 2-9 below. The following sub-commands also include wireless interface information: - show interface brief - show interface status - show interface switchport	
<a href="#">show ip igmp groups</a>	The wireless interface is now included when appropriate on wireless-equipped models	
<a href="#">show mac address-table</a>	Wireless subsystem software version information is displayed if using a wireless-equipped model	
<a href="#">show version</a>	Wireless subsystem software version information is displayed if using a wireless-equipped model	

Table 4-9: Commands affected by the Wireless Interface

Command	Effect	Notes
<code>show vlan</code>	Wireless ports are included if using a wireless-equipped model	

## 4.6.1 Wireless Commands

This chapter provides an alphabetical reference of commands used to configure and display interfaces.

Table 4-10: Wireless Commands

Commands
authentication key-management
authentication open
channel
client-isolation
config-reset
deny
dot11 ssid
guest-mode
interface dot11 radio 0.0
max-association
permit
protocol-family
show controllers dot11 radio
show dot11 associations
show controllers dot11 radio
show dot11 bssid
show interface dot11 radio 0.0
show interface dot11 radio 0.0 status
show wireless country supported
shutdown
ssid-name
vlan
world-mode dot11d country-code
wpa-psk

## AUTHENTICATION KEY-MANAGEMENT

**Syntax** authentication key-management {wpa-mixed-psk | wpa-psk | wpa2-psk}

**Description** Use this command to configure the key management for the radio interface. The WiFi interface supports WiFi Protected Access (WPA) Pre-Shared Key, WPA2 and WPA/WP2 Mixed Mode where:

- wpa-mixed-psk: Employs the WPA/TKIP and WPA2/CCMP-AES encryption protocol
- wpa-psk: Employs the TKIP encryption protocol
- wpa2-psk: Employs the CCMP-AES encryption protocol

**Feature** Switching Commands

**Mode** Global SSID Configuration Mode

**Release** 4.3.3

**Note** Configure the key with command 'wpa-psk {hex | ascii} <encryption-key>' before setting the authentication key-management.

### Options

Option	Description	Range	Default Value
key-management	Type of authentication required for the selected network SSID. Possible values are: wpa-mixed-psk wpa-psk wpa2-psk	NA	NA

**Example** An example can be the following:

```
awplus(config)# dot11 ssid iMG1425W_30_01_02
awplus(config-if-ssid)# authentication key-management wpa-mixed-psk
```

## AUTHENTICATION OPEN

**Syntax** authentication open

**Description** Use this command to configure the radio interface for open authentication. Use the 'no' form to restore the default value.

**Feature** Switching Commands

**Mode** Global SSID Configuration Mode

**Release** 4.3.3

**Options**

Option	Description	Range	Default Value
authentication open	Configure the radio interface, for specified SSID to support open authentication.	NA	NA

**Example**

```
awplus(config)# dot11 ssid iMG1425W_30_01_02
awplus(config-if-ssid)# authentication open
```

**CHANNEL**

**Syntax** `channel {channel number <Frequency MHz> | least-congested}`

**Description** Use this command to set the radio channel frequency, radio channel number or automatic channel selection (least-congested). Use the 'no' form to restore the default channel.

**Feature** Switching Commands

**Mode** dot11radio ConfigurationMode

**Release** 4.3.3

Option	Description	Range	DefaultValue
<channel-number>	The channel number selected for the Wi-Fi interface. Possible values are between 1 and 13 depending on the country.	NA	NA
<frequency-MHz>	The frequency (expressed in MHz) corresponding to the channel. The possible values are: Channel 1 - 2412 MHz Channel 2 - 2417 MHz Channel 3 - 2422 MHz Channel 4 - 2427 MHz Channel 5 - 2432 MHz Channel 6 - 2437 MHz Channel 7 - 2442 MHz Channel 8 - 2447 MHz Channel 9 - 2452 MHz Channel 10 - 2457 MHz Channel 11 - 2462 MHz Channel 12 - 2467 MHz Channel 13 - 2472 MHz	NA	NA
<least-congested>	Auto-channel.	NA	NA

**Example** The following examples show how to set the channel:

Example 1 set channel number:

```
awplus(config)# interface dot11radio1.0.1
awplus(config-if-dot11radio)# channel 3
awplus(config-if-dot11radio)# end
```

Example 2 set channel frequency in MHz:

```
awplus(config)# interface dot11radio1.0.1
awplus(config-if-dot11radio)# channel 2422
awplus(config-if-dot11radio)# end
```

Example 3 set auto channel:

```
awplus(config)# interface dot11radio1.0.1
awplus(config-if-dot11radio)# least-congested
```

## CLIENT-ISOLATION

**Syntax** `client-isolation`

**Description** Use this command to enable client isolation. Use the 'no' form to disable client isolation. When client isolation is enabled, the broadcast traffic generated by one wireless host does not interfere with the traffic of the other wireless hosts.

**Feature** Switching Commands

**Mode** Global Configuration Mode

**Release** 4.3.3

**Note** Use '[do] show interface dot11 radio 1.0.1' for display this information.

**Options**

Option	Description	Range	Default Value
client-isolation	Configure the radio interface (for the specified SSID) to support wireless client isolation.	NA	NA

**Example** The following example enables client isolation on a specific Wi-Fi network

```
awplus(config)# dot11 ssid iMG1425W_30_01_02
awplus(config-if-ssid)# client-isolation
```



## CONFIG-RESET

**Syntax** `awplus(config-if-dot11radio)# config-reset`

**Syntax**

**Description** Use this command to reset the wireless configuration to default values.

**Feature** Switching Commands

**Mode** dot11radio ConfigurationMode

**Release** 4.3.3

**Note** The 'no' form is not present for this command

**Options**

Option	Description	Range	Default Value
config-reset	Reset the wireless module to factory.	NA	NA

**Example** The following example resets the wireless interface to the default settings

```
awplus(config)# interface dot11radio1.0.1
awplus(config-if-dot11radio)# config-reset
```

## DENY

**Syntax**            deny [<mac-address>]  
                      [no] deny [<mac-address>]

**Description**        Use the command “deny” followed by a mac-address to create a black list of mac addresses that are not allowed to connect. Use the command “deny” without any option to enable the black list.

**Feature**            Switching Commands

**Mode**              Global SSID Configuration Mode

**Release**            4.3.3

**Note**                It is important at first to set a list of mac-addresses for blacklist and enable this list afterwards. If the list is empty the following message will be shown in your console:

```
% The filter list must contain at least one entry before filtering can be enabled.
```

**Note:** You can not activate two lists (white and black) at the same time.

### Options

Option	Description	Range	Default Value
mac-address	The mac addresses to be added to the black list.	NA	NA

**Example**            The following example adds three wireless hosts to the black list and enables the black list

```
awplus(config)# dot11 ssid iMG1425W_30_01_02

awplus(config-if-ssid)# deny 00:01:02:03:04:05
awplus(config-if-ssid)# deny 00:01:02:03:04:06
awplus(config-if-ssid)# deny 00:01:02:03:04:07
awplus(config-if-ssid)# deny
```

**DOT11 SSID**

**Syntax** dot11 ssid <ssid-name>

**Description** Use this command to enter SSID configuration mode for the named SSID.

**Feature** Switching Commands

**Mode** Global Configuration Mode

**Release** 4.3

**Options**

Option	Description	Range	Default Value
ssid-name	Name of the existing SSID that you wish to configure.	NA	NA

**Example** The following example shows the wireless interface network SSIDs.

```
awplus# show dot11 bssid
Interface      BSSID          Guest  SSID          VLAN
dot11radio1.0.1 e2:0c:25:00:01:6d Yes    iMG1425W_00_01_6d Default
dot11radio1.0.1
dot11radio1.0.1
dot11radio1.0.1
dot11radio1.0.1
dot11radio1.0.1
awplus# configure
Enter configuration commands, one per line. End with CNTL/Z.
awplus(config)# dot11 ssid iMG1425W_00_01_6d
awplus(config-if-ssid)#
```

## GUEST-MODE

**Syntax** guest-mode

**Description** This command hides or makes visible the network SSID to wireless hosts. The [no] format hides the network SSID.

**Feature** Switching Commands

**Mode** Global SSID Configuration Mode

**Release** 4.3.3

**Note** Use '[do] show dot11 ssid' to display this information

### Options

Option	Description	Range	Default Value
guest-mode	Make visible the network SSID.	NA	NA

**Example** The following example shows how to make visible or hide the network SSID.

```
awplus(config)# dot11 ssid iMG1425W_30_01_02
awplus(config-if-ssid)# guest-mode
```

hide access point use 'no' form, an example is:

```
awplus(config)# dot11 ssid iMG1425W_30_01_02
awplus(config-if-ssid)# no guest-mode
```

## INTERFACE DOT11RADIO1.0.1

**Syntax**            `interface dot11radio1.0.1`

**Description**      This command access the interface level for the 2.4GHz wireless.

**Feature**            Switching Commands

**Mode**              Global Configuration Mode

**Release**            4.2

**Options**            NA

**Note**               NA

**Example**            The following example shows the command to software-enable the wireless interface

```
awplus(config)# interface dot11radio1.0.1
```

```
awplus(config-if-dot11radio)# no shutdown
```

## MAX-ASSOCIATION

**Syntax** max-associations  
[no] max-associations

**Description** Use this command to specify the maximum number of wireless hosts that can connect to the wireless network.

**Feature** Switching Commands

**Mode** Global Configuration Mode

**Release** 4.3.3

### Options

Option	Description	Range	Default Value
max-associations	Configure the maximum number of hosts (for the specified SSID) supported by the radio interface.	1-512	32

**Example** The following example sets at 512, the maximum number of Wi-Fi stations supported by the selected network SSID.

```
awplus(config)# dot11 ssid iMG1425W_30_01_02
awplus(config-if-ssid)# max-associations 512
```

Restore max association with 'no' form an example is:

```
awplus(config)# dot11 ssid iMG1425W_30_01_02
awplus(config-if-ssid)# no max-associations
```

## PERMIT

**Syntax**            `permit [<mac-address>]`  
                     `[no] permit [<-address>]`

**Description**      Use the command “permit” followed by a mac address to create a white list of mac addresses allowed to connect. Use the command “permit” without any option to enable the white list.

**Feature**            Switching Commands

**Mode**              Global SSID Configuration Mode

**Release**           4.3.3

**Note**               It is important at first to set a list of mac-addresses for white list and enable this list afterwards. If the list is empty the following message will be shown in your console:

% The filter list must contain at least one entry before filtering can be enabled.

**Note:** You can not activate two lists (white and black) at the same time.

**Note:** Use "[do] show dot11 associations" for display this setting.

### Options

Option	Description	Range	Default Value
mac-address	The mac address to be added to the white list.	NA	NA

**Example**            The following example adds three wireless hosts to the white list and enables the white list.

```
awplus(config)# dot11 ssid iMG1425W_30_01_02
```

```
awplus(config-if-ssid)# permit 00:01:02:03:04:05
```

```
awplus(config-if-ssid)# permit 00:01:02:03:04:06
```

```
awplus(config-if-ssid)# permit 00:01:02:03:04:07
```

```
awplus(config-if-ssid)# permit
```

## PROTOCOL-FAMILY

**Syntax** `protocol-family <Wi-Fi mode>`

**Description** Use this command to select the Wi-Fi mode. Possible modes are: b, g, g-only, n, n-only  
Use the [no] form to restore the default mode to “n”.

**Options** dot11radio ConfigurationMode

**Mode** Global Configuration Mode

**Release** 4.3.3

**Options**

Option	Description	Range	Default Value
Wi-Fi mode	The Wi-Fi mode. Some of the possible values: b, g, g-only, n, n-only.	NA	n

**Example** The following example shows how to force wireless interface to operate in “b” mode.

```
awplus(config)# interface dot11radio1.0.1
awplus(config-if-dot11radio)# protocol-family b
```



## SHOW CONTROLLERS DOT11 RADIO

**Syntax** awplus# show controllers dot11radio1.0.1

**Description** Displays the radio type, frequency and current channel.

**Feature** Switching Commands

**Mode** Global Configuration Mode

**Release** 4.3.3

**Options**

Option	Description	Range	Default Value
show controllers dot11radio	Display the radio type, frequency and current channel.	NA	NA

**Example** The following example shows the configuration of the wireless interface.

```
awplus# show controllers dot11radio1.0.1
```

```
Interface dot11radio1.0.1
Radio Atheros AR5B97, Driver Version 0.9.17.1, Hostapd Version v1.0
Wireless multifunction button status: Enabled
Country: UNITED STATES (US)
Current Frequency: 2412 Mhz is Channel 1 in auto select
Allowed Frequencies: 2412(1) 2417(2) 2422(3) 2427(4) 2432(5) 2437(6) 2442(7) 2447(8) 2452(9)
2457(10) 2462(11)
Current IEEE 802.11 protocol family: n
Allowed IEEE 802.11 protocols family: b g g-only n n-only
```

## SHOW DOT 11 ASSOCIATIONS

**Syntax** awplus# show dot11 associations

**Description** Display the radio association table, radio association statistics, encryption mode.

**Feature** Switching Commands

**Mode** Global Configuration Mode

**Release** 4.3.3

**Options**

Option	Description	Range	Default Value
show dot11 associations	Display the radio association table.	NA	NA

**Example** The following example shows the wireless hosts associated to each network SSID.

```
awplus# show dot11 associations

802.11 Client Stations on dot11radio1.0.1
SSID1
  IEEE 802.11n  SSID: IMG1425W_30_01_02
  MAC Filtering State: Permitted
  Denied Mac Addresses
  00:01:02:03:04:05
  00:01:02:03:04:06
  Permitted Mac Addresses
  00:03:06:06:09:12
```

## SHOW DOT11 BSSID

**Syntax**            show dot11 bssid

**Description**      Use the show dot11 bssid command to display the relationship between SSIDs and BSSIDs or MAC addresses.

**Feature**            Switching Commands

**Mode**              Global Configuration Mode

**Release**            4.3

**Example**            The following example shows the networks SSIDs and the associated BSSID and VLAN.

```
awplus# show dot11 bssid
```

Interface	BSSID	Guest	SSID	VLAN
dot11radio1.0.1	e2:0c:25:00:01:71	Yes	iMG1425W_00_01_71	2
dot11radio1.0.1	f2:0c:25:00:01:71	Yes	Guest1	2
dot11radio1.0.1	02:0c:25:00:01:71	Yes	Guest2	2
dot11radio1.0.1	12:0c:25:00:01:71	Yes	Guest3	2

**SHOW INTERFACE DOT11RADIO1.0.1**

<b>Syntax</b>	show interface dot11radio1.0.1
<b>Description</b>	Use this command to display the wireless interface configuration and status.
<b>Feature</b>	Switching Commands
<b>Mode</b>	Global Configuration Mode
<b>Release</b>	4.3
<b>Options</b>	NA
<b>Example</b>	The following example if wireless interface is enabled.

```
awplus# show interface dot11radio1.0.1
Interface dot11radio1.0.1
  Link is UP, administrative state is UP
  ethWls1:
    MAC address is e2:0c:25:00:01:6d
    IEEE 802.11ng ESSID:"iMG1425W_00_01_6d"
    Mode:Master Frequency:2.437 GHz Access Point: E2:0C:25:00:01:6D
    Bit Rate:144.4 Mb/s Tx-Power:19 dBm
    RTS thr:off Fragment thr:off
    Encryption key:off
    Power Management:off
    Link Quality=94/94 Signal level=-96 dBm Noise level=-95 dBm
    Rx invalid nwid:3600 Rx invalid crypt:0 Rx invalid frag:0
    Tx excessive retries:0 Invalid misc:0 Missed beacon:0
    Current channel is 6
```

## SHOW INTERFACE DOT11RADIO1.0.1 STATUS

**Syntax**            `show interface dot11radio1.0.1 status`

**Description**      Use this command to display the status of the wireless interface.

**Feature**            Switching Commands

**Mode**              Global Configuration Mode

**Release**            4.3

**Example**            The following example shows what is displayed.

```
awplus# show interface dot11radio1.0.1 status
```

Port	Name	Status	Vlan	Duplex	Speed	Type
dot11radio1.0.1		up	1	auto	auto	N/A

```
awplus#
```

**SHOW WIRELESS COUNTRY SUPPORTED**

**Syntax**            show country supported

**Description**      Use this command to display the name of the supported countries and their abbreviations.

**Feature**            Switching Commands

**Mode**              Global Configuration Mode

**Release**            4.3.2

**Example**            The following example shows what is displayed.

```
awplus# show wireless country
```

```
Interface dot11radio1.0.1
```

ISO Country Code	Country Name
'AL'	'ALBANIA'
'DZ'	'ALGERIA'
'AR'	'ARGENTINA'
'AM'	'ARMENIA'
'AW'	'ARUBA'
'AU'	'AUSTRALIA'
'AT'	'AUSTRIA'
'AZ'	'AZERBAIJAN'
'BS'	'BAHAMAS'
'BH'	'BAHRAIN'
'BD'	'BANGLADESH'
'BB'	'BARBADOS'
'BY'	'BELARUS'
'BE'	'BELGIUM'
'BZ'	'BELIZE'
'BM'	'BERMUDA'
'BO'	'BOLIVIA'
'BA'	'BOSNIA AND HERZEGOVINA'
'BR'	'BRAZIL'
'BN'	'BRUNEI DARUSSALAM'
'BG'	'BULGARIA'
'KH'	'CAMBODIA'
'CA'	'CANADA'
'CL'	'CHILE'
'CN'	'CHINA'
'CO'	'COLOMBIA'
'CR'	'COSTA RICA'
'HR'	'CROATIA'

---

'CY'	'CYPRUS'
'CZ'	'CZECH REPUBLIC'
'DK'	'DENMARK'
'DO'	'DOMINICAN REPUBLIC'
'EC'	'ECUADOR'
'EG'	'EGYPT'
'SV'	'EL SALVADOR'
'EE'	'ESTONIA'
'FI'	'FINLAND'
'FR'	'FRANCE'
'GE'	'GEORGIA'
'DE'	'GERMANY'
'GR'	'GREECE'
'GL'	'GREENLAND'
'GD'	'GRENADA'
'GU'	'GUAM'
'GT'	'GUATEMALA'
'HT'	'HAITI'
'HN'	'HONDURAS'
'HK'	'HONG KONG'
'HU'	'HUNGARY'
'IS'	'ICELAND'
'IN'	'INDIA'
'ID'	'INDONESIA'
'IR'	'IRAN'
'IE'	'IRELAND'
'IL'	'ISRAEL'
'IT'	'ITALY'
'JM'	'JAMAICA'
'JP'	'JAPAN'
'JO'	'JORDAN'
'KZ'	'KAZAKHSTAN'
'KE'	'KENYA'
'KR'	'KOREA REPUBLIC'
'KW'	'KUWAIT'
'LV'	'LATVIA'
'LB'	'LEBANON'
'LI'	'LIECHTENSTEIN'
'LT'	'LITHUANIA'
'LU'	'LUXEMBOURG'

---

---

'MO'	'MACAU SAR'
'MK'	'MACEDONIA, FYRO'
'MY'	'MALAYSIA'
'MT'	'MALTA'
'MU'	'MAURITIUS'
'MX'	'MEXICO'
'MC'	'MONACO'
'ME'	'MONTENEGRO'
'MA'	'MOROCCO'
'NP'	'NEPAL'
'NL'	'NETHERLANDS'
'AN'	'NETHERLANDS ANTILLES'
'NZ'	'NEW ZEALAND'
'NI'	'NICARAGUA'
'KP'	'NORTH KOREA'
'NO'	'NORWAY'
'OM'	'OMAN'
'PK'	'PAKISTAN'
'PA'	'PANAMA'
'PG'	'PAPUA NEW GUINEA'
'PY'	'PARAGUAY'
'PE'	'PERU'
'PH'	'PHILIPPINES'
'PL'	'POLAND'
'PT'	'PORTUGAL'
'PR'	'PUERTO RICO'
'QA'	'QATAR'
'RS'	'REPUBLIC OF SERBIA'
'RO'	'ROMANIA'
'RU'	'RUSSIA'
'RW'	'RWANDA'
'SA'	'SAUDI ARABIA'
'SG'	'SINGAPORE'
'SK'	'SLOVAKIA'
'SI'	'SLOVENIA'
'ZA'	'SOUTH AFRICA'
'ES'	'SPAIN'
'LK'	'SRI LANKA'
'SE'	'SWEDEN'
'CH'	'SWITZERLAND'

---



---

'SY'	'SYRIAN ARAB REPUBLIC'
'TW'	'TAIWAN'
'TZ'	'TANZANIA'
'TH'	'THAILAND'
'TT'	'TRINIDAD AND TOBAGO'
'TN'	'TUNISIA'
'TR'	'TURKEY'
'UG'	'UGANDA'
'UA'	'UKRAINE'
'AE'	'UNITED ARAB EMIRATES'
'GB'	'UNITED KINGDOM'
'US'	'UNITED STATES'
'UY'	'URUGUAY'
'UZ'	'UZBEKISTAN'
'VE'	'VENEZUELA'
'VN'	'VIETNAM'
'YE'	'YEMEN'
'ZW'	'ZIMBABWE'

**Note:** Release 4.3.2 introduces the lock of Wi-Fi frequencies depending on the country where the unit is used. The frequency lock is done at production level therefore is not possible to remove the lock without RMA the unit. For those countries where the lock is active the web interface does not allow to change the Wi-Fi country (and therefore the frequency channels range). In other cases the Wi-Fi country can be changed either via web or CLI.

## SHUTDOWN

**Syntax**            shutdown  
                     no shutdown

**Description**      Use this command to software-disable the wireless interface. Use the 'no' form of this command to software-enable the wireless interface.

**Feature**            Switching Commands

**Options**            Global Configuration Mode

**Release**            4.3

**Note**                NA

**Example**            This command may be overridden by the wireless multifunction button.

```
awplus# configure
Enter configuration commands, one per line. End with CNTL/Z.
awplus(config)# interface dot11radio1.0.1
awplus(config-if-dot11radio)# shutdown
awplus(config-if-dot11radio)#
```

## SSID-NAME

**Syntax** `ssid-name <network-name>`

**Description** Use this command to set or modify SSID string. Use the 'no' form of this command to restore the name of SSID to default string.

**Feature** Switching Commands

**Mode** Global SSID Configuration Mode

**Release** 4.3.3

**Note** Use [do] show dot11 bssid' for displaying the current name of SSID

### Options

Option	Description	Range	Default Value
network-name	Enter as a case-sensitive alphanumeric string up to 32 characters length.	1-32	32

**Example** The following example shows what is displayed

```
awplus(config)# dot11 ssid iMG1425W_30_01_02
awplus(config-if-ssid)# ssid-name iMG1425W_30_01_02_New
```

Restore ssid identify with 'no' form an example is:

```
awplus(config)# dot11 ssid iMG1425W_30_01_02_New
awplus(config-if-ssid)# no ssid-name
```

## VLAN

**Syntax**           vlan <vlan-ID>  
                 no vlan

**Description**       Use this command to associate an SSID with a VLAN. Use the 'no' form of this command to remove the current VLAN association from an SSID.

**Feature**           Switching Commands

**Options**           Global SSID Configuration Mode

**Release**           4.3

**Note**             An SSID may be associated with at most one VLAN at a time.

**Example**           The following example shows what is displayed.

```
awplus# configure
Enter configuration commands, one per line. End with CNTL/Z.
awplus(config)# vlan
awplus(config-vlan)# vlan 2
awplus(config-vlan)# end
awplus# show dot11 bssid
Interface      BSSID          Guest  SSID          VLAN
dot11radiol.0.1 e2:0c:25:00:01:6d Yes    iMG1425W_00_01_6d Default
dot11radiol.0.1                Guest1
dot11radiol.0.1                Guest2
dot11radiol.0.1                Guest3

awplus(config)# dot11 ssid iMG1425W_00_01_6d
awplus(config-if-ssid)# vlan 2
awplus(config-if-ssid)# exit
awplus(config)# exit
awplus#
```

## WORLD-MODE DOT11D COUNTRY-CODE

**Syntax**            world-mode dot11d country-code <country code>  
                     no world-mode dot11d country-code

**Description**      Use this command to configure the country code.

**Feature**            Switching Commands

**Options**            Dot11 radio Configuration Mode

**Release**            4.3.2

**Options**

Option	Description	Range	Default Value
country-code	The country code abbreviation. See command "show country".	NA	NA

**Example**            The following example sets the Wi-Fi frequencies range to respect US spectrum conformance.

```
awplus(config-if-dot11radio)# world-mode dot11d country-code US
<Length:2> Two character ISO/IEC 3166-1 country code
```

```
awplus(config-if-dot11radio)# world-mode dot11d country-code US
```

## WPA-PSK

**Syntax** `wpa-psk {hex | ascii} <encryption-key>`

**Description** Configure a pre-shared key for use in WPA authenticated key management.

**Feature** Switching Commands

**Mode** Global Configuration Mode

**Release** 4.3.3

### Options

Option	Description	Range	Default Value
wpa-psk	Configure a pre-shared key for use in WPA authenticated key management.	NA	NA

**Example** The following example configures the WPA passphrase in ascii format.

```
awplus(config)# dot11 ssid iMG1425W_30_01_02
awplus(config-if-ssid)# wpa-psk ascii 12345678
awplus(config-if-ssid)# end
```

## 5. Multicast Applications

The Layer3 functionality of the iMG includes the following:

- [IGMP Snooping Introduction and Configuration](#)
- [Multicast Command List](#)

---

### 5.1 IGMP Snooping Introduction and Configuration

#### 5.1.1 Multicasting overview

Multicasting is a technique developed to send packets from one location in the Internet to many other locations, without any unnecessary packet duplication. In Multicasting, one packet is sent from a source and is replicated as needed in the network to reach as many end-users as necessary.

The concept of a group is crucial to Multicasting. Every Multicast stream requires a Multicast group; the sender (or source) transmits to the group address, and only members of the group can receive the Multicast data. A group is defined by a Class D address.

Multicasting is useful because it conserves bandwidth by replicating packets as needed within the network, thereby not transmitting unnecessary packets. Multicasting is the most economical technique for sending a packet stream (which could be audio, video, or data) from one location to many other locations on the Internet simultaneously.

Of course, Multicasting has to be a connectionless process. The server simply sends out its Multicast UDP packets, with no idea of who will be receiving them, and whether they get received. It would be quite impossible for the server to have to wait for ACKs from all the recipients, and remember to retransmit to those recipients from whom it does not receive ACKs. Apart from anything else the server does not know who the recipients are, or how many there are.

##### 5.1.1.1 Multicast Group addresses

A Multicast stream is a stream of data whose destination address is a Multicast address – i.e. an IP address with the first byte having a value of 224 to 240. The destination address used by a stream is referred to as its Group address. These Group Addresses, like all IP addresses, are a limited resource, and there are all sorts of rules about who may use addresses from which address ranges.

A server sends out a Multicast stream to a group Multicast address but the way it is routed to the hosts that actually want to receive it is a very different process to routing unicast packets. With unicast packets, the destination address of the packet uniquely identifies the host who should receive the packet and all the routers along the path just need to look in their routing tables to work out which is the correct route to send the packet down.

However, in the case of Multicast, the stream is simply being sent out, with no particular knowledge of who wants to receive it, and where the recipients are. One approach would be for every router that receives a Multicast stream on one interface to just retransmit that stream out ALL its other interfaces. In that way it would be guaranteed to eventually reach every host that might be interesting in receiving it. However, that would be an inefficient use of bandwidth, as a lot of the time the routers would be sending the streams out along paths that do not contain any hosts that want to receive them. Given that the main reason for having Multicasting is to make efficient use of bandwidth, this would not be a good approach.

So, a more efficient approach is needed. This is where IGMP comes in.

### 5.1.1.2 IGMP protocol

IGMP (*Internet Group Management Protocol*) is the protocol whereby hosts indicate that they are interested in receiving a particular Multicast stream. When a host wants to receive a stream (in Multicast jargon, this is called '*joining a group*') it sends to its local router an IGMP packet containing the address of the group it wants to join – this is called an IGMP Membership report (sometimes called a *Join packet*).

Now, the local router is generally going to be a long way from the server that is generating the stream. So, having received the IGMP join packet, the router then knows that it has to forward the Multicast stream onto its LAN (if it is not doing so already). However, if the router is not already receiving the Multicast stream from the server (probably many hops away) what does the router do next in order to ensure that the Multicast stream gets to it? This is achieved by elaborate process involving Multicast routing protocols like PIM, DVMRP, and MOSPF.

The IGMP packet exchange works as described in the following paragraphs.

At a certain period (default is 125 seconds), the router sends an IGMP query message onto the local LAN. The destination address of the query message is a special '*all Multicast groups*' address. The purpose of this query is to ask, "Are there any hosts on the LAN that wish to remain members of Multicast Groups?"

Hosts on the LAN receive the query; if any given host wishes to remain in a Multicast group, it sends a new IGMP Membership report (Join message) for that group (of course some hosts may be members of more than one group – so they will send join messages for all the groups that they are members of).

The router looks at the responses it receives to its query, and compares these to the list of Multicast streams that it has currently registered to receive. If there are any items in that list for which it has not received query responses, it will send a message upstream, asking to no longer receive that stream – i.e. to be 'pruned' from the tree through which that stream is flowing.

In IGMP version 2, a host can explicitly inform its router that it wants to leave a particular Multicast group sending the an IGMP leave message. So, the router keeps a table of how many hosts have joined particular groups, and removes hosts from the table when it receives leave messages, then it can know straight away when there are no hosts on its LAN that are still members of a given group. So, it can ask to be pruned from that tree straight away, rather than having to wait until the next query interval.

### 5.1.1.3 Multicast MAC addresses

Multicast IP addresses are Class D IP addresses. So, all IP addresses from 224.0.0.0 to 239.255.255.255 are Multicast IP addresses. They are also referred to as *Group Destination Addresses* (GDA).

For each GDA there is an associated MAC address. This MAC address is formed by 01-00-5e, followed by the last 23 bits of the GDA translated in hex. Therefore:

230.20.20.20 corresponds to MAC 01-00-5e-14-14-14

224.10.10.10 corresponds to MAC 01-00-5e-0a-0a-0a

Consequently, this is not a one-to-one mapping, but a one-to-many mapping:

224.10.10.10 corresponds to MAC 01-00-5e-0a-0a-0a

226.10.10.10 corresponds to MAC 01-00-5e-0a-0a-0a, as well.

It is required that when an IP Multicast packet is sent onto an Ethernet, the destination MAC address of the packet must be the MAC address that corresponds to the packet's GDA. So, it is possible, from the destination MAC address of a Multicast packet, to know the set of values that its GDA must fall within.

### 5.1.1.4 IGMP snooping Functional Overview

IGMP snooping is a filtering process performed at layer 2 to reduce the amount of Multicast traffic on a LAN.



It is designed to solve the problem when a Multicast traffic is received from a layer 2 switch due to join requests performed by hosts connected to some of the switch ports.

If individual hosts on the LAN (i.e. hosts connected to ports on the switches) wish to receive Multicast streams, then they will send out IGMP joins, which will get up to the Multicast router; and the router will join into the appropriate Multicast trees; and the Multicast flows will then reach the router, and it will forward them into the LAN.

By default, when a switch receives a Multicast packet, it must forward it out all its ports (except the port upon which it was received). So, considering the example where only host number 1 actually requests to join a particular Multicast group, what will happen is that all the hosts on the LAN will start receiving the Multicast packets, as all the switches will forward the Multicast packets to all their ports.

This is rather a waste of bandwidth, and the purpose of Multicasting is to make efficient use of bandwidth.

The solution to this problem is to make the layer-2 switch aware of the IGMP packets that are being passed around. That is, although the IGMP packets are destined for the router, the layer-2 switch needs to 'snoop' them as they go past. Then the layer-2 switch can know which hosts have asked to join which Multicast groups, and only forward the Multicast data to the places where it really needs to go.

IGMP snooping is designed to work in a network environment where both Multicast router(s) and Multicast host(s) are present.

**Note:** Multicast packets having as destination IP the following range: 224.0.0.[0-255] and 224.0.1.[0-255] will NOT be blocked in the upstream direction since belonging to reserved traffic (OSPF, RIPv2, PIM etc....)

The goal is to construct an internal view of the Multicast network based on the IGMP messages received both from Multicast router(s) and Multicast host(s).

---

## 5.2 IGMP Snooping on iMG

AT-iMG1400, AT-iMG1500, AT-iMG2400 and AT-iMG2500 supports three IGMP operation modes:

- IGMP Snoop Only mode: in this mode the iMG does not modify the signaling between STBs and Multicast network but it simply elaborates IGMP messages to create the proper filters to avoid the flooding of Multicast streams.
- IGMP Proxy mode: this mode is a variation of IGMP Snooping mode where the iMG participates actively on the handling of IGMP messages hiding the internal STBs to the Multicast network.
- IGMP Proxy Routed mode: this mode is an extended version of IGMP Proxy mode where Multicast traffic is routed between vlans.

The system is also able to manage IGMP V1, V2 and IGMP V3 signaling messages at the same time, allowing mixed network operating in V1/v2 or V3 modes to interoperate each others.

### 5.2.1 IGMP Snoop Only Mode

#### 5.2.1.1 Join operation

When IGMP task operates in Snoop Only mode, each IGMP Report/Leave message sent by internal Set-Top-Boxes or Multicast hosts, is analyzed by the system.

The iMG keeps record of the interface (port 1.0.1, ...) where the message has been received.

If the iMG receives a Multicast stream and none of the existing interfaces has requested that stream, then the Multicast flow is forwarded to all the interfaces (belonging to the video vlan).

If the IGMP message is a Report to a Multicast stream, the system adds a MAC static entry corresponding to the joined Multicast address in the switch FDB. Then the message is forwarded as it is (same STB source IP/MAC addresses) upstream to the Multicast network.

A timer is also started to record the presence of that specific Multicast stream on that specific interface.

This timer is used to purge the learned Multicast entry in case the STB disconnects without sending any IGMP leave message.

The Multicast stream received on the WAN interface will be forwarded only to the interface(s) that have a static MAC address matching the stream Multicast MAC address, i.e. only to those LAN interfaces that have requested that stream.




FIGURE 5-1 IGMP Snooping

### 5.2.1.2 Leave operation

When a STB sends a IGMP leave message for a Multicast stream, the system will detect on which LAN interface the IGMP leave message has been received.

At this point any static MAC address matching the Multicast MAC address, will be removed from the switch FDB. This immediately causes the drop of the received Multicast stream for that specific LAN interface.

Then the message is forwarded as it is (same STB source IP/MAC addresses) upstream to the Multicast network. Depending on the design of the Multicast network then the stream could be stopped or additional actions could be taken to discover any outstanding host still interested to receive that specific stream.

#### 5.2.1.2.1 Expiring of a Multicast entry

The IGMP module is designed to age out Multicast streams in case a Set-Top-Box or Multicast host does not reply to IGMP Generic or Specific Queries and has not sent any leave message for an existing Multicast stream (or because the leave message is lost in the communication).

To avoid that an incoming stream remains active on the LAN interface, the system starts a timer when the Report message is received.

If during the query-interval period, the Set-Top-Box does not renew the join to the existing Multicast stream by sending a corresponding IGMP report message, after a period of time equals the query-interval \* robustness-variable + query-max-response-time, the static MAC address matching the stream Multicast MAC address, will be removed from the switch FDB.

This immediately causes the drop of the received Multicast stream for that specific LAN interface.

**Note:** When IGMP Snoop Only mode is configured, the fast-leave attribute does not take effect.




FIGURE 5-2 Expiring of a Multicast entry

### Example

In this example the video service is provided via video vlan VID=205. The iMG is configured for IGMP Snoop Only mode. WAN (port1.0.6) is tagged on VID=205 while LAN interfaces (port1.0.1-port1.0.5) belong to video VLAN as untagged interfaces:

First configure the video In this example the video VLAN has VID=205:

```
awplus# configure terminal
awplus(config)# vlan database
awplus(config-vlan)# vlan 205 name video
awplus(config-vlan)# exit
awplus(config)# interface port1.0.6
awplus(config-if)# switchport mode trunk
awplus(config-if)# switchport trunk allowed vlan add 205
awplus(config-if)# switchport trunk native vlan none
awplus(config-if)# exit
awplus(config)# interface port1.0.1-port1.0.5
awplus(config-if)# switchport mode access
awplus(config-if)# switchport access vlan 205
awplus(config-if)# exit
```

Then enable IGMP snooping on video vlan 205

```
awplus(config)# interface vlan205
awplus(config-if)# ip igmp snooping
awplus(config-if)# exit
```

And disable IGMP proxy mode (that it's enabled by default)

```
awplus(config)# no ip igmp proxy-service
awplus(config)# ip igmp version 2
awplus(config)# end
```

## 5.2.2 IGMP Proxy Mode

### 5.2.2.1 Join operation

The main characteristic of IGMP Proxy mode is that there is a complete separation of the IGMP signaling messages receive/transmitted between the upstream Multicast network and IGMP signaling messages receive/transmitted within the home video network.

Each IGMP Report/Leave message sent by internal set-top-boxes or Multicast hosts are not forwarded upstream but are terminated on the iMG IGMP module. The same happens for IGMP Queries received from the Multicast network.

If the IGMP message is a Report to a Multicast stream, the system adds a MAC static entry corresponding to the joined Multicast address in the switch FDB.

If no other hosts have already joined the same Multicast stream, the message is sent upstream to the Multicast network. Before the message is sent, the source MAC/IP address is replaced with the iMG MAC address and with the IP address of the vlan where IGMP has been enabled.

**Note:** If a previous hosts has already joined the same Multicast channel, than the Report received from the STB is retained and it's not forwarded upstream avoiding in this way to flood the network with redundant IGMP messages.

On the LAN side, for each IGMP Report received, the IGMP task updates an internal Multicast table that keeps track of the active streams, Multicast hosts and channels timeouts.

To refresh the content of the Multicast table, IGMP Proxy module sends periodically query messages to the internal LAN interfaces to discover any active Multicast host.

The frequency of these IGMP Query messages is given by the query-interval timer and it's completely independent from the frequency IGMP queries are received from the Multicast network.

Also the Max Response Time value contained in the Query message is configurable by the iMG IGMP module via the query-max-response-time attribute.

On the WAN side, at the reception of a Generic Query from the Multicast network, the IGMP Proxy module will answer with the list of the channels stored on its Multicast channels table.




FIGURE 5-3 Join operation

### 5.2.2.2 Leave operation

If the IGMP message is a Leave from a Multicast stream, the system will detect on which LAN interface the IGMP leave message has been received.

At this point, depending on the setting of the fast-leave attribute, the IGMP module can act in two different ways:

If fast-leave is enabled, the static MAC address matching the stream Multicast MAC address, will be removed from the switch FDB (only for the LAN that has received the IGMP leave message).

This immediately causes the drop of the received Multicast stream for that specific LAN interface.

If there are no other hosts existing in the Multicast channels table for that specific channel, then a leave message is sent upstream to the Multicast network. The leave message will have the iMG MAC address and IP address of the vlan where IGMP has been enabled hiding in this way any information about the internal host.

If fast-leave is disabled, before purging the static MAC address matching the stream Multicast MAC address, the IGMP Proxy module will send one or more Specific IGMP Queries to check if there are internal hosts that are still interested to receive the channel going to be closed.

The number of Specific IGMP Queries is configurable by the robustness variable.

If there are no hosts replying to the Specific IGMP Queries, then the static MAC address matching the stream Multicast MAC address will be removed from the switch FDB (only for the LAN that has received the IGMP leave message). This causes the drop of the received Multicast stream for that specific LAN interface.

If there are no other hosts existing in the Multicast channels table for that specific channel, then a leave message is sent upstream to the Multicast network. The leave message will have the iMG MAC address and IP address of the vlan where IGMP has been enabled hiding in this way any information about the internal host.




FIGURE 5-4 Leave operation

### 5.2.2.3 Expiring of a Multicast entry

Similarly to IGMP Snoop Only mode, the IGMP module ages out the learned Multicast entries in case a Set-Top-Box or Multicast host does not reply to IGMP Queries (generic or specific) and has not sent any leave message for an existing Multicast stream (because it was turned off or because the leave message is lost in the communication).

The time a Multicast entry is kept in the IGMP database equals the query-interval \* robustness-variable + query-max-response-time.

This timer is restarted every time the IGMP module receives a Report message.

Differently from IGMP Snoop Only mode, when the timer expires, the iMG generates upstream an IGMP Leave message corresponding to the Multicast address of the entry that is aged out.

The Leave message is sent only if it is the only existing entry in the IGMP database for the Multicast stream. If the IGMP module has registered other ports or hosts still receiving that Multicast stream, then the Leave message is not sent (this to avoid that the network stops sending the stream while other hosts are still wishing to receive it).

#### Example

In this example the video service is provided via video vlan VID=205. The iMG is configured for IGMP Proxy mode. WAN (port1.0.6) is tagged on VID=205 while LAN interfaces (port1.0.1-port1.0.5) belong to video VLAN as untagged interfaces:

First configure the video vlan.

```
awplus# configure terminal
awplus(config)# vlan database
awplus(config-vlan)# vlan 205 name video
awplus(config-vlan)# exit
awplus(config)# interface port1.0.6
awplus(config-if)# switchport mode trunk
```

```
awplus(config-if)# switchport trunk allowed vlan add 205
awplus(config-if)# switchport trunk native vlan none
awplus(config-if)# exit
awplus(config)# interface port1.0.1-port1.0.5
awplus(config-if)# switchport mode access
awplus(config-if)# switchport access vlan 205
awplus(config-if)# exit
```

Then enable IGMP snooping on video vlan 205

```
awplus(config)# interface vlan205
awplus(config-if)# ip igmp snooping
awplus(config-if)# exit
```

And enable IGMP proxy mode (this is enabled by default and it's here reported just for clarity)

```
awplus(config)# ip igmp proxy-service
awplus(config)# ip igmp version 2
awplus(config)# end
```

### 5.2.3 IGMP Proxy Routed Mode (Multicast Acceleration)

IGMP Proxy mode supports an extended mode called Routed Mode or also Multicast Acceleration that allows the routing (pseudo routing) of Multicast traffic between VLANs.

In Proxy Routed Mode the local user network is isolated from the access network: a DHCP server configured on the iMG is typically used to assign local IP addresses to the user network and NAT is then adopted to allow the access to the service provider network.

Proxy Routed Mode allows Multicast streams received at the WAN interface of the service provider video network to be routed internally to the private user network.

Multicast Acceleration does not perform a true routing of Multicast frames, i.e. the IP TTL value is not decremented and the Ethernet header is left unchanged too. It uses the properties of the switch silicon for wire speed throughput performances.

Join, Leave and expire operations are the same as for IGMP Proxy Mode.

The only difference is that the Source IP address of the IGMP messages sent internally is the IP address of the Internal IP interface where usually the DHCP server runs.

So, the IGMP Report and Leave messages sent upstream will have the IP address of the WAN video network and the IGMP query messages sent downstream will have the IP address of the LAN Internal home network where typically the DHCP server runs.




FIGURE 5-5 IGMP Proxy Routed Mode (Multicast Acceleration)

### Example

In this example the Internet and Video services share the same service provider VALN VID=205.

The users has a Media Center Box on a local private vlan VID=100.

First configure the video vlan.

```
awplus# configure terminal
awplus(config)# vlan database
awplus(config-vlan)# vlan 205 name video
awplus(config-vlan)# exit
awplus(config)# interface port1.0.6
awplus(config-if)# switchport mode trunk
awplus(config-if)# switchport trunk allowed vlan add 205
awplus(config-if)# switchport trunk native vlan none
awplus(config-if)# exit
awplus(config)# interface vlan205
awplus(config-if)# ip address dhcp
awplus(config-if)# ip dhcp client request 3
awplus(config-if)# ip dhcp client request 6
awplus(config-if)# ip dhcp client request 15
awplus(config-if)# ip nat enable
```

Then enable IGMP proxy service on the Internet/Data vlan. This setting tells the system to enable the support for Multicast Acceleration:



```
awplus# configure terminal
awplus(config)# interface vlan205
awplus(config-if)# ip igmp snooping
awplus(config-if)# ip igmp proxy-service
awplus(config)# end
```

Then create the internal VLAN:

```
awplus# configure terminal
awplus(config)# vlan database
awplus(config-vlan)# vlan 100 name internal
awplus(config-vlan)# exit
awplus(config)# interface port1.0.1-port1.0.5
awplus(config-if)# switchport mode access
awplus(config-if)# switchport access vlan 100
awplus(config-if)# end
```

And finally configure the DHCP server on Internal VLAN and enable IGMP snooping support on it:

```
awplus# configure terminal
awplus(config)# interface vlan100
awplus(config-if)# ip address 192.168.100.1/24
awplus(config-if)# ip dhcp pool
awplus(dhcp-config)# range 192.168.100.10 192.168.100.20
awplus(dhcp-config)# subnet 255.255.255.0
awplus(dhcp-config)# lease 0 0 15
awplus(dhcp-config)# exit
awplus(config-if)# ip dhcp server
awplus(config-if)# ip igmp snooping
awplus(config-if)# exit
awplus(config)# ip igmp version 2
awplus(config)# end
```

## 5.2.4 Multicast Command List

This chapter provides an alphabetical reference of configure, clear, and show commands related to Internet Group Management Protocol (IGMP).

Table 5-1: Switching Commands

Commands
<a href="#">ip igmp last-member-query-interval</a>
<a href="#">ip igmp limit</a>
<a href="#">ip igmp proxy-service</a>
<a href="#">ip igmp proxy-service (interface level)</a>
<a href="#">ip igmp query-interval</a>
<a href="#">ip igmp query-max-response-time</a>
<a href="#">ip igmp robustness-variable</a>
<a href="#">ip igmp snooping</a>
<a href="#">ip igmp snooping fast-leave</a>
<a href="#">ip igmp version</a>
<a href="#">show ip igmp</a>
<a href="#">show ip igmp groups</a>

## IP IGMP LAST-MEMBER-QUERY-INTERVAL

**Syntax**            `ip igmp last-member-query-interval <duration>`  
                     `no ip igmp last-member-query-interval`

**Description**       This command configures the frequency at which the router sends IGMP specific query messages after a Leave message has been received.  
                     IGMP specific query messages are sent only when IGMP is configured for Proxy Mode or Multicast Acceleration Mode.  
                     Use the no variant of this command to set this frequency to the default value

**Feature**            IGMP Multicast Commands

**Mode**               Global configuration mode

**Release**            4.1

### Options

Option	Description	Range	Default Value
<duration>	The duration in tenth of seconds at which IGMP group-specific host query messages are sent	1-2147483647	10 (tenth of seconds)

**Note**                NA

**Example**            In the following example IGMP group-specific host query message is configured to 2 seconds (20tenths of seconds)::

```
awplus> enable
awplus# configure terminal
awplus(config)# ip igmp last-member-query-interval 20
```

## IP IGMP LIMIT

**Syntax**      `ip igmp limit <limitvalue>`  
`no ip igmp limit`

This command configures the limit on the maximum number of group membership entries managed by the IGMP module.

Use the no variant of this command to reset the limit to the default value

**Mode**            Global configuration mode

**Feature**        IGMP Multicast Commands

**Mode**            Global configuration mode

**Release**        4.1

**Options**

Option	Description	Range	Default Value
<limitvalue>	Maximum number of group membership entries	0-4095	64

**Note**            NA

**Example**        The following example configures an IGMP limit of 100 group membership entries on the IGMP:

```
awplus# configure terminal
awplus(config)# ip igmp limit 100
```

## IP IGMP PROXY-SERVICE

**Syntax**            `ip igmp proxy-service`  
                  `no ip igmp proxy-service`

This command enables and configures IGMP module to work in Proxy Mode.

**Feature**            IGMP Multicast Commands

**Mode**              Global configuration mode

**Release**            4.2

**Options**            NA

**Example**            The following example enables IGMP Proxy Mode:

```
awplus# configure terminal
awplus(config)# ip igmp proxy-service
```

**IP IGMP PROXY-SERVICE (INTERFACE LEVEL)**

**Syntax**            ip igmp proxy-service  
                     no ip igmp proxy-service

**Description**      This command is used to identify this VLAN interface as the Multicast proxy, and sets the Multicast accelerated mode on the WAN.

                     Use the no variant of this command to remove the designation of the VLAN interface as an upstream proxy-service interface.

**Feature**            IGMP Multicast Commands

**Mode**              Interface Config (VLANs).

**Release**            4.2

**Options**            NA

**Note**               NA

**Example**            The following example designates the vlan1 interface as the upstream proxy-service interface:

```
awplus# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
awplus(config)# interface vlan205
awplus(config-if)# ip igmp proxy-service
```

**IP IGMP QUERY-INTERVAL**

**Syntax**      `ip igmp query-interval <interval>`  
                  `no ip igmp query-interval`

**Description**      This command configures the period for sending IGMP General Query messages. The IGMP query interval specifies the time between IGMP General Query messages being sent.

Use the `no` variant of this command to return to the default query interval period

This command applies to interfaces configured for IGMP. Note that the IGMP query interval is automatically set to a greater value than the IGMP query max response time.

For example, if you set the IGMP query max response time to 2 seconds using the `ip igmp query-max-response-time` command, and the IGMP query interval is currently less than 3 seconds, then the IGMP query interval period will be automatically reconfigured to be 3 seconds, so it is greater than the IGMP query maximum response time.

Use the `ip igmp query-interval` command when a non-default interval for IGMP General Query messages is required.

The `ip igmp query-holdtime` command can occasionally delay the sending of IGMP Queries

**Feature**      IGMP Multicast Commands

**Mode**      Global configuration mode

**Release**      4.1

**Options**

Option	Description	Range	Default Value
<interval>	Query interval value expressed in seconds at which IGMP host query messages are sent	0-2147483647	125

**Note**      IGMP query interval must be greater than IGMP query maximum response time

**Example**      The following example changes the period between IGMP host-query messages to 3 minutes (180 seconds):

```
awplus# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
awplus(config)# ip igmp query-interval 180
```

**Example**      The following example resets the period between sending IGMP host-query messages to the default (125 seconds):

```
awplus# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
awplus(config-if)# no ip igmp query-interval
```

## IP IGMP QUERY-MAX-RESPONSE-TIME

**Syntax**            `ip igmp query-max-response-time <responsetime>`  
                     `no ip igmp query-max-response-time`

**Description**       This command configures the maximum response time advertised in IGMP Queries.

Use the no variant of this command to restore the default value.

This command applies to interfaces configured for IGMP. Note that the IGMP query interval is automatically set to a greater value than the IGMP query maximum response time.

For example, if you set the IGMP query interval to 3 seconds using the `ip igmp query-interval` command, and the current IGMP query interval is less than 3 seconds, then the IGMP query maximum response time will be automatically reconfigured to be 2 seconds, so it is less than the IGMP query interval time.

To get the network to converge faster, use the `ip igmp query-max-response-time` command and set a low response time value, such as one or two seconds, so that the clients will respond immediately with a report as a response to the IGMP Queries

**Feature**            IGMP Multicast Commands

**Mode**              Global configuration mode)

**Release**            4.1

**Options**

Option	Description	Range	Default Value
<responsetime>	Response time value expressed in tenths of seconds. Maximum response time advertised in IGMP queries.	0-2147483647	10 (1 second)

**Note**                The IGMP query maximum response time must be less than the IGMP query interval.

**Example**            The following example configures a maximum response time of 8 seconds:

```
awplus# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
awplus(config)# ip igmp query-max-response-time 80
```

**Example**            The following example restores the default maximum response time of 10 seconds:

```
awplus# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
awplus(config)# ip igmp query-max-response-time
```



## IP IGMP ROBUSTNESS-VARIABLE

**Syntax**            `ip igmp robustness-variable <2-2147483647>`  
                     `no ip igmp robustness-variable`

**Description**       This command sets the value for the network robustness, allowing tuning based upon expected packet loss on the network.

Use the no variant of this command to return to the default value on an interface.

**Feature**            IGMP Multicast Commands

**Mode**                Global configuration mode

**Release**            4.1

**Options**

Option	Description	Range	Default Value
robustness-variable	This robustness value will modify the time, in proxy mode only, between the leave on the LAN facing network and the leave being sent on the WAN facing network will be robustness times the lastmemberqueryintvl. It functions by forcing multiple IGMP Packet transmissions.	2-2147483647	2

**Note**                NA

**Example**            To set the robustness variable to 3, enter the following:

```
awplus# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
awplus(config)# ip igmp robustness-variable 3
```

## IP IGMP SNOOPING

**Syntax**            `ip igmp snooping`  
                     `no ip igmp snooping`

**Description**        This command enables IGMP Snooping. When this command is used in the Global Configuration mode, IGMP Snooping is enabled at the switch level. When this command is used in Interface Configuration mode, IGMP Snooping is enabled for the specified VLANs.

Use the no variant of this command to disable IGMP Snooping on a specified interface.

By default, IGMP Snooping is enabled globally and disabled on all VLANs.

For IGMP snooping to operate on particular VLAN interfaces, it must be enabled both globally by using this command in Global Configuration mode, and on individual VLAN interfaces by using this command in Interface Configuration mode (both are enabled by default.)

**Feature**            IGMP Multicast Commands

**Mode**                Interface Config (VLANs)

**Release**            4.1

**Options**            NA

**Note**                NA

**Example**            To enable IGMP snooping, enter the following:

```
awplus# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
awplus(config)# interface vlan1
awplus(config-if)# ip igmp snooping
```

## IP IGMP SNOOPING FAST-LEAVE

<b>Syntax</b>	<code>ip igmp snooping fast-leave</code> <code>no ip igmp snooping fast-leave</code>
<b>Description</b>	<p>This command enables IGMP Snooping fast-leave processing. Fast-leave processing is analogous to immediate-leave processing; the IGMP group-membership entry is removed as soon as an IGMP leave group message is received, without sending out a group-specific query.</p> <p>Use the no variant of this command to disable fast-leave processing</p> <p>By default, snooping fast-leave processing is enabled.</p>
<b>Feature</b>	IGMP Multicast Commands
<b>Mode</b>	Global configuration mode
<b>Release</b>	4.1
<b>Options</b>	NA
<b>Note</b>	NA
<b>Example</b>	<p>This example shows how to enable fast-leave processing on a VLAN:</p> <pre>awplus# configure terminal Enter configuration commands, one per line.  End with CNTL/Z. awplus(config)# ip igmp snooping fast-leave</pre>

## IP IGMP VERSION

**Syntax**            `ip igmp version <1-3>`  
                     `no ip igmp version`

**Description**       This command sets the current IGMP version (IGMP version 1, 2 or 3) on an interface.  
  
                     Use the no variant of this command to return to the default version.  
  
                     This command applies to VLAN interfaces configured for IGMP

**Feature**            IGMP Multicast Commands

**Mode**               Global configuration mode

**Release**            4.1

**Options**

Option	Description	Range	Default Value
<1-3>	IGMP protocol version number.	NA	3

**Note**                NA

**Example**            To set the IGMP version, enter the following:

```
awplus# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
awplus(config)# ip igmp version 2
```

**SHOW IP IGMP**

**Syntax**            show ip igmp

**Description**      This command displays the status of IGMP.

**Feature**            IGMP Multicast Commands

**Mode**               Privileged Exec Mode

**Release**            4.1

**Options**            NA

**Note**               NA

**Example**            The following command displays IGMP status:

```
awplus# show ip igmp
IGMP snooping is enabled for vlan144
IGMP proxy mode is enabled
IGMP Routed Proxy service is not enabled
IGMP version is 2
IGMP Max number of groups is 64
IGMP robustness variable is 2
IGMP query interval is 125 seconds
IGMP max query response time is 10 (1/10 seconds)
IGMP Last member query response interval is 10 (1/10 seconds)
```

**Note**               IGMP snooping fast-leave is enabled

**Example**            The following command displays iMG1425W IGMP statistics:

```
iMG1425W# show ip igmp snooping statistics

IGMP Snooping statistics
#Channels: 1
#Hosts: 1
Query Rx: 0 GS Query Rx: 0 V3 Query Tot Rx: 0
Join Rx: 0 Leave Rx: 0 V3 Report Rx 0
Total Rx: 0
Query Tx: 0 GS Query Tx: 0 V3 Query Tot Tx: 0
Join Tx: 0 Leave Tx: 0 V3 Report TX 0
Total Tx: 0
```

Group Address	Interface	Port	Reporter	Uptime
LastJoin Expires				
224.2.2.50	vlan2	dot11radio1.0.1	192.168.100.11	01:55:30
00:00:48 00:02:21				

**Example**            The following command displays iMG1425W snooping statistics interface dot11radio1.0.1:

```
IGMP Snooping statistics
#Channels: 1
#Hosts: 1
Query Rx: 0 GS Query Rx: 0 V3 Query Tot Rx: 0
Join Rx: 0 Leave Rx: 0 V3 Report Rx 0
Total Rx: 0
Query Tx: 0 GS Query Tx: 0 V3 Query Tot Tx: 0
Join Tx: 0 Leave Tx: 0 V3 Report TX 0
Total Tx: 0
```

Group Address	Interface	Port	Reporter	Uptime
LastJoin Expires				
224.2.2.50	vlan2	dot11radio1.0.1	192.168.100.11	01:55:40
00:00:59 00:02:10				

**Example** The following command displays iMG1425W snooping statistics interface dot11radio1.0.1 for wireless ports:

```
pre-existing cli commands still working
on all devices:
show ip igmp snooping statistics interface port1.0.x
show ip igmp snooping statistics interface vlanxxx
```

**Example** The following command displays iMG2524H snooping statistics for the HPNA port:

```
awplus# show ip igmp snooping statistics interface hpna1.0.1
```

```
IGMP Snooping statistics
#Channels: 3
#Hosts: 2
Query Rx: 0 GS Query Rx: 0 V3 Query Tot Rx: 0
Join Rx: 0 Leave Rx: 0 V3 Report Rx 0
Total Rx: 0
Query Tx: 0 GS Query Tx: 0 V3 Query Tot Tx: 0
Join Tx: 0 Leave Tx: 0 V3 Report TX 0
Total Tx: 0
```

Group Address	Interface	Port	Reporter	Uptime	LastJoin	Expires
225.10.10.10	vlan100	hpna1.0.1	192.168.100.11	25:00:59	00:00:51	00:03:28
224.2.2.62	vlan100	hpna1.0.1	192.168.100.11	00:31:36	00:00:51	00:03:28
224.2.2.52	vlan100	hpna1.0.1	192.168.100.10	00:06:09	00:00:50	00:03:29

**SHOW IP IGMP GROUPS**

**Syntax**            show ip igmp groups

**Description**      This command displays the Multicast group entries registered on each interface and the expire time-out.

**Feature**            IGMP Multicast Commands

**Mode**              Global configuration Mode

**Release**            4.3

**Options**            NA

**Note**               NA

**Example**            The following example displays the IGMP entries for a iMG1425W where three Multicast host are connected on LAN port1.0.5 and on Wireless interface :

```
awplus# awplus# show ip igmp groups
```

```
IGMP IGMP Connected Group Membership
```

Group Address	Interface	Uptime	Expires	Last Reporter
239.255.255.254	port1.0.5	00:21:30	00:03:57	10.17.90.1
224.0.1.60	port1.0.5	00:21:24	00:03:54	10.17.90.31
239.255.255.100	port1.0.5	00:19:52	00:02:38	10.17.90.78
224.2.2.52	dot11radio1.0.1	00:02:56	00:02:30	10.17.90.131

## 6. Access and Security

The Access and Security functions of the iMG include the following:

- [Quality of Service Model](#)
- [QoS Command List](#)
- [Secure Shell Protocol](#)
- [SSH Command List](#)
- [Security \(Trigger, Firewall, Access Control List, Logging\)](#)
- [Security Command List](#)

---

### 6.1 Quality of Service Model

#### 6.1.1 Address management

The primary function of the layer 2 switch is to receive good packets from the ports, process them and forward them to the appropriate ports for transmission. This frame processing involves the Ingress Policy, Queue Controller, Output Queues and Egress Policy.

The normal packet flow involves learning how to switch packets only to the correct ports. The switch learns which port and end station is connected to by remembering each packet's Source Address along with the port number on which the packet arrived - and the vlan that it is on.

When a packet is directed to a new, unlearned MAC address, the packet is flooded out of all the ports (as long as they belong on the same VLAN) except for the one on which it arrived. Once a MAC address/port number is learned, all future packets directed to that end station's MAC addresses are directed to the learned port number only. This ensures that the packet is sent to the correct end station. This table can be displayed via the CLI.

The address database is stored in the embedded switch memory and has a default aging time of about 300 seconds (5 minutes). If no packets are received from that MAC Address during that aging interval, then the address is purged from the database. If a MAC Address is received from a different port during this time, then the MAC address is learned on that new port and all traffic is then routed to that new port.

To see the entries in the address database - execute the following command:

```
show mac address-table
```

#### 6.1.2 Rate limiting support

The integrated layer 2 switch supports hardware rate limiting on receive and transmit independently on a per port basis. The rate limiting applies to all the frame types: unicast, broadcast and Multicast.

If the number of bytes exceeds the programmed limit, the switch will stop receiving or transmitting packets on the port. In the transmit direction, extra packets are placed in one or more FIFO queues and sent as soon as possible given the configured limit. Note that when multiple queues are configured, the highest priority queue is emptied first.



In the receive direction, on some devices, there is an option provided for flow control to prevent packet loss. In this case, if the configured limit is reached, and Flow Control is enabled, then a PAUSE frame will be sent to the peer device. This will stop transmission of packets until the Gateway is ready to receive packets again.

Commands are:

```
egress-rate-limit  
ingress-rate-limit
```

### 6.1.3 Quality of Service Classification

QoS switching policy is performed by the Queue Controller. The priority of a frame is determined in priority order by:

The IEEE 802.3ac Tag containing IEEE 802.1p priority information: this IEEE 802.1p priority information is used in determining frame priority when IEEE 802.3ac tagging is enabled on the port.

The IPv4 Type of Service (TOS)/DiffServ field when enabled on the port. IPv4 priority classification can be configured on a port basis to have a higher priority than IEEE Tag.

The user can enable one of these QoS classifications on a port.

All untagged frames entering a port are tagged and have their p-bit value set to the port's default priority. This priority is then used to manage the traffic from that port.

A four Queue scheme is in place which allows the user to map the different priority values to one of the four internal queues.

Highest priority queues are emptied first before the lower priority queues...and as such, it is possible for the low priority traffic to get starved out.

The integrated layer 2 switch supports two Class of Service (CoS) mechanisms: IEEE 802.1p tagging (Layer 2) and Differentiated Services (DS) as an advanced architecture of ToS (Layer 3).

### 6.1.4 802.1p traffic priority

The IEEE 802.1p signalling technique is an IEEE endorsed specification for prioritizing network traffic at the data-link/MAC sub-layer (OSI Reference Model Layer 2).

IEEE 802.1p is a spin-off of the IEEE 802.1q (VLAN tagging) standard and they work in tandem.

The 802.1q standard specifies a VLAN tag that appends to a MAC frame. The VLAN tag carries VLAN information. The VLAN tag has two parts: The VLAN ID (12-bit) and User Priority (3-bit). The User Priority field was never defined in the VLAN standard. The 802.1q implementation defines this prioritizing field.

Switches, routers, servers, even desktop systems, can set these priority bits in the three-bit user priority field, which allows packets to be grouped into various traffic classes. If a packet is received that does not have this tag added, then the switch adds it to the packet and uses the default priority associated with the port.

The value in the user priority is used to determine which queue to place the packet into directly. This mapping is configurable via the following commands:

```
mls qos map cos-queue <p-bit value> to <queue number>
```

### 6.1.5 Differentiated services code point (DSCP)

The IEEE 802.1p signalling technique is an IEEE endorsed specification for prioritizing network traffic.

The DSCP octet in the IP header classifies the packet service level. The DSCP replaces the ToS Octet in the IPv4 header. Refer to [Figure 6-1](#).

Currently, only the first six bits are used. Two bits of the DSCP are reserved for future definitions. This allows up to 64 different classifications for service levels.

The value in the user priority used to determine which queue to place the packet into directly. This mapping is configurable with the command:

```
mls qos map Pre-mark-dscp <dscp value> to new-queue <queue number>
```




FIGURE 6-1 IP Packet Overview

## 6.1.6 QoS Command List

This chapter provides an alphabetical reference of configure, clear, and show commands related to QoS.

Table 6-1: QoS Commands

Commands
<a href="#">egress-rate-limit</a>
<a href="#">flowcontrol</a>
<a href="#">ingress-rate-limit</a>
<a href="#">mls qos cos</a>
<a href="#">mls qos map cos-queue</a>
<a href="#">mls qos map premark-dscp to new-queue</a>
<a href="#">mls qos trust cos</a>
<a href="#">mls qos trust dscp</a>
<a href="#">show mls qos interface</a>
<a href="#">show mls qos maps cos-queue</a>
<a href="#">show mls qos maps premark-dscp</a>

## EGRESS-RATE-LIMIT

**Syntax** egress-rate-limit <num>|<num>k|<num>m|<num>g  
no egress-rate-limit

**Description** This command sets a limit on the amount of traffic that can be transmitted per second from this port. The default unit is in Kb, but Mb or Gb can also be specified. The minimum is 651 Kb

Use the no variant of this command to disable the limiting of traffic egressing on the interface.

**Feature** QoS Commands

**Mode** Interface Configuration Mode

**Release** 4.1

### Options

Option	Description	Default Value	Default Value
<num>	A number optionally followed by a unit specifier: 'k' for Kb, 'm' for Mb, 'g' for Gb.  If no unit specifier is included, the units are in Kb. The system rounds up to the next 64Kb boundary. For example, limit of 63Kb becomes 64Kb, and limit of 65Kb becomes 128Kb.	NA	NA

**Note** NA

**Example** To enable egress rate limiting on the port, use the commands :

```
awplus(config)# interface port1.0.1  
awplus(config-if)# egress-rate-limit 500m
```

## FLOWCONTROL

**Syntax**            `flowcontrol {both}`  
                     `no flowcontrol`

**Description**       Use this command to enable flow control, and configure the flow control mode for the switch port. Use the no variant of this command to disable flow control for the specified switch port.

The flow control mechanism specified by 802.3x is only for full duplex links. It operates by sending PAUSE frames to the link partner to temporarily suspend transmission on the link.

**Feature**            QoS Commands

**Mode**               Interface Configuration Mode

**Release**            4.1

**Options**

Option	Description	Default Value	Default Value
<both>	For both send and receive. This is the default value,	NA	both

**Note**                NA

**Example**            To set flowcontrol, use the commands:

```
awplus(config)# interface port1.0.1
awplus(config-if)# flowcontrol both
```

## INGRESS-RATE-LIMIT

**Syntax**            ingress-rate-limit <num>|<num>k|<num>m|<num>g  
                     no ingress-rate-limit

**Description**       This command sets a limit on the amount of traffic that can be received per second from this port. The default unit is in Kb, but Mb or Gb can also be specified. The minimum is 64 Kb

Use the no variant of this command to disable the limiting of traffic ingressing on the interface.

**Feature**            QoS Commands

**Mode**               Interface Configuration Mode

**Release**            4.1

### Options

Option	Description	Range	Default Value
<num>	A number optionally followed by a unit specifier: 'k' for Kb, 'm' for Mb, 'g' for Gb.  If no unit specifier is included, the units are in Kb. The system rounds up to the next 64Kb boundary. For example, limit of 63Kb becomes 64Kb, and limit of 65Kb becomes 128Kb.	NA	NA

**Note**                NA

**Example**            To enable ingress rate limiting on the port, use the commands:

```
awplus(config)# interface port1.0.1
awplus(config-if)# ingress-rate-limit 500m
```

## MLS QOS COS

**Syntax**            mls qos cos <0-7>  
                     no mls qos cos

**Description**       This command assigns a CoS (Class of Service) user-priority value to untagged frames entering a specified interface.

Use the no variant of this command to return the interface to the default CoS setting for untagged frames entering the interface. For tagged frames the default does not alter CoS value.

**Feature**            QoS Commands

**Mode**               Interface Configuration Mode

**Release**            4.1

**Options**

Option	Description	Range	Default Value
cos	The Class of Service, user-priority value.	0-7	NA

**Note**                NA

**Example**            To assign a CoS, use the commands:

```
awplus(config)# interface port1.0.1-port1.0.4
awplus(config-if)# mls qos cos 3
```

**MLS QOS MAP COS-QUEUE**

**Syntax**            mls qos map cos-queue <cos-pri> to <queue-num>  
                       no mls qos map cos-queue

**Description**      Used to set the CoS to queue mapping. This is the default queue mapping for packets that do not get assigned a queue via any other QoS functionality.

Use the no variant of this command to reset the cos-queue map back to its default setting. The default mappings for this command are:

CoS Priority: 0 1 2 3 4 5 6 7

CoS Queue:     1 0 0 1 2 2 3 3

**Feature**            QoS Commands

**Mode**                Global Configuration Mode

**Release**            4.1.2

**Options**

Option	Description	Range	Default Value
<cos-priority>	CoS priority value, Can take a value 0 to 7	NA	NA
<queue-number>	Queue number. Can take a value 0 to 3, since the iMG supports up to four queues.	0-3	NA

**Note**                The iMG supports only four Queues, from 0 to 3.

**Example**            To map CoS 2 to queue 3, use the commands:

```
awplus(config)# mls qos map cos-queue 2 to 3
```

**Example**            To map to queues 4-7 results in the following:

```
awplus(config)# mls qos map cos-queue 6 to 4 <--queues 4-7 are not allowed
% Invalid queue number. Should be 0 to 3.
awplus(config)# mls qos map cos-queue 6 to 3
awplus(config)#
```



## MLS QOS MAP PREMARK-DSCP TO NEW-QUEUE

**Syntax**      `mls qos map premark-dscp <0-63> to new-queue <queue-num>`  
`no mls qos map premark-dscp [<0-63>]`

**Description**      This command configures the premark-dscp map. It is used when traffic has trust dscp configured. Based on a lookup DSCP, the system determines a new queue for the traffic.

The no variant of this command resets the premark-dscp map to its defaults. If no DSCP is specified then all DSCP entries will be reset to their default

**Feature**      QoS Commands

**Mode**      Global Configuration Mode

**Release**      4.1

**Options**

Option	Description	Range	Default Value
premark-dscp	The DSCP value on ingress	NA	NA
<queue-num>	The queue that the packet will be in on egress. If unspecified, this value will be set to zero.	NA	NA

**Note**      NA

**Example**      To set the entry for DSCP 2 to use queue 3, use the command:

```
awplus(config)# mls qos map premark-dscp 2 new-queue 3
```

## MLS QOS TRUST COS

<i>Syntax</i>	<code>mls qos trust cos</code>
<i>Description</i>	This command sets QoS mode for the port to use 802.1p bits (CoS bits) for classification.
<i>Feature</i>	QoS Commands
<i>Mode</i>	Interface Configuration Mode
<i>Release</i>	4.1
<i>Options</i>	NA
<i>Note</i>	NA
<i>Example</i>	To enable, use the commands:

```
awplus(config)# interface port1.0.1
awplus (config-if)# mls qos trust cos
```

## MLS QOS TRUST DSCP

**Syntax**            `mls qos trust dscp`

**Description**      This command sets QoS mode for the port to use DSCP bits for classification.

**Feature**            QoS Commands

**Mode**              Interface Configuration Mode

**Release**           4.1

**Options**           NA

**Note**              NA

**Example**           To enable, use the commands :

```
awplus(config)# interface port1.0.1
awplus (config-if)# mls qos trust dscp
```

**SHOW MLS QOS INTERFACE**

**Syntax**            `show mls qos interface <ifrange>`

**Description**      This command displays the current settings for the interface. This includes it's default CoS and queue, scheduling used for each queue, and any policies/maps that are attached.

**Feature**            QoS Commands

**Mode**              Privileged Exec Mode

**Release**            4.1

**Options**

Option	Description	Range	Default Value
<ifrange>	One or more ports. For a range, separate with a dash (-)	NA	NA

**Note**                NA

**Example**            To enable, use the commands :

```
awplus# show mls qos interface port1.0.1-port1.0.3
port1.0.1:
  Trust mode: ..... CoS
  Default CoS priority: ..... 0
  Default queue: ..... 0
  Number of egress queues: .... 4
  Egress rate limit: ..... 0Kb
  Ingress rate limit: ..... 0Kb
port1.0.2:
  Trust mode: ..... None
  Default CoS priority: ..... 0
  Default queue: ..... 0
  Number of egress queues: .... 4
  Egress rate limit: ..... 0Kb
  Ingress rate limit: ..... 0Kb
port1.0.3:
  Trust mode: ..... None
  Default CoS priority: ..... 0
  Default queue: ..... 0
  Number of egress queues: .... 4
  Egress rate limit: ..... 0Kb
```

**SHOW MLS QOS MAPS COS-QUEUE**

**Syntax**            `show mls qos maps cos-queue`

**Description**      This command displays the current configuration of the cos-queue map.

**Feature**            QoS Commands

**Mode**              Privileged Exec Mode

**Release**            4.1

**Options**            NA

**Note**               NA

**Example**            To view the cos-queue map, use the command :

```
awplus# show mls qos maps cos-queue
COS-TO-QUEUE-MAP:
COS :    0    1    2    3    4    5    6    7
-----
QUEUE:  0    0    0    0    2    3    0    0
```

**SHOW MLS QOS MAPS PREMARK-DSCP**

**Syntax**            `show mls qos maps premark-dscp`

**Description**      This command displays the dscp-to-queue mapping that is configured on the iMG.

**Feature**            QoS Commands

**Mode**              Privileged Exec Mode

**Release**            4.1

**Options**            NA

**Note**              NA

**Example**            To show the premark-dscp values, use the commands

```
awplus# show mls qos maps premark-dscp
```

```
DSCP-TO-QUEUE-MAP:
   0  1  2  3  4  5  6  7  8  9
-----
  0: 00 00 00 00 00 00 00 00 00 00
 10: 00 00 00 00 00 00 00 00 00 00
 20: 00 00 00 00 00 00 00 00 00 00
 30: 00 00 00 00 00 02 00 00 00 00
 40: 00 00 00 00 00 03 00 00 00 00
 50: 00 00 00 00 00 00 00 00 00 00
 60: 00 00 00 00
```

## 6.2 Secure Shell Protocol

### 6.2.1 Introduction

This chapter describes how the Secure Shell protocol is implemented in the AlliedWare Plus™ Operating System. It covers:

- Using Secure Shell to manage your device.

Secure management is important in modern networks, as the ability to easily and effectively manage switches and routers, and the requirement for security, are two almost universal requirements. Protocols such as Telnet and rlogin allow you to manage devices remotely, but can have serious security problems, such as relying on reusable plaintext passwords that are vulnerable to wiretapping or password guessing. The Secure Shell (SSH) protocol is superior to these protocols by providing encrypted and strongly authenticated remote login sessions.

SSH provides sessions between a host running a SSH server and a machine with a SSH client. The AlliedWare Plus™ OS includes a SSH server and a SSH client to enable you to securely—with the benefit of cryptographic authentication and encryption—manage your devices over an insecure network:

- SSH replaces Telnet for remote terminal sessions; SSH is strongly authenticated and encrypted.
- Remote command execution allows you to send commands to a device securely and conveniently, without requiring a terminal session on the device.
- SSH allows you to connect to another host from your switch or router.

The AlliedWare Plus™ OS supports Secure Copy (SCP) and SSH File Transfer Protocol (SFTP). Both these protocols allow you to securely copy files between your device and remote machines. SFTP provides additional features from SCP, such as allowing you to manipulate the remote files, and halt or resume file transfers without closing the session.

## 6.2.2 Configuring the SSH Server

This section provides instructions on:

- Enabling the Server
- Validating the Server Configuration

### 6.2.2.1 Enabling the Server

You must enable the SSH server before connections from SSH, SCP, and SFTP clients are accepted. When the SSH server is disabled it rejects connections from SSH clients. The SSH server is enabled by default on your device.

To enable the SSH server, use the command:

```
awplus(config)# service ssh
```

To disable the SSH server, use the command:

```
awplus(config)# no service ssh
```

### 6.2.3 SSH Command List

This chapter provides an alphabetical reference of configure, clear, and show commands related to Secure Shell (SSH).

Table 6-2: SSH Commands

Commands
<a href="#">debug sshd</a>
<a href="#">service ssh</a>
<a href="#">show ssh server</a>



## DEBUG SSHD

**Syntax** `debug sshd level <log-level>`

**Description** This command enables the SSH server debugging facility. When enabled, the SSH server sends diagnostic messages to the system log. To display the debugging messages on the terminal, use the terminal monitor command.

The no variant of this command disables the SSH server debugging facility. This stops the SSH server from generating diagnostic debugging messages.

SSH server debugging is disabled by default

**Feature** SSH Commands

**Mode** Privileged Exec Mode and Global Configuration Mode

**Release** 4.1.2

**Options**

Option	Description	Default Value	Default Value
<log-level>	Valid values are: - debug - notice -error	NA	debug

**Note** NA

**Example** To start SSH server debugging, use the command:

```
awplus# debug sshd level debug
```

**Example** To disable SSH server debugging, use the command

```
awplus# no debug sshd
```

## SERVICE SSH

**Syntax**            `service ssh`  
                     `no service ssh`

**Description**       This command enables the Secure Shell server on the device. Once enabled, connections coming from SSH clients are accepted.

SSH server needs a host key before it starts. The SSHv1 and SSHv2 host keys are created automatically.

The no variant of this command disables the Secure Shell server. When the Secure Shell server is disabled, connections from SSH clients are not accepted. This command does not affect existing SSH sessions.

The Secure Shell server is disabled by default.

**Feature**            SSH Commands

**Mode**              Global Configuration Mode

**Release**           4.1

**Options**           NA

**Note**               NA

**Example**           To enable both the IPv4 Secure Shell server, use the commands :

```
awplus(config)# service ssh
```

**Example**           To disable the IPv4 Secure Shell server only, use the commands :

```
awplus(config)# no service ssh
```

**SHOW SSH SERVER**

<b>Syntax</b>	<code>show ssh server</code>
<b>Description</b>	This command displays the current configuration of the Secure Shell server.
<b>Feature</b>	SSH Commands
<b>Mode</b>	Privileged Exec Mode
<b>Release</b>	4.1
<b>Options</b>	NA
<b>Note</b>	Note that changes to the SSH configuration affects only new SSH sessions coming from remote hosts, and does not affect existing sessions

**Example**

```
awplus# show ssh server
Secure Shell Server Configuration
-----
SSH Server                      : enabled
```

## 6.3 Security (Trigger, Firewall, Access Control List, Logging)

### 6.3.1 Overview

Security means to deal with preventing access from unwanted hosts that try to connect to the device.

In detail, it is possible to define which host (or set of hosts) can connect to the device and on which port (or set of ports); this is called access restriction.

It is possible to have static access restrictions as well as dynamic ones (that is, conditioned to the presence of a triggering connection), and to define the default behavior in case no access restrictions have been defined.

Moreover, in case of an intrusion attempt by an unwanted host, it is possible to log the event.

Each access restriction produces rules in the IP tables, that in a Linux environment is a collection of statements for which IP packets are submitted; security concepts like triggers, firewalls and so on merely add or remove IP tables rules.

Each VLAN interface has its own behavior in respect to security, and is independent of the others; this means that each VLAN interface has its own access restrictions, whether static or dynamic.

Implementing the security on a device means to define the behavior for each VLAN interface and for each port.

### 6.3.2 Triggers

Triggers are used to inform the security mechanism to expect secondary sessions and handle the situation dynamically, allowing the secondary sessions for data flow for the duration of the session.

The user configures the iMG with a range of primary port number(s). The Primary port number refers to the TCP/UDP port number to which the primary (starting) session of the application is established. During session set up, if there is a local host that was expecting the incoming session, then the session is established. If a local host is not found, then the packet is discarded.

This mechanism enables the iMG to allow in only those incoming secondary sessions that should be allowed in, and can reject malicious attempts to establish incoming sessions.

**Note:** The sum of the primary port ranges must be less than 1000, due to limited resources. The secondary port ranges must be less than 1000 for each trigger created. Moreover, a few ports are unavailable because they are registered by other applications. Refer to [ip firewall trigger \(config-if\)](#) for details.

### 6.3.3 Firewall

The firewall feature permits to block every incoming packet on a board.

More precisely, this feature defines the default behavior for each port: in case the firewall is enabled, each incoming packet is blocked, otherwise is accepted.

However, it is possible to change the default behavior for each port with the access lists mechanism, as explained later.

Now let's suppose that we know this mechanism and let's focus on a specific interface, no matter which.

Let's suppose too that, for example, we are able to permit access on telnet port only for host 10.10.10.10.

This means that if 10.10.10.10 tries to connect via telnet, the connection will be accepted, while an host like 10.10.10.11 will be refused.

Now, what about the other services, like SSH, http and so on, that uses different ports?

If firewall is disabled, each host will be permitted to access; if enabled, each host will be refused.

This means that if firewall status is changed, the restriction given on a particular port remains the same.

In case of telnet service, the access restriction remains the same, no matter if the firewall is enabled or not.

Note that in case an active connection isn't permitted anymore, either because the firewall has been enabled or because the access restriction rules are changed, the connection isn't dropped and remain active until isn't closed.

Once the firewall is enabled, every incoming packet is dropped except for the following:

- TR69 messages - other access methods (telnet, SSH, http) are blocked.
- Port Filters - These are configured with the local GUI for DHCP client and server messages: otherwise enabling firewall would result in IP addresses expiring.
- Packets of already established connections
- Triggers - Refer to [6.3.2](#).
- Access List - Refer to [6.3.6](#).

When the firewall is disabled, the IP tables are set to empty, unless some access restriction has been defined. Both behaviors can be achieved by using IP tables commands.

In 4.2 IPv6 can be enabled, as well as IPv4; when IPv6 is enabled the following conditions occur;

- Enabling the firewall enables both IPv4 and IPv6 Firewall. (both IPv4 and IPv6 packets will be blocked).
- Disabling the firewall disables both IPv4 and IPv6 Firewall.

### 6.3.4 Port Filters (using the GUI)

These are port attributes that define:

- What protocol type is allowed (specified using the protocol number or the protocol name)
- The range of source and destination port numbers allowed
- The direction that packets are allowed to travel in (inbound, outbound, neither, or both)

Refer to [9.2](#).

### 6.3.5 Logging Intrusion Attempts

Each attempt of intrusion by unwanted hosts can be logged properly. This means that a message describing the attempt features is reported in the log. Each message can be marked from a log level, that tells us about its importance. The log levels can be set.

The log informations about such attempts are put in the system log; debug level can also be specified (error, notice, debug). The available log levels are neither more nor less a subset of the Linux system log (error=3, notice=5, debug=7).

In order to set it, one command is provided:

```
awplus(config)# debug access level <error|notice|debug>
```

The command that shows the log content is:

```
awplus# show log
```

An intrusion message is like the following:

```
Intrusion -> IN=ppp0.4000 OUT= MAC= SRC=10.10.10.11 DST=10.10.10.33 LEN=64 TOS=0x00 PREC=0x00  
TTL=125 ID=63441 DF PROTO=TCP SPT=1618 DPT=23 WINDOW=65535 RES=0x00 SYN URGP=0 MARK=0x1
```

This refers to the example of 5.4.3: host 10.10.10.11 is trying to telnet the board but it's refused.

Note that IN field is the VLAN interface name, while SRC and DST are the unwanted host and the board IP addresses (DPT is the destination port, that is 23 for telnet).

In order to avoid flooding, a maximum of 6 messages per hour is permitted.

### 6.3.6 Access Control List (ACL)

#### 6.3.6.1 Overview

Sometimes the iMG is required to limit access to applications and services on the device to only to few selected hosts for security. Such access restriction can be obtained by using Access Control List (ACL) and Access Group.

An ACL is a filter that is applied to a VLAN interface to permit packets that match the filter definitions. The filter definitions are:

- a port (for example, 23 for telnet) - defined by the protocol parameter.
- the subnet which is permitted access to it.

ACLs refer to a particular port to restrict the access only for that port and leave the access rules for the other ports unchanged.

The set of hosts that can reach the switch on that port is identified by the IP subnet.

Once an ACL has been created, it is still not active; the ACL must be applied to a VLAN interface to have packets blocked on it. Once this association is made the filter begins working.

Each VLAN interface has its own Access Group, which is the collection of ACLs applied.

So to have filtering on the interface, you:

1. create the necessary ACLs (each ACL is tagged with an ID number created by the user).
2. apply one or more ACLs to the interface Access Group (each interface has only one access group).
3. Note that the same ACL can be associated with different access groups.

Once done, the filtering will start and packets will be blocked or forwarded, according to the content of the ACLs. Once an ACL has been applied to an interface for a specific port, all the hosts not belonging to the subnet will not be able to access the switch on the port, unless further ACLs are created and applied.

The same ACL can be applied to different interfaces with minimum effort.

If no ACL is applied to an interface for one port, all the hosts can access that interface on that port.

When the filtering is no longer required, an ACL can be removed from an Access Group.

For an example, to restrict telnet access to the subnet of hosts having IP addresses ranging from 10.17.90.1 to 10.17.90.4.

- Create the ACL

```
awplus(config)# access-list 1 permit 10.17.90.1/30 telnet
awplus(config)# access-list 2 permit
```

- Associate the ACL to the proper access group. Note that in the current release you must apply each ACL separately.

```
awplus(config)# config interface vlan1
awplus(config-if)# access-group 1
awplus(config-if)# access-group 2
....
awplus(config-if)# access-group 99
```

- To remove the access group from the VLAN interface (and therefore remove the access restriction), enter:

```
awplus(config)# no access-group 1
```

### 6.3.6.2 Extended Access Lists

Previously, access lists refer to a source subnet and a destination port; in most cases that is enough to define an access restriction. In this case the access list is referred as a “normal” access list.

However, there are few cases in which an “extended” access list is required.

The extended access list permits you to define a range of ports, and not only one; also a destination subnet and source port(s) can be defined.

Once defined, they can be used as the normal access lists.

### 6.3.7 IPv6 Access Lists

In 4.2 IPv6 also has access restriction capabilities that are the same as IPv4, except for the following differences:

- IPv6 Access Lists only support the extended format, as shown in the [ipv6 access-list extended](#) command.
- To apply the access lists to a VLAN interface, the command used is [ipv6 traffic-filter](#) (rather than [access-group](#)).
- Once an access list has been applied, the IP tables contains some extra rules. They merely permit the following ICMPv6 messages to be accepted: router-advertisement, neighbor-advertisement, neighbor-solicitation. See the traffic filter command explanation.

### 6.3.8 Protected Ports

The Protected Ports feature allows certain ports to be designated as protected. Protected ports have the following attributes:

- By default a port is unprotected and must be specifically designated as protected.
- On a protected port, **all** traffic is included (so not on a VLAN basis).
- Traffic between members of different protected port groups is blocked.
- Protected ports are able to send traffic to unprotected ports

Because traffic is protected on a port basis, one command is used. Refer to [protected](#).

### 6.3.9 Security Command List

This chapter provides an alphabetical reference of configure, clear, and show commands related to Security.

Table 6-3: Security Commands

Commands
<a href="#">access-group</a>
<a href="#">access-list</a>
<a href="#">debug access level</a>
<a href="#">firewall enable (config-if)</a>
<a href="#">ip firewall trigger (config-if)</a>
<a href="#">ipv6 access-list extended</a>
<a href="#">ipv6 traffic-filter</a>
<a href="#">protected</a>
<a href="#">show access-group</a>
<a href="#">show access-list</a>
<a href="#">show ip firewall status</a>
<a href="#">show ipv6 access-list extended</a>
<a href="#">show ipv6 traffic-filter</a>

## ACCESS-GROUP

**Syntax**

```
access-group <1-99>
no access-group [<VLAN id>] [<1-99>]
```

This command adds or removes an access-list to a vlan interface.

The no variant of this command removes the selected access-group from the VLAN interface. The id ranges from 1 to 99.

To use, first create an access list that applies the appropriate permit requirements etc. Then use the access-group command to apply this access list to a specific vlan interface. Only permitted packets will be accepted for the specified protocol. You can add to an access group more than one access list. Note that this command will apply the access-list only to incoming data packets.

**Feature** IPv4 Access Control List (ACL) Commands

**Mode** Global Configuration mode, Interface Configuration

**Release** 4.1

**Options**

Option	Description	Range	Default Value
<1-99>	Access group number	NA	NA

**Note** NA

**Example** To add the numbered access-list 99 to the vlan1 interface, enter the following commands:

```
awplus(config)# interface vlan1
awplus(config-if)# access-group 99
```

**Example** To remove the numbered access-list 99 from the vlan1 interface, enter the following commands

```
awplus(config)# interface vlan1
awplus(config-if)# no access-group 99
```



**ACCESS-LIST**

**Syntax**

```
access-list <acl-id> permit [[tcp|udp]
<source> {eq <sourceport>|range <start-range> <end-range>}
<destination> {eq <destport>|range <start-range> <end-range>}]
eq <service-name>
no access-list <access-list-id>
```

**Description** This command configures a standard numbered access-list that permits packets from a specific source IP address and for a specific protocol. The no variant of this command removes a specified standard numbered access-list.

Note that this command has variations depending on the options chosen. Refer to the Examples.

Use this command when configuring a standard numbered access-list for filtering IP software packets.

**Feature** IPv4 Access Control List (ACL) Commands

**Mode** Privileged Exec Mode

**Release** 4.1

**Options**

Option	Description	Range	Default Value
<acl-id>	Number to label the access list.	1-99	NA
permit	The Access List accepts packets from the specified source	NA	NA
tcp   udp	whether the protocol is over udp or tcp.	NA	NA
<source>	- The IP address and port (with text <code>eq</code> ) or port range (with text <code>range</code> ) of the source.  The IP address is followed by a forward slash, then the prefix length. This matches any source IP address within the specified subnet. For instance 192.168.200.1/24 identifies all the hosts ranging from 192.168.200.1 to 192.168.200.255	NA	NA
<destination>	- The IP address and port (with text <code>eq</code> ) or port range (with text <code>range</code> ) of the destination.  The IP address is followed by a forward slash, then the prefix length. This matches any source IP address within the specified subnet. For instance 192.168.200.1/24 identifies all the hosts ranging from 192.168.200.1 to 192.168.200.255	start and end port values	NA
service name	The name of the service the subnet will be permitted to have. Available values are: - 21 (ftp) - 69 (tftp) - 23 (telnet) - 22 (ssh) - 80 (http) - 161 (snmp) - 30005 (tr69)	NA	NA

**Note** NA

**Example** For accepting TCP packets coming from the subnet 10.16.90.1/24, sent from a port ranging from 10400 to 10499, meant for the port 23 of the host 192.168.255.3:

```
awplus(config)# access-list 2 permit tcp 10.16.90.1/24 range 10400 10499 192.168.255.3/32 eq 23
```

**Example** Different versions of the command can be used to specify certain options. Here are examples:

```
awplus(config)# access-list 1 permit 10.17.90.0/24 telnet
awplus(config)# access-list 2 permit 10.17.90.0/24 ftp
awplus(config)# access-list 3 permit 10.17.90.0/24 http
awplus(config)# access-list 4 permit 10.17.90.0/24 snmp
awplus(config)# access-list 5 permit 10.17.90.0/24 ssh
awplus(config)# access-list 6 permit 10.17.90.0/24 tftp
awplus(config)# access-list 7 permit 10.17.90.0/24 tr69
awplus(config)# access-list 9 permit tcp 10.17.90.0/24 eq 2000 0.0.0.0/0 eq 4000
awplus(config)# access-list 10 permit tcp 10.17.90.0/24 range 200 201 0.0.0.0/0 range 200 201
awplus(config)# access-list 10 permit udp 10.17.90.0/24 eq 3000 0.0.0.0/0 eq 4000
awplus(config)# access-list 11 permit udp 10.17.90.0/24 range 300 301 0.0.0.0/0 range 400 401
```

**Example** Note the below error message if you attempt to show an undefined access-list

```
show access-list 2
Access list 2 not found
```

## DEBUG ACCESS LEVEL

**Syntax** `debug access level <error|notice|debug>`

**Description** This command enables attempt intrusions to be placed in the system log. (The command to show the log content is [show log](#).)

**Feature** Logging Commands

**Mode** Interface Configuration Mode

**Release** 4.1

**Options**

Option	Description	Range	Default Value
level	the debug level error notice debug	NA	NA

**Note** NA

**Example** To set the log level to debug, enter the following commands:

```
awplus(config)# debug access level debug
```

## FIREWALL ENABLE (CONFIG-IF)

**Syntax**            firewall enable  
                     no firewall enable

**Description**      This command enables the firewall for the VLAN interface. (This command can also be used at the configuration level and including the VLAN ID.) Enabling the firewall will result in having the IP tables configured as they are explained in Section [6.3.3](#).

The no variant of this command removes the firewall function from the VLAN interface.

**Feature**            Security Commands

**Mode**              Global Configuration mode, Interface Configuration

**Release**            4.1

**Options**            NA

**Note**                Enabling a firewall means blocking all the incoming packets, so define the proper exceptions before. If IPv6 is enabled, when the firewall is enabled, both IPv4 and IPv6 packets are blocked, except for the packets specified in the access lists (if any) and for the following IPv6 messages: router-advertisement, neighbor-advertisement, neighbor-solicitation. This gets the Neighbor Discovery Protocol and the Stateless Address Autoconfiguration working, as they use such messages.

**Example**            To enable the firewall on the VLAN interface, enter the following commands:

```
awplus(config)# interface vlan1
awplus(config-if)# firewall enable
or -
awplus(config)# firewall enable 1
```

**IP FIREWALL TRIGGER (CONFIG-IF)**

**Syntax**      `ip firewall trigger <name> <triggerProtocol> <triggerPortStart> <triggerPortEnd> <openProtocol> <openPortStart> <openPortEnd>`  
`no ip firewall trigger <name>`

**Description**      This command creates a trigger that sets the conditions where if certain ports are opened (triggering ports), allows connections to other ports (triggered ports). A trigger therefore opens a secondary port dynamically. Triggered ports are closed when the triggering ports are closed, and there is no time dependence. The no variant of this command removes the trigger mechanism.

**Feature**      Security Commands

**Mode**      Interface Configuration

**Release**      4.1

**Options**

Option	Description	Range	Default Value
<name>	A label that helps identify the trigger. It cannot start with a digit.	NA	NA
<triggerProtocol>	Protocol for the application, tcp, udp, or all	NA	all
<triggerPortStart>	First port in the range for the control session	NA	NA
<triggerPortEnd>	Last port in the range for the control session.	NA	NA
<openProtocol>	Protocol for the port(s) that will be opened	NA	NA
<openPortStart>	The start of the secondary port range for an existing trigger.	NA	NA
<openPortEnd>	The end of the secondary port range for an existing trigger	NA	NA

**Note**      Some TCP ports (21, 80, 1720, 1723, 6667) and some UDP ports (69, 161, 162, 517, 518, 5060) are pre-configured and therefore unavailable. Moreover, the sum of the primary port ranges cannot exceed the maximum limit of 1000, and the secondary port range for each trigger cannot exceed the maximum limit of 1000, due to limited resources of the system. When the limit is exceeded, an error message is displayed.

**Example**      To create a trigger, once a TCP connection has been established on port 6969, will permit a TCP connection on ports 6881-6889, enter the following commands:

```
awplus(config)# interface vlan1
awplus(config-if)# ip firewall trigger btTrigger tcp 6969 6969 tcp 6881 6889
```

**Example**      To remove the trigger, input the following:

```
awplus(config)# interface vlan1
awplus(config-if)# no ip firewall trigger btTrigger
```

**IPv6 ACCESS-LIST EXTENDED**

**Syntax** `ipv6 access-list extended <list-name> permit {{icmp, tcp, udp} <source> {eq <sourceport>, range <start-range> <end-range>} <destination> {eq <destport>, range <start-range> <end-range>}}`  
`no access-list <access-list-id>`

**Description** This command configures an extended numbered access-list that permits packets from a specific source IPv6 address and for a specific protocol. The no variant of this command removes a specified extended numbered access-list, and removes all the related access restrictions as well. Use this command when configuring an extended numbered access-list for filtering IPv6 software packets.

**Feature** IPv6 Access Control List (ACL) Commands

**Mode** Privileged Exec Mode

**Release** 4.2

**Options**

Option	Description	Range	Default Value
list-name	A user specified name for the access list.	NA	NA
permit	The Access List accepts packets from the specified source	NA	NA
tcp   udp   icmp  ip_address	The protocol or the IP address. For ICMP note that icmpv6 is used.	NA	NA
source	- The IPv6 address and port range of the source.  The IP address is followed by a forward slash, then the prefix length. This matches any source IP address within the specified subnet for ipv6 addresses. The prefix format is X:X::/M such as 2001:db8::/64). The IPv6 format is X:X::X:X such as 2001:db8::1. Refer to <a href="#">IPv6 Addresses and Prefixes</a> for a description of the ipv6 format, especially the use of double colons (::).  The port range is the start and end port values.	NA	NA
destination	- The IPv6 address and port range of the destination.  The IP address is followed by a forward slash, then the prefix length. This matches any source IP address within the specified subnet for ipv6 addresses. The prefix format is X:X::/M such as 2001:db8::/64). The IPv6 format is X:X::X:X such as 2001:db8::1. Refer to <a href="#">IPv6 Addresses and Prefixes</a> for a description of the ipv6 format, especially the use of double colons (::).  The port range is the start and end port values.	NA	NA

**Note** NA

**Example** To create the access-list uran, for accepting tcp packets coming from the ip address 2001:05c0:1515:3a00::1, sent from a port ranging from 1024 to 65535, meant for the port 23 of the host 2001:05c0:1515:3a00::43. This is to permit telnet through the firewall.

```
ipv6 access-list extended uran tcp 2001:05c0:1515:3a00::1 range 1024 65535
2001:05c0:1515:3a00::43 eq 23
```

```
awplus(config)# interface vlan2
awplus(config-if)# ip firewall enable
awplus(config-if)# ipv6 traffic-filter uran
```

**Example**      Note the below error message if you attempt to show an undefined access-list

```
awplus# show access-list 2
Access list 2 not found
```

## IPV6 TRAFFIC-FILTER

**Syntax** `ipv6 traffic-filter <list-name>`

**Description** This command is similar to the access-group command in that it associates an IPv6 Access list to a VLAN interface.

**Feature** IPv6 Access Control List (ACL) Commands

**Mode** Privileged Exec Mode

**Release** 4.2

**Options**

Option	Description	Range	Default Value
list-name	A user specified name for the access list that has already been created.	NA	NA

**Note** The concept of sub-interfaces can apply to this command. Refer to [Multiple IP Addresses on a Subinterface \(subvlan\)](#).

**Example** Refer to the example for `ipv6 access-list extended`.



## PROTECTED

**Syntax**           protected  
                  no protected

**Description**       This command is applied to a port and ensures that all traffic from the protected port cannot flow to another protected port.

**Feature**           Switching Commands

**Mode**             Interface Configuration

**Release**           4.2

**Options**           NA

**Note**             Traffic from a protected port will flow to an unprotected port. Also, the command cannot be executed for hpna interface.

**Example**           To create a protected port, select the port first, as follows:

```
awplus(config)# interface port1.0.1
awplus(config-if)# protected
```

**Example**           To remove the trigger, input the following:

```
awplus(config)# interface port1.0.1
awplus(config-if)# unprotected
```

```
awplus# show interface port1.0.1
```

```
Interface port1.0.1
  Link is DOWN, administrative state is UP
  Address is 000c.2503.9a18
  Description:
  index 1 mtu N/A
  flowcontrol both, configured duplex auto, configured speed auto
  jumbo frame support is disabled
  Protected switching mode is enabled
```

## SHOW ACCESS-GROUP

**Syntax** `show access-group [VLAN id]`

**Description** Use this command to show the access-lists attached globally. If a VLAN id is specified, only the access-lists belonging that VLAN will be displayed.

In case of access to config-if submenu, the VLAN id is implicit and there's no need to specify it, as the help menu suggests.

**Feature** IPv4 Access Control List (ACL) Commands

**Mode** Privileged Exec Mode

**Release** 4.1

**Options**

Option	Description	Range	Default Value
VLAN id	Optional. Specify a VLAN id.	NA	NA

**Note** NA

**Example** To show all access-lists attached globally:

```
awplus(config-if)# do show access-group
Access list index: 5
```

```
-----
Protocol: TCP
Port number: 22
IP address: 32.32.32.29
Netmask: 255.255.255.255
Enabled on VLAN id: 1,2
Disabled on VLAN id: 4
```

```
Access list index: 6
```

```
-----
Protocol: UDP
Port number: 69
IP address: 32.32.32.28
Netmask: 255.255.255.255
Enabled on VLAN id: 1,2,4,5,6
Disabled on VLAN id:
```

```
awplus(config-if)#
awplus(config-if)# do show access-group 5
Access list index: 5
```

```
-----
Protocol: TCP
Port number: 22
IP address: 32.32.32.29
Netmask: 255.255.255.255
Vlan id: 1,2
```

## SHOW ACCESS-LIST

**Syntax** `show access-list [<1-99>]`

**Description** This command displays the specified access-list, or all access-lists if none have been specified. Note that only defined access-lists are displayed. An error message is displayed for an undefined access-list

**Feature** IPv4 Access Control List (ACL) Commands

**Mode** Privileged Exec Mode

**Release** 4.1

**Options**

Option	Description	Range	Default Value
<1-99>	IP standard access-list.	NA	NA

**Note** NA

**Example** To show the access-list with an ID of 20:

```
awplus# show access-list 20
Standard IP access list 20
  permit TCP 192.168.20.1 255.255.255.0 port 22 any
```

**Example** To display all the access lists:

```
awplus# show access-list
Standard IP access list 1
  permit TCP 192.168.20.1 255.255.255.0 port 80 any

Standard IP access list 2
  permit TCP 141.29.100.12 255.255.255.255 port 22 any
```

## SHOW IP FIREWALL STATUS

<b>Syntax</b>	show firewall status [VLAN-id]
<b>Description</b>	This command shows the status of the firewall for the selected VLAN ID. (This command can also be used at the configuration and interface configuration level and not including the VLAN ID.)
<b>Feature</b>	Security Commands
<b>Mode</b>	Global Configuration mode, Interface Configuration
<b>Release</b>	4.1
<b>Options</b>	NA
<b>Note</b>	NA
<b>Example</b>	To show the firewall status the VLAN interface, enter the following commands:

```
awplus# show ip firewall status vlan1
or -
awplus(config)# do show ip firewall status vlan1
or -
awplus(config)# interface vlan1
awplus(config-if)# do show ip firewall status
WAN interface: eth5.v1
-----
Firewall is disabled

WAN interface: brv1.1
-----
Firewall is disabled

LAN interface: brv199.199
-----
Firewall is enabled
```

**SHOW IPV6 ACCESS-LIST EXTENDED**

**Syntax** `show ipv6 access-list extended [access-list-name]`

**Description** This command displays information about the extended ipv6 access-list.

**Feature** Security Commands

**Mode** Global Configuration mode, Interface Configuration

**Release** 4.2

**Options**

Option	Description	Range	Default Value
access-list-name	The extended access-list name that was created.	NA	NA

**Note** NA

**Example** To show the firewall status the VLAN interface, enter the following commands:

```
awplus# show ipv6 access-list
```

```
Extended IPv6 access list pluto
```

```
    permit ICMPv6 (source: address 2001:5c0:1515:3a20::2/128) (destination: address 2001:5c0:1515:3a00::1/128)
```

```
Extended IPv6 access list venus
```

```
permit TCP (source: port 5001-5002 address 2001:5c0:1515:3a20::2/128) (destination: port 4003 address 2001:5c0:1515:3a00::1/128)
```

**SHOW IPV6 TRAFFIC-FILTER**

**Syntax** `show ipv6 traffic-filter [VLAN id][list-name]`

**Description** This command displays information about the access-lists applied to an interface.

**Feature** Security Commands

**Mode** Global Configuration mode, Interface Configuration

**Release** 4.2

**Options**

Option	Description	Range	Default Value
VLAN id	The VLAN the access-list was enabled on.		
access-list-name	The extended access-list name that was created.	NA	NA

**Note** NA

**Example** To show the status the VLAN interface, enter the following commands:

```
awplus# show ipv6 traffic-filter
```

```
Access restriction: pluto
```

```
-----
```

```
Protocol: ICMPv6
```

```
Source:
```

```
  IP address: 2001:5c0:1515:3a20::2/128
```

```
  Port(s):
```

```
Destination:
```

```
  IP address: 2001:5c0:1515:3a00::1/128
```

```
  Port(s):
```

```
Disabled on:
```

```
Enabled on: 200
```

```
Access restriction: saturn
```

```
-----
```

```
Protocol: TCP
```

```
Source:
```

```
  IP address: 2001:5c0:1515:3a20::2/128
```

```
  Port(s): 1024-65535
```

```
Destination:
```

```
  IP address: 2001:5c0:1515:3a20::1/128
```

```
  Port(s): 23
```

```
Disabled on: 200
```

```
Enabled on: 201
```

## 7. Network Management

The Network Management functions of the iMG include the following:

- [Network Address Translation \(NAT\)](#)
- [Network Time Protocol \(NTP\)](#)
- [NTP Command List](#)
- [Dynamic Host Configuration Protocol \(DHCP\)](#)
- [DHCP Command list](#)
- [Simple Network Management Protocol \(SNMP\)](#)
- [The following OIDs are registered for the iMG Models.SNMP Command List](#)

---

### 7.1 Network Address Translation (NAT)

#### 7.1.1 Introduction

NAT is a protocol used to translate IP packet addresses. This allows to have either the source IP address or the destination one to be changed. The same can be applied for the ports.

For now, two scenarios have been introduced: the classical one and the port mapping (virtual server). See RFC 1631 to have a better comprehension. To give a clearer idea about them, two examples follow.

In the first one, a laptop is locally connected to a board. As the laptop IP address is a local one, given by the DHCP server on board, packets cannot travel outside the local network. Enabling the NAT, the source address of the packets is replaced by the one of the WAN interface, that is a public IP address, and the laptop is allowed to use services outside the LAN. The board keeps trace of the connection, so that the packets sent can go outside the LAN by changing the source IP address, and the packets received by the WAN interface can be forwarded to the laptop by changing the destination IP address. The laptop has the illusion to use a service available on the board while it can be located elsewhere, and the host having the service has the illusion to talk with the WAN interface.

In the second one, the laptop has an SSH server running on it. An external host is connected via SSH to the board and can use the CLI on board. Let's suppose that a port mapping is performed, and to remap the board IP address and SSH port with the laptop ones. Once the external host reopens the connection, the laptop SSH server will answer instead. The host will have the illusion to talk with the board always, but things have been changed, so that the laptop is the final destination of the host connection.

#### 7.1.2 NAT on the iMG

The implementation of NAT on the iMG is based on the following RFCs: 1631.

### 7.1.3 NAT Command List

This chapter provides an alphabetical reference of configure, clear, and show commands related to Network Address Translation (NAT).

Table 7-1: NAT Commands

Commands
<code>ip nat enable</code>
<code>ip nat portmap</code>
<code>show ip nat</code>
<code>show ip firewall status &lt;VLAN id&gt;</code>



## IP NAT ENABLE

**Syntax**            `ip nat enable`  
                     `no ip nat enable`

**Description**       This command activates the NAT service on a LAN interface.  
  
                     Use the no variant of this command to disable the NAT on a LAN interface

**Feature**            NAT Commands

**Mode**              Global Configuration Mode

**Release**           4.2

**Options**           NA

**Note**              NAT Translations occur between All Non-NAT Enabled interfaces and the present interface. This implies that traffic between interfaces that have NAT Enabled is routed.

**Example**           See the following commands for options to enable NAT on the VLAN 2

```
awplus(config)# interface vlan 2
awplus(config-if)# ip nat enable
```

**Example**           To disable NAT on the VLAN 2, use following commands

```
awplus(config)# interface vlan 2
awplus(config-if)# no ip nat enable
```

**IP NAT PORTMAP**

**Syntax** `ip nat portmap <name> protocol <prot> remote-host <IP address> external-port <port> [to <port>] local-host <IP address> internal-port <port> [to <port>]  
no ip nat portmap <name>`

**Description** This command creates a virtual server specifying the port mapping to be performed. A remote host trying to connect on the external port will be connected to a local host on its internal port, giving the remote host the illusion to communicate with the board. Remote host 0.0.0.0 has a special meaning, as it refers to all the hosts.

Local host 0.0.0.0 isn't allowed.

Use the no variant of this command to remove the configured port mapping.

**Feature** NAT Commands

**Mode** Global Configuration Mode

**Release** 4.4

**Options**

Option	Description	Range	Default Value
<name>	Name of the port mapping configured	NA	NA
<prot>	Level 3 protocol, that is: tcp, udp or all (both)	NA	all
<IP address>	Specify the IP address of either the remote host or the local host, entered in the form A.B.C.D.	NA	NA
<port>	Specify the port number (1-65535) of either the remote host or the local host, it can be the initial port of a range setting	1-65535	NA
to <port>	Specify the second port of the range setting	1-65535	NA

**Note** NA

**Example** See the following commands for options to configure a virtual server listening on port 22 and using a local host (whose address is 192.168.20.2 and having the real SSH server on board) connected to a board whose address is 90.90.90.90.

```
awplus(config)# interface vlan 2
awplus(config-if)# ip nat portmap sshRemap protocol tcp remote-host 90.90.90.90
external port 22 local-host 192.168.20.2 internal-port 22
```

**Example** To remove a port mapping, use the following commands

```
awplus(config)# interface vlan 2
awplus(config-if)# no ip nat sshRemap
```

**Example** See the following commands for options to configure a virtual server listening on a range of ports 22-28 and using a local host (whose address is 192.168.20.2 and having the real SSH server on board) connected to a board whose address is 90.90.90.90.

```
awplus(config)# interface vlan 2
awplus(config-if)# ip nat portmap sshRemap protocol tcp remote-host 90.90.90.90
external port 22 to 28 local-host 192.168.20.2 internal-port 22 to 28
```

## SHOW IP NAT

**Syntax** show ip nat <VLAN id> <portmap>

**Description** This command shows the NAT status. For each VLAN the status of the NAT is given, followed by the list of portmap if any

**Feature** NAT Commands

**Mode** Global Configuration Mode

**Release** 4.3.1

**Options**

Option	Description	Range	Default Value
<VLAN id>	Specify the VLAN id	1-4094	NA
<portmap>	Specify the portmap name	NA	NA

**Note** NA

### Example

```
awplus# show ip nat
```

```
WAN IP interface: vlan204
```

```
-----
```

```
NAT is enabled
```

```
Port map: BattleCom
```

```
.....
```

```
Protocol: TCP
```

```
External IP address: all
```

```
External port Start: 47624
```

```
External port End: 47624
```

```
Internal IP address: 192.168.100.1
```

```
Internal port Start: 47624
```

```
Internal port End: 47624
```

```
Port map: BattleCom
```

```
.....
```

```
Protocol: UDP
```

```
External IP address: all
```

```
External port Start: 47624
```

```
External port End: 47624
```

```
Internal IP address: 192.168.100.1
```

```
Internal port Start: 47624
```

```
Internal port End: 47624
```

```
Port map: BattleCom
```

```
.....
```

```
Protocol: TCP
```

```
External IP address: all
```

```
External port Start: 2300
```

```
External port End: 2400
```

```
Internal IP address: 192.168.100.1
```

```
Internal port Start: 2300
Internal port End: 2400

Port map: BattleCom
.....
Protocol: UDP
External IP address: all
External port Start: 2300
External port End: 2400
Internal IP address: 192.168.100.1
Internal port Start: 2300
Internal port End: 2400
```

**SHOW IP FIREWALL STATUS <VLAN ID>**

**Syntax** do show ip firewall status <VLAN id>

**Description** This command shows the firewall status. For each VLAN the status of the firewall can be enabled or disabled. In case a trigger is present, its features will be displayed.

**Feature** Firewall Commands

**Mode** Global Configuration Mode

**Release** 4.2

**Options**

Option	Description	Range	Default Value
<VLAN id>	Specify the VLAN id	1-4094	NA

**Note** NA

**Example**

```
awplus# show ip firewall status
```

```
WAN IP interface: vlan202
```

```
-----  
Firewall is disabled
```

```
WAN IP interface: vlan203
```

```
-----  
Firewall is disabled
```

```
WAN IP interface: vlan204
```

```
-----  
Firewall is enabled
```

```
WAN IP interface: vlan205
```

```
-----  
Firewall is disabled
```

```
LAN interface: vlan100
```

```
-----  
Firewall is disabled
```

```
LAN interface: vlan500
```

```
-----  
Firewall is disabled
```

```
awplus#
```

---

## 7.2 Network Time Protocol (NTP)

### 7.2.1 Introduction

NTP is a protocol for synchronizing the time clocks on a collection of network devices using a distributed client/server mechanism. NTP uses UDP (User Datagram Protocol) as the transport mechanism. NTP evolved from the Time Protocol (RFC 868) and the ICMP Timestamp message (RFC 792).

NTP provides protocol mechanisms to specify the precision and estimated error of the local clock and the characteristics of the reference clock to which it may be synchronized.

A number of primary reference clocks, synchronized to national standards, are connected to widely accessible resources (such as backbone gateways or switches) operating as primary time servers. The primary time servers use NTP between them to crosscheck clocks, to mitigate errors due to equipment or propagation failures, and to distribute time information to local secondary time servers. The secondary time servers redistribute the time information to the remaining local hosts.

The hierarchical organization and distribution of time information reduces the protocol overhead, and allows selected hosts to be equipped with cheaper but less accurate clocks. NTP provides information which organizes this hierarchy on the basis of precision or estimated error.

- An NTP entity operating in a client mode sends periodic messages to its peers, requesting synchronization by its peers.
- An NTP entity enters symmetric passive mode in response to a message from a peer operating in Symmetric Active mode. An NTP entity operating in this mode announces its willingness to synchronize and be synchronized by its peers.
- An NTP entity operating in broadcast mode periodically sends messages announcing its willingness to synchronize all of its peers but not to be synchronized by any of them.

The same message format is used for both requests and replies. When a request is received, the server interchanges addresses and ports, fills in or overwrites certain fields in the message, recalculates the checksum, and returns it immediately. The information included in the NTP message allows each client/ server peer to determine the timekeeping characteristics of its peers, including the expected accuracies of their clocks. Each peer uses this information and selects the best time from possibly several other clocks, updates the local clock, and estimates its accuracy.

There is no provision in NTP for peer discovery, acquisition, or authentication. Data integrity is provided by the IP and UDP checksums. No reachability, circuit-management, duplicate-detection, or retransmission facilities are provided or necessary.

By its very nature clock synchronization requires long periods of time (hours or days) and multiple comparisons in order to maintain accurate timekeeping. The more comparisons performed, the greater the accuracy of the timekeeping.

### 7.2.2 NTP on the iMG

The implementation of NTP on the iMG is based on the following RFCs:

RFC 958, Network Time Protocol (NTP)

RFC 1305, Network Time Protocol (Version 3) Specification, Implementation and Analysis

RFC 1510, The Kerberos Network Authentication Service (V5)

Two modes of operation are supported: client and server. The switch is in client mode most of the time where it polls the configured peer at least once every preconfigured minimum time period.

The peer that the switch refers to must be a more accurate clock source than the switch itself or another switch directly connected to a more accurate clock source. The switch operates as a secondary time server. It cannot operate as a primary time server unless the primary clock source is operating in server mode. A primary clock source usually operates in broadcast mode, which is not supported by the switch's implementation of NTP. There is no support for clock selection or filtering. When the switch receives a valid reply from the peer, it synchronizes its own internal clock according to the information from the reply.

If the switch receives a synchronization request from an NTP client, it temporarily changes to server mode. It replies to the request with the current time from the switch's internal clock along with other information useful for synchronization. The switch's internal clock is accurate to 0.005 seconds.

### 7.2.3 NTP Command List

This chapter provides an alphabetical reference of configure, clear, and show commands related to Network Time Protocol (NTP).

Table 7-2: NTP Commands

Commands
<a href="#">ntp conf</a>
<a href="#">ntp peer</a>
<a href="#">ntp sync</a>
<a href="#">show ntp associations</a>
<a href="#">show ntp status</a>



**NTP CONF**

**Syntax** `ntp conf {pollingtime || time-out || robustness} <value>`

**Description** This command can set the value of three different parameters. See below for their meaning.

**Feature** NTP Commands

**Mode** Global Configuration Mode

**Release** 4.2

**Options**

Option	Description	Range	Default Value
polling-time	Seconds to wait between two consecutive poll attempts toward the same server	NA	60
time-out	Seconds to wait before trying again to contact a server	NA	5
Robustness	Number of attempts to be tried before declaring a server unreachable	NA	3

**Note** NA

**Example** The following example sets the parameters so to have a synchronization every 5 minutes, with retries every 10 seconds for a maximum of 4 attempts

```
awplus(config)# ntp conf polling-time 300
awplus(config)# ntp conf time-out 10
awplus(config)# ntp conf robustness 4
```

## NTP PEER

**Syntax**

```
ntp peer {<peeraddress>|<peername>}  
no ntp peer {<peeraddress>|<peername>}
```

**Description**

This command activates the NTP client on the switch and to specify the IP address of the SNTP or NTP server from which it is to obtain its date and time. You can specify only one SNTP or NTP server. After you enter this command, the switch automatically begins to query the network for the defined server. If no NTP server is specified, the network won't be queried and an error message will appear.

Use the no variant of this command to remove the configured NTP peer association. (If no NTP peer is specified, all the peers are removed).

**Feature** NTP Commands

**Mode** Global Configuration Mode

**Release** 4.2

**Options**

Option	Description	Range	Default Value
<peeraddress>	Specify the IP address of the peer, entered in the form A.B.C.D.	NA	NA
<peername>	Specify the peer hostname.	NA	NA

**Note** NA

**Example**

See the following commands for options to configure NTP peer association for the peer with an IP address of 192.0.2.23:

```
awplus(config)# ntp peer 192.0.2.23
```

**Example**

To remove an NTP peer association for this peer, use the following commands

```
awplus(config)# no ntp peer 192.0.2.23
```

**NTP SYNC**

**Syntax**            `ntp sync`

**Description**       This command forces a NTP synchronization. No parameters are used.

**Feature**            NTP Commands

**Mode**               Global Configuration Mode

**Release**            4.2

**Options**            NA

**Note**               The NTP client must be running in order for this command to work - it is enabled by means of the [ntp peer](#) command.

**Example**            See the following commands for options to configure an NTP server association, key and NTP version for the server with an IP address of 192.0.2.23:

```
awplus(config)# ntp peer 192.0.2.23
awplus(config)# ntp sync
```

**SHOW NTP ASSOCIATIONS**

**Syntax**            `show ntp associations`

**Description**      Use this command to display the status of NTP associations. Only the list of available NTP servers is showed in this release.

**Feature**            NTP Commands

**Mode**              Privileged Exec Mode

**Release**            4.2

**Options**            NA

**Note**               NA

**Example**            See the sample output of the `show ntp associations`

```
awplus# show ntp associations
```

```
awplus# show ntp associations
address
ntp1.ien.org
time.nist.gov
```

## SHOW NTP STATUS

**Syntax**            `show ntp status`

**Description**      This command displays the status of the Network Time Protocol (NTP).

**Feature**            NTP Commands

**Mode**              Privileged Exec Mode

**Release**            4.2

**Options**            NA

**Note**               NA

**Example**            See the sample output of the `show ntp status` command displaying information about the Network Time Protocol.:

```
awplus#show ntp status
```

```
Clock is synchronized, reference is: ntp2.ien.it
```

```
Polling time: 60 sec
```

```
Timeout: 5 sec
```

```
Maximum number of attempts: 3
```

## 7.3 Dynamic Host Configuration Protocol (DHCP)

This chapter describes the Dynamic Host Configuration Protocol (DHCP) support provided by your device. This includes how to configure your device to:

- act as a DHCP and BOOTP server
- use the DHCP client to obtain IP addresses for its own interfaces

### 7.3.1 BOOTP

Bootstrap Protocol (BOOTP) is a UDP-based protocol that enables a booting host to dynamically configure itself without external interventions. A BOOTP server responds to requests from BOOTP clients for configuration information, such as the IP address the client should use. BOOTP is defined in RFC 951, Bootstrap Protocol (BOOTP).

RFC 1542, Clarifications and Extensions for the Bootstrap Protocol, defines extensions to the BOOTP protocol, including the behavior of a DHCP relay agent.

### 7.3.2 DHCP

DHCP is widely used to dynamically assign host IP addresses from a centralized server that reduces the overhead of administering IP addresses. DHCP helps conserve the limited IP address space because IP addresses no longer need to be permanently assigned to hosts. DHCP centrally manages IP address assignment for a large number of subscribers.

DHCP is based on BOOTP, and is defined in RFC 2131. It extends the BOOTP mechanism by providing:

- a method for passing configuration information to hosts on a TCP/IP network
- automatic allocation of reusable network addresses
- other additional configuration options

When your device is configured as a DHCP server, it allocates IP addresses and other IP configuration parameters to clients (hosts), when the client requests them. This lets you configure your IP network without manually configuring every client. Note that each client must also be configured to receive its IP address automatically.

As well as addresses, a DHCP server assigns a wide range of parameters to clients, including subnet information and mask, domain and hostname, server addresses, keepalive times, MTUs, boot settings, encapsulation settings, time settings, and TCP settings.

DHCP is designed to interoperate with BOOTP clients and DHCP clients, without the BOOTP clients needing any change to their initialization software.

### 7.3.3 Configuring the DHCP Server

The DHCP server uses address pools when responding to DHCP client requests. Address pools contains specific IP configuration details that the DHCP server can allocate to a client. Each VLAN corresponding to a LAN interface has its own address pool

To configure a pool, you must:

- Enter its configuration mode.
- Define the Network the pool applies to.
- Define the Range of IP addresses that the server can allocate to clients. You can specify multiple address ranges for each pool.
- Set the Lease for the clients. This defines whether the clients receive a dynamic, permanent, or static IP address.
- Set the Options (standard and user-defined) that the clients of a pool require when configuring their IP details.

After configuring the address pools, you can then enable the DHCP server by using the command:

```
awplus(config)# service dhcp server
```

#### 7.3.3.1 Access the Pool

To access a DHCP pool and enter the configuration mode for the pool, use the command:

```
awplus(config)# ip dhcp pool <VLAN-id>
```

or the command:

```
awplus(config)# ip dhcp pool
```

#### 7.3.3.2 Access the Pool for IPV6

To access a DHCP pool and enter the configuration mode for the pool, use the command:

```
awplus(config)# ipv6 dhcp pool <VLAN-id>
```

or the command:

```
awplus(config)# ipv6 dhcp pool
```

### 7.3.3.3 Define the Subnet

Define the subnet that the DHCP clients are in:

```
awplus (dhcp-config) # subnet <subnet-address>
```

### 7.3.3.4 Define the Range

Configure an IP address range for the pool. This range must be in the same subnet as the pool's network setting. Use the command:

```
awplus (dhcp-config) # range <ip-address> [<ip-address>]
```

The first IPv4 address specifies the low end of the range, while the second IP address is the high end. You can set the range to a single IP address by specifying only one IP address.

### 7.3.3.5 Set the Lease

The DHCP server assigns IP settings to hosts for specific times (the lease time). Each DHCP pool has one lease time setting. You can use DHCP to allocate the following types of addresses:

- A dynamic IP addresses - These are available to a host for a limited amount of time. When the lease expires, the server can reallocate the IP address to another device. To set the lease time for the DHCP pool so that it assigns dynamic IP addresses, use the command:

```
awplus (dhcp-config) # lease <days> <hours> <minutes>
```

- A permanent IP addresses - These are available to a host for an unlimited amount of time. To set the lease time to assign permanent IP addresses, use the command:

```
awplus (dhcp-config) # lease infinite
```

- A static IP addresses - These are allocated to a particular client. The DHCP server recognizes the client by its MAC address. This lets you use DHCP to manage most of your network automatically, while having unchanging IP addresses on key devices such as servers. To assign a static IP address to a device, use the command:

```
awplus (dhcp-config) # host <ip-address> <mac-address>
```

BOOTP requests can be satisfied by pools with leases set to infinity.

### 7.3.3.6 Set the Options

DHCP allows clients to receive options from the DHCP server. Options describe the network configuration, and various services that are available on the network. Options are configured separately on each DHCP pool. You can configure the following standard predefined options:

- dns-server
- domain-name
- filename
- subnet-mask

And the following extended options:

- nis-domain (dhcp option 40)

- nis-servers (dhcp option 41)
- ntp-servers (dhcp option 42)
- tftp-server-name (dhcp option 66)
- undefined-128 (dhcp option 128)
- undefined-201 (dhcp option 201)
- vendor-class-identifier (dhcp option 60)
- vendor-specific-info (dhcp option 43)
- www-server (dhcp option 72)
- classless static route (dhcp option 121)

### 7.3.4 Configuring the DHCP Client

You can configure an interface on your device with a static IP address, or with a dynamic IP address assigned using your device's DHCP client. When you use the DHCP client, it obtains the IP address for the interface, and other IP configuration parameters, from a DHCP server. To configure an interface and gain its IP configuration using the DHCP client, use the command:

```
awplus(config)# interface <ifname>
awplus(config-if)# ip address dhcp
```

The DHCP client supports the following IP configuration options:

- Option 1 - the subnet mask for your device.
- Option 3 - a list of default routers.
- Option 6 - a list of DNS servers. This list appends the DNS servers set on your device with the ip name-server command.
- Option 15 - a domain name used to resolve host names. This option replaces the domain name set with the ip domain-name command. Your device ignores this domain name if it has a domain list set using the ip domain-list command.
- Option 43 - a vendor-specific "ACS url".
- Option 51 - lease expiration time.
- Option 121 - Classless Static Route.

If an IP interface is configured to get its IP address and subnet mask from DHCP, the interface does not take part in IP routing until the IP address and subnet mask have been set by DHCP.

For information on configuring static IP address on an interface, see the ip address command.



### 7.3.5 DHCP Command list

This chapter provides an alphabetical reference for commands used to configure DHCP.

For information about modifying or redirecting the output from show commands to a file, see “Controlling “show” Command Output.

Commands
<a href="#">dns-server</a>
<a href="#">dns-server (ipv6)</a>
<a href="#">domain-name</a>
<a href="#">domain-name (ipv6)</a>
<a href="#">filename</a>
<a href="#">host</a>
<a href="#">import dns-server (ipv6)</a>
<a href="#">import domain-name (ipv6)</a>
<a href="#">ip address dhcp</a>
<a href="#">ip dhcp client broadcast-flag</a>
<a href="#">ip dhcp client class-id</a>
<a href="#">ip dhcp client client-id</a>
<a href="#">ipv6 dhcp client request</a>
<a href="#">ip dhcp pool</a>
<a href="#">ip dhcp server interface</a>
<a href="#">ipv6 dhcp client pd</a>
<a href="#">ipv6 dhcp client request</a>
<a href="#">ipv6 dhcp pool</a>
<a href="#">lease</a>
<a href="#">option</a>
<a href="#">range</a>
<a href="#">service dhcp-server</a>
<a href="#">show counter dhcp-client</a>
<a href="#">show counter dhcp-server</a>
<a href="#">show dhcp lease</a>
<a href="#">show ip dhcp binding</a>
<a href="#">show ip dhcp pool</a>
<a href="#">show ip dhcp server summary</a>

Commands
<code>show ipv6 dhcp interface</code>
<code>subnet-mask</code>

## DNS-SERVER

**Syntax**            `dns-server <ip-address>`  
                     `no dns-server [<ip-address>]`

**Description**       This command adds a Domain Name System (DNS) server to the DHCP address pool you are configuring. You can use this command multiple times to create a list of DNS name servers available to the client.

The no variant of this command removes either the specified DNS server, or all DNS servers from the DHCP pool.

**Feature**            DHCP Commands

**Mode**               DHCP Configuration

**Release**            4.2

**Options**

Option	Description	Range	Default Value
<ip-address>	IPv4 address of the default router, in dotted decimal notation.	NA	NA

**Note**                NA

**Example**            To add the DNS server with the assigned IP address 192.168.1.1 to the DHCP pool of VLAN 1, use the following commands:

```
awplus(config)# ip dhcp pool 1
awplus(dhcp-config)# dns-server 192.168.1.1
```

**Example**            To remove the DNS server with the assigned IP address 192.168.1.1 from the DHCP pool of VLAN 1, use the following commands:

```
awplus(config)# ip dhcp pool 1
awplus(dhcp-config)# no dns-server 192.168.1.1
```

**Example**            To remove all DNS servers from the DHCP of VLAN 1, use the following commands:

```
awplus(config)# ip dhcp pool 1
awplus(dhcp-config)# no dns-server
```

## DNS-SERVER (IPv6)

**Syntax**            `dns-server <ipv6-address>`  
                     `no dns-server [<ipv6-address>]`

**Description**        This command adds a Domain Name Server (DNS) to the DHCP address pool you are configuring. You can use this command multiple times to create a list of DNS name servers available to the client.

To display the configured Domain Name Server (DNS) list use the following command:

`show ipv6 dhcp interface vlan-id`

The no variant of this command removes either the specified DNS server, or all DNS servers from the DHCP pool.

**Feature**            DHCP Commands

**Mode**              DHCP Configuration

**Release**           4.2

### Options

Option	Description	Range	Default Value
<ip-address>	IPv6 address of the default router, in dotted decimal notation.	NA	NA

**Note**              NA

**Example**            To add the DNS server with the assigned IP address 2001:db8::1 to the DHCP pool of VLAN 1, use the following commands:

```
awplus(config)# ipv6 dhcp pool 1
awplus(dhcp-config)# dns-server 2001:db8::1
```

or

```
awplus(config)# interface vlan 1
awplus(config-if)# ipv6 dhcp pool 1
awplus(dhcp-config)# dns server 2001:db8::1
```

**Example**            To remove the DNS server with the assigned IP address 2001:db8::1 from the DHCP pool of VLAN 1, use the following commands:

```
awplus(config)# ipv6 dhcp pool 1
awplus(dhcp-config)# no dns-server 2001:db8::1
```

**Example**            To remove all DNS servers from the DHCP of VLAN 1, use the following commands:

```
awplus(config)# ipv6 dhcp pool 1
awplus(dhcp-config)# no dns-server
```

**DOMAIN-NAME**

**Syntax** domain-name <domain-name>  
no domain-name

**Description** This command adds a domain name to the DHCP address pool you are configuring. Use this command to specify the domain name that a client should use when resolving host names using the Domain Name System.

The no variant of this command removes the domain name from the address pool.

**Feature** DHCP Commands

**Mode** DHCP Configuration

**Release** 4.3

**Options**

Option	Description	Range	Default Value
<domain-name>	The domain name you wish to assign the DHCP pool. Valid characters are any printable character. If the name contains spaces then you must enclose it in "quotation marks".	NA	NA

**Note** NA

**Example** To add the domain name Nerv\_Office to DHCP pool of VLAN 1, use the commands:

```
awplus(config)# ip dhcp pool P2
awplus(dhcp-config)# domain-name Nerv_Office
```

**Example** To remove the domain name Nerv\_Office from DHCP pool of VLAN 1, use the commands:

```
awplus(config)# ip dhcp pool 1
awplus(dhcp-config)# no domain-name
```

**DOMAIN-NAME (IPV6)**

**Syntax** domain-name <domain-name>  
no domain-name

**Description** This command adds a domain name to the DHCP address pool you are configuring. Use this command to specify the domain name that a client should use when resolving host names using the Domain Name System.

The no variant of this command removes the domain name from the address pool.

**Feature** DHCP Commands

**Mode** DHCP Configuration

**Release** 4.2

**Options**

Option	Description	Range	Default Value
<domain-name>	The domain name you wish to assign the DHCP pool. Valid characters are any printable character.	NA	NA

**Note** NA

**Example** To add the domain name Nerv\_Office to DHCP pool of VLAN 1, use the commands:

```
awplus(config)# ipv6 dhcp pool 1
awplus(dhcp-config)# domain-name Nerv_Office
```

**Example** To remove the domain name Nerv\_Office from DHCP pool of VLAN 1, use the commands:

```
awplus(config)# ipv6 dhcp pool 1
awplus(dhcp-config)# no domain-name
```

**FILENAME**

**Syntax** filename <string:bootfile>  
no filename

**Description** This command adds a file name to the DHCP address pool you are configuring. Use this command to insert a string to identify a boot file name header.

**Feature** DHCP Commands

**Mode** DHCP Configuration

**Release** 4.3.3

**Options**

Option	Description	Range	Default Value
<filename>	The filename you wish to assign the DHCP pool. Valid characters are any printable character excepting "blank" and "question mark".	NA	NA

**Note** NA

**Example** To add the filename my\_bootfilename to DHCP pool of VLAN 1, use the commands:

```
awplus(config)# interface vlan1
awplus(config-if)# ip dhcp pool
awplus(dhcp-config)# filename my-bootfilename
awplus(dhcp-config)# exit
```

**Example** To remove filename my\_bootfilename from DHCP pool of VLAN 1, use the commands:

```
awplus(config)# interface vlan1
awplus(config-if)# ip dhcp pool
awplus(dhcp-config)# no filename
awplus(dhcp-config)# exit
```

## HOST

**Syntax**

```
host <ip-address> <mac-address>  
no host <ip-address>  
no host all
```

**Description** This command adds a static host address to the DHCP address pool you are configuring. The client with the matching MAC address is permanently assigned this IP address. No other clients can request it.

The no variant of this command removes the specified host address from the DHCP pool. Use the no host all command to remove all static host addresses from the DHCP pool.

Note that a network/mask must be configured using a network command before issuing a host command. Also note that a host address must match a network to add a static host address.

**Feature** DHCP Commands

**Mode** DHCP Configuration

**Release** 4.2

**Options**

Option	Description	Range	Default Value
<ip-address>	IPv6 address of the DHCP client, in dotted decimal notation in the format A.B.C.D	NA	NA
<mac-address>	MAC address of the DHCP client, in hexadecimal notation in the format	NA	NA

**Note** NA

**Example** To add the host at 192.168.1.5 with the MAC address 000a.451d.6e34 to DHCP pool of VLAN 1, use the commands:

```
awplus(config)# ip dhcp pool 1  
awplus(dhcp-config)# network 192.168.1.0/24  
awplus(dhcp-config)# host 192.168.1.5 00:0a:45:1d:6e:34
```

**Example** To remove the host at 192.168.1.5 with the MAC address 000a.451d.6e34 from DHCP pool 1, use the commands:

```
awplus(config)# ip dhcp pool 1  
awplus(dhcp-config)# no host 192.168.1.5 00:0a:45:1d:6e:34
```



## IP ADDRESS DHCP

**Syntax**            `ip address dhcp`  
                     `no ip address dhcp`

**Description**        This command activates the DHCP client on the interface you are configuring. This allows the interface to use the DHCP client to obtain its IP configuration details from a DHCP server on its connected network.

The no variant of this command stops the interface from obtaining IP configuration details from a DHCP server.

**Feature**            DHCP Commands

**Mode**              Interface Configuration for a VLAN interface

**Release**           4.2

**Options**           NA

**Note**              NA

**Example**           To set the interface vlan10 to use DHCP to obtain an IP address, use the command:

```
awplus(config)# interface vlan10
awplus(config-if)# ip address dhcp
```

**Example**           To stop the interface vlan10 from using DHCP to obtain its IP address, use the command:

```
awplus(config)# interface vlan10
awplus(config-if)# no ip address dhcp
```

## IMPORT DNS-SERVER (IPV6)

**Syntax**            `import dns-server interface <vlan-id>  
no import dns-server`

**Description**       This command imports the Domain Name Server (DNS) from the IPv6 interface associated with the specified vlan to the DHCP address pool you are configuring. To display the configured Domain Name Server (DNS) list use the following command:

`show ipv6 dhcp interface vlan-id`

The no variant of this command removes the association and resets the DNS servers for the DHCP pool.

**Feature**            DHCP Commands

**Mode**              DHCP Configuration

**Release**           4.5

**Options**

**Note**              NA

**Example**           To add the DNS server from VLAN 100 to the DHCP pool of VLAN 1, use the following commands:

```
awplus(config)# ipv6 dhcp pool 1  
awplus(dhcp-config)# import dns-server intere vlan100
```

**Example**           To remove the importation of the domain name, use the following commands:fac

```
awplus(config)# ipv6 dhcp pool 1  
awplus(dhcp-config)# no import dns-server
```

## IMPORT DOMAIN-NAME (IPv6)

**Syntax**            `import domain-name interface <vlan-id>`  
                     `no import domain-name`

**Description**        This command imports the domain name from the IPv6 interface associated with the specified vlan to the DHCP address pool you are configuring. Use this command to specify the domain name that a client should use when resolving host names using the Domain Name System.

The no variant of this command removes the association and resets the domain name from the address pool.

**Feature**            DHCP Commands

**Mode**                DHCP Configuration

**Release**            4.5

**Options**

**Note**                NA

**Example**            To add the domain name from vlan 100 to the DHCP pool of VLAN 1, use the commands:

```
awplus(config)# ipv6 dhcp pool 1
awplus(dhcp-config)# import domain-name interface vlan100
```

**Example**            To remove the importation of the domain name, use the commands:

```
awplus(config)# ipv6 dhcp pool 1
awplus(dhcp-config)# no import domain-name
```

## IP DHCP CLIENT BROADCAST-FLAG

<b>Syntax</b>	<code>ip dhcp client broadcast-flag</code> <code>no ip dhcp client broadcast-flag</code>
<b>Description</b>	This command sets the broadcast flag
<b>Feature</b>	DHCP Commands
<b>Mode</b>	Interface Configuration for a VLAN interface
<b>Release</b>	4.4
<b>Options</b>	NA
<b>Note</b>	See SHOW DHCP LEASE command to show the dhcp client broadcast-mode setting
<b>Example</b>	To set broadcast flag use the command:

```
awplus# configure terminal
awplus(config)# interface vlan1
awplus(config-if)# ip dhcp client broadcast-flag
awplus(config-if)# end
```

## IP DHCP CLIENT CLASS-ID

**Syntax**            `ip dhcp client client-id ascii <STRING:option_value>`  
                     `no ip dhcp client client-id`

**Description**       This command sets the client-id vendor class-id (option 60) to an ascii string.

**Feature**            DHCP Commands

**Mode**               Interface Configuration for a VLAN interface

**Release**            4.4

**Options**            NA

Option	Description	Range	Default Value
<STRING:option_value>	An ascii string.	NA	NA

**Note**               See SHOW DHCP LEASE command to show the dhcp client settings

**Example**            To send a custom dhcp client-id to the DHCP use the command:

```
aawplus(config-if)# ip dhcp client ?
  class-id  Set Vendor Class-ID (Option 60)  <-- new
  client-id Set Client-ID (option 61)         <-- no change
  request   Permit the DHCP client to make requests to DHCP server
aawplus(config-if)# ip dhcp client class-id ?
  ascii
aawplus(config-if)# ip dhcp client class-id ascii ?
  <STRING:option_value>
aawplus(config-if)# ip dhcp client class-id ascii myimg
```

**IP DHCP CLIENT CLIENT-ID**

**Syntax** `ip dhcp client client-id {ATI-proprietary <ATI-value> | IAID <hex-string>}`  
`no ip dhcp client client-id {ATI-proprietary | IAID}`

**Description** This command creates or sets the client-id options.

The client-id option behaves as follows:

- If ATI-proprietary is not provisioned then the option 61 (client-ID) sent by the iMG in DHCP discover & request messages is formatted according to RFC4361 clause 6.1 with type 255 and containing an RFC3315 DUID-EN. Furthermore; if IAID is not provisioned by the user, the appropriate VLAN-ID will be inserted in this field. The DUID enterprise number will contain the Allied Telesis registered Private Enterprise Number (207) and the variable-length identifier will contain the iMG MAC address coded in ASCII characters of the form nn:nn:nn:nn:nn:nn. The user may override the default VLAN-ID IAID value by using the IAID option.
- If ATI-proprietary is provisioned then the iMG will send ATI legacy format Option 61 in DHCP discover & request messages (this is the format supported by ISOS-based iMGs).

**Feature** DHCP Commands

**Mode** Interface Configuration for a VLAN interface

**Release** 4.2

**Options**

Option	Description	Range	Default Value
<ATI-value>	A string of up to 254 printable ascii characters (excepting white space). This value is copied verbatim into the Client-ID option of outgoing DHCP discover & request messages.	NA	NA
<hex-string>	A string of hex characters up to 8 digits (i.e. 0 – FFFFFFFF). This value is used as the IAID in an RFC4361 Client-ID option for outgoing DHCP discover & request messages.  Note that an RFC3315 DUID-EN is used for the DUID, and the DUID identifier value is the iMG MAC address in ASCII with separating colons included.  If neither ATI-proprietary nor IAID are provisioned, then Client-ID option is sent with the value of the vlan-id where the dhcp client is actually running.	NA	NA

**Note** See SHOW DHCP LEASE command to show the dhcp client settings

**Example** To send a custom dhcp client-id to the DHCP use the command:

```
awplus(config)# interface vlan10
awplus(config-if)# ip dhcp client client-id ATI-proprietary sample
```

**IP DHCP CLIENT REQUEST**

**Syntax**      `ip dhcp client request {<option name>|<option value>}`  
                  `no ip dhcp client request {<option name>|<option value>}`

**Description**      This command configures the DHCP client options.

The DHCP client supports the following IP configuration options

Option 3 - a list of default routers.

Option 6 - a list of DNS servers. This list appends the DNS servers set on your device with the `ip name-server` command.

Option 15 - a domain name used to resolve host names. This option replaces the domain name set with the `ip domain-name` command. Your device ignores this domain name if it has a domain list set using the `ip domain-list` command.

Option 121 - classless static route. Enables the DHCP client to request classless routes from the DHCP server.

**Feature**      DHCP Commands

**Mode**      Interface Configuration for a VLAN interface

**Release**      4.2

**Options**

Option	Description	Range	Default Value
<option name>	router dns-name-server domain-name classless-static-route	NA	NA
<option value>	3 (default router). 6 (DNS servers). 15 (domain name). 121 (classless static route).	NA	NA

**Note**      See `SHOW DHCP LEASE` command to show the dhcp client settings

**Example**      To get the DHCP server giving the client a list of DNS servers, use the command:

```
awplus(config)# interface vlan10
awplus(config-if)# ip dhcp client request 6
```

## IP DHCP POOL

**Syntax** `ip dhcp pool <VLAN-id>`

**Description** This command will enter the configuration mode for the pool of the VLAN specified. If in the interface configuration submenu there is no need to specify the VLAN id.

**Feature** DHCP Commands

**Mode** Global Configuration Mode

**Release** 4.2

**Options**

Option	Description	Range	Default Value
<VLAN-id>	Id of the VLAN the pool refers to (1-4094)	1-4094	NA

**Note** See SHOW DHCP LEASE command to show the dhcp client settings

**Example** To enter the DHCP pool of the vlan 2, use either of these command:

```
awplus(config)# ip dhcp pool 2
```



## IP DHCP SERVER INTERFACE

**Syntax**            `ip dhcp server interface <VLAN id >`  
                     `[no] ip dhcp server interface <VLAN id >`

**Description**      This command starts DHCP server on the interface related to the VLAN id specified. The no variant stops it.

**Feature**            DHCP Commands

**Mode**              Privileged Exec Mode

**Release**           4.2

**Options**

Option	Description	Range	Default Value
<vlan_ID>	ID of the VLAN (1-4094)	NA	NA

**Note**                See SHOW DHCP LEASE command to show the dhcp client settings

**Example**            To enable a DHCP server on the interface related to VLAN 2, type  
`awplus(config-if)# ip dhcp server interface 2`

**Example**            To disable a DHCP server on the interface related to VLAN 2, type:  
`awplus(config-if)# no ip dhcp server interface 2`

**IPv6 DHCP CLIENT PD**

**Syntax**      `ipv6 dhcp client pd <prefix-name> [hint <ipv6-prefix>] [rapid-commit]`  
                  `no ipv6 dhcp client pd [<prefix-name>]`

**Description**      The `ipv6 dhcp client pd` command enables request for prefix delegation through the interface on which this command is configured. When prefix delegation is enabled and a prefix is successfully acquired, the prefix is stored in the IPv6 general prefix pool with an internal name defined by the `ipv6-prefix` argument. Other commands and applications (such as the `ipv6 address` command) can then refer to the prefixes in the general prefix pool. The `hint` keyword with the `ipv6-prefix` argument enables the configuration of an IPv6 prefix that will be included in DHCP for IPv6 solicit and request messages sent by the DHCP for IPv6 client on the interface as a hint to prefix-delegating routers. Multiple prefixes can be configured by issuing the `ipv6 dhcp client pd hint ipv6-prefix` command multiple times. The new prefixes will not overwrite old ones. The `rapid-commit` keyword enables the use of the two-message exchange for prefix delegation and other configuration. If it is enabled, the client will include the rapid commit option in a solicit message.

**Feature**      DHCP Commands

**Mode**      Interface Configuration for a VLAN interface

**Release**      4.2

**Options**

Option	Description	Range	Default Value
<prefix-name>	IPv6 general prefix name	NA	NA
<hint>	An IPv6 prefix sent a hint	NA	NA
<ipv6-prefix>	IPv6 general prefix .	NA	NA
<rapid-commit>	(Optional) Allows two-messages exchange method for prefix delegation.	NA	NA

**Note**      See `SHOW DHCP LEASE` command to show the dhcp client settings

**Example**      To enable prefix delegation:

```
Router(config-if)# ipv6 dhcp client pd dhcp-prefix
aRouter(config-if)# ipv6 dhcp client pd hint 2001:0DB8:1/48
```

**Example**      To configure a hint for prefix-delegating routers:

```
aRouter(config-if)# ipv6 dhcp client pd hint 2001:0DB8:1/48
```

## IPV6 DHCP CLIENT REQUEST

**Syntax** `ipv6 dhcp client request <option name | > [rapid-commit]`  
`[no] ipv6 dhcp client request <option name | > [rapid-commit]`

**Description** This command either gets the DHCPv6 client asking the server for some option or gets the DHCPv6 not asking. Allowed options are: domain-name-servers (option 23) or domain-search-list (option 24). Rapid-commit enable DHCPv6 two-message (solicit, reply) exchange.

**Feature** DHCP Commands

**Mode** Privileged Exec Mode

**Release** 4.2

### Options

Option	Description	Range	Default Value
<option name>	Name of the option to be requested or not. Allowed values are: domain-name-servers (option 23) or domain-search-list (option 24)	NA	NA

**Note** See SHOW DHCP LEASE command to show the dhcp client settings

**Example** To request default router list use one of these commands  
`awplus(config-if)# ipv6 dhcp client request domain-name-servers`

**Example** To don't ask for router list type use one of these commands:  
`awplus(config-if)# no ipv6 dhcp client request domain-name-servers`

## IPV6 DHCP POOL

**Syntax** `ipv6 dhcp pool <VLAN-id>`

**Description** This command will enter the configuration mode for the pool of the VLAN specified. If in the interface configuration submenu there is no need to specify the VLAN id.

**Feature** DHCP Commands

**Mode** Global Configuration Mode

**Release** 4.2

**Options**

Option	Description	Range	Default Value
<VLAN-id>	Id of the VLAN the pool refers to (1-4094)	1-4094	NA

**Note** See SHOW DHCP LEASE command to show the dhcp client settings

**Example** To enter the DHCP pool of the vlan 2, use either of these command:

```
awplus(config)# ipv6 dhcp pool 2
```

or

```
awplus(config)# interface vlan 2
```

```
awplus(config-if)# ipv6 dhcp pool
```

**LEASE**

**Syntax**

```
lease <days> <hours> <minutes>
lease infinite
no lease
```

**Description** This command sets the expiration time for a leased address for the DHCP address pool you are configuring. The time set by the days, hours, minutes and seconds is cumulative. The minimum total lease time that can be configured is 20 seconds. The maximum total lease time that can be configured is 120 days.

Note that if you add a user-defined option 51 using the option command, then you will override any settings created with this command. Option 51 specifies a lease time of 1 day.

Use the infinite parameter to set the lease expiry time to infinite (leases never expire).

Use the no variant of this command to return the lease expiration time back to the default of one day.

**Feature** DHCP Commands

**Mode** DHCP Configuration

**Release** 4.2

**Options**

Option	Description	Range	Default Value
<days>	The number of days, from 0 to 120, that the lease expiry time is configured for.	0-120	1
<hours>	The number of hours, from 0 to 24, that the lease expiry time is configured for. Default: 0	0-24	0
<minutes>	The number of minutes, from 0 to 60, the lease expiry time is configured for. Default: 1	1-60	1
infinite	The lease never expires.	NA	NA

**Note** NA

**Example** To set the lease expiration time for address pool of VLAN 2 to 35 minutes, use the commands:

```
awplus(config)# ip dhcp pool 2
awplus(dhcp-config)# lease 0 0 35
```

**Example** To set the lease expiration time for the address pool of VLAN 2 to 1 day, 5 hours, and 30 minutes, use the commands

```
awplus(config)# ip dhcp pool 2
awplus(dhcp-config)# lease 1 5 30
```

**Example** To set the lease expiration time for the pool to never expire, use the command:

```
awplus(dhcp-config)# lease infinite
```

**Example** To return the lease expiration time to the default of one day, use the command:

```
awplus(dhcp-config)# no lease
```

**OPTION**

**Syntax**      `option <option-name> <option-value>`  
                  `no option <option-name>]`

**Description**      This command adds a user-defined option to the DHCP address pool you are configuring. Options with an ip type can hold a list of IP addresses or masks (i.e. entries that have the A.B.C.D address format), so if the option already exists in the pool, then the new IP address is added to the list of existing IP addresses.

The no variant of this command removes the specified user-defined option from the DHCP pool, or all user-defined options from the DHCP pool.

**Feature**          DHCP Commands

**Mode**            DHCP Configuration

**Release**        4.2

**Options**

Option	Description	Range	Default Value
<option-name>	Option 40 - nis-domain. Option 41 - nis-servers. Option 42 - ntp-servers. Option 66 - tftp-server-name. Option 128 - undefined 128. . Option 201 - undefined 201. Option 60 - vendor-class-identifier Option 43 - vendor-specific-info Option 72 - www-server	NA	NA

**Note**            NA

**Source**        AW+

**Example**        These are all the possible options available that can be configured for the pool 3030:

```
awplus(config)# ip dhcp pool 3030
awplus(dhcp-config)# option tftp-server-name server1
awplus(dhcp-config)# option tftp-server-name 172.30.1.229
awplus(dhcp-config)# option nis-domain nis.ati-common.it
awplus(dhcp-config)# option nis-servers 192.168.100.45
awplus(dhcp-config)# option ntp-servers 10.17.90.68
awplus(dhcp-config)# option undefined-128 pippo.pluto
awplus(dhcp-config)# option undefined-201 paperino.topolino
awplus(dhcp-config)# option vendor-specific-info 00:14:22:b6:77:ef
awplus(dhcp-config)# option www-server 192.168.200.45
```

## RANGE

**Syntax**

```
range <ip-address> [<ip-address>]  
no range <ip-address> [<ip-address>]  
no range all
```

**Description** This command adds an address range to the DHCP address pool you are configuring. The DHCP server responds to client requests received from the pool's network. It assigns an IP addresses within the specified range. The IP address range must lie within the network. Only one address range is permitted in this release.

The no variant of this command removes the address range from the DHCP pool. Use the no range all command to remove all address ranges from the DHCP pool. (It is the same as no range, since there is only one range).

**Feature** DHCP Commands

**Mode** DHCP Configuration

**Release** 4.2

**Options**

Option	Description	Range	Default Value
<ip-address>	IPv4 address range for DHCP clients, in dotted decimal notation. The first IP address is the low end of the range, the second IP address is the high end. Specify only one IP address to add an individual IP address to the address pool.	NA	NA

**Note** NA

**Example** To add an address range of 192.0.2.5 to 192.0.2.16 to VLAN 2, use the command:

```
awplus(config)# ip dhcp pool 2  
awplus(dhcp-config)# range 192.0.2.5 192.0.2.16
```

**Example** To add the individual IP address 192.0.2.2 to a pool, use the command:

```
awplus(dhcp-config)# range 192.0.2.2
```

**Example** To remove all address ranges from a pool, use the command:

```
awplus(dhcp-config)# no range all
```

## SERVICE DHCP-SERVER

**Syntax** `service dhcp-server`

**Description** This command enabled the DHCP server on your device. Now use the `ip dhcp server interface <vlanid>` command to do it

**Feature** DHCP Commands

**Mode** Global Configuration Mode

**Release** 4.2

**Options**

Option	Description	Range	Default Value
<ip-address>	IPv4 address of the default router, in dotted decimal notation.	NA	NA

**Note** NA

**Example** To enable the DHCP server, use the command:

```
awplus(config)# service dhcp-server
```



**SHOW COUNTER DHCP-CLIENT**

**Syntax**            `show counter dhcp-client`

**Description**      This command shows counters for the dhcp client on your device.

**Feature**            DHCP Commands

**Mode**              Privileged Exec Mode

**Release**            4.2

**Options**            AW+

**Note**               NA

**Source**             AW+

**Example**            To display the message counters for the DHCP client on your device, use the command:

```
awplus# show counter dhcp-client
```

```
show counter dhcp-client
```

```
DHCPDISCOVER out      ..... 10
DHCPREQUEST out       ..... 34
DHCPDECLINE out       ..... 4
DHCPRELEASE out       ..... 0
DHCPOFFER in          ..... 22
DHCPACK in            ..... 18
```

Table 7-3: Parameters in the output of the show counter dhcp-client command

Parameter	Description
DHCPDISCOVER out	The number of DHCP Discover messages sent by the client.
DHCPREQUEST out	The number of DHCP Request messages sent by the client.
DHCPDECLINE out	The number of DHCP Decline messages sent by the client.
DHCPRELEASE out	The number of DHCP Release messages sent by the client.
DHCPOFFER in	The number of DHCP Offer messages received by the client.
DHCPACK in	The number of DHCP Acknowledgement messages received by the client.
DHCPNAK in	The number of DHCP Negative Acknowledgement messages received by the client.

**SHOW COUNTER DHCP-SERVER**

**Syntax**            show counter dhcp-server

**Description**      This command shows counters for the DHCP server on your device.

**Feature**            DHCP Commands

**Mode**              Privileged Exec Mode

**Release**           4.2

**Options**           NA

**Note**               NA

**Example**           To display counters for the DHCP server on your device, use the command:

```
awplus# show counter dhcp-server
DHCP server counters
DHCPDISCOVER in      ..... 20
DHCPREQUEST in       ..... 12
DHCPDECLINE in        ..... 1
DHCPRELEASE in        ..... 0
DHCPIFORM in          ..... 0
DHCP OFFER out        ..... 8
DHCPACK out           ..... 4
DHCPNAK out           ..... 0
BOOTREQUEST in        ..... 0
BOOTREPLY out         ..... 0
DHCPLEASEQUERY in     ..... 0
DHCPLEASEUNKNOWN out  ..... 0
DHCPLEASEACTIVE out   ..... 0
DHCPLEASEUNASSIGNED out ..... 0
```

Table 7-4: Parameters in the output of the show counter dhcp-client command

Parameter	Description
DHCPDISCOVER in	The number of Discover messages received by the DHCP server.
DHCPREQUEST in	The number of Request messages received by the DHCP server.
DHCPDECLINE in	The number of Decline messages received by the DHCP server.
DHCPRELEASE in	The number of Release messages received by the DHCP server.
DHCPIFORM in	The number of Inform messages received by the DHCP server.
DHCP OFFER out	The number of Offer messages sent by the DHCP server.
DHCPACK out	The number of Acknowledgement messages sent by the DHCP server.
DHCPNAK out	The number of Negative Acknowledgement messages sent by the DHCP server. The server sends these after receiving a request that it cannot fulfil because either there are no available IP addresses in the related address pool, or the request has come from a client that doesn't fit the network setting for an address pool.
BOOTREQUEST in	The number of bootp messages received by the DHCP server from bootp clients.

Table 7-4: Parameters in the output of the show counter dhcp-client command

Parameter	Description
BOOTREPLY out	The number of bootp messages sent by the DHCP server to bootp clients.
DHCPLEASEQUERY in	The number of Lease Query messages received by the DHCP server from DHCP relay agents.
DHCPLEASEUNKNOWN out	The number of Lease Unknown messages sent by the DHCP server to DHCP relay agents.
DHCPLEASEACTIVE out	The number of Lease Active messages sent by the DHCP server to DHCP relay agents.
DHCPLEASEUNASSIGNED out	The number of Lease Unassigned messages sent by the DHCP server to DHCP relay agents.

## SHOW DHCP LEASE

**Syntax**            `show dhcp lease [<interface>]`

**Description**      This command shows details about the leases that the DHCP client has acquired from a DHCP server for interfaces on the device.

**Feature**            DHCP Commands

**Mode**              Privileged Exec Mode

**Release**            4.2

**Options**

Option	Description	Range	Default Value
<interface>	Interface name to display dhcp lease details for.	all	all

**Note**                Only option 3, 6, 15, 60, and 61 are supported.

**Example**            To show the current lease for vlan1, use the command:

```
awplus# show dhcp lease vlan1
DHCP lease
-----

Interface vlan1
-----
Options:
  router: 10.17.90.1
  dns-name-server: 10.17.39.11,10.16.48.11
  domain-name: atg.lc
  class-id: class
  client-id: 67746774
```

**Example**            To show the current lease expiry times for all interfaces, use the command:

```
awplus# show dhcp lease
```

**SHOW IP DHCP BINDING**

**Syntax** `show ip dhcp binding [<ip-address>|<vlan-name>]`

**Description** This command shows the lease bindings that the DHCP server has allocated clients.

**Feature** DHCP Commands

**Mode** Privileged Exec Mode

**Release** 4.2.1

**Options**

Option	Description	Range	Default Value
<ip-address>	IPv4 address of a leased IP address, in dotted decimal notation. This displays the lease information for the specified IP address.	NA	NA
<vlan-name>	The vlan-name will be used to display the lease information for all clients within in specified VLAN-ID.	1-4094	NA

**Note** NA

**Example** To display all leases for every client in all address pools, use the command:

```
awplus# show ip dhcp binding
```

DHCP Client Entry

```
-----
IP Address      ClientId        Type      Expiry In
-----
192.168.1.200   00:02:02:34:2c:31  Dynamic   waiting client renewal
192.168.1.201   00:0b:db:de:cb:5a  Dynamic   00:59:18
192.168.1.210   00:0b:db:de:ca:5b  Static    Infinite
```

**Example** To display the details for the leased IP address 192.168.1.200, use the command:

```
awplus# show ip dhcp binding 192.168.1.200
```

**Example** To display the leases from the address pool vlan1, use the command:

```
awplus# show ip dhcp binding vlan1
```

## SHOW IP DHCP POOL

**Syntax** show ip dhcp pool <vlan-id>

**Description** This command shows the settings of a DHCP pool

**Feature** DHCP Commands

**Mode** Privileged Exec Mode

**Release** 4.2

**Options**

Option	Description	Range	Default Value
<vlan-id>	ID of the VLAN.	1-4094	NA

**Note** NA

**Example** To display the settings of DHCP pool of VLAN 1, use the command:

```
awplus (config)# do show ip dhcp pool 1
DHCP pool for LAN 1:
.....
network: 192.168.2.1 255.255.255.0
address range:
  addr:192.168.2.10 to 192.168.2.20
static host addresses:
lease <01:00:00:00>
subnet-mask: 255.255.255.248
DNS servers: 0.0.0.0,0.0.0.0
domain name: Home
```

**Example** To display the settings of DHCP pool of VLAN 3030, use the command:

```
awplus (config)# do show ip dhcp pool 3030
DHCP pool for LAN 3030:
.....
network: 192.168.1.1 255.255.255.0
address range:
addr:192.168.1.200 to 192.168.1.210
static host addresses:
lease <00:01:00:00>
subnet-mask: 255.255.255.0
DNS servers: 192.168.1.1
domain name: IMG1000
```

## SHOW IP DHCP SERVER SUMMARY

**Syntax**            `show ip dhcp server summary`

**Description**      This command shows the settings of the DHCP server.

**Feature**            DHCP Commands

**Mode**              Privileged Exec Mode

**Release**           4.2

**Options**           NA

**Note**              NA

**Example**           To display the settings of DHCP server, use the command:

```
awplus(config)# do show ip dhcp server summary
DHCP server summary
-----
```

```
LAN 1:
.....
DHCP server: enabled
DHCP relay: disabled
DNS servers: 10.17.90.1,10.16.48.33
Domain name: (null)
```

```
LAN 3030:
.....
DHCP server: enabled
DHCP relay: disabled
DNS servers: 192.168.1.1
Domain name: iMG1000
```

**SHOW IPV6 DHCP INTERFACE**

**Syntax** `show ipv6 dhcp interface <vlan-id>`

**Description** This command is to display Dynamic Host Configuration Protocol (DHCP) for IPv6 interface information, use the `show ipv6 dhcp interface` command.

**Feature** DHCP Commands

**Mode** Privileged Exec Mode

**Release** 4.2

**Options**

Option	Description	Range	Default Value
<vlan-id>	ID of the VLAN.	1-4094	NA

**Note** NA

**Example** To display whether the specified interface is in server or client mode. If a vlan ID is not specified it will show all information related to all interfaces.:

```
awplus# show ipv6 dhcp interface vlan12
DHCP pool for LAN 12:
.....
vlan is in server mode
DNS servers: 2001:5c0:1000:11::2
Domain name: dodici.com
DHCP client for WAN 12:
.....
vlan is in client mode
Address: 2012:900:1666:1:1000:1000:1111:1110/64
Set to make DHCP request for domain name servers: disabled
Set to make DHCP request for domain search list: disabled
DNS servers:
Domain name:
Rapid-Commit: enabled
Prefix delegation: disabled
awplus# show ipv6 dhcp interface vlan2
DHCP pool for LAN 2:
.....
vlan ins't in server mode
DNS servers:
Domain name:
DHCP client for WAN 2:
.....
vlan is in client mode
Address: 2001:5c0:1515:3a00::64/64
Set to make DHCP request for domain name servers: disabled
Set to make DHCP request for domain search list: disabled
DNS servers:
Domain name:
Prefix delegation: enabled
General prefix name: my-prefix
Prefix delegation hint: ::/63
```



## SUBNET-MASK

**Syntax** subnet-mask <mask>  
no subnet-mask

**Description** This command sets the subnet mask option for a DHCP address pool you are configuring. Use this command to specify the client's subnet mask as defined in RFC 950. This sets the subnet details using the pre-defined option 1.

The no variant of this command removes a subnet mask option from a DHCP pool. The pool reverts to using the pool's network mask.

**Feature** DHCP Commands

**Mode** DHCP Configuration

**Release** 4.2

**Options**

Option	Description	Range	Default Value
<mask>	Valid IPv4 subnet mask, in dotted decimal notation.	NA	NA

**Note** NA

**Example** To set the subnet mask option to 255.255.255.0 for DHCP pool of VLAN 2, use the commands:

```
awplus(config)# ip dhcp pool 2
awplus(dhcp-config)# subnet-mask 255.255.255.0
```

**Example** To remove the subnet mask option from DHCP pool of VLAN 2, use the commands:

```
awplus(config)# ip dhcp pool 2
awplus(dhcp-config)# no subnet-mask
```

**NETWORK (DHCP)**

**Syntax**            network {<ip-subnet-address/prefix-length>|<ip-subnet-address/mask>}  
no network

**Description**      This command sets the network (subnet) that the DHCP address pool applies to.

The no variant of this command removes the network (subnet) from the DHCP address pool.

This command will fail if it would make existing ranges invalid. For example, if they do not lie within the new network you are configuring.

The no variant of this command will fail if ranges still exist in the pool. You must remove all ranges in the pool before issuing a no network command to remove a network from the pool.

**Feature**            DHCP Commands

**Mode**                DHCP Configuration

**Release**            4.2

**Options**

Option	Description	Range	Default Value
<ip-subnet-address/prefix-length>	The IPv4 subnet address in dotted decimal notation followed by the prefix length in slash notation.	NA	NA
<ip-subnet-address/mask>	The IPv4 subnet address in dotted decimal notation followed by the subnet mask in dotted decimal notation.	NA	NA

**Note**                NA

**Example**            To configure a network for the address pool of the VLAN 2, where the subnet is 192.0.2.5 and the mask is 255.255.255.0, use the commands:

```
awplus(config)# ip dhcp pool 2
awplus(dhcp-config)# network 192.0.2.5/24
```

**Example**            or you can use dotted decimal notation instead of slash notation for the subnet-mask:

```
awplus(config)# ip dhcp pool 2
awplus(dhcp-config)# network 192.0.2.5 255.255.255.0
```

## 7.4 Simple Network Management Protocol (SNMP)

### 7.4.1 Introduction

The Simple Network Management Protocol (SNMP) is the network management protocol of choice for the Internet and IP-based internetworks.

This chapter describes the main features of SNMP Version 1 (SNMPv1), SNMP Version 2c (SNMPv2c). It also describes support for SNMP on the switch, and how to configure the switch's SNMP agent.


Unless a particular version of SNMP is named, “SNMP” in this chapter refers to versions SNMPv and SNMPv2c.

**Note:** SNMPv3 is not supported.

## 7.4.2 Network Management Framework

A network management system has the following components:

- One or more managed devices, each containing an agent that provides the management functions. A managed device may be any computing device with a network capability, for example, a host system, workstation, terminal server, printer, router, switch, bridge, hub or repeater.
- One or more Network Management Stations (NMS). An NMS is a host system running a network management protocol and network management applications, enabling the user to manage the network.
- A network management protocol used by the NMS and agents to exchange information.



**FIGURE 7-1 Components of a network management system**

The Internet-standard Network Management Framework is the framework used for network management in the Internet. The framework was originally defined by the following documents:

- RFC 1155, Structure and identification of management information for TCP/IP based internets (referred to as the SMI), details the mechanisms used to describe and name the objects to be managed.
- RFC 1213, Management Information Base for network management of TCP/ IP-based internets: MIB-II (referred to as MIB-II), defines the core set of managed objects for the Internet suite of protocols. The set of managed objects can be extended by adding other MIBs specific to particular protocols, interfaces or network devices.
- RFC 1157, A Simple Network Management Protocol (SNMP), is the protocol used for communication between management stations and managed devices.

Subsequent documents that have defined SNMPv2c are:

- RFC 1901, Introduction to Community-based SNMPv2
- RFC 1902, Structure of Management Information for Version 2 of the Simple Network Management Protocol (SNMPv2)
- RFC 1903, Textual Conventions for Version 2 of the Simple Network Management Protocol (SNMPv2)
- RFC 1904, Conformance Statements for Version 2 of the Simple Network Management Protocol
- RFC 1905, Protocol Operations for Version 2 of the Simple Network Management Protocol (SNMPv2)
- RFC 1906, Transport Mappings for Version 2 of the Simple Network Management Protocol (SNMPv2)
- RFC 1907, Management Information Base for Version 2 of the Simple Network Management Protocol (SNMPv2)
- RFC 2576, Coexistence between Version 1, Version 2, and Version 3 of the Internet-standard Network Management Framework
- RFC 2578, Structure of Management Information Version 2 (SMIv2)
- RFC 2579, Textual Conventions for SMIv2


- RFC 2580, Conformance Statements for SMIv2

### 7.4.3 Structure of Management Information

The structure of management information (SMI) defines the schema for a collection of managed objects residing in a virtual store called the management information base (MIB). The information in a MIB includes administrative and operational configuration information, as well as counters of system events and activities.

The MIB is organized into a tree-like hierarchy in which nodes are each assigned an identifier consisting of a non-negative integer and an optional brief textual description.

Each managed object is represented by a leaf node and is defined by its name, syntax, access mode, status and description. It can also be specifically identified by its unique position within the tree. This position is expressed as a series of dot-delimited sub-identifiers that start at the root node and end in the sub-identifier at the particular object's leaf node. For example, in Figure 85-2 the object named interfaces would be uniquely identified by the string of individual sub-identifiers, 1.3.6.1.2.1.2.



**FIGURE 7-2 Top levels of the Internet-standard Management Information Base (MIB)**

Objects defined in the Internet-standard MIB (MIB-II) reside in the mib(1) sub-tree.

### 7.4.4 Names

Names are used to identify managed objects, and are hierarchical in nature. An object identifier is a globally unique, authoritatively assigned sequence of non-negative integers which traverse the MIB tree from the root to the node containing the object.

Object identifiers may be represented in one of the following forms:

- Dotted notation lists the integer values found by traversing the tree from the root to the node in question, separated by dots. For example, the following identifies the MIB-II sub-tree:

1.3.6.1.2.1

- The following identifies the sysDescr object in the system group of MIB-II:

1.3.6.1.2.1.1.1

- Textual notation lists the textual descriptions found by traversing the tree from the root to the node in question, separated by spaces and enclosed in braces. For following example identifies the internet sub-tree:

{ iso org dod 1 }

- The name may be abbreviated to a relative form. The following example identifies the first (directory) node of the internet sub-tree:

{ internet 1 }

- Combined notation lists both the integer values and textual descriptions found by traversing the tree from the root to the node in question. The integer value is placed in parentheses after the textual description. The labels are separated by spaces and enclosed in braces. For example, the following identifies the first (directory) node in the internet sub-tree:

{iso(1) org(3) dod(6) internet(1) 1 }

- The name may be abbreviated to the following:

directory(1)

Since there is no effective limit to the magnitude of non-negative integers, and no effective limit to the depth of the tree, the MIB provides an unlimited name space.

An object is also usually assigned an object descriptor. The object descriptor is a unique, mnemonic, printable string intended for humans to use when discussing the MIB.

### 7.4.5 Instances

Objects are just templates for data types. An actual value that can be manipulated by an NMS is an instance of an object. An instance is named by appending an instance identifier to the end of the object's object identifier. The instance identifier depends on the object's data type:

- If the object is not a column in a table, the instance identifier is 0 (zero). For example, the instance of the sysDescr object is:

sysDescr.0

or 1.3.6.1.2.1.1.1.0

- If the object is a column in a table, the method used to assign an instance identifier varies. Typically, the value of the index column or columns is used.

The object ifTable in MIB-II contains information about interfaces and is indexed by the interface number, ifIndex. The instance of the ifDescr object for the first interface is:

ifDescr.1

or 1.3.6.1.2.1.2.2.1.2.1

If the index column is an IP address, the entire IP address is used as the instance identifier. The object `ipRouteTable` in MIB-II contains information about IP routes and is indexed by the destination address, `ipRouteDest`. The instance of the `ipRouteNextHop` object for the route 131.203.9.0 is:

`ipRouteNextHop.131.203.9.0`

or 1.3.6.1.2.1.4.21.1.7.131.203.9.0

If the table has more than one index, the values of all the index columns are combined to form the instance identifier. The object `tcpConnTable` in MIB-II contains information about existing TCP connections and is indexed by the local IP address (`tcpConnLocalAddress`), the local port number (`tcpConnLocalPort`), the remote IP address (`tcpConnRemAddress`) and the remote port number (`tcpConnRemPort`) of the TCP connection. The instance of the `tcpConnState` object for the connection between 131.203.8.36,23 and 131.203.9.197,1066 is:

`tcpConnState.131.203.8.36.23.131.203.9.197.1066`

or 1.3.6.1.2.1.6.13.1.1.131.203.8.36.23.131.203.9.197.1066

### 7.4.6 Syntax

The syntax of an object describes the abstract data structure corresponding to that object type. For example, INTEGER or OCTET STRING.

### 7.4.7 Access

The access mode of an object describes the level of access for the object.

Access modes for MIB objects are:

- Read-only                The object's value can be read but not set.
- Read-write              The object's value can be read and set.
- Write-only               The object's value can be set but not read.
- Not-accessible          The object's value cannot be read or set.

### 7.4.8 Status

The status of an object describes the implementation requirements for the object.

Status values for MIB objects are:

- Mandatory               Managed devices must implement the object.
- Optional                 Managed devices may implement the object.
- Obsolete                 Managed devices need no longer implement the object.
- Deprecated              Managed devices should implement the object. However, the object may be deleted from the next version of the MIB. A new object with equal or superior functionality is defined.

### 7.4.9 Description

The definition of an object may include an optional textual description of the meaning and use of the object. This description is often essential for successful understanding of the object.

### 7.4.10 The SNMP Protocol

The SNMP protocol provides a mechanism for management entities, or stations, to extract information from the Management Information Base (MIB) of a managed device.

The normal method of accessing information in a MIB is to use a Network Management Station (NMS), typically a PC or workstation, to send commands to the managed device (in this case the switch) using the SNMP protocol.

SNMP can use a number of different protocols as its underlying transport mechanism, but the most common transport protocol, and the only one supported by the switch, is UDP. Therefore the IP module must be enabled and properly configured in order to use SNMP. SNMP trap messages are sent to UDP port 162; all other SNMP messages are sent to UDP port 161. The switch's SNMP agent accepts SNMP messages up to the maximum UDP length the switch can receive.

Other transport mappings have been defined (e.g. OSI [RFC 1418], AppleTalk [RFC 1419] and IPX [RFC 1420]), but the standard transport mapping for the Internet (and the one the switch uses) is UDP. The IP module must be enabled and configured correctly. See [Layer 3 Routing Command List](#) for detailed descriptions of the commands required to enable and configure IP.

#### 7.4.10.1 SNMP Versions

iMG supports SNMP version 1 (SNMPv1) and SNMP version 2c (SNMPv2c). The two versions operate similarly.

SNMPv2c updated the original protocol, and offered the following main enhancements:

- a new format for trap messages.
- the get-bulk-request PDU allows for the retrieval of large amounts of data, including tables, with one message.
- more error codes mean that error responses to set messages have more detail than is possible with SNMPv1.
- three new exceptions to errors can be returned for get, get-next and get-bulk-request messages. These are: noSuchObject, noSuchInstance, and endOfMibView.

SNMPv3 provides significant enhancements to address the security weaknesses existing in the earlier versions. This is achieved by implementing two new major features:

- Authentication - by using password hashing and time stamping.
- Privacy - by using message encryption.

Support for multiple versions of SNMP is achieved by responding to each SNMP request with a response of the same version. For example, if an SNMPv1 request is sent to the switch, an SNMPv1 response is returned. If an SNMPv2c request is sent, an SNMPv2c response is returned. Therefore, authentication and encryption functions are not invoked when messages are detected as having either an SNMPv1 or SNMPv2c protocol format.

#### 7.4.10.2 SNMP Messages

The SNMP protocol is termed simple because it has only six operations, or messages—get, get-next, get-response, set, and trap, and SNMPv2c also has the get-bulk-request message. The replies from the managed device are processed by the NMS and generally used to provide a graphical representation of the state of the network. The two major SNMP operations available to a management station for interacting with a client are the get and set operations. The SNMP set operator can lead to security breaches, since SNMP is not inherently very secure. When forced to operate in either SNMPv1 or v2 mode, when operating with older management stations for example, care must be taken in the choice and safe-guarding of community names, which are effectively passwords for SNMP.

#### 7.4.10.3 Polling versus Event Notification

SNMP employs a polling paradigm. A Network Management Station (NMS) polls the managed device for information as and when it is required, by sending get-request, get-next-request, and/or get-bulk-request PDUs to the managed device. The managed device responds by returning the requested information in a get-response PDU. The NMS may manipulate objects in the managed device by sending a set-request PDU to the managed device.

The only time that a managed device initiates an exchange of information is in the special case of a trap PDU. A managed device may generate a limited set of traps to notify the NMS of critical events that may affect the ability of the NMS to communicate with the managed device or other managed devices on the network, and therefore to “manage” the network. Such

events include the restarting or re-initialization of a device, a change in the status of a network link (up or down), or an authentication failure.

#### 7.4.10.4 Message Format for SNMPv1 and SNMPv2c

Table 7-5: Fields in an SNMP message

Field	Function
Version	The version of the SNMP protocol. The value is version-1 (0) for the SNMP protocol as defined in RFC 1157, or version-2c (1) for the SNMP protocol as defined in RFC 1902.
Community	The name of an SNMP community, for authentication purposes
SNMP PDU	An SNMP Protocol Data Unit (PDU).

Table 7-6: SNMP PDUs

PDU	Function
get-request	Sent by an NMS to an agent, to retrieve the value of an object.
get-next-request	Sent by an NMS to an agent, to retrieve the value of the next object in the sub-tree. A sub-tree is traversed by issuing a get-request PDU followed by successive get-next-request PDUs.
get-bulk-request	Sent by an NMS to an agent to request a large amount of data with a single message. This is for SNMPv2c messages.
set-request	Sent by an NMS to an agent, to manipulate the value of an object. SNMP PDU Version Community
get-response	Sent by an agent to an NMS in response to a get-request, get-next-request, get-bulk-response, or set-request PDU.
trap	Sent by an agent to an NMS to notify the NMS of a extraordinary event.
report	Although not explicitly defined in the RFCs, reports are used for specific purposes such as EngineID discovery and time synchronization.

Table 7-7: Generic SNMP Traps

Value	Meaning
coldStart	The agent is re-initializing itself. Objects may be altered.
warmStart	The agent is re-initializing itself. Objects are not altered.
linkDown	An interface has changed state from up to down.
linkUp	An interface has changed state from down to up.
authenticationFailure	An SNMP message has been received with an invalid community name.
egpNeighborLoss	An EGP peer has transitioned to down state.



### 7.4.1.1 SNMP Communities (Version v1 and v2c)

A community is a relationship between an NMS and an agent. The community name is used like a password for a trivial authentication scheme. Both SNMPv1 and SNMPv2c provide security based on the community name only.

#### 7.4.1.1.1 SNMPv1 and SNMPv2c

Although software levels 2.6.3 and higher support the specific facilities of SNMP v1 and v2, their documentation is available to provide backward compatibility with older network management systems. The far superior security features offered by implementing SNMPv3 should be used wherever possible.

The switch's implementation of SNMPv1 is based on RFC 1157, A Simple Network Management Protocol (SNMP), and RFC 1812, Requirements for IP Version 4 Routers.

When the SNMP agent is disabled, the agent does not respond to SNMP request messages. The agent is disabled by default. The current state and configuration of the SNMP agent can be displayed.

#### 7.4.1.1.2 SNMP MIB Views for SNMPv1 and SNMPv2c

An SNMP MIB view is a arbitrary subset of objects in the MIB. Objects in the view may be from any part of the object name space, and not necessarily the same sub-tree. An SNMP community profile is the pairing of an SNMP access mode (read-only or read-write) with the access mode defined by the MIB for each object in the view. For each object in the view, the community profile defines the operations that can be performed on the object.

Pairing an SNMP community with an SNMP community profile determines the level of access that the agent affords to an NMS that is a member of the specified community. When an agent receives an SNMP message, it checks the community name encoded in the message. If the agent knows the community name, the message is deemed to be authentic and the sending SNMP entity is accepted as a member of the community. The community profile associated with the community name then determines the sender's view of the MIB and the operations that can be performed on objects in the view.

#### 7.4.1.1.3 SNMP Communities

SNMP communities were introduced into SNMPv1 and retained in version 2c. Although the switch's software still supports communities, this is to provide backward compatibility with legacy management systems. Communities should not be used where a secure network is required. Instead, use the secure network features offered by SNMPv3.

An SNMP community is a pairing of an SNMP agent with a set of SNMP application entities. Communities are the main configuration item in the switch's implementation of SNMPv1 and v2, and are defined in terms of a list of IP addresses which define the SNMP application entities (trap hosts and management stations) in the community.

Important community names act as passwords and provide minimal authentication. Any SNMP application entity that knows a community name can read the value of any instance of any object in the MIB implemented in the switch. Any SNMP application entity that knows the name of a community with write access can change the value of any instance of any object in the MIB implemented in the switch, possibly affecting the operation of the switch. For this reason, take care with the security of community names.

When a trap is generated by the SNMP agent it is forwarded to all trap hosts in all communities. The community name and manager addresses are used to provide trivial authentication. An incoming SNMP message is deemed authentic if it contains a valid community name and originated from an IP address defined as a management station for that community.

When a community is disabled, the SNMP agent behaves as if the community does not exist and generates authentication failure traps for messages directed to the disabled community.

The SNMP agent does not support a default community called "public" with read-only access, traps disabled and open access as mandated in RFC 1812, as this is a security hole open for users who wish to use the switch with minimal modification to the default configuration. The default configuration of the switch has no defined communities. Communities must be explicitly created.

SNMP authentication (for SNMPv1 and v2) is a mechanism whereby an SNMP message is declared to be authentic, that is from an SNMP application entity actually in the community to which the message purports to belong. The mechanism may be trivial or secure. The only form of SNMP authentication implemented by the switch's SNMP agent is trivial authentication. The authentication failure trap may be generated as a result of the failure to authenticate an SNMP message.

Switch interfaces can be enabled or disabled via SNMP by setting the ifAdminStatus object in the ifTable of MIB-II MIB to 'Up(1)' or 'Down(2)' for the corresponding ifIndex. If it is not possible to change the status of a particular interface the switch returns an SNMP error message.

The switch's implementation of the ifOperStatus object in the ifTable of MIB-II MIB supports two additional values—"Unknown(4)" and "Dormant(5)" (e.g. an inactive dial-on-demand interface).

**Caution:** An unauthorized person with knowledge of the appropriate SNMP community name could bring an interface up or down. Community names act as passwords for the SNMP protocol. When creating an SNMP community with write access, take care to select a secure community name and to ensure that only authorized personnel know it.

An SNMP MIB view is a subset of objects in the MIB that pertain to a particular network element. For example, the MIB view of a hub would be the objects relevant to management of the hub, and would not include IP routing table objects, for example. The switch's SNMP agent does not allow the construction of MIB views. The switch supports all relevant objects from all MIBs that it implements.

Note that the switch's standard set and show commands can also be used to access objects in the MIBs supported by the switch.

#### 7.4.11.4 Defining Management Stations within Communities

You can add management stations to a community either individually, by entering just its IP address, or you can enter a range of management stations by entering an IP address that ends with a '/' character followed by a number between 1 and 32. The number that follows the '/' character operates as an address mask to define a range of addresses for the management stations. The following example shows how to allocate a band of three binary addresses to a portion of the subnet 146.15.1.X

In this example we make provision for up to 8 possible management stations within a community called "admin".

#### 7.4.12 Configuration Example (SNMPv1 and v2)

This example shows how to configure the switch's SNMP agent. Two network management stations have been set up on a large network. The central NMS (IP address 192.168.11.5) monitors devices on the network and uses SNMP set messages to manage devices on the network. Trap messages are sent to this management station. The regional network management station (IP addresses 192.168.16.1) is used just to monitor devices on the network by using SNMP get messages. Link traps are enabled for all interfaces on this particular switch.

IP and VLANs must be correctly configured in order to access the SNMP agent in the switch. This is because the IP module handles both the TCP transport functions, and the UDP functions that enable datagrams to transport SNMP messages.

To configure SNMP

1. Enable the SNMP agent.

Enable the SNMP agent and enable the generation of authenticate failure traps to monitor unauthorized SNMP access. SNMP is enabled by default in AlliedWare Plus.

```
awplus(config)# snmp-server
```

**Note:** Battery traps require the power-management feature to be enabled.

#### 7.4.13 Object ID (OID) Numbers for iMG Models

### 7.4.14 The following OIDs are registered for the iMG Models. **SNMP Command List**

Table 7-8: OID Registration Numbers

Model	OID
iMG1505	1.3.6.1.4.1.207.1.17.101
iMG1525	1.3.6.1.4.1.207.1.17.89
iMG1525RF	1.3.6.1.4.1.207.1.17.91
iMG2504	1.3.6.1.4.1.207.1.17.108
iMG2522	1.3.6.1.4.1.207.1.17.110
iMG2524	1.3.6.1.4.1.207.1.17.93
iMG2524H	1.3.6.1.4.1.207.1.17.95
iMG2524F	1.3.6.1.4.1.207.1.17.109
iMG1405	1.3.6.1.4.1.207.1.17.111
iMG1405W	1.3.6.1.4.1.207.1.17.126
iMG1425	1.3.6.1.4.1.207.1.17.112
iMG1425W	1.3.6.1.4.1.207.1.17.113
iMG12426F	1.3.6.1.4.1.207.1.17.125

This provides an alphabetical reference for commands used to configure SNMP.

For information about modifying or redirecting the output from show commands to a file, see Controlling “show” Command Output.

Table 7-9: SNMP Command List

<a href="#">show running-config snmp</a>
<a href="#">show snmp-server</a>
<a href="#">show snmp-server community</a>
<a href="#">show snmp-server traps</a>
<a href="#">snmp-server ip</a>
<a href="#">snmp-server community</a>
<a href="#">snmp-server contact</a>
<a href="#">snmp-server enable traps link-status</a>
<a href="#">snmp-server host</a>
<a href="#">snmp-server location</a>
<a href="#">snmp-server system-shutdown</a>

**SHOW RUNNING-CONFIG SNMP**

**Syntax**            `show running-config snmp`

**Description**      This command displays the current configuration of SNMP on your device.

**Feature**            SNMP Commands

**Mode**              Privileged Exec Mode

**Release**           4.2

**Options**           NA

**Note**              NA

**Example**           To display the current configuration of SNMP on your device, use the command:

```
awplus# show running-config snmp
snmp-server host 212.58.224.138
snmp-server location Milan
snmp-server contact info@alliedtelesis.com
snmp-server community public ro
snmp-server community private rw
snmp-server ip
```

**SHOW SNMP-SERVER**

**Syntax**            `show snmp-server`

**Description**       This command displays the status and current configuration of the SNMP server.

**Feature**            SNMP Commands

**Mode**              Privileged Exec Mode

**Release**           4.2

**Options**           NA

**Note**              NA

**Example**           To display the status of the SNMP server, use the command:

```
awplus# show snmp-server
SNMP Server      Enabled
IP Protocol      IPv4
System Shutdown  Enabled
```

**SHOW SNMP-SERVER COMMUNITY**

**Syntax**            `show snmp-server community`

**Description**       This command displays the SNMP server communities configured on the device. SNMP communities are specific to v1 and v2c.

**Feature**            SNMP Commands

**Mode**              Privileged Exec Mode

**Release**           4.2

**Options**           NA

**Note**              NA

**Example**           To display the status of the SNMP server, use the command:

```
awplus# show snmp-server community
SNMP community information:
Community Name  private
    Access  Read-write
Community Name  public
    Access  Read-only
```

**SHOW SNMP-SERVER TRAPS**

**Syntax**            `show snmp-server traps`

**Description**       This command displays the current configuration of SNMP server traps.

**Feature**            SNMP Commands

**Mode**              Privileged Exec Mode

**Release**           4.4

**Options**           NA

**Note**              NA

**Example**           To display the current configuration of SNMP on your device, use the command:

```
awplus# show snmp-server traps
```

```
SNMP traps information:
```

```
  Link-Status Traps ..... Enabled
```

## SNMP-SERVER IP

**Syntax**            `snmp-server ip`  
                     `no snmp-server ip`

**Description**        This command enables the SNMP agent (server) on the switch. The SNMP agent receives and processes SNMP packets sent to the switch, and generates notifications (traps) that have been enabled by the `snmp-server enable trap` command on page 86.18.

Use the `no` variant of this command to disable the SNMP agent on the switch. When SNMP is disabled, SNMP packets received by the switch are discarded, and no notifications are generated. This does not remove any existing SNMP configuration.

By default, the SNMP agent is enabled for IPv4 (IPv6 is not supported.)

**Feature**            SNMP Commands

**Mode**              Global Configuration Mode

**Release**            4.2

**Options**            NA

**Note**               NA

**Example**            To enable the SNMP agent for IPv4 on the device, use the commands:

```
awplus(config)# snmp-server ip
```

**Example**            To disable the SNMP agent for IPv4 on the switch, use the commands:

```
awplus(config)# no snmp-server ip
```



## SNMP-SERVER COMMUNITY

**Syntax** `snmp-server community <community-name> [ro|rw]`  
`no snmp-server community <community-name>`

**Description** This command creates an SNMP community, optionally setting the access mode for the community. The default access mode is read only. If view is not specified, the community allows access to all the MIB objects. The SNMP communities are only valid for SNMPv1 and v2c and provide very limited security. Communities should not be used when operating SNMPv3.

The no variant of this command removes an SNMP community. The specified community must already exist on the device.

**Feature** SNMP Commands

**Mode** Global Configuration Mode

**Release** 4.2

**Options**

Option	Description	Range	Default Value
<community-name>	Community name. The community name is a string up to 20 characters long and is case sensitive.	NA	NA
read/write	Controls whether the community is Read only (ro) or Read Write (rw)	NA	NA

**Note** NA

**Example** The following command creates an SNMP community called "public" with read only access to all MIB variables from any management station

```
awplus(config)# snmp-server community public ro
```

**Example** The following command removes an SNMP community called "public":

```
awplus(config)# no snmp-server community public
```

## SNMP-SERVER CONTACT

**Syntax**           snmp-server contact <contact-name>  
                  no snmp-server contact

**Description**       This command sets the contact details of the system. The contact details are

- displayed in the output of the show system command
- stored in the MIB object sysContact

Use the no variant of this command to remove the configured contact details from the system.

**Feature**           SNMP Commands

**Mode**             Global Configuration Mode

**Release**          4.2

**Options**

Option	Description	Range	Default Value
<contact-name>	The contact details of the system, from 1 to 32 characters long. Valid characters are any printable character and spaces.	NA	NA

**Note**             NA

**Example**          To set the contact details to "info@alliedtelesis.com", use the following commands:

```
awplus(config)# snmp-server contact info@alliedtelesis.com
```

## SNMP-SERVER ENABLE TRAPS LINK-STATUS

**Syntax**           snmp-server enable traps link-status  
                  no snmp-server enable traps link-status

This command enables the SNMP traps link status. A trap of link up is sent when a cable is plugged on port1.0.1-port1.0.5 or hpna1.0.1. A trap of link down is sent when a cable is unplugged on port1.0.1-port1.0.5 or hpna1.0.1..

**Feature**           SNMP Commands

**Mode**             Global Configuration Mode

**Release**          4.4

**Options**          NA

**Note**             NA

**Example**          To enable the SNMP traps link-status, use the commands:

```
awplus(config)# snmp-server enable traps link-status
```

**Example**          To disable the SNMP traps link-status, use the commands:

```
awplus(config)# no snmp-server enable traps link-status
```

## SNMP-SERVER HOST

**Syntax**            `snmp-server host {<ipv4-address>}`  
                     `no snmp-server host`

**Description**       This command specifies an SNMP trap host destination to which Trap messages generated by the device are sent.

Use the no variant of this command to remove the SNMP trap host. The trap host must already exist.

The trap host is uniquely identified by:

- host IP address (IPv4),

**Feature**            SNMP Commands

**Mode**                Global Configuration Mode

**Release**            4.2

### Options

Option	Description	Range	Default Value
host	Configure SNMP trap host.	NA	NA
no	Remove the specified SNMP trap host.	NA	NA
<ipv4-address>	IPv4 trap host address in the format A.B.C.D, for example, 192.0.2.2.	NA	NA

**Note**                NA

**Example**            To configure the device to send generated traps to the IPv4 host destination 192.0.2., use the following command:

```
awplus(config)# snmp-server host 192.0.2.5
```

**Example**            To remove a configured trap host, use the following command:

```
awplus(config)# no snmp-server host
```

## SNMP-SERVER LOCATION

**Syntax**           snmp-server location <location-name>  
                  no snmp-server location

**Description**       This command sets the location of the system. The location is:

- displayed in the output of the show system command
- stored in the MIB object sysLocation

The no variant of this command removes the configured location from the system.

**Feature**           SNMP Commands

**Mode**             Global Configuration Mode

**Release**           4.2

**Options**

Option	Description	Range	Default Value
<location-name>	The location of the system, from 1 to 32 characters long. Valid characters are any printable character and spaces.	NA	NA

**Note**             NA

**Example**           To set the location to "server room 523", use the following commands:

```
awplus(config)# snmp-server location server room 523
```

## SNMP-SERVER SYSTEM-SHUTDOWN

<b>Syntax</b>	<code>snmp-server system-shutdown</code> <code>no snmp-server system-shutdown</code>
<b>Description</b>	This command enables a remote provisioning system to restart the CPE by setting the private SNMP object <code>sysRestart</code> . By default this object is protected and any attempt to force its value is refused. Due to the insecure level of SNMP v1/v2C it is strongly recommended to do not enable this feature unless strictly required by the management framework. In this case it's recommended to use access-list to control and protect access to SNMP objects.
<b>Feature</b>	SNMP Commands
<b>Mode</b>	Global Configuration Mode
<b>Release</b>	4.3.3
<b>Note</b>	NA
<b>Example</b>	Enable <code>sysRestart</code> SNMP object: <code>awplus(config)# snmp-server system-shutdown</code>

---

## 7.5 TR69 Configuration

### 7.5.1 Introduction

The iMG supports the following Broadband Forum data models:

- TR-098
- TR-104

The following TR-69 RPC methods are also supported:

- GetRPCMethods
- SetParameterValues
- GetParameterValues
- GetParameterNames
- GetParameterAttributes
- SetParameterAttributes
- AddObject
- DeleteObject
- Reboot
- Download
- Upload
- GetQueuedTransfers
- ScheduleInform
- FactoryReset

There are several ways to set up the iMG as a tr69 client to communicate with the Auto-Configuration Server (ACS).

- AlliedView NMS - the iMG Boot Configurator Refer to the *AlliedView NMS Administration Guide*.
- iMG GUI - Refer to [Using the GUI Application](#).

- Commands - This is covered in this section.

### 7.5.2 TR69 Command List

This provides an alphabetical reference for commands used to configure SNMP.

For information about modifying or redirecting the output from show commands to a file, see Controlling “show” Command Output.

Table 7-10: TR69 Command List

<a href="#">show tr69-client</a>
<a href="#">tr69-client acs-authentication</a>
<a href="#">tr69-client acs-url</a>
<a href="#">tr69-client bind source-interface &lt;if-name&gt;</a>
<a href="#">tr69-client inform</a>
<a href="#">tr69-client request-authentication</a>

## SHOW TR69-CLIENT

**Syntax**            show tr69-client

**Description**      This command shows the configuration of the iMG TR69 client

**Feature**            TR69 Commands

**Mode**              Privileged Exec Mode

**Release**           4.2

**Options**            NA

**Note**              Passwords are deliberately obscured.

**Example**            See the example output below:

```
awplus# show tr69-client
-----
TR69 Client Configuration
-----
Periodic Inform                               : Enabled
Periodic Inform Interval (seconds): 300
ACS URL                                       : http://10.17.90.63:9797/cwmp/ACS
ACS User Name                                 : manager
ACS Password                                  : ****
Source Interface                              : vlan203
Connection Request Authentication : Disabled
Connection Request User Name                :
Connection Request Password                 :
```



## TR69-CLIENT ACS-AUTHENTICATION

**Syntax**            `tr69-client acs-authentication {password <password> | username <username>  
no tr69-client acs-authentication {password | username}`

**Description**        This command configures the username and password used to authenticate the iMG when making a connection to an ACS.

Use the no variant of this command to remove configured username and password

**Feature**            TR69 Commands

**Mode**                Global Configuration Mode

**Release**            4.2

### Options

Option	Description	Range	Default Value
<password>	.A string of up to 256 characters. May not include white-space.	NA	NA
<username>	A string of up to 256 characters. May not include white-space.	NA	NA

**Note**                Used only for HTTP-based authentication of the iMG.

**Example**            See the example output below

```
awplus(config)# tr69-client acs-authentication username Bilbo_Baggins  
awplus(config)# tr69-client acs-authentication password secret_hobbit
```

## TR69-CLIENT ACS-URL

**Syntax**           tr69-client acs-url <url\_string>  
                  no tr69-client acs-url

**Description**       This command provides the URL that the iMG will use in order to connect with an ACS.  
                  Use the no variant of this command to remove a previously configured ACS URL.

**Feature**           TR69 Commands

**Mode**             Global Configuration Mode

**Release**           4.2

### Options

Option	Description	Range	Default Value
<url_string>	A string of up to 256 characters. This parameter must be in the form of a valid HTTP or HTTPS URL.	NA	NA

### Note

**Example**           See the example output below

```
awplus(config)# tr69-client acs-url http://10.17.90.52:9797/ACS
```

**TR69-CLIENT BIND SOURCE-INTERFACE <IF-NAME>**

**Syntax**           tr69-client bind source-interface <if-name>  
                  no tr69-client bind

**Description**       This command manually associates the tr69 client to the interface (VLAN) that will be used by the tr69 client to communicate with the ACS. This is useful since the TR69 client will bind to the first available Interface that has a status of connected, and will send messages on that interface, which may not be the preferred route to the ACS.

Use the no variant of this command to remove the associated Interface.

**Feature**           TR69 Commands

**Mode**             Global Configuration Mode

**Release**          4.2

**Options**

Option	Description	Default Value
<if-name>	The VLAN that is used to communicate with the ACS.	Any_WAN

**Note**             If the iMG is configured using DHCP (option 43), the VLAN receiving option 43 will be set as the VLAN for communication with the ACS.

**Example**          See the example output below

```
awplus(config)# tr69-client bind source-interface vlan202
```

**TR69-CLIENT BIND SOURCE-INTERFACE <VLAN:VLAN>**

**Syntax**           tr69-client bind source-interface <VLAN:vlan>  
tr69-client bind source-interface

**Description**      This command binds ACS signaling to a specific interface “VLAN id”. Use the no variant of this command to set a default value “Any\_WAN”.

**Feature**           TR69 Commands

**Mode**             Global Configuration Mode

**Release**          4.2

**Options**

Option	Description	Range	Default Value
<VLAN:vlan>	The VLAN that is used to bind the ACS signaling with.	vlan1 - vlan4094	Any_WAN

**Note**             NA

**Example**          See the example output below

```
awplus(config)# tr69-client bind source-interface vlan203
```

## TR69-CLIENT INFORM

**Syntax**            `tr69-client inform {interval <interval>}`  
                     `no tr69-client inform`

**Description**       This command configures the interval at which the iMG will invoke the TR69 inform method to send iMG information to the ACS. This command is also used enable the sending of periodic informs.

Use the no variant of this command to disable the sending of periodic informs.

**Feature**            TR69 Commands

**Mode**                Global Configuration Mode

**Release**            4.2

**Options**

Option	Description	Range	Default Value
<interval>	An integer value in the range 1 – 4294967295 seconds.	1-4294967295	300

**Note**                NA

**Example**            See the example output below

```
awplus(config)# tr69-client inform interval 500
awplus(config)# tr69-client inform
awplus(config)# no tr69-client inform
```

## TR69-CLIENT REQUEST-AUTHENTICATION

**Syntax**            `tr69-client request-authentication {password <password> | username <username>}`  
                      `no tr69-client request-authentication {password | username}`

**Description**        This command configures the username and password used to authenticate an ACS when an incoming connection request is received by the iMG.

Use the no variant of this command to remove configured username and password

**Feature**            TR69 Commands

**Mode**                Global Configuration Mode

**Release**            4.2

**Options**

Option	Description	Range	Default Value
<password>	A string of up to 256 characters. May not include white-space	NA	NA
<username>	A string of up to 256 characters. May not include white-space	NA	NA

**Note**                NA

**Example**            See the example output below

```
awplus(config)# tr69-client request-authentication username Saruman
awplus(config)# tr69-client request-authentication password good_istari
```

## 7.5.3 Universal Plug and Play

### 7.5.3.1 Introduction

Universal Plug and Play (UPnP) is a networking protocol that permits devices, such as the iMG, to discover the presence of other devices on the network and establish functional network services for data sharing, communications, and entertainment. The iMG supports version 1.0 of the UPnP Device Architecture (<http://upnp.org/specs/arch/UPnP-arch-DeviceArchitecture-v1.0.pdf>).

### 7.5.3.2 UPnP on the iMG

The primary use for UPnP on the iMG is to allow the iMG to utilize the UPnP implementation of a NAT traversal protocol called Internet Gateway Device (IGD). A device that supports this combined UPnP/IGD protocol can reveal itself as an Internet Gateway Device. This opening can allow a local UPnP control point to perform a set of actions including:

- Retrieve the external IP address of the device
- Enumerate existing port mappings
- Add port mappings
- Remove port mappings

For example, by adding a port mapping, a UPnP controller behind the IGD can enable traversal of the IGD from an external address to an internal client.

### 7.5.3.3 UPnP Command List

This section provides an alphabetical reference of configure, clear, and show commands related to UPnP.

Table 7-11: UPnP Command List

<a href="#">ip upnp local enable</a>
<a href="#">ip upnp network enable</a>
<a href="#">show ip upnp</a>

## IP UPNP LOCAL ENABLE

**Syntax**            ip upnp local enable  
                     no ip upnp local enable

**Description**      This command activates UPnP on the interface.

**Feature**            UPnP Commands

**Mode**                Global Configuration Mode

**Release**            4.3.1

**Options**            NA

**Note**                NA

**Example**            See the following commands for options to enable UPnP on the local interface, in this case VLAN 100:

```
interface vlan100
ip upnp local enable
```

**Example**            To disable UPnP on VLAN 100, use the following commands:

```
interface vlan100
no ip upnp local enable
```



## IP UPNP NETWORK ENABLE

**Syntax**            ip upnp network enable  
                     no ip upnp network enable

**Description**      This command activates UPnP on the network interface.

**Feature**            UPnP Commands

**Mode**                Global Configuration Mode

**Release**            4.3.1

**Options**            NA

**Note**                NA

**Example**            See the following commands for options to enable UPnP on the network interface, in this case VLAN 200:

```
interface vlan200
ip upnp network enable
```

**Example**            To disable UPnP on VLAN 200, use the following commands:

```
interface vlan200
no ip upnp network enable
```

## SHOW IP UPNP

**Syntax**            ip upnp network enable  
                     no ip upnp network enable

**Description**      This command displays information regarding UPnP.

**Feature**            UPnP Commands

**Mode**              Global Configuration Mode

**Release**            4.3.1

**Options**            NA

**Note**              NA

### Example

```
awplus# show ip upnp
```

```
UPnP summary
```

```
-----
```

```
Enabled           : yes
Status            : active
Network interface : vlan200
Local interface   : vlan100
```

```
awplus#
```

### Example

```
awplus# show ip upnp
```

```
UPnP summary
```

```
-----
```

```
Enabled           : no
Status            : inactive
Network interface : n/a
Local interface   : n/a
```

```
awplus#
```

## 8. Voice Management

The Voice Management functions of the Allied Telesis Gateway Product Family devices include the following:

- [Voice Service and Protocols](#)
- [Voice Service Command List \(config-voi-serv\)](#)
- [Enable/Disable MGCP Command List \(config-serv-mgcp\)](#)
- [Enable/Disable SIP Command List \(config-serv-sip\)](#)
- [Configure MGCP Protocol Command List \(config-mgcp\)](#)
- [Configure SIP Protocol Command List \(config-sip-ua\)](#)
- [Configuring Voice Applications on Device and Ports](#)
- [Access Codes \(Supplementary Services\) Command list \(config-voipapp-fac\)](#)
- [Supplementary Service Command list \(voipapp-suppl-serv-port\)](#)
- [Endpoint Command List \(config-voice-port\)](#)
- [Configuring Codecs Command List](#)
- [Configuring Dial Peers](#)
- [Configuring Dial Peers Command List \(config-dial-peer\)](#)

---

### 8.1 Voice Service and Protocols

#### 8.1.1 Introduction

Telephone service uses Voice Over Internet Protocol technology (VOIP). VOIP involves two components:

- The signaling protocol that manages the phone conversation
- The media protocol that encodes / encapsulates the audio information.

The Allied Telesis Gateway Product Family devices (referred to for the rest of this sections as the iMG) support media transmission through various audio codecs which are encapsulated in Real Time Protocol (RTP) packets. It supports two signaling protocols which are the following: Media Gateway Control Protocol (MGCP) and Session Initiation Protocol (SIP). During operation only one protocol can be active, however switching between protocols is possible with relative ease.

Configuration of the voice system can be achieved through two mechanisms. The first configuration path is through the use of an Automated Configuration Server (ACS) utilizing the TR-069 and TR-104 specifications. Refer to Section 1. Configuring voice service using the CLI is described in this section.

#### 8.1.2 MGCP

The Media Gateway Control Protocol (MGCP) relies on a master / slave methodology. The Media Gateway Controller (MGC) is an "intelligent" central point where all call control decisions are made. In this architecture, the iMG plays the role of the Media Gateway (MG) and is responsible for carrying out any instructions that are given to it by the central server.

There are many different ways in which the iMG can be used in a MGCP environment. The two general forms of operation are an "out-of-band" configuration or a Network Controlled Signaling (NCS) configuration. The "out-of-band" mode of oper-

ation relies on the MGCP protocol to transmit information between the MGC and the MG. This would include events originating from the CPE (user events such as digits, hook changes) and information being sent to the device from the server (signal requests, media configuration). The details of the MGCP protocol are described in RFC3435. The NCS configuration utilizes the media stream itself to carry information between the server and the client (or between the two endpoints directly). Events and signals are encoded in the Real Time Protocol (RTP) using the mechanisms described in RFC4733

### 8.1.2.1 MGCP Endpoints

Allied Telesis Gateway Product Family devices support the configuration of each FXS (Foreign Exchange Station) voice port as a separate MGCP analogue endpoint allowing a different level of services (number of phone lines) to be delivered.

Each voice port is identified univocal through an endpoint identifier that, by default, takes the following syntax:

```
aaln/<slot>@[$IP]
```

where:

- **AALN** -Analog Access Line endpoint. This name indicates that the endpoint is analog type (only FXS voice interfaces are supported). **<slot>** - indicates the index of the voice port. Physical voice ports start with index 0, the second physical voice port uses index 1 and so on. The starting number can be specified to be 1 rather than 0.
- **\$IP** - it's the ip address of the ip interface where the MGCP protocol is enabled. It is typically used in a multi host configuration where more than one IP interface is configured in the system or when the ip interface is dynamic and therefore the value is dynamically assigned by the network.

Analog endpoint MGCP identifiers can be customized to meet VoIP network configuration requirements.

The syntax of the local name of each endpoint identifier is in the format:

```
aaln/<slot>
```

where **<slot>** is 0 for the first POTS interface and 1 for the second POTS interface, i.e:

```
aaln/0
```

```
aaln/1
```

The syntax of the local name can be changed forcing the index of the POTS interfaces to start from 1 instead from 0 (i.e. aaln/1 and aaln/2):

```
awplus(config-mgcp)# endpoint offset
```

The syntax of the domain name component of each endpoint identifier can be set to any string and can use also special keywords identified by the "\$" sign that are automatically replaced by the value of the attribute that they represent.

The following two special keywords are supported:

- **\$IP** - when used, this keyword is automatically replaced by the ip address value (in IPv4 dotted format) of the ip interface where MGCP protocol has been enabled.
- **\$MAC** - when used, this keyword is automatically replaced by the MAC address of the Allied Telesis Gateway Product Family device.
- **\$HOST** – when used, this keyword is automatically replaced by the hostname of the Allied Telesis Gateway Product Family device.

It is therefore possible create complex endpoint identifiers like the following:

- `aaln/0@[$IP]` that will be translated at runtime for example in: `aaln/0@[172.30.1.1]`
- `aaln/0@$IP` that will be translated at runtime for example in: `aaln/0@172.30.1.1`
- `aaln/0@$MAC` that will be translated at runtime for example in: `aaln/0@00:0d:da:01:fe:ac`
- `aaln/0@any-string-here`

To specify a new endpoint syntax for an existing voice port the following command is used:

```
Awplus(config-mgcp)# domain <ip-address|mac_address|domain-name-string>
```

**Note:** By default each endpoint is disabled. To enable the endpoint (i.e. to register each endpoint to the Call Agent) use the following command:

```
awplus(config-voiceport)# no shutdown
```

### 8.1.2.2 MGCP Wildcard

Wildcard is a method to reduce the amount of MGCP signaling traffic generated during the registration phase.

In this case the User Agent notifies to the Call Agent only one RSIP message (instead of two) to request the registration of both of the two endpoints.

Wildcard support is also needed for interoperability with some Call Agents that use wildcard in their Audit Endpoint requests.

To enable the wildcard support (by default it is disabled), the following command is used:

```
awplus(config-mgcp)# behavior rsip-range all
```

### 8.1.2.3 MGCP Heartbeat

The Allied Telesis Gateway Product Family supports the heartbeat mechanism to detect whether User Agents are still active. Each Allied Telesis Gateway Product Family voice port has a unique User Agent permanently associated to it. Heartbeat mechanism is typically requested on deployments that use Network Address Translation (NAT). The reason for this requirement is that if a NAT binding expires, there is no way for a Call Agent to send an incoming call to the User Agent as NAT bindings are generated via outgoing UDP packets. Using a heartbeat mechanism allows the User Agent to detect loss of the NAT binding (due for example to DSL uplink fails) and recreate it if required. The heartbeat mechanism is implemented through the use of Audit commands as AuditConnection and AuditEndpoint.

The Allied Telesis Gateway Product Family endpoints support a configurable messaging mechanism and a configurable heartbeat timer. The endpoint waits for either the expiration of this timer, the reception of a command for the endpoint from the Call Agent, or the detection of a local user activity for the endpoint, such as for example an off-hook transition.

If the heartbeat timer expires the User Agent enters the “disconnected” procedure. The User Agents run a further disconnect timer and if they do not receive a command from the Call Agent or detect local activity before the timer expires, the endpoint sends an RSIP disconnected command to the Call Agent. If it does not receive a response it continues to periodically retry to contact the provisioned Call Agents. If the Call Agent is using the above heartbeat mechanism, the heartbeat timer should be set to a value that allows the Call Agent to send an audit command sufficiently often that the User Agent will see at least 3 audit commands in the heartbeat time interval. This is to prevent a single packet loss causing the User Agent to become “disconnected”.

By default heartbeat is disabled and can be enabled via the following command:

```
Awplus(config-mgcp)# behavior heartbeat RSIP-refresh 10
```

When heartbeat is enabled, each endpoint (or User Agent) supervises the operative status of Call Agent independently of the status of the other endpoints.

It is possible to force a specific endpoint to check for Call Agent activity and to be master also for the other endpoints. If the specific endpoint does not receive a command from the Call Agent within the heartbeat timer time-out it forces all the User Agents to enter into the disconnected procedure.

To activate this behavior it's necessary to enable the heartbeat and specify also the master endpoint entering the following command:

```
awplus(config-mgcp)# behavior heartbeat RSIP-refresh 10 master tel2
```

If no commands are received from the Call Agent within the timeframe specified by the heartbeat refresh time, the User Agents starts to notify to the Call Agent an heartbeat message.

The type of MGCP message notified to the User Agent and used for the heartbeat can be selected between:

- NTFY L/hb
- RSIP Keepalive
- RSIP Refresh

The retransmission of heartbeat messages from the User Agent follows the same rules as for the transmission of any message sent by the User Agent.

The User Agent will attempt to send a maximum of "Request retries" messages for period of time no longer than "Request timeout" before entering into the disconnect procedure.

#### 8.1.2.4 MGCP Call Agent Failover

The Allied Telesis Gateway Product Family supports dual Call Agents failover mechanism to switch between inactive to active call agents in order to support high availability services. The failover mechanism is triggered any time a request sent by the User Agents does not get any answer from the Call Agent within the round-trip time-out.

In this case if more than one call agent is configured, the User Agent will re-send the same command toward the second call agent. As soon the User Agent get an answer from the second call agent, the second call agent becomes the active call agent and will be used for all the subsequent requests.

The process repeats any time a call agent is not reachable switching in this way the communications between primary call agent to secondary call agent and vice versa.

To set the primary call agent use the following command:

```
awplus(config-mgcp)# call-agent <ip-address>
```

To specify the secondary call agent use the following command:

```
awplus(config-mgcp)# backup-call-agent <ip-address>
```

If the user Agent has sent a message but the Call Agent is not available (and the Backup Call Agent is not available too) the retransmission procedure takes place.

The User Agent will attempt to send the same MGCP message for a number of times defined by the "Request retries" attribute and for a period of time not longer than the timeout specified by the "Request timeout" attribute.

If no answers are received, then the endpoint goes in disconnected status and RSIP-restart messages are sent until the registration is acknowledged.

The following commands are used to change the number of retries and the timeout duration:

```
awplus(config-mgcp)# request retries <number-of-retries>
awplus(config-mgcp)# request timeout <seconds>
```

### 8.1.3 SIP

#### 8.1.3.1 Introduction

The Session Initiation Protocol (SIP) implements a more flexible control methodology. This flexibility gives SIP the ability to be utilized in many different network architectures. Example models are given below:

1. Master / Slave Signaling

This architecture follows the same model as MGCP. A central server is responsible for making all decisions and the protocol is used to notify the end devices what of what operations to perform. This system is used often in architectures that need to be strictly administered by a central authority.

## 2. Direct Signaling

SIP has the ability to communicate directly with any other device that implements the protocol. This includes another iMG or any other SIP Soft Phone product that may have access to the IP network. In this configuration, no server is required to provide signaling because the endpoints distribute the decision making responsibilities between them. A forwarding database is required on each endpoint so that requests can be directed to their proper proxy, gateway system or remote SIP endpoint device. This type of signaling may be done on a smaller network where administration is less complex and the number of devices is small.

## 3. Registration / Proxy Signaling

This architecture is a hybrid of the above two models. Each endpoint is required to register with a central agent called the Registrar. The purpose of this system is to provide directory service for every device on the network. When a call is initiated, the location of the destination device is determined. The server then has the option of notifying the originator of the destination's location, or it can act on behalf of the originator and complete the call

### 8.1.3.2 SIP Digit Map

The Digit Map is a rule used by the access port to understand when dialing is to be considered completed and the dialed number is ready to be processed by the call control layer. It works for outgoing calls (in the direction from user to VoIP network). A digit map is defined either by a (case insensitive) string or by a list of strings.

Each string in the list is an alternative numbering scheme, specified either as a set of digits or timers, or as an expression over which the port will attempt to find a shortest possible match. The following constructs can be used in each digit map:

- **DTMF** - A digit from '0' to '9' or one of the symbols 'A', 'B', 'C', 'D'. Symbols '#' or '\*', if necessary, have to be added separately.
- **Timer** - The symbol 'T' matching the timer expiry. The symbol 'T' at the end of Digit Map indicates that if user has not dialed a digit for a time longer than the value of the inter-digit time, the dialed number shall be considered complete. If the symbol T appears in the middle of digit map expression is not considered and skipped during expression evaluation.
- **Wildcard** - The symbol 'x', which matches any digit ('0' to '9').
- **Range** - One or more DTMF symbols enclosed between square brackets ('[' and ']').
- **Subrange** - Two digits separated by a hyphen ('-') that matches any digit between and including the two. The subrange construct can only be used inside a range construct, i.e., between '[' and ']'.
- **Position** - A period ('.'), which matches an arbitrary number, including zero, of occurrences of the preceding construct.

**Note:** The digit map, when fully expressed, shall not exceed 255 characters. Also, for call processing for SIP, the digit map is entered by the CLI or the NMS/ACS. For MGCP, it is sent to the iMG from the callagent using the MGCP messaging.

Let's consider an example where the user in an office wants to call a co-worker's 3-digit extension. The **Digit Map** is defined in such a way that the called number is processed after the user has entered 3 digits.

The command to set the Digit Map could look as follows:

```
Awplus(config-Dial-peer)# destination-pattern xxx
```

**Note:** Dial Peer 3 is the one that is used for routing calls – and thus the one that must be modified to achieve everything below.

This Digit Map specifies that after the user has entered any three digits, the call is placed. It's possible to refine this Digit Map by including a range of digits. For example, if all extensions in the user company begin with 2, 3, or 4, the corresponding Digit Map command could look as:

```
Awplus(config-Dial-peer)# destination-pattern [2-4]xx
```

If the number dialed begins with anything other than 2, 3, or 4, the call is rejected and a busy tone is generated.

Another way to achieve the same result would be:

```
Awplus(config-Dial-peer)# destination-pattern [234]xx
```

It is possible to combine two or more expressions in the same Digit Map by using the '|' operator, which is equivalent to OR. The left-most expression has precedence over the other expressions.

Let's consider the case of a choice: the Digit Map must check if the number is internal (an extension), or external (a local call). Assuming that dialling '9' makes an external call, the Digit Map could be defined with the command:

```
Awplus(config-Dial-peer)# destination-pattern ([2-4]xx|9[2-9]xxxxxx)
```

In this case the Digit Map checks if the number begins with 2, 3, or 4 and the number has 3 digits. If not, it checks if the number begins with 9 and the second digit is any digit between 2 and 9 and the number has 7 digits

It may sometimes be required that users dial the '#' or '\*' to make calls. This can be easily incorporated in a Digit Map with the command:

```
Awplus(config-Dial-peer)# destination-pattern xxxxxxx#|xxxxxxx*
```

The '#' or '\*' character could indicate that users must dial the '#' or '\*' character at the end of their number to indicate it is complete. When the outgoing call is in process, the call control layer removes any '#', '\*' and 'T' symbols from the dialed number.

### 8.1.3.3 SIP Proxy and SIP Registrar (with Failover)

It is possible to specify different servers addresses for SIP Registrar and SIP Proxy.

SIP Registrar is used only for registration purposes.

**Note:** If no registrar is specified, the proxy server values will be used, and the iMG will attempt to register at the address of the SIP Proxy server.

SIP Proxy address must always be configured in order to have SIP signaling working properly during outgoing and incoming calls.

To configure SIP Registrar address use the following command:

```
awplus(config-sip-ua)# registrar <ip-address>
```

To configure SIP Proxy address use the following command:

```
awplus(config-sip-ua)# sip-server
```

It's also possible to specify the sip domain associated to each local dial-peer and used in the registration messages by the following command:

```
awplus(config-serv-sip)# localhost dns <sip-domain>
```

For the Failover feature, it is possible to specify a **secondary** server for both Proxy and Registrar.

**Note:** You must always configure the Primary Proxy server (you cannot configure only the Secondary).

The rules for Proxy failover are as follows:

- The INVITE message is sent by the user agent four times. If there is no response, the user agent declares a failover and tries with the Secondary.
- If the four attempts on the Secondary fail, the user agent switches back to the Primary

**Note:** If Proxy servers are used for registration, it uses the same registration procedure but uses the proxy server list instead.



The rules for Registrar failover are as follows:

- The user agent will attempt registration for 28 seconds.
- If no response, restart registration is started on the Secondary with a delay of 20 seconds.
- If the secondary doesn't respond, the user agent returns to the Primary and tries again
- A successful registration marks a server as "active" and initiates re-registration on all endpoints

**Note:** Subsequent restarts will use the last known good registration agent.

## 8.1.4 Services (Common)

### 8.1.4.1 Dial Peers

Dial peers are used to control call routing. There are two different types of dial-peers supported:

The **pots dial-peer** is used to define the characteristics of the phone interface. For MGCP – this is essentially just the fact that the protocol is associated with this port; while for SIP – it includes the local address of the user that is associated with the port as well as other user specific information including the username. Currently two pots dial-peers are automatically created when the system is initialized. (tags 1 for tel1 and 2 for tel2). When the SIP protocol is enabled, it is automatically associated with these two Dial-Peers. Likewise, when the MGCP protocol is enabled, it is automatically associated with these two dial-peers.

The **voip dial-peer** maps a dialed digit string to a remote device. By default one dial-peer is created – (tag3). The user is then able to specify the digit map – via the destination-pattern option. By default, when a dial-peer is matched, the system will initiate the call to the configured sip server (under the sip-ua submenu).

**Note:** voip dial-peer settings affect only SIP protocol. It has no meaning when MGCP protocol is configured. In this case the digitmap is controlled and defined at runtime by the Call Agent.

It is possible to specify additional voip dial peers; each dial peer create has an associated sip server ip addresses and a destination pattern, creating a forwarding database.

### 8.1.4.2 DTMF Relay

Digit communication is most often accomplished in modern telephony through the use of DTMF tones. The idea is that different harmonies of frequencies relay different digits that the user presses. Very often in compression algorithms, these frequencies can be distorted or dropped. The solution is to add an additional mechanism through which digits and tones can be transmitted without interfering in audio communication.

#### MGCP Protocol

When MGCP protocol is used, it's possible to select in which way DTMF events can be notified to the Call Agent: RFC2833 or InBand.

Selection of RFC2833 method is done using the command:

```
awplus(config-voi-srv)# dtmf-relay voip mode rtp-nte
```

The usage of RFC2833 to notify DTMF to the call agent depends if the Call Agent has explicitly requested the support for RFC2833 telephone-event:

- If the session has been established with Call Agent requiring RFC2833, then the User Agent will use it and will also notify each DTMF through MGCP NTFY messages.
- If the session has been established without the Call Agent requiring RFC2833, then the User Agent will notify each DTMF only through MGCP NTFY messages.

Selection of InBand method is done using the command:

```
awplus(config-voi-srv)# no dtmf-relay
```

In this case, independently if the session has been established with Call Agent requiring or not requiring RFC2833, the User Agent will notify each DTMF only through MGCP NTFY messages and DTMF will be present in the voice media path.

Similar to DTMF, it's also possible to notify Named Telephone Events (i.e. On-Hook, Off-Hook, Flash-Hook events) by means of RFC2833.

Selection of RFC2833 method for the Named Telephone Events is done using the command:

```
awplus(config-mgcp)# package-capability lcs-package
```

As for DTMF, the usage of RFC2833 to notify Named Telephone Events to the call agent depends if the Call Agent has explicitly requested the support for RFC2833 named-telephone-event:

- If the session has been established with Call Agent requiring RFC2833, then the User Agent will use it and will also notify each Telephone Event through MGCP NTFY messages.
- If the session has been established without the Call Agent requiring RFC2833, then the User Agent will notify each Telephone Event only through MGCP NTFY messages.

It is possible to force the User Agent to notify Named Telephone Events by means of RFC2833 independently from the session attribute negotiation by entering the following command:

```
awplus(config-mgcp)# rtp payload-type nte static
```

It is also possible to set a specific payload type to be used on RFC2833 packets by entering the following command:

```
awplus(config-voi-srv)# rtp payload-type nte <value>
```

**Note:** The usage of RFC2833 for DTMF relay is incompatible with the usage of RFC2833 for Named Telephone Events and vice versa. Once RFC2833 option is user for a class of events, the other class of events cannot use RFC2833.

**Note:** The usage of RFC2833 for Named Telephone Events applies only for MGCP-NCS signaling profile.

#### SIP Protocol

When SIP protocol is used, it's possible to select in which way DTMF events can be notified to the Call Agent: RFC2833 or InBand or SIP Information.

Selection of RFC2833 or SIP Info is done using the command:

```
awplus(config-voi-srv)# dtmf-relay voip mode rtp-nte
```

or

```
awplus(config-voi-srv)# dtmf-relay voip mode rtp-nte sip-notify
```

while selection of InBand method is done using the command:

```
awplus(config-voi-srv)# no dtmf-relay
```

- When RFC2833 is enabled, the User Agent will try to negotiate it with the Softswitch and only if negotiation ends successfully, DTMF will be sent encapsulated in RFC2833. Otherwise DTMF will be sent InBand.
- When SIP Info is enabled, RFC2833 is not negotiated (or any attempt to negotiate it is refused) and the User Agent will use always SIP Info messages to notify DTMF.
- Finally, when InBand setting is configured, RFC2833 is not negotiated (or any attempt to negotiate is refused) and the User Agent will send DTMF only in the voice media path.

As for MGCP, it's also possible to set a specific payload type to be used on RFC2833 packets by entering the following command:

```
awplus(config-voi-srv)# rtp payload-type nte <value>
```

### 8.1.4.3 Telecom Tone Management

The iMG is able to reproduce the same country-specific telecom tones used by Central Offices or Foreign Exchanges.

To change the country tones settings enter the following command:

```
awplus(config-voi-srv)# cptone <country-code>
```

**Dial Tone**, **Busy Tone**, and **Ring Back Tone** refer to ITU-T E.180 specifications as reported in the following table:

Table 8-1: Country-specific Telecom tones

Country	<country code>	Dial Tone		Busy Tone		Ring Back Tone	
		Frequency (Hz)	Cadence (msec)	Frequency (Hz)	Cadence (msec)	Frequency (Hz)	Cadence (msec)
Australia	AU	425x25	Continuous	400	375 - 375	400x17	400 - 200 - 400 - 2000
Austria	AT	450	Continuous	450	300 - 300	450	1000 - 5000
Belgium	BE	425	Continuous	425	500 - 500	425	1000 - 3000
Canada	CA	350+440	Continuous	480+620	500 - 500	440+480	2000 - 4000
China	CN	450	Continuous	450	350 - 350	450	1000 - 4000
France	CY	440	Continuous	440	500 - 500	440	1500 - 3500
Germany	DE	425	Continuous	425	480 - 480	425	250 - 4000 - 1000 - 4000 - 1000 - 4000
Israel	IL	400	Continuous	400	500 - 500	400	1000 - 3000
Italy	IT	425	600 - 1000 - 200 - 200	425	200 - 200	425	1000 - 4000
Japan	JP	400	Continuous	400	500 - 500	400x16	1000 - 2000
New Zealand	NZ	400	Continuous	400	500 - 500	400 + 450	400 - 200 - 400 - 2000
Russia	RU	no tone	//	425	400 - 400	425	800 - 3200
Singapore	SG	425	Continuous	425	750 - 750	425x24	400 - 200 - 400 - 2000
Spain	ES	425	Continuous	425	200 - 200	425	1500 - 3000
Norway	NO	no tone	//	425	1000-4000	425	500 - 500
Sweden	SE	425	Continuous	425	250 - 250	425	1000 - 5000
Turkey	TR	450	Continuous	450	500 - 500	450	2000 - 4000
United Kingdom	GB	350+440	Continuous	400	375 - 375	400+450	400 - 200 - 400 - 2000
United States	US	350+440	Continuous	480+620	500 - 500	440+480	2000 - 4000

**Note:** Frequency in Hz:f1xf2 means f1 is modulated by f2

**Note:** f1+f2 is the juxtaposition of two frequencies f1 and f2 without modulation.

**Note:** Cadence in seconds:ON – OFF

#### 8.1.4.4 Media Format

The audio of a phone conversation is converted into a byte stream using an encoding codec. There are several different codecs available; each has different positives and negatives depending on the customer's needs and the resources of the network. The two characteristics that are most affected by the codec selection are the required bandwidth and the overall quality of the audio when it reaches its destination. A higher quality codec has better audio performance but requires more network bandwidth to complete a call. Audio performance is important for customer / user satisfaction but a provider's network resources may be limited. Other codecs are available which utilize compression algorithms to reduce their bandwidth consumption, while still providing an acceptable level of audio performance. Unfortunately, these codecs may impair the function of automated devices such as modems or fax machines.

There are two solutions to this problem which are the following: protocol based indications and RFC2833 style indications. The first method involves using the signaling protocol itself to transmit the digits. On SIP this often is implemented through the use of INFO messages and in MGCP it is accomplished through the use of NTFY messages. Details of these mechanisms are covered in other references. The second method that can be used is to follow the RFC2833 specification if RTP is the media format in use. This mechanism encodes the digit or tone using a different format, but placing it in the existing data stream.

#### 8.1.4.5 FAX/Modem Relay

Fax and modem communication is susceptible to the same distortion and encoding issues that are described in the section regarding DTMF Relay. The function of fax machines and modems relies on the transmission of data using a spectrum of tones and data encoded throughout the audio stream. The issues with these devices can be solved in one of two ways which are the following: switch the encoding format to one that is less likely to cause data distortion (a clear codec) or by using another encoding format all together that is designed to carry the data format (T.38 is a good example for fax).

The most commonly implemented solution is to perform an "upshift" of the codec to a higher bandwidth codec. The CPE (if properly configured) will monitor for tones indicating that an upshift is required and the appropriate actions are taken to notify all members of the call that a high bandwidth encoding is required. The second option is to switch to a specifically defined encoding format which is best suited for the data format. In the case of fax transmissions, a common format that is being deployed for use is T.38.

#### 8.1.4.6 RTP Media Management

Allied Telesis Gateway Product Family devices allow to specify a specific pool of IP UDP ports to be used for media (RTP) transport. Each even media port is paired with the subsequent odd port and assigned to RTP or RTCP streams respectively.

The maximum number of simultaneously streams is therefore half of the size of the media range. When VoIP MGCP protocol is used, the lowest ports pair is assigned to the first configured end-point, the subsequent pair is assigned to the second configured end-point and so on.

When SIP protocol is used, ports pair are used in a round robin fashion.

The Allied Telesis Gateway Product Family devices allow you to specify a specific RTP packetization time for each codec as the timeframe between two consecutive RTP packets. Packetization time can also be negotiated at runtime during the call establishment phase.

The value specified via CLI is the value that is normally advertised by the VoIP protocol (via VoIP signalling messages) and that is used when it is not negotiated during the call setup.

### 8.1.4.7 Distinctive Ringing

For each country exists a table of ring patterns identified as Pattern1, Pattern2...that are typically used to inform the user about special or priority calls. On SIP only, it's possible then to specify what ring pattern must be played accordingly to the Alert-Info header string received in the SIP INVITE message during an incoming call..

**Note:** This feature is for a future release.

### 8.1.4.8 Prefix Replacement

Only for SIP protocol, it's possible to automatically add a prefix or replace the first part of a dialed number. The administrator can create a set of rules (a translation set) that look for specific patterns in the dialed number and then perform an action like replace the matching number with another one or add a prefix in front of the dialed number. A translation set is created by entering the command `voice translation-rule <index>` when in global Configuration Mode. The index used in the command is a label used to univocally identify the translation set when it will be associated to a POTS interface. Rules in a translation set are ordered by a precedence with the lowest values having the highest priority. Each rule defines its own matching pattern and has an action associated: replace the matching pattern or add a prefix. More than one rule can be assigned to a translation set but only one translation set can be assigned to a POTS interface. Let's consider an example where the voice service inside an organization is deployed as an hosted cloud based voip PBX solution.

- All the users belonging to the company are registered using their full address: area code + company number + office extension. Calls between company users need to be presented to the hosted PBX using the full destination address but to simplify the internal communication we want to use only the telephone extension numbers preceded by the digit 5. A prefix replacement that checks if the first digit is 5 and then replace it with the area code and company number is therefore a perfect solution.
- Calls to international numbers that start with 011 need to be replaced by the prefix 00.
- Calls to local area numbers not leading with 0 need to prefix with the local area code
- And finally a call to the number 9 must be replaced to the front desk phone number.

The following are the steps needed to configure the above behavior:

- Create a translation set with index 1

```
awplus(config)# voice translation-rule 1
```

- Create the first rule that replaces the leading digit 5 with the complete company phone number (02-1723231)

```
awplus(config-voi-trans-rule)# rule 0 5 021723231 replace
```

- Create the second rule that replaces the leading international prefix number 011 with the code 00

```
awplus(config-voi-trans-rule)# rule 1 011 00 replace
```

- Create the third rule that replaces the number 9 with the front desk number (02-1723231201)

```
awplus(config-voi-trans-rule)# rule 2 9 021723231201 replace
```

- Create the fourth rule that add the local area code (prefix 02) to any number that starts with 1-9

```
awplus(config-voi-trans-rule)# rule 3 [1-9]x 02 prefix
```

- Assign the translation set to the POTS interface

```
awplus(config)# dial-peer voice 1 pots
```

```
awplus(config-dial-peer)# translate-outgoing 1
```

- The translation set 1 should look something like:

```
awplus# show voice translation-rule 1
```

```
Translation Rule 1
```

```
Precedence      : 0
Match Digits    : 5
Translate Digits : 021723231
Translate Mode   : replace
```

```
Precedence      : 1
Match Digits    : 011
Translate Digits : 00
Translate Mode   : replace
```

```
Precedence : 2
Match Digits : 9
Translate Digits : 021723231201
Translate Mode : replace
```

```
Precedence : 3
Match Digits : [1-9]x
Translate Digits : 02
Translate Mode : prefix
```

```
awplus# show dial-peer
```

```
POTSPeer1
    peer type = voice
    Admin state is up
    tag = 1
    protocol is session protocol sipv2
    destination-pattern = 021723231981'
    voice-port = 'tel1'
    translate-outgoing = 1
    SIP authentication username = '021723231981'1
```

### 8.1.5 Voice Quality Management

To increase the voice/data quality additional parameters can be set on the voice system DSP. The following settings are available on iMG models:

- Jitter buffer. It's possible to specify the way jitter buffer operates: adaptive or fixed. It's also possible to specify the jitter buffer depth (from 60msec to 200msec) or to disable it completely.
- Separate TX and RX direction (from user-to-network and from network-to-user respectively) volume gain control. Adjustable between -48dB and +24dB (1 dB increments).
- Voice activity detection (VAD)/comfort noise generation (CNG).

It's also possible to configure the DSCP value for RTP streams and for VoIP signaling messages originated at the iMG.

The following command configure the DSCP value for rtp streams:

```
awplus(config-voi-srv)# ip rtp precedence <dscp-value>
```

The following command configure the DSCP value for VoIP signaling messages:

```
awplus(config-voi-srv)# ip signaling precedence <dscp-value>
```

**Note:** SIP and MGCP voip protocols also set automatically the COS (802.1p) value for originated messages and streams to the value 5. This value cannot be changed.

## 8.2 Voice Service Configuration for the iMG

### 8.2.1 Overview

The following figures show how MGCP and SIP service can be configured using the iMG. There is a separate figure for each type of protocol, since providers usually provide only one service type for their network.

These figures are similar to the figures introduced in Section 2 in that the same VLANs are used: VLAN10 for data and VLAN40 for video.

**Note:** VLAN7, which is used for the AlliedView NMS VLAN, is not included in this figure, since it was set up for data and video services. However, VLAN7 can be included to be used for voice service through the use of NMS profiles for voice and voice service GUIs. Refer to the AlliedView NMS Administration Guide.





FIGURE 8-1 Configuration for MGCP



**FIGURE 8-2 Configuration for SIP**

### 8.2.2 Basic Command Sequences for Provisioning

Refer to [Table 2-2](#), which lists the Modes used for the command set, how to access them, and what they provide.

MGCP and SIP provisioning usually follow a command sequence that starts at a high level (select the protocol, system-wide attributes), provisions the ports for the protocol, and then associates the ports with specific attributes for the subscriber/endpoints.

This sequence is shown in the following tables.

Table 8-5 is for MGCP with the following attributes:

- VLAN : 20
- Country : US
- Call-Agent : 10.52.142.7

Table 8-6 is for SIP with the following attributes:

- VLAN : 20
- Country : US
- Proxy Server : 10.52.142.6
- DigitMap : x.T
- Tel1 DN : 20800
- Tel2 DN : 20801



Table 8-2: Example Sequence for MGCP

Go to Level	Task	Example Command	Notes
mgcp (from Voice Service)	1 - Enable protocol	call service	
	2 - Associate protocol to voice VLAN	bind source-interface vlan20	
Voice Service	3 - Configure country	cptone us	
Voice Port	4 - Configure voice port and activate	voice-port tel1 (to access) no shutdown	
mgcp (protocol)	5 - Configure mgcp client and identify call agent address	call agent 10.52.142.6	

Table 8-3: Example Sequence for SIP

Go to Level	Task	Example Command	Notes
sip (from Voice Service) (config-serv-sip)	1 - Enable protocol	call service	
	2 - Associate protocol to voice VLAN	bind source-interface vlan20	
Voice Service (config-voi-serv)	3 - Configure country	cptone us	
Voice Port (config-voiceport)	4 - Configure voice port and activate	voice-port tel1 (to access) no shutdown	
	5 - Configure other voice port and activate	voice-port tel2 (to access) no shutdown	
Dial Peer (config-dial-peer)	6 - Configure incoming dial peer ports	dial-peer voice 1 pots (to access) destination pattern 20800	
	7 - Configure outgoing dial peer for termination to SIP softswitch	dial peer voice 3 voip (to access) destination-pattern x.T	
	8 - Define user address and Authentication Password	dial-peer voice 1 (to access) authentication username john pass- word john_pw	
sip (protocol) (config-sip-ua)	9 - Configure SIP User Agent and identify proxy server address	sip-server 10.52.142.6	

Table 8-3: Example Sequence for SIP

Go to Level	Task	Example Command	Notes
Voice Applications (access codes) (config-voipapp-fac)	10 - Define prefixes required	prefix * call forward all 66 call forward all cancel 76 call-waiting 67 call-waiting cancel 77 conference 757 transfer blind 545 transfer consult 454	
Supplementary Services (config-voipapp-suppl-serv-port)	11 - Set up services on a port	port tell (to access) call forward all 919-645-5530 transfer-mode consult transfer-mode blind conference hold-resume	
Voice Port (config-voiceport)	12 - Activate service	voice-port tell (to access) call waiting	Can repeat tell commands




FIGURE 8-3 Command Levels for SIP Example (Table 8-5)

## 8.3 Command Reference

### 8.3.1 Voice Service Logging

This subsection describes the debug command for voice

Table 8-4: Voice Log Commands (config)

Commands
<code>debug voip category (config)</code>

**DEBUG VOIP CATEGORY (CONFIG)**

**Syntax**            debug voip <[category] | [level] | [verbosity]>  
                      no debug voip [category]

**Description**    Set the logging system to enable or disable voice logging for one or more categories.  
                      Use the no variant to disable a specific or all categories or

**Feature**           VoIP Commands

**Mode**             Privileged Exec and Global Configuration Mode

**Release**          4.1

**Options**

Option	Description	Range	Default Value
category	The type of voip activity or protocol. Values are: aep - Analog Endpoint ca - Call Agent config - Configuration drv - DSP abstraction layer drvtone - Driver - fax and modem tones gwa - Gateway Information (user db, memory, etc mep - Media Endpoint mgcp - Media Gateway Control Protocol. Within mgcp are event, general, and msg. sdp - Session Description Protocol sep - Signalling Endpoint sigcon - Signalling Connection sip - Session Initiation Protocol. Within sip are event, general, and msg vrg VRG interface for Broadcom platforms	NA	all
level	Sets the level of the output. Values are: debug - Set application log to output debug level messages error - Set application log to output error level messages notice - Set application log to output notice level messages	NA	error
verbosity	The amount of detail for each log. Values are: high - Enable medium format process name and timestamp low - Enable basic output message format medium - Enable low format plus function name and line number	NA	medium

**Note** By default all voip logs are enabled at error level. To do selective logging the best strategy is to disable all voip logs (no debug voip) then enable the desired ones at the appropriate level. Refer to the example.

**Example** See the following commands for option:

```
awplus(config)# do show log config
```

Permanent Log:

Status ..... Enabled

Filters:

Level ..... debug

Program .....

Level ..... notices

Program .....

Level ..... errors

Program ..... httpd sshd telnetd swupdate snmpd igmp access voip

Under Voip subcategory:

The verbosity is: Medium

aep ..... Enabled

ca ..... Enabled

config ..... Enabled

drv ..... Enabled

drvtone ..... Enabled

gwa ..... Enabled

mep ..... Enabled

mgcp ..... Enabled

mgcpEvent ..... Enabled

mgcpMsg ..... Enabled

sdp ..... Enabled

sep ..... Enabled

sigcon ..... Enabled

sip ..... Enabled

sipevent ..... Enabled

sipMsg ..... Enabled

vrg ..... Enabled

```
awplus(config)# no debug voip <!-- disables all subcategories
```

```
awplus(config)# do show log config
```

Permanent Log:

Status ..... Enabled

Filters:

Level ..... debug

Program .....

Level ..... notices

Program .....

Level ..... errors

Program ..... httpd sshd telnetd swupdate snmpd igmp access voip

Under Voip subcategory:

The verbosity is: Medium

aep ..... Disabled

ca ..... Disabled

config ..... Disabled

drv ..... Disabled

drvtone ..... Disabled

gwa ..... Disabled

```

mep ..... Disabled
mgcp ..... Disabled
mgcpEvent ..... Disabled
mgcpMsg ..... Disabled
sdp ..... Disabled
sep ..... Disabled
sigcon ..... Disabled
sip ..... Disabled
sipevent ..... Disabled
sipMsg ..... Disabled
vrg ..... Disabled

```

```

awplus(config)# debug voip category mgcp event <!-- Enabling one subcategory
awplus(config)# do show log config

```

Permanent Log:

Status ..... Enabled

Filters:

Level ..... debug

Program .....

Level ..... notices

Program .....

Level ..... errors

Program ..... httpd sshd telnetd swupdate snmpd igmp access voip

Under Voip subcategory:

The verbosity is: Medium

```

aep ..... Disabled
ca ..... Disabled
config ..... Disabled
drv ..... Disabled
drvtone ..... Disabled
gwa ..... Disabled
mep ..... Disabled
mgcp ..... Disabled
mgcpEvent ..... Enabled <!-- Only one Enabled
mgcpMsg ..... Disabled
sdp ..... Disabled
sep ..... Disabled
sigcon ..... Disabled
sip ..... Disabled
sipevent ..... Disabled
sipMsg ..... Disabled
vrg ..... Disabled

```

### 8.3.2 Voice Service Command List (config-voi-serv)

This subsection provides an alphabetical reference of configure, clear, and show commands related to activating and deactivating voice service.

Table 8-5: Voice Service Commands (config-voi-serv)

Commands
<a href="#">cptone (config-voi-serv)</a>
<a href="#">dtmf-relay voip (config-voi-serv)</a>
<a href="#">fax protocolt38 (config-voi-serv)</a>
<a href="#">ip rtp precedence (config-voi-serv)</a>
<a href="#">ip signaling precedence (config-voi-serv)</a>
<a href="#">rtp behavior discard-when-remote-unknown (config-voi-serv)</a>
<a href="#">rtp behavior discard-when-source-unknown (config-voi-serv)</a>
<a href="#">rtp payload-type (config-voi-serv)</a>
<a href="#">shutdown (config-voi-serv)</a>
<a href="#">tone incoming (config-voi-srv)</a>

**CPTONE (CONFIG-VOI-SERV)**

**Syntax**           cptone  
                  [no] cptone

**Description**       Configure the voice port to utilize a specific countries tone set for items such as Dial Tone etc.  
Use the no variant of reset it to the default IT.

**Feature**           VoIP Commands

**Mode**             Voice Service Configuration Mode

**Release**           4.1

**Options**

Option	Description	Range	Default Value
<country-code>	ISO specific set of country codes - default is "IT". Refer to <a href="#">8.1.4.2</a> for a country tones listing.	NA	IT

**Note**             This triggers the restart of DSP, so this will take time to finish. Also, this does not change the hook qualification timers, so you should change these if necessary.

**Example**         See the following commands for option:

```
awplus#(config)# voice service voip
awplus(config-voi-serv)# cptone US
```



**DTMF-RELAY VOIP (CONFIG-VOI-SERV)**

**Syntax** dtmf-relay voip mode <rtp-nte | sip-info>  
no dtmf-relay

**Description** This command enables dtmf-relay support for the transmission of DTMF events. The mode indicates whether the digits should be transmitted as rtp events (RFC2833), SIPINFO messages (only when SIP is enabled), or InBand (no dtmf-relay), as follows:

- rtp-nte = DTMF are sent via RFC2833. The real usage of RFC2833 will depend on the result of the negotiation phase for media attributes.=
- sip-notify = DTMF are sent via SIP INFO messages. It applies only when SIP protocol is used.
- in-band = DTMF are sent in band, i.e. using the same RTP speech codec used for the voice path.

Use the no variant of this command to disable the dtmf relay (inband).

**Feature** VoIP Commands

**Mode** Voice Service Configuration Mode

**Release** 4.1

**Options**

Option	Description	Range	Default Value
<mode>	rtp-nte - use RFC2833 to transmit DTMF digits sip-info - use SIP Notify Messages to transmit the digits	NA	rtp-nte

**Note** NA

**Example** See the following commands for options

CLI capture:

Enter configuration commands, one per line. End with CNTL/Z.

```
awplus(config)# voice serv voip
```

```
awplus(config-voi-srv)# dtmf-relay voip mode ?
```

```
    rtp-nte    Use RTP Network Terminal Events to transmit the digits
```

```
    sip-info   Use SIP Info Messages to transmit the digits
```

```
awplus(config-voi-srv)# dtmf-relay voip mode rtp-nte ?
```

```
<cr>
```

```
awplus(config-voi-srv)# dtmf-relay voip mode sip-info ?
```

```
<cr>
```

```
awplus(config-voi-srv)# no dtmf-relay ?
```

```
<cr>
```

**FAX PROTOCOLT38 (CONFIG-VOI-SERV)**

<b>Syntax</b>	fax protocol t38 [no] fax protocol t38
<b>Description</b>	This command enables activation of T38 upon detection of FAX.
<b>Feature</b>	VoIP Commands
<b>Mode</b>	Voice Service Configuration Mode
<b>Release</b>	4.1
<b>Options</b>	NA
<b>Note</b>	T.38 is only supported for SIP.
<b>Example</b>	See the following commands:

```
awplus#(config)# voice service voip
awplus(config-voi-serv)# fax protocol t38
```

**IP RTP PRECEDENCE (CONFIG-VOI-SERV)**

**Syntax**            `ip rtp precedence <value>`  
                     `[no] ip rtp precedence`

**Description**       This command specifies the DSCP value to be used for all voice traffic (RTP traffic).  
                     Use of the no option restores the value to the default.

**Feature**            VoIP Commands

**Mode**               Voice Service Configuration Mode

**Release**            4.1

**Options**

Option	Description	Range	Default Value
value	DSCP value to be used in IP packet	0-63	0

**Note**               NA

**Example**           See the following commands:

```
awplus#(config)# voice service voip
awplus(config-voi-serv)#ip rtp precedence 46
```

**IP SIGNALING PRECEDENCE (CONFIG-VOI-SERV)**

**Syntax**            ip signaling precedence <value>  
                      [no] ip signalling

**Description**       This command specifies the DSCP value to be used for all Voip Signaling. Valid values are from 0 to 63. The default value is 0.

The no option on this command restores the value to it's default

**Feature**            VoIP Commands

**Mode**                Voice Service Configuration Mode

**Release**            4.1

**Options**

Option	Description	Range	Default Value
value	DSCP value to be used for signaling traffic	0-63	0

**Note**                NA

**Example**            See the following commands:

```
awplus#(config)# voice service voip
awplus(config-voi-serv)# ip signaling precedence 46
```

**RTP BEHAVIOR DISCARD-WHEN-REMOTE-UNKNOWN (CONFIG-VOI-SERV)**

<b>Syntax</b>	<code>rtp behavior discard-when-remote-unknown</code> <code>no rtp behavior discard-when-remote-unknown</code>
<b>Description</b>	This command forces the voice stack to accept or discard RTP frames that arrive from a remote peer when the IP address of the remote peer specified in the SDP connection field is null (0.0.0.0). The no option returns this parameter to the default (accept unknown frames).
<b>Feature</b>	VoIP Commands
<b>Mode</b>	Voice Service Configuration Mode
<b>Release</b>	4.2
<b>Options</b>	NA
<b>Note</b>	NA
<b>Example</b>	See the following command:  <code>awplus(config-voi-serv)# no rtp behavior discard-when-remote-unknown</code>

**RTP BEHAVIOR DISCARD-WHEN-SOURCE-UNKNOWN (CONFIG-VOI-SERV)**

<b>Syntax</b>	<code>rtp behavior discard-when-source-unknown</code> <code>no rtp behavior discard-when-source-unknown</code>
<b>Description</b>	<p>This command forces the voice stack to accept or discard RTP frames that arrive from a remote peer having an IP address when the IP address that differs from the IP address specified in the SDP connection field.</p> <p>The no option returns this parameter to the default (drop frames in case of IP addresses mismatch).</p>
<b>Feature</b>	VoIP Commands
<b>Mode</b>	Voice Service Configuration Mode
<b>Release</b>	4.2
<b>Options</b>	NA
<b>Note</b>	NA
<b>Example</b>	<p>See the following command:</p> <pre>awplus(config-voi-serv)# rtp behavior discard-when-source-unknown</pre>

## RTCP (CONFIG-VOI-SERV)

<b>Syntax</b>	rtcp [no] rtcp
<b>Description</b>	This command enables or disables RTCP for voice traffic  The no option returns this parameter to the default.
<b>Feature</b>	VoIP Commands
<b>Mode</b>	Voice Service Configuration Mode
<b>Release</b>	4.1
<b>Options</b>	NA
<b>Note</b>	NA
<b>Example</b>	See the following commands:

```
awplus#(config)# voice service voip  
awplus(config-voi-serv)# rtcp
```

**RTP PAYLOAD-TYPE (CONFIG-VOI-SERV)**

**Syntax**            rtp payload-type nte <number>  
                     no rtp payload-type nte

**Description**       This command specifies Payload-type to be used for RTP Named Terminal Events. Valid range is 94 to 127. Default is 97.

The no option returns this parameter to the default.

**Feature**            VoIP Commands

**Mode**               Voice Service Configuration Mode

**Release**            4.1

**Options**

Option	Description	Range	Default Value
nte	Named Telephone Events.	NA	NA
number	The value used for the name telephone event payload.	96-127	97

**Note**                NA

**Example**            See the following commands.:

```
awplus#(config)# voice service voip
awplus(config-voi-serv)# rtp payload-type nte 98
```



**SHUTDOWN (CONFIG-VOI-SERV)**

<b>Syntax</b>	shutdown [no] shutdown
<b>Description</b>	This command disables or enables the voip service on the device
<b>Feature</b>	Voice Commands
<b>Mode</b>	Voice Service Configuration Mode
<b>Release</b>	4.1
<b>Options</b>	NA
<b>Note</b>	To enable, the user protocol must have already been specified.
<b>Example</b>	See the following commands:

```
awplus#(config)# voice service voip  
awplus(config-voi-serv)# shutdown
```

**TONE INCOMING (CONFIG-VOI-SRV)**

<b>Syntax</b>	tone incoming ans-all disable echo suppressor [no] tone incoming
<b>Description</b>	Activate to enable Tone detection (2100-Hz Answer (ANS)) and to disable the echo canceller. The No option disables tone detection.
<b>Feature</b>	VoIP Commands
<b>Mode</b>	Voice Service Configuration Mode
<b>Release</b>	4.1
<b>Default</b>	Tone incoming ans-all disable echo suppressor
<b>Note</b>	NA
<b>Example</b>	See the following commands:

```
awplus#(config)# voice service voip
awplus(config-voi-serv)# tone incoming ans-all disable echo suppressor
```

### 8.3.3 Enable/Disable MGCP Command List (config-serv-mgcp)

This chapter provides an alphabetical reference of configure, clear, and show commands related to enabling and disabling MGCP service.

Table 8-6: MGCP Service Commands (config-serv-mgcp)

Commands
<a href="#">bind (config-serv-mgcp)</a>
<a href="#">call service restart (config-serv-mgcp)</a>
<a href="#">call service (config-serv-mgcp)</a>
<a href="#">listen-port (config-serv-mgcp)t</a>

**BIND (CONFIG-SERV-MGCP)**

**Syntax**            `bind source-interface <interface_id>`  
                     `[no] bind`

**Description**       This command specifies the vlan interface that the MGCP client should use to source and receive both signalling and rtp traffic.

**Feature**            VoIP Commands

**Mode**               Voice Service Configuration Mode

**Release**            4.1

**Options**

Option	Description	Range	Default Value
<interface_id>	The name of the interface - that the MGCP Signalling and RTP traffic should originate from.	NA	NA

**Note**                NA

**Example**            Refer to the following commands:

```
aw(config-voi-serv)#plus#(config)# voice service voip
awplus(config-voi-serv)#mgcp
awplus(config-serv-mgcp)# bind source-interface vlan115
```

**CALL SERVICE RESTART (CONFIG-SERV-MGCP)**

**Syntax** `call service restart [forced]`

**Description** This command triggers the restart of the MGCP Client  
  
Forces MGCP client on the device to restart. Note that the forced option is mandatory - and forces all existing calls to get torn down.

**Feature** VoIP Commands

**Mode** Voice Service Configuration Mode

**Release** 4.1

**Options**

Option	Description	Range	Default Value
forced	No graceful end to existing calls. MGCP client will destroy existing calls and restart. (Mandatory)	NA	forced

**Note** NA

**Example** Refer to the following commands:

```
aw(config-voi-serv)#plus#(config)# voice service voip
awplus(config-voi-serv)#mgcp
awplus(config-serv-mgcp)# call service restart forced
```

**CALL SERVICE (CONFIG-SERV-MGCP)**

<b>Syntax</b>	<code>call service</code> <code>[no] call service</code>
<b>Description</b>	This command disables or enables MGCP Protocol.
<b>Feature</b>	VoIP Commands
<b>Mode</b>	Voice Service Configuration Mode
<b>Release</b>	4.1
<b>Options</b>	NA
<b>Note</b>	NA
<b>Example</b>	Refer to the following commands:

```
aw(config-voi-serv)#plus#(config)# voice service voip
awplus(config-voi-serv)#mgcp
awplus(config-serv-mgcp)# call service
```

**LISTEN-PORT (CONFIG-SERV-MGCP)**

**Syntax**           listen-port <port-num>  
                  [no] listen-port

**Description**       This command specifies the port that the MGCP Client should listen on for MGCP Signalling. The no form of the command resets it to the default value of 2427.

**Feature**           VoIP Commands

**Mode**             Voice Service Configuration Mode

**Release**           4.1

**Options**

Option	Description	Range	Default Value
port-num	The IP Port number that SIP Signalling is expected to arrive on.	NA	2427

**Note**             NA

**Example**          Refer to the following commands:

```
aw(config-voi-serv)#plus#(config)# voice service voip
awplus(config-voi-serv)#mgcp
awplus(config-serv-mgcp)# listen-port 2440
```

### 8.3.4 Enable/Disable SIP Command List (config-serv-sip)

This chapter provides an alphabetical reference of configure, clear, and show commands related to enabling and disabling SIP service.

Table 8-7: SIP Service Commands (config-serv-sip)

Commands
<a href="#">bind (config-serv-sip)</a>
<a href="#">call service restart (config-serv-sip)</a>
<a href="#">call service (config-serv-sip)</a>
<a href="#">hairpin (config-serv-sip)</a>
<a href="#">listen-port (config-serv-sip)</a>
<a href="#">localhost (config-serv-sip)</a>



**BIND (CONFIG-SERV-SIP)**

**Syntax**            `bind source-interface <interface_id>`  
                     `[no] bind`

**Description**       This command binds SIP Signalling and RTP Traffic to a specific interface. Specifies the source interface that the SIP Client should use to source & receive both signalling and rtp traffic.

The no form of this command restores IP interface back to default: vlan 1.

**Feature**            Voice-SIP Commands

**Mode**              Voice Service Configuration Mode

**Release**           4.1

**Options**

Option	Description	Range	Default Value
interface_id	The name of the interface - here it is the form "vlan<num>".	NA	NA

**Note**              NA

**Example**           Refer to the following commands:

```
awplus#(config)# voice service voip
awplus(config-voi-serv)#sip
awplus(config-serv-sip)#bind source-interface vlan115
```

**CALL SERVICE RESTART (CONFIG-SERV-SIP)**

**Syntax** `call service restart [forced]`

**Description** This command triggers restart of the SIP Client

Forces the SIP client on the device to restart. Note that the forced parameter is mandatory - and forces all existing calls to get torn down.

**Feature** Voice-SIP Commands

**Mode** Voice Service Configuration Mode

**Release** 4.1

**Options**

Option	Description	Range	Default Value
forced	No graceful end to existing calls. SIP Client will destroy existing calls and restart (Mandatory)	NA	forced

**Note** NA

**Example** Refer to the following commands:

```
awplus#(config)# voice service voip
awplus(config-voi-serv)#sip
awplus(config-serv-sip)#call service restart forced
```

**CALL SERVICE (CONFIG-SERV-SIP)**

<b>Syntax</b>	<code>call service</code> <code>[no] call service</code>
<b>Description</b>	This command disables or enables SIP Client.  Command enables - or disables SIP client. Disable is done without preserving existing calls.
<b>Feature</b>	Voice-SIP Commands
<b>Mode</b>	Voice Service Configuration Mode
<b>Release</b>	4.1
<b>Options</b>	NA
<b>Note</b>	NA
<b>Example</b>	Refer to the following commands:  <code>awplus#(config)# voice service voip</code> <code>awplus(config-voi-serv)#sip</code> <code>awplus(config-serv-sip)#call service</code>

## HAIRPIN (CONFIG-SERV-SIP)

<b>Syntax</b>	hairpin [no] hairpin
<b>Description</b>	<p>This command allows SIP Signalling to terminate on the same device</p> <p>When enabled, SIP Signalling is allowed to terminate on the same device it originated from without going to an external device. As a result, no signalling is sent to the configured ProxyServer.</p> <p>The no form of the command resets this capability to the default - which is disabled.</p>
<b>Feature</b>	Voice-SIP Commands
<b>Mode</b>	Voice Service Configuration Mode
<b>Release</b>	4.1
<b>Options</b>	NA
<b>Note</b>	This command does not include RTP traffic; it will perform a hairpin if instructed by the signaling protocol.
<b>Example</b>	<p>Refer to the following commands:</p> <pre>awplus#(config)# voice service voip awplus(config-voi-serv)#sip awplus(config-serv-sip)#hairpin</pre>

**LISTEN-PORT (CONFIG-SERV-SIP)**

**Syntax**           listen-port <port-num>  
                  [no] listen-port

**Description**       This command specifies the port for the SIP Client to listen on for SIP Signalling traffic.  
  
                  Specifies the port that the SIP Client should listen on for SIP Signalling. The no form of the command resets it to the default value of 5060.

**Feature**           VoIP Commands

**Mode**             Voice Service Configuration Mode

**Release**          4.1

**Options**

Option	Description	Range	Default Value
port-num	The IP Port number that SIP Signalling is expected to arrive on.	NA	5060

**Note**             NA

**Example**          Refer to the following commands:

```
awplus#(config)# voice service voip
awplus(config-voi-serv)#sip
awplus(config-serv-sip)#listen-port 5080
```

**LOCALHOST (CONFIG-SERV-SIP)**

**Syntax**            localhost dns domain  
                      [no] localhost

**Description**      This command configures the gateway to substitute a DNS hostname or domain as the localhost instead of the IP address.

**Feature**            VoIP Commands

**Mode**                Voice Service Configuration Mode

**Release**            4.1

**Options**

Option	Description	Range	Default Value
domain	The DNS domain - including a domain name and optionally a hostname.	NA	NA

**Note**                NA

**Example**            Refer to the following commands:

```
awplus#(config)# voice service voip
awplus(config-voi-serv)#sip
awplus(config-serv-sip)#localhost dns somedomain
```

### 8.3.5 Configure MGCP Protocol Command List (config-mgcp)

This chapter provides an alphabetical reference of configure, clear, and show commands related to configuring the MGCP protocol.

Table 8-8: MGCP Protocol Commands (config-mgcp)

Commands
<a href="#">backup-call-agent (config-mgcp)</a>
<a href="#">behavior heartbeat (config-mgcp)</a>
<a href="#">behavior rsip-range (config-mgcp)</a>
<a href="#">call-agent (config-mgcp)</a>
<a href="#">domain (config-mgcp)</a>
<a href="#">endpoint offset (config-mgcp)</a>
<a href="#">package-capability lcs-package (config-mgcp)</a>
<a href="#">persistent (config-mgcp)</a>
<a href="#">piggyback message (config-mgcp)</a>
<a href="#">request retries (config-mgcp)</a>
<a href="#">request timeout (config-mgcp)</a>
<a href="#">rtp payload-type (config-mgcp)</a>
<a href="#">show mgcp</a>

**BACKUP-CALL-AGENT (CONFIG-MGCP)**

**Syntax** backup-call-agent <ip-address|host-name> <port>  
[no] backup-call-agent

**Description** This command specifies the secondary Call Agent that the MGCP Client will attempt to register with. Note that the service-type is inherited from the configured primary call-agent. Once configured, the MGCP client can start to communicate with the Call Agent

**Feature** Voice-MGCP Commands

**Mode** MGCP Configuration Mode

**Release** 4.1

**Options**

Option	Description	Range	DefaultValue
<ip-address>	IPV4 IP Address used as the destination for MGCP signalling	NA	NA
host-name	The qualified hostname that is used as the destination for MGCP Signalling.	NA	NA
<port>	The port number that the MGCP Call Agent signalling is sent to.	NA	2727

**Note** to know which Call Agent the iMG is actually registered to, use the show mgcp command and check the information reported in the bottom lines for the Endpoints Active Agent status.

**Example** Refer to Refer to the following commands:

```
iMG1525RF-214# show mgcp
Admin State ENABLED
Call agent: 172.30.1.228 2727 service is MGCP
Backup call agent: 172.30.1.229 2727
Gateway Source Interface: vlan203
Gateway Port : 2427
DTMF-relay for VoIP is inband for all codec types
Tone detection is ans-all disable echo suppressor
T.38 Fax is ENABLED
NTE payload type is DYNAMIC
RTP Payload type for nte is 101
RTP precedence: 0
RTP discard on unknown remote is ENABLED
RTP discard on mismatched source is ENABLED
RTCP ENABLED
Piggyback msg ENABLED
Heartbeat message is: DISABLED
Heartbeat master port is *
Heartbeat refresh timeout is: 15 seconds
Rsip-range use is : INDIVIDUAL
Request timeout: 20 seconds
Request retries: 7
Signaling precedence: 0
Domain: [$IP]
```



---

```
Package capability: basic-package, dtmf-package, gm-package, line-  
package, rtp-package  
Endpoint offset is DISABLED  
Persistent Events: none  
Endpoints: aaln/0 port: tel1 Admin State ENABLED Oper State Up Call State  
Idle Active Agent Primary  
Endpoints: aaln/1 port: tel2 Admin State ENABLED Oper State Up Call State  
Idle Active Agent Primary
```

**BEHAVIOR HEARTBEAT (CONFIG-MGCP)**

**Syntax**            behavior heartbeat {NTFY | RSIP-Refresh | RSIP-keepalive} <seconds> [master <portname>]  
                      [no] behavior heartbeat

**Description**      This command enables and disables the Heartbeat mechanism, configure the interval between heartbeat messages, as well as specify the messaging used. This feature is used to ensure that the call-agent is aware of the devices in the network - and the current state of those devices.

**Feature**            Voice-MGCP Commands

**Mode**               MGCP Configuration Mode

**Release**            4.1

**Options**

Option	Description	Range	Default Value
NTFY	Use the Notify Message with "N:hb" indication	NA	NA
RSIP-Refresh	Use the RSIP Message with the "RM:x-refresh" parameter	NA	NA
RSIP-keepalive	Use the RSIP Message with the "RM:x-keepalive" parameter	NA	NA
master	Specifies the port that manages the heartbeat: tel1 or tel2 or * for both. If this port fails, all other ports are failed.	NA	*
<seconds>	The number of seconds between transmission of messages.	NA	10

**Note**                NA

**Example**            Refer to the following commands:

```
awplus#(config)# mgcp
awplus(config-mgcp)# behavior heartbeat NTFY 10
```

**BEHAVIOR RSIP-RANGE (CONFIG-MGCP)**

**Syntax** `behavior rsip-range {all|none}`

**Description** This command specifies whether the MGCP Client will transmit RSIPs for all ports on the device, or for each port.

**Feature** Voice-MGCP Commands

**Mode** MGCP Configuration Mode

**Release** 4.1

**Options**

Option	Description	Range	Default Value
{all none}	all implies that the RSIP Range will be used. None implies that it will not be used. The default is none.	NA	none

**Note** NA

**Example** Refer to the following commands:

```
awplus#(config)# mgcp
awplus(config-mgcp)# behavior rsip-range all
```

**CALL-AGENT (CONFIG-MGCP)**

**Syntax** `call-agent <ip-address|host-name> <port> service-type {mgcp | mgcp-ncs}  
[no] call-agent`

**Description** This command specifies the call agent and protocol variant

Specifies the primary Call Agent that the MGCP Client will attempt to register with. Also allows the user to specify the service-type or variant of the protocol that is

**Feature** Voice-MGCP Commands

**Mode** MGCP Configuration Mode

**Release** 4.1

**Options**

Option	Description	Range	Default Value
<ip-address>	IPV4 IP Address used as the destination for MGCP signalling	NA	NA
host-name	The qualified hostname that is used as the destination for MGCP Signalling.	NA	NA
<port>	The port number that the MGCP Call Agent signalling is sent to.	NA	2727
service-type	The version of the MGCP Protocol that is being used. MGCP implies MGCP I.0. MGCP-NCS implies NCS I.0.	NA	NA

**Note** NA

**Example** Refer to the following commands:

```
awplus#(config)# mgcp  
awplus(config-mgcp)# call-agent 10.52.90.17 2400 service-type mgcp
```

**DOMAIN (CONFIG-MGCP)**

**Syntax** domain <ipaddr|domainstr|mac>  
[no] domain

**Description** This command specifies the format and contents of the Domain Name - used in the source address in MGCP client signalling.

Use the no form of the command to reset the value to the default (The ip address of the device)

**Feature** Voice-MGCP Commands

**Mode** MGCP Configuration Mode

**Release** 4.1

**Options**

Option	Description	Range	Default Value
<ipaddr>	IPV4 IP Address used as the destination for MGCP signalling	NA	NA
domainstr	Can be any valid string or \$IP, \$MAC, or \$Host, where \$ means have these values substituted	NA	[\$IP]
mac	The MAC Address that is used as the Domain for MGCP Signalling.	NA	NA

**Note** NA

**Example** Refer to the following commands:

```
awplus#(config)# mgcp
awplus(config-mgcp)# domain 10.53.44.23
```

## ENDPOINT OFFSET (CONFIG-MGCP)

<b>Syntax</b>	endpoint offset [no] endpoint offset
<b>Description</b>	This command, when enabled, marks the endpoint address (aaln/#) starting from 1 rather than the default, starting from 0 (aaln/0). This, combined with the domain attribute, is used to define the endpoint identifier.
<b>Feature</b>	Voice-MGCP Commands
<b>Mode</b>	MGCP Configuration Mode
<b>Release</b>	4.1
<b>Options</b>	NA
<b>Note</b>	NA
<b>Example</b>	Refer to the following commands:  awplus#(config)# mgcp awplus(config-mgcp)# endpoint offset

**PACKAGE-CAPABILITY LCS-PACKAGE (CONFIG-MGCP)**

<b>Syntax</b>	package-capability lcs-package no package-capability lcs-package
<b>Description</b>	Configure MGCP to add the Line Control Signaling (RFC3660 lcs-package) to the package capabilities list. The No option returns to the default setting.
<b>Feature</b>	Voice-MGCP Commands
<b>Mode</b>	Global Configuration Mode
<b>Release</b>	4.3
<b>Options</b>	NA
<b>Default</b>	For MGCP service type, lcs-package is disabled. For MGCP-NCS service-type, lcs-package is enabled.
<b>Note</b>	NA
<b>Example</b>	Refer to the following commands:  awplus# configure terminal awplus(config)# mgcp awplus(config-mgcp)# package-capability lcs-package

## PERSISTENT (CONFIG-MGCP)

**Syntax**            persistent [hookflash|offhook|onhook|digits]  
                     no persistent [hookflash|offhook|onhook|digits]

**Description**      Configure the persistence of hook-events and digits for MGCP. This command is used to enable the persistence of hook-events with MGCP call-agent that sometimes does not provide a RequestedEvents parameter in RQNT NotificationRequest messages during hook-events. Also used to enable the ability to send digits when the call-agent does not request the digits.  
The No option of this command returns the settings to their default value.

**Feature**            Voice-MGCP Commands

**Mode**              Global Configuration Mode

**Release**            4.3

### Options

Option	Description	Range	Default Value
hookflash	Telephone hook-flash event	NA	NA
offhook	Telephone off-hook event	NA	NA
onhook	Telephone on-hook event	NA	NA
digits	Digits dialed or digits pressed during a call	NA	NA

**Default**            For MGCP service-type, all event-types are disabled.  
For MGCP-NCS service-type, hookflash, offhook and onhook are enabled, digits is disabled.

**Note**                NA

**Example**            Refer to the following commands:

```
awplus# configure terminal
awplus(config)# mgcp
awplus(config-mgcp)# persistent
```



---

**PIGGYBACK MESSAGE (CONFIG-MGCP)**

<b>Syntax</b>	<code>piggyback message</code> <code>[no] piggyback message</code>
<b>Description</b>	This command, when enabled, allows the MGCP Client to send multiple messages in one packet. This can reduce messaging overhead. As reported in RFC2705, piggyback refers to the support for a call agent to send several messages to the gateway using the same udp message and separating each message by a line of text containing a single dot. By default this is enabled.
<b>Feature</b>	Voice-MGCP Commands
<b>Mode</b>	Global Configuration Mode
<b>Release</b>	4.1
<b>Options</b>	NA
<b>Note</b>	NA
<b>Example</b>	Refer to the following commands:  <code>awplus#(config)# mgcp</code> <code>awplus(config-mgcp)# no piggyback message</code>

**REQUEST RETRIES (CONFIG-MGCP)**

**Syntax**            request retries <number>  
                      [no] retries

**Description**      This command specifies the number of retransmissions to attempt when no response received for MGCP Signaling.

                      Specifies the number of time the client will re-transmit an MGCP protocol message - prior to giving up....and possibly switching over to the backup call-agent.

                      Use the no form of this command to reset the value to the default

**Feature**            Voice-MGCP Commands

**Mode**                MGCP Configuration Mode

**Release**            4.1

**Options**

Option	Description	Range	Default Value
<number>	The number of times a message is retransmitted.	NA	7

**Note**                NA

**Example**            Refer to the following commands:

```
awplus#(config)# mgcp
awplus(config-mgcp)# request retries 5
```

**REQUEST TIMEOUT (CONFIG-MGCP)**

**Syntax**            request timeout <seconds>  
                      [no] request timeout

**Description**       This command specifies the maximum time a message waiting for an acknowledge can stay in the network before the endpoint enters in the disconnect procedure.

**Description**       The No form of this command resets the value to the default (20 secs)

**Feature**            Voice-MGCP Commands

**Mode**               MGCP Configuration Mode

**Release**            4.1

**Options**

Option	Description	Range	Default Value
<seconds>	The number of seconds that the MGCP Client will wait for a response. Default is 20.	NA	20

**Note**                Timeout period is specified in seconds instead of milliseconds.

**Example**            Refer to the following commands:

```
awplus#(config)# mgcp
awplus(config-mgcp)# request timeout 250
```

**RTP PAYLOAD-TYPE (CONFIG-MGCP)**

**Syntax**            rtp payload-type nte {dynamic|static}  
                     no rtp payload-type nte

**Description**      Configure the RTP NTE (Named Terminal Events) payload-type to static or dynamic for MGCP. The No form of this command resets the value to the default.

**Feature**            Voice-MGCP Commands

**Mode**                MGCP Configuration Mode

**Release**            4.3

**Options**

Option	Description	Range	Default Value
dynamic	Enable negotiation of NTE payload type.	NA	NA
static	Force-fixed NTE payload type.	NA	NA

**Note**                NA

**Default**            Dynamic

**Example**            Refer to the following commands:

```
awplus# configure terminal
awplus(config)# mgcp
awplus(config-mgcp)# rtp payload-type nte static
```

## SHOW MGCP

<b>Syntax</b>	show mgcp
<b>Description</b>	This command displays the configuration in place for the MGCP Client
<b>Feature</b>	Voice-MGCP Commands
<b>Mode</b>	Privileged Exec Mode
<b>Release</b>	4.1
<b>Options</b>	NA
<b>Note</b>	NA
<b>Example</b>	Refer to the following commands:

```
awplus# show mgcp
Admin State ENABLED
Call agent: 172.30.1.228 2727 service is MGCP-NCS
Backup call agent: 172.30.1.229 2727
Gateway Source Interface: vlan203
Gateway Port : 2427
DTMF-relay for VoIP is rtp-nte for all codec types
Tone detection is ans-all disable echo suppressor
T.38 Fax is ENABLED
NTE payload type is DYNAMIC
RTP Payload type for nte is 97
RTP precedence: 0
RTP discard on unknown remote is DISABLED
RTP discard on mismatched source is ENABLED
RTCP DISABLED
Piggyback msg ENABLED
Heartbeat message is: DISABLED
Heartbeat master port is *
Rsip-range use is : INDIVIDUAL
Request timeout: 20 seconds
Request retries: 7
Signaling precedence: 0
Domain: [$IP]
Package capability: basic-package, dtmf-package, gm-package,
                    lcs-package, line-package, rtp-package
Endpoint offset is DISABLED
Endpoints: aaln/0 port: tel1 Admin State ENABLED Oper State Up Call State
Idle
Endpoints: aaln/1 port: tel2 Admin State ENABLED Oper State Up Call State
Idle
```

<b>Syntax</b>	show mgcp service
<b>Description</b>	This command displays the status of the MGCP Service (Enabled or Disabled).
<b>Feature</b>	Voice-MGCP Commands
<b>Mode</b>	Privileged Exec Mode
<b>Release</b>	4.1
<b>Options</b>	NA
<b>Note</b>	NA
<b>Example</b>	Refer to the following commands:

```
awplus# show mgcp service
MGCP is Enabled
```

### 8.3.6 Configure SIP Protocol Command List (config-sip-ua)

This section provides an alphabetical reference of configure, clear, and show commands related to configuring the SIP protocol.

Table 8-9: SIP Protocol Commands (config-sip-ua)

Commands
<a href="#">authentication method (config-sip-ua)</a>
<a href="#">behavior disable-url-matching</a>
<a href="#">behavior hook-flash (config-sip-ua)</a>
<a href="#">behavior softswitch (config-sip-ua)</a>
<a href="#">map alertinfo (config-sip-ua)</a>
<a href="#">map alertinfo (config-sip-ua)</a>
<a href="#">rel xx</a>
<a href="#">show sip service</a>
<a href="#">show sip-ua</a>
<a href="#">show sip-ua map alertinfo</a>
<a href="#">sip-server (config-sip-ua)</a>
<a href="#">subscribe message-summary</a>

**AUTHENTICATION METHOD (CONFIG-SIP-UA)**

**Syntax** authentication method {proxy | www}  
[no] authentication method

**Description** Specifies the authentication method used in SIP digest authentication. It is possible to enable both methods of authentication by entering the command twice. Use the no form of this command to disable authentication.

**Feature** Voice-SIP Commands

**Mode** SIP UA Configuration Mode

**Release** 4.1

**Options**

Option	Description	Range	Default Value
Proxy	Support Proxy digest authentication method	NA	NA
www	Support the www digest authentication method	NA	NA

**Note** NA

**Example** Refer to the following commands:

```
awplus# configure terminal
awplus#(config)# sip-ua
awplus(config-sip-ua)# authentication method proxy
awplus(config-sip-ua)# authentication method www
```



**BEHAVIOR DISABLE-URL-MATCHING**

<b>Syntax</b>	behavior disable-url-matching no behavior disable-url-matching (default)
<b>Description</b>	Disable URL matching on incoming Request messages.
<b>Feature</b>	Voice-SIP Commands
<b>Mode</b>	SIP UA Configuration Mode
<b>Release</b>	4.3.3
<b>Options</b>	NA NA
<b>Source</b>	NA.
<b>Example</b>	Refer to the following commands:

```
awplus# configure terminal
awplus(config)# sip-ua
awplus(config-sip-ua)# behavior ?
    disable-url-matching
```

**BEHAVIOR HOOK-FLASH (CONFIG-SIP-UA)**

**Syntax**            behavior hook-flash {ext-in-call|external|internal|default}  
                       no behavior hook-flash

**Description**      Configure how the iMG processes hook-flash events for call-waiting, three-way call and call-transfers. The iMG can handle these call features internally to behave as an 'intelligent' SIP access device or as a 'non-intelligent' SIP access device and let the call-server handle the call features. To reset to the default, use the no form of this command or use the 'default' option. The default value used depends on the sip-server profile selected (see default setting description).

**Feature**            Voice-SIP Commands

**Mode**                SIP UA Configuration Mode

**Release**            4.4

**Options**

Option	Description	Range	Default Value
ext-in-call	Configure hook-flash for external control during a call. Hook-flash events during a call will be handled by SIP INFO. This is a modified version of the 'non-intelligent' mode of operation.	NA	NA
external	Configure hook-flash for external control. Hook-flash events will typically be handled by SIP INFO whenever possible. This is the 'non-intelligent' mode of operation.	NA	NA
internal	Configure hook-flash for internal control. Hook-flash events will typically be handled by SIP INVITE. This is the 'intelligent' mode of operation.	NA	NA
default	The default setting depends on the sip-server profile used (see behavior sip-server command). 'Internal' is the default for all sip-server profiles except for the Lucent profile which defaults to 'ext-in-call'.	NA	NA

**Default**            The hook-flash control is set to a preferred setting by the sip-server profile used (see behavior sip-server command):

Hook-flash	behavior sip-server profile
-----	-----
internal	(none), Broadsoft
ext-in-call	Lucent

The no form of this command will reset the hook-flash behavior to 'Internal' for any of the sip-server profile settings.

**Source**            The ability to process the incoming SIP INFO messages is controlled by the sip-server profile. So if you receive an INFO message from the Lucent switch it will play CWT tone. However if you attempt to flash-hook its going to send out an INVITE / inactive instead of an INFO / hook-flash. Same rules apply to Broadsoft profile. Having Broadsoft configured will allow the Broadsoft formatted INFO message. If you have changed the hook-flash control from "internal" to "ext-in-call" the hook-flash will cause an INFO / hook-flash instead of handling the call-wait internally. In summary, the sip-server profile setting will configure the SIP INFO message format and set the hook-flash control to a preferred setting. But it can be overridden by the CLI. You should only need to do this for an unexpected operating environment.

**Source**            iMG

**Example** Refer to the following commands:

```
awplus# configure terminal
awplus(config)# sip-ua
awplus(config-mgcp)# behavior hook-flash internal
```

**BEHAVIOR SOFTSWITCH (CONFIG-SIP-UA)**

**Syntax**            behavior sip-server {lucent | broadsoft}  
                     no behavior sip-server (default)

**Description**      Configures the system softswitch so that it is tailored to work with the specified softswitch. For all other softswitches, the parameter should be left at its default <none>

**Feature**            Voice-SIP Commands

**Mode**               SIP UA Configuration Mode

**Release**            4.2

**Options**

Option	Description	Range	Default Value
Lucent	Name for a softswitch	NA	NA
Broadsoft	Name for a softswitch	NA	NA

**Note**                NA

**Source**            iMG

**Example**            Refer to the following commands:

```
awplus# configure terminal
awplus#(config)# sip-ua
awplus(config-sip-ua)# behavior sip-server lucent
```

**MAP ALERTINFO (CONFIG-SIP-UA)**

**Syntax**      `map alertinfo <pattern #> <text string>`  
                  `no map alertinfo <pattern #>`

**Description**      This command associates the specified pattern number with the given alert info string. Use the `no` command to configure the specified pattern # with a default. These patterns also apply to call waiting.

**Feature**          Voice-SIP Commands

**Mode**            SIP UA Configuration Mode

**Release**        4.1.2

**Options**

Option	Description	Range	Default Value
pattern #	The pattern number (cadence mappings) that are used. In the USA these are the following: 1 - long 2 - long long 3 - short short long 4 - short long short 5 - ringsplash 6 - short short short 7 - short short short short 8 - short short short short short 9 - short 10 - ringsplash	NA	NA
TextString	Value of the Alert-Info SIP header (pattern for alert-info 1) (pattern for alert-info 2) (pattern for alert-info 3) (pattern for alert-info 4) (pattern for alert-info 5) (pattern for alert-info 6) (pattern for alert-info 7) (pattern for alert-info 8) (pattern for alert-info 9) (pattern for alert-info 10)	String	(shown below) distinctive-ring-1 distinctive-ring-2 distinctive-ring-3 distinctive-ring-4 distinctive-ring-5 distinctive-ring-6 distinctive-ring-7 distinctive-ring-8 distinctive-ring-9 distinctive-ring-10

**Note**            SIP must be specified as the signaling protocol for this command to work. Also, in a call waiting scenario, the distinctive pattern will carry over (for patterns 1-4).

**Example**        Refer to the following commands:

```
awplus# configure terminal
awplus(config)#sip-ua
awplus(config-sip-ua)# map alertinfo 1 Bellcore-dr1
```

**MAP ALERTINFO (CONFIG-SIP-UA)**

**Syntax** registrar {[host-name]|ip-addr [port-num]}[secondary]  
[no] registrar [secondary]

**Description** This command specifies the location server destination and port-number. Also used to identify whether it is the primary location server - or a backup address.

Use the no form to remove the entry.

**Feature** Voice-SIP Commands

**Mode** SIP UA Configuration Mode

**Release** 4.1.2

**Options**

Option	Description	Range	Default Value
host-name	The fully qualified hostname of the SIP Location Server	NA	NA
ip-addr	The IP address of the SIP Location Server	NA	NA
port-num	The port number that the Location Server will be listening on.	NA	5060
secondary	An indication that this location is the secondary contact, and that attempts to register should first be targeted at the non-secondary entry.	NA	NA

**Note** The primary server must always be registered (not secondary only) for SIP service to work.

**Example** Refer to the following commands:

```
awplus# configure terminal
awplus#(config)# sip-ua
awplus(config-sip-ua)# registrar 172.30.1.121 5060
awplus(config-sip-ua)# registrar 172.30.1.123 5060 secondary
```

**REL1XX**

<b>Syntax</b>	rellxx supported 100rel (default) rellxx disable no rellxx
<b>Description</b>	This command controls whether or not the "100rel" option appears in the SIP SUPPORTED header field. The "100rel" extension provides support for the reliability of provisional responses as defined in RFC-3262.
<b>Feature</b>	Voice-SIP Commands
<b>Mode</b>	SIP UA Configuration Mode
<b>Release</b>	4.1.3
<b>Options</b>	NA
<b>Note</b>	NA
<b>Example</b>	Refer to the following commands:  awplus# configure terminal awplus(config)# sip-ua awplus(config-sip-ua)# rellxx supported 100rel

**SHOW SIP SERVICE**

<i>Syntax</i>	show sip service
<i>Description</i>	This command displays the status of the SIP Service
<i>Feature</i>	Global Configuration Mode
<i>Mode</i>	Privileged Exec Mode
<i>Release</i>	4.1
<i>Options</i>	NA
<i>Note</i>	NA
<i>Example</i>	Refer to the following commands:

```
awplus# configure terminal
awplus# show sip service
SIP is Enabled
```



## SHOW SIP-UA

**Syntax**            `show sip-ua`

**Description**      This command displays configuration of the SIP User Agent, and includes any primary or backup servers if configured.

**Feature**            Global Configuration Mode

**Mode**              Privileged Exec Mode

**Release**           4.1

**Options**           NA

**Note**              NA

**Example**           Refer to the following commands:

```
awplus# configure terminal
awplus(config-sip-ua# do show sip-ua
Admin State ENABLED
  registrar: 172.30.1.121 5060
  secondary registrar : 172.30.1.123 5060 (active)
  sip-server: 172.30.1.121 5060 (active)
  secondary sip-server : 172.30.1.123 5060
  Source Interface: vlan2000
  Local host is : 172.30.1.121
  Sip User Port : 5060
  dtmf-relay for VoIP is rtp-nte for all codec types
  tone detection is DISABLED
  T.38 Fax is DISABLED
  rtp Payload type for nte is 97
  rtp precedence: 46
  rtcp is DISABLED
  authentication : proxy, www
  subscribe      : DISABLED
  signaling precedence is 32
  Hair pinning of signaling is enabled
  User Agents: 1 port: tel1 Admin State ENABLED Oper State Up Call State Idle
  User Agents: 2 port: tel2 Admin State ENABLED Oper State Up Call State Idle
```

## SHOW SIP-UA MAP ALERTINFO

<b>Syntax</b>	show sip-ua map alertinfo
<b>Description</b>	This command displays configuration of the alert info string and the cadence.
<b>Feature</b>	Global Configuration Mode
<b>Mode</b>	Privileged Exec Mode
<b>Release</b>	4.2.3
<b>Options</b>	NA
<b>Note</b>	NA
<b>Example</b>	Refer to the following commands:

```
awplus# configure terminal
awplus(config-sip-ua# do show sip-ua map alertinfo
  Pattern 1 : distinctive-ring-1
  Pattern 2 : distinctive-ring-2
  Pattern 3 : distinctive-ring-3
  Pattern 4 : distinctive-ring-4
  Pattern 5 : distinctive-ring-5
  Pattern 6 : distinctive-ring-6
  Pattern 7 : distinctive-ring-7
  Pattern 8 : distinctive-ring-8
  Pattern 9 : distinctive-ring-9
  Pattern 10 : distinctive-ring-10
```

**SIP-SERVER (CONFIG-SIP-UA)**

**Syntax** sip-server {[host-name]|ip-addr [port-num]} [secondary]  
[no] sip-server [secondary]

**Description** Use to specify the softswitch or proxy server destination and port-number. Also use to identify whether it is the primary softswitch - or a backup address. Use the no form to remove the entry.

**Feature** Voice-SIP Commands

**Mode** SIP UA Configuration Mode

**Release** 4.1.2

**Options**

Option	Description	Range	Default Value
host-name	The fully qualified hostname of the SIP Proxy Server	NA	NA
ip-addr	The IP address of the SIP Proxy Server	NA	NA
port-num	The port number that the Proxy Server will be listening on.	NA	5060
secondary	An indication that this is the secondary contact - and that attempts to register should first be targeted at the non-secondary entry.	NA	NA

**Note** The primary server must always be registered (not secondary only) for SIP service to work.

**Example** Refer to the following commands:

```
awplus# configure terminal
awplus#(config)# sip-ua
awplus(config-sip-ua)# sip-server 172.30.1.121 5060
awplus(config-sip-ua)# sip-server 172.30.1.123 5060 secondary
```

**SUBSCRIBE MESSAGE-SUMMARY**

**Syntax**            subscribe message-summary {[active]}[passive]}  
                      no subscribe message-summary

**Description**      This command enables the SIP subscribe service for receiving SIP messages for Message Waiting Indicator (MWI). Entering 'subscribe message summary' without any parameters specified will select the default method defined for the currently selected 'SIP server behaviour' (see sip-ua behavior sip-server command). If LUCENT has been selected then the default message-summary subscribe method is Passive, otherwise all the other server behaviours will use the Active method.

**Feature**            Voice-SIP Commands

**Mode**               SIP UA Configuration Mode

**Release**            4.2.3

**Options**

Option	Description	Range	Default Value
active	When Active mode is selected, SIP NOTIFY requests will not be accepted without a previous successful SUBSCRIBE exchange. When Passive mode is selected, SIP NOTIFY requests will be accepted independently from a previous successful SUBSCRIBE exchange.	NA	Default
passive	When Passive mode is selected, SIP NOTIFY requests will be accepted independently from a previous successful SUBSCRIBE exchange.	NA	NA

**Note**                NA

**Example**            To enable message-summary subscribe when Lucent profile has been selected, enter the command:

```
awplus# configure terminal
awplus(config)# sip-ua
awplus(config-sip-ua)# subscribe message-summary

awplus# show sip-ua

Admin State ENABLED
registrar: 172.30.1.1 5060 (active)
secondary registrar : not configured
sip-server: 172.30.1.1 5060 (active)
secondary sip-server : not configured
sip-server behavior : Lucent
Source Interface: vlan203
Local host is : not configured
Sip User Port : 5060
dtmf-relay for VoIP is rtp-nte for all codec types
tone detection is ans-all disable echo suppressor
T.38 Fax is ENABLED
rtp Payload type for nte is 97
rtp precedence: 0
rtp discard on unknown remote is DISABLED
rtp discard on mismatched source is ENABLED
```

```
rtcp is DISABLED
authentication : proxy, www
subscribe      : ENABLED
subscribe method : Default
signaling precedence is 0
Hair pinning of signaling is enabled
100rel support is enabled
User Agents: 1 port: tel1 Admin State ENABLED Oper State Up Call State Idle
User Agents: 2 port: tel2 Admin State DISABLED Oper State Disabled Call State
Idle
awplus(config-sip-ua)# subscribe message-summary
```

### 8.3.7 Configuring Voice Prefix Replacement (config-voi-trans-rule)

This subsection provides an alphabetical reference regarding configure, clear, and show commands related to prefix replacement (also called translation rule).

Table 8-10: SIP Voice Translation Rule Commands (config-voi-trans-rule)

Commands
<a href="#">voice translation-rule</a>
<a href="#">rule</a>
<a href="#">show voice translation-rule</a>

## VOICE TRANSLATION-RULE

**Syntax**            voice translation-rule <index>  
                      [no] voice translation-rule <index>

**Description**      Creates a new translation set and assigns an identifier <index> to it. Use the no variant to remove the translation set. When command is entered, the mode is switched into voice translation rule configuration (config-voi-trans-rule).

**Feature**            Voice Commands

**Mode**                Global Configuration Mode

**Release**            4.3

**Options**

Option	Description	Range	Default Value
num	An integer that univocally identifies the translation set.	0-4294967295	NA

**Note**                It's possible to create more than one translation set but only one can be applied in a given moment to a POTS interface

**Example**            The following command creates a translation set with identifier 3 and then moves the user into config-voi-trans-rule in order to continue with the configuration of the translation rules

```
awplus# configure terminal
awplus#(config)# voice translation-rule 3
awplus(config-voi-trans-rule)#
```

**RULE**

**Syntax**      `rule <priority> <digit-map> <digits> { prefix | replace }  
[no] rule <priority>`

**Description**      Creates a new translation rule inside the selected translation set. The rule will look inside the dialed number for the digit-map and if finds a correspondence it will replace the digit-map with the digits (if replace action has been specified) or will add a the digits as prefix (if prefix action has been selected). The default action is replace. The priority value is used to specify which rule is checked first. The lowest priority values have precedence over the highest values. As soon a positive match happens, the action rule is applied.

**Feature**      Voice Commands

**Mode**      Voice Translation Rule Configuration Mode

**Release**      4.3

**Options**

Option	Description	Range	Default Value
priority	An integer that univocally identifies the translation set.	0-4294967295	NA
digit-map	The digit-map to be search inside the dialed number.	A string 1 to 64 chars long	NA
digits	The new digits to be replaced or added as prefix when the rule matches.	A string of digits 1 to 64 chars lon	NA
prefix	In case of a positive match of the digit-map, the digits are added in front of the dialed number to form the complete called number.	A string of digits 1 to 64 chars lon	NA
replace	In case of a positive match of the digit-map, the digit-map is replaced by the digits to form the complete called number.	A string of digits 1 to 64 chars lon	NA

**Note**      In case of replacement type rules, the digit-map can be only digits, i.e. it's possible to replace only the leading digits of a dialed number. It's not possible to perform a pattern search inside a number and then replace that pattern.

**Example**      Refer to the following commands:

```
awplus# configure terminal
awplus#(config)# voice translation-rule 1

awplus(config-voi-trans-rule)# rule 5 1[6-7]2[2-3][1-2]3xxx1 50 prefix

awplus(config-voi-trans-rule)# rule 6 011 00 replace
awplus#(config)# dial-peer voice 1 pots
awplus(config-dial-peer)# translate-outgoing 1#
```



## SHOW VOICE TRANSLATION-RULE

**Syntax** `show voice translation-rule <index>`

**Description** The command displays the configured translation rules. If no rule set index is specified the command will return the list of all the translation sets and their corresponding rules.

**Feature** Voice Commands

**Mode** Global Configuration Mode

**Release** 4.3

**Options**

Option	Description	Range	Default Value
index	An integer that identifies the translation set.	0-4294967295	NA

**Note** It's possible to create more than one translation set but only one can be applied in a given moment to a POTS interface

**Example**

```
awplus# configure terminal
awplus#(show voice translation-rule 22
```

Translation Rule 22

```
Precedence : 2
Match Digits : 17232xxxxxxx
Translate Digits : 50
Translate Mode : prefix
```

```
Precedence : 5
Match Digits : 1[6-7]2[2-3][1-2]3xxx1|100xxxxxxx
Translate Digits : 20
Translate Mode : prefix
```

```
Precedence : 7
Match Digits : 800xxxx
Translate Digits : 10
Translate Mode : prefix
```

```
Precedence : 16
Match Digits : [4-7]xxx
Translate Digits : 60
Translate Mode : prefix
```

## 8.4 Configuring Voice Applications on Device and Ports

This section describes the telephone features, usually where the subscriber enters an access code, with a prefix and suffix, to activate or deactivate the feature. Voice applications are configured using commands from the following:

- **Access Codes** - This is where the access codes are defined that allow the subscriber to activate, deactivate, and in some cases provide telephone numbers that may be part of a features (such as call forwarding). These are configured at the device level.

- Supplementary Services - This is where services are defined on a port basis (tel1 or tel2).
- Endpoints - This is where the features for the voice port (tel1 or tel2) are activated.

### 8.4.1 Access Codes (Supplementary Services) Command list (config-voipapp-fac)

This sub-section provides an alphabetical reference for commands used to configure access codes, which are used to configure various subscriber services.

**Note:** When setting up access codes, be aware that if you use the Prefix command (usually set at “\*”), all activation codes are set to \* as the default setting. If any feature is then enabled without explicitly setting its activation code, there can be unintended matches and so unexpected results. Therefore, ensure that after setting up a Prefix, configure the access code for each feature that will be enabled. (You can also not use the Prefix command and include the \* as part of the feature code command.) Refer to [prefix \(config-voipapp-fac\)](#).

For information about modifying or redirecting the output from show commands to a file, see “Controlling “show” Command Output.

Table 8-1 I: Access Codes (Supplementary Service) Commands (config-voipapp-fac)

Commands
<a href="#">call forward all (config-voipapp-fac)</a>
<a href="#">call forward all cancel (config-voipapp-fac)</a>
<a href="#">call forward busy (config-voipapp-fac)</a>
<a href="#">call forward busy cancel (config-voipapp-fac)</a>
<a href="#">call forward no-answer (config-voipapp-fac)</a>
<a href="#">call forward no-answer cancel (config-voipapp-fac)</a>
<a href="#">call-waiting (config-voipapp-fac)</a>
<a href="#">call-waiting cancel (config-voipapp-fac)</a>
<a href="#">caller-id block override off (config-voipapp-fac)</a>
<a href="#">caller-id block override on (config-voipapp-fac)</a>
<a href="#">conference (config-voipapp-fac)</a>
<a href="#">per-call call-waiting (config-voipapp-fac)</a>
<a href="#">per-call call-waiting cancel (config-voipapp-fac)</a>
<a href="#">prefix (config-voipapp-fac)</a>
<a href="#">show voipapp</a>
<a href="#">suffix (config-voipapp-fac)</a>
<a href="#">transfer blind (config-voipapp-fac)</a>
<a href="#">transfer consult (config-voipapp-fac)</a>
<a href="#">warmline (config-voipapp-fac)</a>
<a href="#">warmline cancel (config-voipapp-fac)</a>

## CALL FORWARD ALL (CONFIG-VOIPAPP-FAC)

**Syntax** `call forward all <digits>`

**Description** This command defines the prefix used to enable the call forwarding on all calls supplementary service. When enabled, an incoming call is automatically redirected to the forwarded number the user has specified via the phone dialpad.

To enable the service the user has to dial the feature access code followed by the digits that represent the forwarded number. The selection of the forwarded number terminates when the user dials the suffix code.

The suffix code is configured by entering the following command:

```
awplus(config-voipapp-fac)# suffix <code>
```

In order to get the supplementary service properly configured, it's also necessary to specify the cancel prefix by entering the following command:

```
awplus(config-voipapp-fac)# call forward all cancel <code>
```

**Feature** Voice Commands

**Mode** Voice Feature Access Codes Configuration Mode

**Release** 4.1

**Options**

Option	Description	Range	Default Value
<digits>	Digits used to access call forward all feature. Can be up to 5 digits and can accept [0-9], *, and #.	NA	NA

**Note** Call forward all call service must be also enabled on the selected POTS interface to make it available to the user.

**Example** Refer to the following commands. Note that if the Prefix is not set, use \*55. Refer to [prefix \(config-voipapp-fac\)](#).

```
awplus#(config)# voipapp feature access-code
awplus(config-voipapp-fac)# call forward all *55
awplus(config-voipapp-fac)# call forward all cancel *65
awplus(config-voipapp-fac)# suffix #
awplus#(config)# voipapp supplementary-services
awplus(config-voipapp-suppl-serv)# port tell
awplus(config-voipapp-suppl-serv-port)# call forward all
```

**CALL FORWARD ALL CANCEL (CONFIG-VOIPAPP-FAC)**

**Syntax** `call forward all cancel <digits>`

**Description** This command defines the feature access combination keys to disable call forward all. This command defines the digits that the end user must dial to de-activate call forward all.

**Feature** Voice Commands

**Mode** Voice Feature Access Codes Configuration Mode

**Release** 4.1

**Options**

Option	Description	Range	Default Value
<digits>	Digits used to disable call forward all feature. Can be up to 5 digits and can accept [0-9], *, and #.	NA	NA

**Note** NA

**Example** Refer to the following commands:

```
awplus#(config)# voipapp feature access-code
awplus(config-voipapp-fac)# call forward all *55
awplus(config-voipapp-fac)# call forward all cancel *65
awplus(config-voipapp-fac)# suffix #
```

## CALL FORWARD BUSY (CONFIG-VOIPAPP-FAC)

**Syntax** `call forward busy <digits>`

**Description** This command defines the prefix used to enable the call forwarding on busy calls supplementary service. When enabled, an incoming call to a busy user is automatically redirected to the forwarded number the user has specified via the phone dialpad.

To enable the service the user has to dial the feature access code followed by the digits that represent the forwarded number. The selection of the forwarded number terminates when the user dials the suffix code.

The suffix code is configured by entering the following command:

```
awplus(config-voipapp-fac)# suffix <code>
```

In order to get the supplementary service properly configured, it's also necessary to specify the cancel prefix by entering the following command:

```
awplus(config-voipapp-fac)# call forward busy cancel <code>
```

Note that Call forward on-busy service must be also enabled on the selected POTS interface to make it available to the user.

**Feature** Voice Commands

**Mode** Voice Feature Access Codes Configuration Mode

**Release** 4.1

**Options**

Option	Description	Range	Default Value
<digits>	Digits used to access call forward all feature. Can be up to 5 digits and can accept [0-9], *, and #.	NA	NA

**Note** NA

**Example** Refer to the following commands:

```
awplus#(config)# voipapp feature access-code
awplus(config-voipapp-fac)# call forward busy *90
awplus(config-voipapp-fac)# call forward busy cancel *91
awplus(config-voipapp-fac)# suffix #
awplus(config)# voipapp supplementary-services
awplus(config-voipapp-suppl-serv)# port tell
awplus(config-voipapp-suppl-serv)# call forward busy
```

**CALL FORWARD BUSY CANCEL (CONFIG-VOIPAPP-FAC)**

**Syntax** `call forward busy cancel <digits>`

**Description** This command defines the feature access combination keys to disable call forward on busy. This command defines the digits that the end user must dial to de-activate call forward on busy.

**Feature** Voice Commands

**Mode** Voice Feature Access Codes Configuration Mode

**Release** 4.1

**Options**

Option	Description	Range	Default Value
<digits>	Digits used to disable call forward all feature. Can be up to 5 digits and can accept [0-9], *, and #.	NA	NA

**Note** NA

**Example** Refer to the following commands:

```
awplus#(config)# voipapp feature access-code
awplus(config-voipapp-fac)# call forward busy *90
awplus(config-voipapp-fac)# call forward busy cancel *91
awplus(config-voipapp-fac)# suffix #
```

## CALL FORWARD NO-ANSWER (CONFIG-VOIPAPP-FAC)

**Syntax** `call forward no-answer <digits>`

**Description** This command defines the prefix used to enable the call forwarding on no answer supplementary service. When enabled, an incoming call that is not answered within 3 rings, is automatically redirected to the forwarded number the user has specified via the phone dialpad.

To enable the service the user has to dial the feature access code followed by the digits that represent the forwarded number. The selection of the forwarded number terminates when the user dials the suffix code.

The suffix code is configured by entering the following command:

```
awplus(config-voipapp-fac)# suffix <code>
```

In order to get the supplementary service properly configured, it's also necessary to specify the cancel prefix by entering the following command:

```
awplus(config-voipapp-fac)# call forward no-answer cancel <code>
```

Note that Call forward on-no-answer service must be also enabled on the selected POTS interface to make it available to the user.

**Feature** Voice Commands

**Mode** Voice Feature Access Codes Configuration Mode

**Release** 4.1

**Options**

Option	Description	Range	Default Value
<digits>	Digits used to access call forward all feature. Can be up to 5 digits and can accept [0-9], *, and #.	NA	NA

**Note** NA

**Example** Refer to the following commands. Note that if the Prefix is not set, use \*55. Refer to [prefix \(config-voipapp-fac\)](#).

```
awplus#(config)# voipapp feature access-code
awplus(config-voipapp-fac)# call forward no-answer *55
awplus(config-voipapp-fac)# call forward no-answer cancel *56
awplus(config-voipapp-fac)# suffix #
awplus(config)# voipapp supplementary-services
awplus(config-voipapp-suppl-serv)# port tell
awplus(config-voipapp-suppl-serv-port)# call forward no-answer
```



**CALL FORWARD NO-ANSWER CANCEL (CONFIG-VOIPAPP-FAC)**

**Syntax** `call forward no-answer cancel <digits>`

**Description** This command defines the feature access combination keys to disable call forward on no-answer. This command defines the digits that the end user must dial to de-activate call forward on no-answer.

**Feature** Voice Commands

**Mode** Voice Feature Access Codes Configuration Mode

**Release** 4.1

**Options**

Option	Description	Range	Default Value
<digits>	Digits used to disable call forward all feature. Can be up to 5 digits and can accept [0-9], *, and #.	NA	NA

**Note** NA

**Example** Refer to the following commands:

```
awplus#(config)# voipapp feature access-code
awplus(config-voipapp-fac)# call forward no-answer *55
awplus(config-voipapp-fac)# call forward no-answer cancel *56
awplus(config-voipapp-fac)# suffix #
```

**CALL-WAITING (CONFIG-VOIPAPP-FAC)**

**Syntax** `call-waiting <digits>`

**Description** This command enables/disables the call waiting supplementary service. When enabled, a user already busy in a call is notified of a new incoming call via a special waiting tone and then the user can put the current call on hold using the flash-hook button and answer the new call. Then the user can switch between each call simply pressing the flash-hook button.

In order to get the supplementary service properly configured, it's also necessary to specify the cancel prefix by entering the following command:

```
awplus(config-voipapp-fac)# call-waiting cancel <code>
```

Note that Call waiting service must be also enabled on the selected POTS interface to make it available to the user.

**Feature** Voice Commands

**Mode** Voice Feature Access Codes Configuration Mode

**Release** 4.1

**Options**

Option	Description	Range	Default Value
<digits>	Digits used to activate the call waiting feature. Can be up to 5 digits.	NA	NA

**Note** NA

**Example** Refer to the following commands:

```
awplus#(config)# voipapp feature access-code
awplus(config-voipapp-fac)# call-waiting *68
awplus(config-voipapp-fac)# call-waiting cancel *69
awplus(config-voipapp-fac)# suffix #
awplus(config)# voipapp supplementary-services
awplus(config-voipapp-suppl-serv)# port tell
awplus(config-voipapp-suppl-serv-port)# call waiting
```

**CALL-WAITING CANCEL (CONFIG-VOIPAPP-FAC)**

**Syntax** `call-waiting cancel <digits>`

**Description** This command defines the feature access combination keys to disable call waiting. This command defines the digits that the end user must dial to de-activate call waiting.

**Feature** Voice Commands

**Mode** Voice Feature Access Codes Configuration Mode

**Release** 4.1

**Options**

Option	Description	Range	Default Value
<digits>	Digits used to disable call waiting feature. Can be up to 5 digits and can accept [0-9], *, and #.	NA	NA

**Note** NA

**Example** Refer to the following commands:

```
awplus#(config)# voipapp feature access-code
awplus(config-voipapp-fac)# call-waiting *68
awplus(config-voipapp-fac)# call-waiting cancel *69
awplus(config-voipapp-fac)# suffix #
```

**CALLER-ID BLOCK OVERRIDE OFF (CONFIG-VOIPAPP-FAC)**

**Syntax** `caller-id block override off <digits>`

**Description** This command defines the feature access combination keys to override caller-id block configuration and force caller id to be suppressed.

**Feature** Voice Commands

**Mode** Voice Feature Access Codes Configuration Mode

**Release** 4.1

**Options**

Option	Description	Range	Default Value
<digits>	Digits used to ensure that caller id info is displayable at the far end. Can be up to 3 digits and can accept [0-9], *, and #.	NA	NA

**Note** CLIR\_DEACTIVATE max 3 digits (chosen from [0-9], \*, and #).

**Example** Refer to the following commands:

```
awplus#(config)# voipapp feature access-code
awplus(config-voipapp-fac)# caller-id block override off *166
awplus(config-voipapp-fac)# suffix #
awplus(config)# voice-port tell
awplus(config-voiceport)# caller-id block default disable
```

**CALLER-ID BLOCK OVERRIDE ON (CONFIG-VOIPAPP-FAC)**

**Syntax** caller-id block override on <digits>

**Description** This command defines the feature access combination keys to override caller-id block configuration and force caller id to be displayed.

**Feature** Voice Commands

**Mode** Voice Feature Access Codes Configuration Mode

**Release** 4.1

**Options**

Option	Description	Range	Default Value
<digits>	Digits used to ensure that caller id info is displayable at the far end. Can be up to 3 digits and can accept [0-9], *, and #.	NA	NA

**Note** CLIR\_ACTIVATE max 3 digits (chosen from [0-9], \*, and #).

**Example** Refer to the following commands:

```
awplus#(config)# voipapp feature access-code
awplus(config-voipapp-fac)# caller-id block override on *167
awplus(config-voipapp-fac)# suffix #
awplus(config)# voice-port tell
awplus(config-voiceport)# caller-id block default enable
```

**CONFERENCE (CONFIG-VOIPAPP-FAC)**

**Syntax**            conference <digits>  
                     [no] conference

**Description**      This command defines the digits required to activate the conference feature

This command sets the digits used to activate the conference feature. The caller 'A' is in conversation with 'B'. 'A' sends a flash to 'B' and then calls 'C' (using the conference feature code defined here and the number). 'A' and 'C' are now in direct conversation. 'A' now flashes, and all three parties are in conversation. When 'A' goes on-hook, all parties are released.

Use the no form of this command to reset the value to it's default - none.

**Feature**            Voice Commands

**Mode**              Voice Feature Access Codes Configuration Mode

**Release**            4.1.2

**Options**

Option	Description	Range	Default Value
<digits>	Digits used to activate the conference feature, but only on the endpoint where it is configured. For release 4.1, any prefix must be a single character, either '*' or '#'. Refer to <a href="#">prefix (config-voipapp-fac)</a> on conditions for using a Prefix.	Up to 6 digits	none

**Note**                NA

**Source**            iMG

**Example**           Refer to the following commands:

```
awplus#(config)# voipapp feature access-code  
awplus(config-voipapp-fac)# conference 757
```

**PER-CALL CALL-WAITING (CONFIG-VOIPAPP-FAC)**

**Syntax** `per-call call-waiting <digits>`

**Description** This command defines the digits required to activate the call waiting feature on a per-call basis. The subscriber enters the prefix code (usually \*) the activate feature digits (such as 71), the specific call digits for the call, and then the suffix (usually #).

**Feature** Voice Commands

**Mode** Voice Feature Access Codes Configuration Mode

**Release** 4.1

**Options**

Option	Description	Range	Default Value
<digits>	Digits used to activate the call waiting feature on a per-call basis. Can be up to 3 digits.	NA	NA

**Note** NA

**Example** Refer to the following commands:

```
awplus#(config)# voipapp feature access-code
awplus(config-voipapp-fac)# per-call call-waiting 71
```

**PER-CALL CALL-WAITING CANCEL (CONFIG-VOIPAPP-FAC)**

**Syntax** `per-call call-waiting cancel <digits>`

**Description** This command defines the digits required to de-activate the call waiting feature on a per-call basis. The subscriber enters the prefix code (usually \*) the de-activate feature digits (such as 70), the specific call digits for the call, and then the suffix (usually #).

**Feature** Voice Commands

**Mode** Voice Feature Access Codes Configuration Mode

**Release** 4.1

**Options**

Option	Description	Range	Default Value
<digits>	Digits used to de- activate the call waiting feature on a per-call basis. Can be up to 3 digits.	NA	NA

**Note** NA

**Example** Refer to the following commands:

```
awplus#(config)# voipapp feature access-code
awplus(config-voipapp-fac)# per-call call-waiting 70
```



**PREFIX (CONFIG-VOIPAPP-FAC)**

**Syntax**            prefix <prefix-character>  
                      [no] prefix

**Description**       Specifies the character that is used to identify that the following digits are a control (activation) code.  
  
If you enter the command `no prefix`, it will remove the \* as part of the activation code or be set to “not configured” if no activation code has been entered.

Be aware that setting Prefix will insert (prepend) the prefix value to **all** activation codes (except ‘suffix’). Once the prefix is set, all activation codes will start with \*. Moreover, the system will process any activated call feature starting with the \*, even if they do not have an activation code and so are only partially configured. This can lead to unexpected results.

Because of this, if you set Prefix, ensure all activation codes that will be used are completely configured with the digits needed (i.e. \*70 instead of \*). Refer to the Example below, where per-call access code is \*70. If call waiting is also enabled, when the subscriber enters \*70 followed by specific number, it will be processed as a call waiting feature immediately after the \*. Therefore, when setting a Prefix, ensure that all features that are enabled have explicit activation codes.

**Feature**            Voice Commands

**Mode**              Voice Feature Access Codes Configuration Mode

**Release**           4.1

**Options**

Option	Description	Range	Default Value
<prefix-string>	A single character - '*' or '#' that precedes the control digits.	NA	NA

**Note**                For release 4.1, the prefix must be a single character, either '\*' or '#'.

**Example**            Refer to the following commands:

```
awplus#(config)# voipapp feature access-code
awplus(config-voipapp-fac)# prefix *
awplus(config-voipapp-fac)# per-call call-waiting 71
awplus(config-voipapp-fac)# per-call call-waiting cancel 70
awplus(config-voipapp-fac)# suffix #
awplus(config-voipapp-fac)# do show voip
(Note * is set for all other features. If call waiting, for example, is enabled, it
must have an activation code added as well.)
```

-----  
Voice Application Feature Codes Configuration  
-----

```
Suffix is : #
Prefix is : *
Call Forward All Register is : *
Call Forward All Deactivate is : *
Call Forward Busy Register is : *
Call Forward Busy Deactivate is : *
Call Forward No-Answer Register is : *
Call Forward No-Answer Deactivate is : *
Calling Line ID Restriction Activate is : *
Calling Line ID Restriction Deactivate is : *
```

```
Call Waiting Activate is      : *
Call Waiting Deactivate is   : *
Per-call Call Waiting Activate is : *71
Per-call Call Waiting Deactivate is : *70
```

**SHOW VOIPAPP**

**Syntax**            show voipapp [feature codes]

<b>Description</b>	This command displays the codes being used for voice features. The parameter <code>feature codes</code> does not change the output.
--------------------	---

<i>Feature</i>	Voice Commands
----------------	----------------

<i>Mode</i>	Privileged Exec Mode
-------------	----------------------

Release 4.1

<i>Options</i>	NA
----------------	----

<i>Note</i>	NA
-------------	----

**Example** Use the following command:

```
awplus# show voipapp
```

Voice Application Feature Codes Configuration	
Suffix is	: #
Prefix	: not configured
Call Forward All Register is	: *72
Call Forward All Deactivate is	: *73
Call Forward Busy Register is	: *222
Call Forward Busy Deactivate is	: *223
Call Forward No-Answer Register is	: *333
Call Forward No-Answer Deactivate is	: *334
Calling Line ID Restriction Activate	: not configured
Calling Line ID Restriction Deactivate	: not configured
Call Waiting Activate	: not configured
Call Waiting Deactivate	: not configured
Per-call Call Waiting Activate	: not configured
Per-call Call Waiting Deactivate	: not configured

**SUFFIX (CONFIG-VOIPAPP-FAC)**

**Syntax**            `suffix <suffix-string>`  
                     `[no] suffix`

**Description**      This command indicates end of programmed number when configuring via dial pad  
                     Use the no form of this command to reset the value to it's default - none.

**Feature**            Voice Commands

**Mode**              Voice Feature Access Codes Configuration Mode

**Release**            4.1

**Options**

Option	Description	Range	Default Value
<suffix-string>	string - starting with the '*' or '#' that follows the programmed forwarding to number.	NA	NA

**Note**                For release 4.1, the prefix must be a single character, either '\*' or '#'.

**Example**            To activate, use the following commands:

```
awplus#(config)# voipapp feature access-code  
awplus(config-voipapp-fac)# suffix #
```

**TRANSFER BLIND (CONFIG-VOIPAPP-FAC)**

**Syntax**           transfer blind <digits>  
                  [no] transfer blind

**Description**       This command defines the digits required to activate the transfer blind feature

Identifies the feature access code dialed - along with the prefix that activates the blind transfer service. You will need to activate the feature on a specific port. Refer to [transfer-mode \(config-voipapp-supply-serv-port\)](#)

This command sets the prefix used to activate the blind call transfer feature. The caller 'A' is in conversation with 'B', 'B' then sends a flash to 'A' and then sends a blind transfer call to 'C' (using the feature code defined here and the 'C' number). When 'C' answers it will be in conversation with 'A'.

Use the no form of this command to remove the feature access code from the feature.

**Feature**           Voice Commands

**Mode**             Voice Feature Access Codes Configuration Mode

**Release**          4.1.2

**Options**

Option	Description	Range	Default Value
<digits>	Digits used to activate the blind transfer feature, but only on the endpoint where it is configured. For release 4.1, any prefix must be a single character, either '*' or '#'. Refer to <a href="#">prefix (config-voipapp-fac)</a> on conditions for using a Prefix.	Up to 6 digits	NA

**Note**             NA

**Example**          Use the following commands:

```
awplus#(config)# voipapp feature access-code
awplus(config-voipapp-fac)# transfer blind 545
```

## TRANSFER CONSULT (CONFIG-VOIPAPP-FAC)

**Syntax**           transfer consult <digits>  
                  [no] transfer consult

**Description**       This command defines the digits required to activate the transfer consult feature.

Identifies the feature access code dialed - along with the prefix that activates the consult transfer service. You will need to activate the feature on a specific port. Refer to [transfer-mode \(config-voipapp-suppl-serv-port\)](#).

This command sets the prefix used to activate the transfer consult feature. The caller 'A' is in conversation with 'B'. 'B' sends a flash to 'A' and then calls 'C' (using the transfer feature code defined here and the 'C' number). 'B' and 'C' are now in direct conversation. When 'B' goes on-hook, 'A' will be in conversation with 'C'.

Use the no form of this command to remove the feature access code from the feature.

**Feature**           Voice Commands

**Mode**             Voice Feature Access Codes Configuration Mode

**Release**          4.1.2

**Options**

Option	Description	Range	Default Value
<digits>	Digits used to activate the blind transfer feature, but only on the endpoint where it is configured. For release 4.1, any prefix must be a single character, either '*' or '#'. Refer to <a href="#">prefix (config-voipapp-fac)</a> on conditions for using a Prefix.	Up to 6 digits	None

**Note**             NA

**Example**         Use the following commands:

```
awplus#(config)# voipapp feature access-code
awplus(config-voipapp-fac)# transfer consult 454
```

**WARMLINE (CONFIG-VOIPAPP-FAC)**

**Syntax**

```
warmline <activation-digits>
warmline reactivate <re-activation-digits>
[no] warmline
```

**Description**

This command defines digits used to activate the warmline feature.

Identifies the feature access code dialed - along with the prefix that activates the warmline feature on that line.

Use the no form of this command to reset the value to its default - none.

**Feature** Voice Commands

**Mode** Voice Feature Access Codes Configuration Mode

**Release** 4.1

**Options**

Option	Description	Range	Default Value
<activation digits>	Digits used to enable the warmline feature. Can be up to 6 digits.	NA	NA
<reactivation digits>	Digits used to re-activate the warmline feature. Can be up to 6 digits.	NA	NA

**Note** For release 4.1, the prefix must be a single character, either '\*' or '#'. Also, refer to [prefix \(config-voipapp-fac\)](#) on conditions for using a Prefix.

**Example** To activate, use the following commands:

```
awplus#(config)# voipapp feature access-code
awplus(config-voipapp-fac)# warmline 44
```

**WARMLINE CANCEL (CONFIG-VOIPAPP-FAC)**

**Syntax**           warmline cancel <de-activation digits>  
                  [no] warmline cancel

**Description**       This command defines access code to disable the warmline feature.  
  
                  Identifies the feature access code dialed - along with the prefix that disables warmline on that line.  
  
                  Use the no form of this command to reset the value to it's default - none.

**Feature**           Voice Commands

**Mode**             Voice Feature Access Codes Configuration Mode

**Release**           4.1

**Options**

Option	Description	Range	Default Value
<de-activation digits>	Digits used to disable the warmline feature. Can be up to 6 digits.	NA	NA

**Note**             For release 4.1, the prefix must be a single character, either '\*' or '#'. Also, refer to [prefix \(config-voipapp-fac\)](#) on conditions for using a Prefix.

**Example**           To activate, use the following commands:

```
awplus#(config)# voipapp feature access-code
awplus(config-voipapp-fac)# warmline cancel 56
```



### 8.4.2 Supplementary Service Command list (voipapp-suppl-serv-port)

This chapter provides an alphabetical reference for commands used to configure supplementary services on a port basis.

For information about modifying or redirecting the output from show commands to a file, see “Controlling “show” Command Output.

Table 8-12: Access Codes (Supplementary Service) -voipapp-suppl-serv-port Commands

Commands
<a href="#">call forward all (config-voipapp-suppl-serv-port)</a>
<a href="#">call forward busy (config-voipapp-suppl-serv-port)</a>
<a href="#">call forward noan (config-voipapp-suppl-serv-port)</a>
<a href="#">conference (config-voipapp-suppl-serv-port)</a>
<a href="#">hold-resume (config-voipapp-suppl-serv-port)</a>
<a href="#">transfer-mode (config-voipapp-suppl-serv-port)</a>
<a href="#">warmline (config-voipapp-suppl-serv-port)</a>
<a href="#">warmline digits (config-voipapp-suppl-serv-port)</a>
<a href="#">warmline timeout (config-voipapp-suppl-serv-port)</a>

**CALL FORWARD ALL (CONFIG-VOIPAPP-SUPPL-SERV-PORT)**

**Syntax**            `call forward all`  
                     `[no] call forward all`

**Description**       This command enables the support for call forward all feature codes on this POTS interface.

To define the call forward all access codes use the following command:

```
awplus(config-voipapp-fac)# call forward all <code>
```

Use the no form of this command to disable the support of call forward all feature codes on this POTS interface.

**Feature**            Voice Commands

**Mode**               Voice Supplementary service Configuration Mode

**Release**            4.1

**Options**            NA

**Note**               NA

**Example**            Refer to the following commands:

```
awplus#(config)# voipapp supplementary-services
awplus(config-voipapp-suppl-serv)# port tell
awplus(config-voipapp-suppl-serv-port)# call forward all
awplus(config)# voipapp feature access-code
awplus(config-voipapp-fac)# call forward all *55
awplus(config-voipapp-fac)# call forward all cancel *65
awplus(config-voipapp-fac)# suffix #
```

**CALL FORWARD BUSY (CONFIG-VOIPAPP-SUPPL-SERV-PORT)**

**Syntax**            `call forward busy`  
                     `[no] call forward busy`

**Description**        This command enable the support for call forward busy feature codes on this POTS interface. To define the call forward busy access codes use the following command:

`awplus(config-voipapp-fac)# call forward busy <code>`

Use the no form of this command to disable the support of call forward busy feature codes on this POTS interface.

**Feature**            Voice Commands

**Mode**              Voice Supplementary service Configuration Mode

**Release**           4.1

**Options**           NA

**Note**              NA

**Example**           Refer to the following commands:

```
awplus#(config)# voipapp supplementary-services
awplus(config-voipapp-suppl-serv)# port tell
awplus(config-voipapp-suppl-serv-port)# call forward busy
awplus(config)# voipapp feature access-code
awplus(config-voipapp-fac)# call forward busy *90
awplus(config-voipapp-fac)# call forward busy cancel *91
awplus(config-voipapp-fac)# suffix #
```

**CALL FORWARD NOAN (CONFIG-VOIPAPP-SUPPL-SERV-PORT)**

**Syntax**            `call forward noan [ring-count] [number]`  
                     `[no] call forward noan [ring-count]`

**Description**        This command enables the support for call forward no-answer feature codes on this POTS interface. To define the call forward no-answer access codes use the following command:

```
awplus(config-voipapp-fac)# call forward no-answer <code>
```

Use the no form of this command to disable the support of call forward no-answer feature codes on this POTS interface.

**Feature**            Voice Commands

**Mode**              Voice Supplementary service Configuration Mode

**Release**           4.1.2

**Options**

Option	Description	Range	Default Value
ring-count	The number of rings that occur before no-answer for call-forwarding-no-answer is declared. Otherwise the default number is used.	NA	3

**Note**

**Note**              NA

**Example**           Refer to the following commands:

```
awplus#(config)# voipapp supplementary-services
awplus(config-voipapp-suppl-serv)# port tell
awplus(config-voipapp-suppl-serv-port)# call forward noan ring-count 2
awplus(config)# voipapp feature access-code
awplus(config-voipapp-fac)# call forward no-answer *55
awplus(config-voipapp-fac)# call forward no-answer cancel *56
awplus(config-voipapp-fac)# suffix #
```

**CONFERENCE (CONFIG-VOIPAPP-SUPPL-SERV-PORT)**

<b>Syntax</b>	conference [no] conference
<b>Description</b>	<p>This command enables the support for conference features. To input the activation digits, refer to <a href="#">conference (config-voipapp-fac)</a>.</p> <p>Use the no form of this command to disable the support of conferencing.</p>
<b>Feature</b>	Voice Commands
<b>Mode</b>	Voice Supplementary service Configuration Mode
<b>Release</b>	4.1.2
<b>Options</b>	NA
<b>Note</b>	NA
<b>Example</b>	<p>Refer to the following commands:</p> <pre>awplus#(config)# voipapp supplementary-services awplus(config-voipapp-suppl-serv)# port tell awplus(config-voipapp-suppl-serv-port)# conference</pre>

**HOLD-RESUME (CONFIG-VOIPAPP-SUPPL-SERV-PORT)**

**Syntax**            `hold-resume`  
                  `[no] hold-resume`

Enables or disables the hold service on the voice-port.

Use the no form of this command to disable it.

**Feature**            Voice Commands

**Mode**              Voice Supplementary service Configuration Mode

**Release**           4.1

**Options**           NA

**Note**              NA

**Example**           Refer to the following commands:

```
awplus#(config)# voipapp supplementary-services
awplus(config-voipapp-suppl-serv)# port tel2
awplus(config-voipapp-suppl-serv-port)# hold-resume
```

**TRANSFER-MODE (CONFIG-VOIPAPP-SUPPL-SERV-PORT)**

**Syntax**            transfer-mode {blind | consult}  
                      [no] transfer-mode

**Description**       This command enables the call transfer feature on this line. Includes the mode that the feature is to be used in. If desired, both modes can be input (with each using different activation codes, refer to [transfer blind \(config-voipapp-fac\)](#) and [transfer consult \(config-voipapp-fac\)](#)). Use the no form of this command to disable the call transfer feature.

**Feature**            Voice Commands

**Mode**                Voice Supplementary service Configuration Mode

**Release**            4.1.2

**Options**

Option	Description	Range	Default Value
blind	Call is transferred directly without contacting the other party	NA	NA
consult	Call is transferred after terminating a call to the second party.	NA	NA

**Note**                NA

**Source**            iMG

**Example**            Refer to the following commands:

```
awplus#(config)# voipapp supplementary-services
awplus(config-voipapp-suppl-serv)# port tell
awplus(config-voipapp-suppl-serv-port)# transfer-mode blind
```

**WARMLINE (CONFIG-VOIPAPP-SUPPL-SERV-PORT)**

**Syntax**           warmline  
                  [no] warmline

**Description**       This command enables the warmline feature on this line. Use the no form of this command to disable the warmline feature.

There are two methods to activate:

- Using the command "warmline digits <digits>" in this section; once entered, as soon the user pick-ups the phone, a call is made automatically to the forwarded number without requiring the user to dial the number on the phone keypad.
- Using the command "warmline <digits>" as part of configuring supplementary services. Refer to [warmline \(config-voipapp-fac\)](#). In this case the user dials the number on the keypad after activating the code for warmline.

The default amount of time for the line to be off-hook before the digits are dialed is set to 4 seconds, but can be changed with the [warmline timeout \(config-voipapp-suppl-serv-port\)](#) command.

**Feature**           Voice Commands

**Mode**             Voice Supplementary service Configuration Mode

**Release**          4.1

**Options**          NA

**Note**             NA

**Example**          Refer to the following commands:

```
awplus#(config)# voipapp supplementary-services
awplus(config-voipapp-suppl-serv)# port tell
awplus(config-voipapp-suppl-serv-port)# warmline
```



**WARMLINE DIGITS (CONFIG-VOIPAPP-SUPPL-SERV-PORT)**

**Syntax**           warmline digits <directory-number>  
                  [no] warmline digits

**Description**       This command configures the digits that are to be used to route the call when the timeout expires. Use the no form of this command to remove the digits.

**Feature**           Voice Commands

**Mode**             Voice Supplementary service Configuration Mode

**Release**           4.1

**Options**

Option	Description	Range	Default Value
<directory-number>	The digits that are to be used to route the call when the timeout expires. There is a maximum of 19 digits for <directory-number>.	NA	NA

**Note**             NA

**Example**          Refer to the following commands:

```
awplus#(config)# voipapp supplementary-services
awplus(config-voipapp-suppl-serv)# port tell
awplus(config-voipapp-suppl-serv-port)# warmline digits 9196455530
```

**WARMLINE TIMEOUT (CONFIG-VOIPAPP-SUPPL-SERV-PORT)**

**Syntax**           warmline timeout <seconds>  
                  [no] warmline timeout

**Description**       This command configure the interval in seconds between when the off-hook is detected - and, if no digits are detected, the call is originated. 0 is the equivalent of hotline. Use the no form of this command for set default timeout to 4 seconds.

**Feature**           Voice Commands

**Mode**             Voice Supplementary service Configuration Mode

**Release**          4.1

**Options**

Option	Description	Range	Default Value
<seconds>	The interval in seconds between when the off-hook is detected and, if no digits are detected, the call is originated. 0 is the equivalent of hotline.	0-30	4 seconds

**Note**             NA

**Example**          Refer to the following commands:

```
awplus#(config)# voipapp supplementary-services
awplus(config-voipapp-suppl-serv)# port tell
awplus(config-voipapp-suppl-serv-port)# warmline timeout 15
```

### 8.4.3 Endpoint Command List (config-voice-port)

This provides an alphabetical reference for commands used to configure Endpoints.

For information about modifying or redirecting the output from show commands to a file, see Controlling “show” Command Output.

Table 8-13: Configure Endpoint Data Commands (config-voice-port)

call-waiting (config-voice-port)
caller-id alerting (config-voice-port)
caller-id block (config-voice-port)
caller-id (config-voice-port)
caller-id mode (config-voice-port)
caller-id signal (config-voice-port)
caller-id standard (config-voice-port)
dial-type (config-voice-port)
disconnect-supervision osi
echo-cancel (config-voice-port)
mwi (config-voice-port)
input gain (config-voice-port)
output attenuation (config-voice-port)
playout-delay (config-voice-port)
playout-delay mode (config-voice-port)
show voice port
shutdown
timing hookflash-input
timing offhook-input
timing onhook-input
timeouts initial
timeouts interdigit
timeouts ringing
vad (config-voice-port)

**CALL-WAITING (CONFIG-VOICE-PORT)**

<b>Syntax</b>	call-waiting [no] call-waiting
<b>Description</b>	This command controls the call waiting feature on the line.  Enables the call waiting feature on the line. Use the no form of this command to disable the feature - returning it to the default state.
<b>Feature</b>	Voice Commands
<b>Mode</b>	Voice Port Configuration Mode
<b>Release</b>	4.1
<b>Options</b>	NA
<b>Note</b>	NA
<b>Example</b>	Refer to the following commands:  awplus#(config)# voice-port tell awplus(config-voice-port)# call waiting

**CALLER-ID ALERTING (CONFIG-VOICE-PORT)**

**Syntax**            caller-id alerting {during-ring|before-ring}  
                      [no] caller-id alerting

**Description**      Controls when the Caller-id data is transmitted - relative to the first ring when terminating a line.  
                      Use the no form of this command to reset to default (during-ring).

**Feature**            Voice Commands

**Mode**                Voice Port Configuration Mode

**Release**            4.1

**Options**

Option	Description	Range	Default Value
during-ring	Caller-id is transmitted while the first ring is being played	NA	NA
before-ring	Caller-id is transmitted before the first ring is played.	NA	NA

**Note**                This is applicable to ETSI Caller ID Standard only.

**Example**            Refer to the following commands:

```
awplus#(config)# voice-port tel1
awplus(config-voice-port)# caller-id alerting before-ring
```

**CALLER-ID BLOCK (CONFIG-VOICE-PORT)**

**Syntax**            caller-id block [default {enable | disable}]  
                      [no] caller-id block

**Description**      This command disables display of Caller Id information on calls originated from this line

                      This command enables the restriction of the display of Caller-id information on calls originating on this line. The default is disabled. Use the no form of this command to return it to the default state - and the default parameter to specify a different default.

**Feature**            Voice Commands

**Mode**                Voice Port Configuration Mode

**Release**            4.1

**Options**

Option	Description	Range	Default Value
default	Provides the ability to specify the default state of this feature on this line. This is useful for lines that can be controlled by the end user via star-code entries.	NA	disable

**Note**                NA

**Example**            Refer to the following commands:

```
awplus#(config)# voice-port tell
awplus(config-voice-port)# caller-id block default enable
```

**CALLER-ID (CONFIG-VOICE-PORT)**

**Syntax**            caller-id [type {1 | 2}]  
                      [no] caller-id [type {1 | 2}]

**Description**      This command enables Caller ID - and specifies type

Enables or disables Caller ID on a particular voice port. Also provides ability to specify the type of Caller-Id supported. When no type is specified, both types are enabled.

Use the no form of the command to disable both types - or a specific type.

**Feature**            Voice Commands

**Mode**                Voice Port Configuration Mode

**Release**            4.1

**Options**

Option	Description	Range	Default Value
type	Type 1 is when the phone is on-hook. Type 2 is while a call is up (i.e. callwait caller-id).	NA	NA

**Note**                NA

**Example**            Refer to the following commands:

```
awplus#(config)# voice-port tel1
awplus(config-voice-port)# caller-id enable
```

**CALLER-ID MODE (CONFIG-VOICE-PORT)**

**Syntax** `caller-id mode {DTMF | FSK}`

**Description** Allows the user to specify the way the Caller-id information is transmitted.

**Feature** Voice Commands

**Mode** Voice Port Configuration Mode

**Release** 4.1

**Options**

Option	Description	Range	Default Value
mode	DTMF - a series of Dual Tone Multi-frequency digits. FSK - frequency shift keyed transmission of the information	NA	FSK

**Note** This only applies to the ETSI standard for caller-id.

**Example** Refer to the following commands:

```
awplus#(config)# voice-port tell
awplus(config-voice-port)# caller-id mode dtmf
```



**CALLER-ID SIGNAL (CONFIG-VOICE-PORT)**

**Syntax**            caller-id signal {DualTone | LineReversal | RingPulse | None}  
                      [no] caller-id signal

**Description**      This command specifies the signal type for the caller-id. The no version of this command sets it to the default (None)

**Feature**            Voice Commands

**Mode**                Voice Port Configuration Mode

**Release**            4.1

**Options**

Option	Description	Range	Default Value
signal	DualTone LineReversal RingPulse None	NA	None

**Note**                Caller ID signal applies only when the selected standard is ETSI and the selected mode is FSK

**Example**            Refer to the following commands:

```
awplus#(config)# voice-port tell
awplus(config-voice-port)# caller-id standard ETSI
awplus(config-voice-port)# caller-id mode FSK
awplus(config-voice-port)# caller-id signal RingPulse
```

**CALLER-ID STANDARD (CONFIG-VOICE-PORT)**

**Syntax** `caller-id standard {Bellcore | ETSI | NTT | TDK | None}`

**Description** This command sets the type of caller ID that is generated during an incoming call

The following Caller ID standards: Bellcore, NTT, and TDK override any setting on the attributes caller-id mode / caller-id alerting / caller-id signal.

**Feature** Voice Command

**Mode** Voice Port Configuration Mode

**Release** 4.1

**Options**

Option	Description	Range	Default Value
Bellcore	Generate a caller ID accordingly to Bellcore standard.	NA	NA
ETSI	Generate a caller ID accordingly to ETSI standard. The ETSI caller ID is FSK: the FSK signals can be sent before the first ring (prior-to-ring) or after the first ring (during-ringing).	NA	NA
NTT	Generate a caller ID accordingly to NTT standard.	NA	NA
TDK	Generate a caller ID accordingly to Denmark DTMF standard. This setting is equal to ETSI DTMF DURING-RINGING. The value is maintained for backward compatibility.	NA	NA
None	Do not generate any caller-id	None	None

**Note** For ETSI Caller-ID it's necessary to specify also the caller-id mode (typically FSK), the caller-id alerting (typically during-ring) and the caller-id signal (typically None).

**Example** Refer to the following commands:

```
awplus#(config)# voice-port tel2
awplus(config-voice-port)# caller-id standard ETSI
```

**DIAL-TYPE (CONFIG-VOICE-PORT)**

**Syntax**            dial-type {dtmf | pulse}  
                      [no] dial-type

**Description**      This command specifies the format in which digits can be detected and interpreted. Default is DTMF.  
                      Use the No form of this command to reset the default.

**Feature**            Voice Commands

**Mode**              Voice Port Configuration Mode

**Release**            4.1

**Options**

Option	Description	Range	Default Value
dtmf	Dual Tone Multi Frequency Digit collection supported	NA	NA
pulse	Pulse receipt of Digits is supported - i.e from a rotary phone	NA	NA

**Note**                NA

**Example**            Refer to the following commands:

```
awplus#(config)# voice-port tel1  
awplus(config-voice-port)# dial-type pulse
```

**DISCONNECT-SUPERVISION OSI**

<b>Syntax</b>	<code>disconnect-supervision osi</code> <code>[no] disconnect-supervision osi</code>
<b>Description</b>	This command configures the POTS line to support timed disconnect mode, i.e. it enables the support for loop current feed open (LCFO) mode. Use the no form of this command to reset the POTS line to the default operating mode, i.e. to immediate release.
<b>Feature</b>	Voice Commands
<b>Mode</b>	Voice Port Configuration Mode
<b>Release</b>	4.1.2
<b>Options</b>	NA
<b>Note</b>	NA
<b>Example</b>	Refer to the following commands:  <code>awplus#(config)# voice-port tell</code> <code>awplus(config-voice-port)# disconnect-supervision osi</code>

**ECHO-CANCEL (CONFIG-VOICE-PORT)**

**Syntax**            echo-cancel  
                      [no] echo-cancel

**Description**      This command configures the voice port to have the Echo Canceller enabled or disabled.

**Feature**            Voice Commands

**Mode**              Voice Port Configuration Mode

**Release**            4.1

**Options**            NA

**Note**               NA

**Example**            Refer to the following commands:

```
awplus#(config)# voice-port tell
awplus(config-voice-port)# no echo-cancel
```

**MWI (CONFIG-VOICE-PORT)**

<b>Syntax</b>	<code>mwi</code> <code>[no]mwi</code>
<b>Description</b>	This command enables or disables Visual Message Waiting Indicator transmission - on this port. Use the no form of this command to restore the default state (disabled).
<b>Feature</b>	Voice Commands
<b>Mode</b>	Voice Port Configuration Mode
<b>Release</b>	4.1
<b>Options</b>	NA
<b>Note</b>	NA
<b>Example</b>	Refer to the following commands:  <code>awplus#(config)# voice-port tel2</code> <code>awplus(config-voice-port)# mwi</code>

**INPUT GAIN (CONFIG-VOICE-PORT)**

**Syntax**            `input gain <decibels>`

**Description**      This command specifies the gain to be applied to the incoming signal. Use the no form of the command to reset to the default value.

**Feature**            Voice Commands

**Mode**              Voice Port Configuration Mode

**Release**            4.1

**Options**

Option	Description	Range	Default Value
<decibels>	Gain in Decibels to be applied to the incoming signal from the interface. A minus value attenuates the input signal. Any value over 0 adds the value in dB of amplification.	-27 to 16	0

**Note**                NA

**Example**            Refer to the following commands:

```
awplus#(config)# voice-port tell
awplus(config-voice-port)# input gain -3
```

**OUTPUT ATTENUATION (CONFIG-VOICE-PORT)**

**Syntax**            `output attenuation <decibels>`

**Description**      This command specifies the attenuation applied to an signal transmitted to the end user. Use the No form of the command to reset it to the default value.

**Feature**            Voice Commands

**Mode**              Voice Port Configuration Mode

**Release**           4.1

**Options**

Option	Description	Range	Default Value
<decibels>	Attenuation in Decibels for the signal on the transmit side of the interface.  A minus value adds the value in dB of gain to the transmitted signal. Any value over 0 adds the value in dB of attenuation to the transmitted signal.  Range is from -27 to 16. Default is -6	-27 to 16	-6

**Note**              NA

**Example**           Refer to the following commands:

```
awplus#(config)# voice-port tell
awplus(config-voice-port)# output attenuation -4
```



**PLAYOUT-DELAY (CONFIG-VOICE-PORT)**

**Syntax**            `playout-delay <mseconds>`  
                     `[no] playout-delay`

**Description**       This command specifies in milliseconds - the delay induced by the Jitter buffer - in order to improve voice quality. Use the no form of this command to reset it to the default.

**Feature**            Voice Commands

**Mode**              Voice Port Configuration Mode

**Release**            4.1

**Options**

Option	Description	Range	Default Value
<mseconds>	The delay induced in the audio stream due to the depth of the Jitter Buffer - Default is 60. Max is 200.	60-200	60

**Note**                NA

**Example**            Refer to the following commands:

```
awplus#(config)# voice-port tel1
awplus(config-voice-port)# playout-delay 100
```

**PLAYOUT-DELAY MODE (CONFIG-VOICE-PORT)**

**Syntax**            `playout-delay mode {adaptive | disabled | fixed}`  
                     `no playout-delay mode`

**Description**       This command specifies the mode for the Jitter Buffer. Use the no form of this command to reset to the default (fixed).

**Feature**            Voice Commands

**Mode**               Voice Port Configuration Mode

**Release**            4.1

**Options**

Option	Description	Range	Default Value
mode	Adaptive - The depth of the Jitter Buffer and thus the delay are adjusted during the call - based on the traffic characteristics. Disabled - There is no delay. Fixed - The delay is fixed - and does not change during a call.	NA	fixed

**Note**                NA

**Example**            Refer to the following commands:

```
awplus#(config)# voice-port tell
awplus(config-voice-port)# playout-delay mode adaptive
```

## SHOW VOICE PORT

**Syntax**            show voice port {tel1 | tel2}

**Description**      This command displays the configuration of the voice-port specified.

**Feature**            Voice Commands

**Mode**              Privileged Exec Mode

**Release**            4.1

### Options

Option	Description	Range	Default Value
<tel1/tel2>	The number of the voice port	NA	NA

**Note**                If any valid settings are made with a TR-69 client (refer to [2.1.3](#)), they are passed through to the show output.

**Example**            Following is an example output.

```
awplus# show voice port tel1
Type of VoicePort is FXS
Operation State is Disabled
Administrative State is Enabled
Call state is Idle
Country is US
Line input gain is -6 dB
Line output attenuation is 0 dB
Echo cancellation is Enabled
Playout delay mode is Fixed
Playout delay is 60 ms
Hook flash in timing is 950 ms
Off Hook Input 250 ms
On Hook Input 1000 ms
Off hook to first digit timeout range is 0-16000 ms
Interdigit timeout range is 0-4000 ms
Ringing interval is 180 seconds
Dial mode is DTMF
Caller ID type 1 (on-hook) is Enabled
Caller ID type 2 (call waiting) is Enabled
Caller ID signal is RingPulse
Caller ID standard is ETSI
Caller ID mechanism is FSK
Caller ID alerting time is During Ring
Caller ID Blocking is Disabled
Call Waiting is Enabled
    Call Waiting is Active
Call Forward Unconditional is Disabled
Call Forward Busy is Disabled
Call Forward No Answer is Disabled
    Number of rings before No-Answer is declared is 3
Warmline is Disabled
Call Forward External is Disabled
Supplementary Service Prefix is Disabled
Call Hold is Enabled
Visual Message Waiting Indicator transmission is Disabled
```

---

Priority	Codec name	Status	Vad Status	Packetization
<hr/>				
Low	G.711MuLaw	Enabled	Enabled	10,20,30
Low	G.711ALaw	Enabled	Enabled	10,20,30
Low	G.726	Disabled	Enabled	10,20,30
Low	G.729	Disabled	Enabled	10,20,30

## SHUTDOWN

<i><b>Syntax</b></i>	shutdown [no] shutdown
<i><b>Description</b></i>	Used to enable or disable the administrative state of a selected voice-port. Note that call features (such as call waiting) are not enabled until activated, using the <a href="#">call-waiting (config-voice-port)</a> command.
<i><b>Feature</b></i>	Voice Commands
<i><b>Mode</b></i>	Privileged Exec Mode
<i><b>Release</b></i>	4.1
<i><b>Options</b></i>	NA
<i><b>Note</b></i>	NA
<i><b>Example</b></i>	Refer to the following commands:  awplus#(config)# voice-port tell awplus(config-voice-port)# shutdown

**TIMING HOOKFLASH-INPUT**

**Syntax**            `timing hookflash-input <mseconds>`

**Description**      Allows the minimum time that an on-hook would be qualified as a hookflash.

**Feature**            Voice Commands

**Mode**              Privileged Exec Mode

**Release**            4.1

**Options**

Option	Description	Range	Default Value
<mseconds>	The minimum time in milliseconds that qualifies as a hookflash.	NA	100

**Note**                NA

**Example**            Refer to the following commands:

```
awplus#(config)# voice-port tel1
awplus(config-voice-port)# timing hookflash-input 650
```

**TIMING OFFHOOK-INPUT**

**Syntax**            `timing offhook-input <mseconds>`

**Description**       Defines the minimum amount of before an offhook is declared.

**Feature**            Voice Commands

**Mode**               Privileged Exec Mode

**Release**            4.1

**Options**

Option	Description	Range	Default Value
<mseconds>	The time in milliseconds that qualifies as an offhook	NA	250

**Note**                NA

**Example**            Refer to the following commands:

```
awplus#(config)# voice-port tell
awplus(config-voice-port)# timing offhook-input 650
```

**TIMING ONHOOK-INPUT**

**Syntax**            `timing offhook-input <mseconds>`

**Description**       Defines the minimum amount of before an onhook is declared.

**Feature**            Voice Commands

**Mode**               Privileged Exec Mode

**Release**            4.1

**Options**

Option	Description	Range	Default Value
<mseconds>	The time in milliseconds that qualifies as an onhook	NA	350

**Note**                NA

**Example**            Refer to the following commands:

```
awplus#(config)# voice-port tell
awplus(config-voice-port)# timing onhook-input 650
```



## TIMEOUTS INITIAL

**Syntax**            `timeouts initial <seconds>`  
                     `[no] timeouts initial`

**Description**       Specifies the maximum time between the user going off-hook and the user dialing the first digit. Use the no form of this command to reset the default value.

**Feature**            Voice Commands

**Mode**               Privileged Exec Mode

**Release**            4.1

### Options

Option	Description	Range	Default Value
<seconds>	The maximum time between going off-hook and receipt of the first digit.	0-60	16

**Note**                NA

**Example**            Refer to the following commands:

```
awplus#(config)# voice-port tel1
awplus(config-voice-port)# timeouts initial 0
```

## TIMEOUTS INTERDIGIT

**Syntax**            `timeouts interdigit <seconds>`  
                     `[no] interdigit ringing`

**Description**       Specifies the maximum time between receipt of one digit and the next. If this timer expires, then an attempt is made to route the call with the collected digits. Use the `no` form of this command to reset the value to the default.

**Feature**            Voice Commands

**Mode**              Privileged Exec Mode

**Release**           4.1

### Options

Option	Description	Range	Default Value
<seconds>	The maximum time between receipt of one digit and the next.	2-10 seconds	4

**Note**               NA

**Example**           Refer to the following commands:

```
awplus#(config)# voice-port tel1
awplus(config-voice-port)# timeouts interdigit 6
```

## TIMEOUTS RINGING

**Syntax**            `timeouts ringing <seconds>`  
                     `[no] timeouts ringing`

**Description**       Specify the amount of time in seconds - that a phone will ring - before the system ends the termination attempt. Use the no form of this command to reset this to the default.

**Feature**            Voice Commands

**Mode**              Privileged Exec Mode

**Release**           4.1

### Options

Option	Description	Range	Default Value
<seconds>	The number of seconds that a phone will ring.	NA	16

**Note**               NA

**Example**           Refer to the following commands:

```
awplus#(config)# voice-port tel1
awplus(config-voice-port)# timeouts ringing 100
```

**VAD (CONFIG-VOICE-PORT)**

<b>Syntax</b>	vad [no] vad
<b>Description</b>	Enable voice activity detection on a voice-port - or disable it. Default is disabled. Use the no form of this command to reset it to the default  Use the no form of this command to remove the set of provisioned codecs.
<b>Feature</b>	Voice Commands
<b>Mode</b>	Voice Port Configuration Mode
<b>Release</b>	4.1
<b>Options</b>	NA
<b>Note</b>	NA
<b>Example</b>	Refer to the following commands:  awplus#(config)# voice-port tell awplus(config-voice-port)# no vad

### 8.4.4 Configuring Codecs Command List

This provides an alphabetical reference for commands used to configure Endpoints.

Table 8-14: Configure Codecs Commands (config-voice-class)

Commands
<a href="#">codec preference (config-voice-class)</a>

**CODEC PREFERENCE (CONFIG-VOICE-CLASS)**

**Syntax** `codec preference <value> <codec> packetization period`  
`<10|20|30|10,20|10,30|20,30|10,20,30>`

**Description** This command specifies a codec that is part of this set of supported codecs

Specifies the codec that is supported - its preference level and the packetization period for the codec. Use the no form of this command to disable the codec.

**Feature** Voice Commands

**Mode** Voice Class Configuration Mode

**Release** 4.1

**Options**

Option	Description	Range	Default Value
<value>	A number used to indicate the priority that should be used when considering this codec vs. others.	1-14	Low
<codec>	The codec that is identified - Valid choices are: G711alaw, g711ulaw, g726r32, g729abr8	NA	NA
<ms>	The packetization period for the RTP traffic.	10, 20, 30	10, 20, 30

**Default** Priority Codec name Status Vad Status Packetization

Low	G.711MuLaw	Enabled	Enabled	10,20,30
Low	G.711ALaw	Enabled	Enabled	10,20,30
Low	G.726	Disabled	Enabled	10,20,30
Low	G.729	Disabled	Enabled	10,20,30

**Source** NA

**Example** Refer to the following commands:

```
awplus(config)# voice class codec tell
awplus(config-voice-class)# codec preference ?
  <INT:value> Valid values <1-14> (1 is high)
awplus(config-voice-class)# codec preference 1 ?
  <STRING:codec> <g711alaw|g711ulaw|g726r32|g729abr8>
awplus(config-voice-class)# codec preference 1 g711ulaw packetization period ?
  <STRING:ms> <10|20|30|10,20|10,30|20,30|10,20,30>
```

### 8.4.5 Voice Diagnostic Command List

This provides an alphabetical reference for commands used to configure Endpoints.

For information about modifying or redirecting the output from show commands to a file, see Controlling “show” Command Output.

Table 8-15: Configure Codecs Commands (config-voice-class)

Commands
<a href="#">test voice port</a>
<a href="#">show test voice port</a>

## TEST VOICE PORT

**Syntax**      `test voice-port <voice-port>`

This command starts GR.909 metallic line testing over the selected POTS interface. When the command is executed any active call on the selected POTS interface is dropped. The command takes some seconds to be completed.

**Feature**      Voice Diagnostic Commands

**Mode**        Privileged Exec Mode

**Release**     4.3

**Options**

Option	Description	Range	Default Value
voice-port	One of the possible POTS names: tel1 or tel2.	tel1, tel2	NA

**Note**        Attempting to enter multiple time the same command before the execution of the previous test is terminated results in a CLI error message.

**Example**

```
awplus# test voice-port tel1
```



**SHOW TEST VOICE PORT**

**Syntax**      test voice-port <voice-port>

This command returns the result of the GR.909 metallic line testing for the selected POTS interface.

**Feature**      Voice Diagnostic Commands

**Mode**          Privileged Exec Mode

**Release**      4.3

**Options**

Option	Description	Range	DefaultValue
voice-port	One of the possible POTS names: tel1 or tel2.	tel1, tel2	NA

**Note**          Attempting to enter multiple time the same command before the execution of the previous test is terminated results in a CLI error message.

**Example**

```
awplus# tel1
      :
Status :                               : Pass      :
      :                               : Criteria  : Results
-----
Pass   : Off Hook Sense                : On        : No problems
found

-----
Pass   : HEMF Tip/Ground   DC voltage : abs <= 135V : 0.287 V
Pass   : HEMF Ring/Ground DC voltage : abs <= 135V : 0.164 V
Pass   : HEMF Tip/Ring    DC voltage : abs <= 135V : 0.451 V
Pass   : HEMF Tip/Ground AC voltage  : abs <= 50V  : 0.65 VRMS
Pass   : HEMF Ring/Ground AC voltage  : abs <= 50V  : 0.149 VRMS
Pass   : HEMF Tip/Ring    AC voltage  : abs <= 50V  : 0.214 VRMS

-----
Pass   : FEMF Tip/Ground   DC voltage : abs <= 6V   : 0.287 V
Pass   : FEMF Ring/Ground DC voltage : abs <= 6V   : 0.164 V
Pass   : FEMF Tip/Ring    DC voltage : abs <= 6V   : 0.451 V
Pass   : FEMF Tip/Ground AC voltage  : abs <= 10V  : 0.65 VRMS
Pass   : FEMF Ring/Ground AC voltage  : abs <= 10V  : 0.149 VRMS
Pass   : FEMF Tip/Ring    AC voltage  : abs <= 10V  : 0.214 VRMS

-----
Pass   : FEMF Tip/Ring    Current      : N/A        : Not Executed
-----
Pass   : Ringer Equivalence              :             : 0.12 REN
-----
Pass   : Resistive Fault (Tip/Ring)      : > 150k     : 185629 k
Pass   : Resistive Fault (Tip/Ground)    : > 150k     : 1650 k
Pass   : Resistive Fault (Ring/Ground)   : > 150k     : 2734 k
awplus#
```

---

## 8.5 Configuring Dial Peers

### 8.5.1 Configuring Dial Peers Command List (config-dial-peer)

This provides an alphabetical reference for commands used to configure Endpoints.

Table 8-16: Configure Dial Peers Command (config-dial-peer)

Commands
<a href="#">authentication username (config-dial-peer)</a>
<a href="#">destination-pattern (config-dial-peer)</a>
<a href="#">dial-peer (config-dial-peer)</a>
<a href="#">domain (config-dial-peer)</a>
<a href="#">registration-name (config-dial-peer)</a>
<a href="#">session target (config dial-peer)</a>
<a href="#">show dial-peer voice</a>
<a href="#">translate-outgoing (config-dial-peer)</a>

**AUTHENTICATION USERNAME (CONFIG-DIAL-PEER)**

**Syntax**            authentication username <username> password <password>  
                      [no] authentication username <username>

**Description**      This command specifies the username and password that is used by the SIP Client to register the particular user. This user is associated with the voice-port associated with the dial-peer, and so needs to be configured on an incoming dial peer associated with a physical port.

Use the no form of this command to remove the username and password. Note that the password can be encrypted - and if so - follows the standard AV+ encryption mechanisms.

**Feature**            Voice Commands

**Mode**                Dial Peer Configuration Mode

**Release**            4.1

**Options**

Option	Description	Range	Default Value
<username>	The username of the sip user - that is used at registration. This is usually the DN of the endpoint.	NA	NA
<password>	The password used when registering this user with the soft switch.	NA	NA

**Note**                The "realm" parameter is not supported. Only supported in POTS dial peers when SIP call service is configured.

**Example**            Refer to the following commands:

```
awplus#(config)# dial-peer voice 1 pots
awplus(config-dial-peer)# authentication username 9195551212 password mypassword
```

**DESTINATION-PATTERN (CONFIG-DIAL-PEER)**

**Syntax** destination-pattern <pattern\_string>  
[no] destination-pattern

**Description** Specifies the pattern-match string for dial-peer destination pattern. Only applies to SIP voice service. POTS dial-peers 1 and 2 map to Tel ports 1 and 2. VoIP dial-peer 3 is used to configure the digit map for the default contact location (sip-server). VoIP dial-peers 4 and above are optional and can be used to specify digit-maps for additional remote contact locations. See also [SIP Digit Map](#).

**Feature** Voice Commands

**Mode** Dial Peer Configuration Mode

**Release** 4.1

**Options**

Option	Description	Range	Default Value
pattern_string	For POTS dial peers, enter the digits for the Tel-port phone number. For VoIP ports enter digit-map as described in section 2.1.5 of RFC3435.	NA	NA

**Note** The destination pattern for dial-peer 3 must also include the destination patterns for dial-peers 4 and above if they exist.

**Example** Refer to the following examples.

```
awplus#(config)# dial-peer voice 1 pots
awplus(config-dial-peer)# destination-pattern 9198217861
```

**Example**

```
awplus#(config)# dial-peer voice 3 voip
awplus(config-dial-peer)# destination-pattern
[x*#].T|9xxxxxxx|99x|777|800xxxx|8000xxxxxxx|1xx|050xxxxxxx|00xxxxxx.T|0[2-4]xxxxxxx|0[6-7]xxxxxxx|09xxxxxxx|080[2-4]xxxxxxx|080[6-9]xxxxxxx|08050xxxxxxx|0800xxx|8xxxxxx
```

```
domain <STRING:hostname>
no domain
(domain only applies to dial-peers 4 and above)
```

```
translate-outgoing <UINT:rule>
no translate-outgoing
```

(translate-outgoing only applies to POTS dial-peers 1 and 2. Also, the translation rule must be pre-configured using the voice translation-rule command. This is already covered in 7.3.7 Configuring Voice Prefix Replacement (config-voi-trans-rule))

**DIAL-PEER (CONFIG-DIAL-PEER)**

**Syntax** `dial-peer voice tag {pots | voip}`

**Description** This command from the global configuration menu creates a dial peer - or enters the dial-peer configuration sub-menu.

**Feature** Voice Commands

**Mode** Dial Peer Configuration Mode

**Release** 4.1

**Options**

Option	Description	Range	Default Value
tag	Digits that define a particular dial-peer. Values are: 1 - tel1 2 - tel2 3 - 4+ SIP dial peers. In 4.2 multiple dial peers can be created.	NA	NA
pots	Indicates that this is a pots dial-peer that uses voip encapsulation. This type of dial-peer acts as an addressable entity and is used to map an FXS port to a digit string. It is also used to apply characteristics to calls terminating to that port.	NA	NA
voip	Indicates that this is a voip peer that uses voip encapsulation. This type of dial-peer maps a dial string to a remote network device - and defines characteristics of that connection.	NA	NA

**Note** NA

**Example** Refer to the following commands:

```
awplus#(config)# dial-peer voice 1 pots
awplus(config-dial-peer)# dial-peer voice tag pots
```

**DOMAIN (CONFIG-DIAL-PEER)**

**Syntax**            domain <STRING:hostname>  
                  no domain

**Description**      This command configures the member domain of dial-peers 4 and above. The No form of this command deletes the domain entry.

**Feature**            Voice Commands

**Mode**              Dial Peer Configuration Mode

**Release**            4.1

**Options**

Option	Description	Range	Default Value
hostname	Hostname representation per RFC-1035	NA	NA

**Note**                NA

**Example**            Refer to the following commands:

```
awplus# configure terminal
awplus(config)# dial-peer voice 4 voip
awplus(config-dial-peer)# domain testnet.org
```

**REGISTRATION-NAME (CONFIG-DIAL-PEER)**

**Syntax** registration-name <registration\_name>  
[no] registration-name

**Description** This command specifies a pseudonym to be used for registration as for outgoing calls in the FROM: header. The registration name can be used also on terminating calls to identify the POTS line. A user registered by pseudonym can then be addressed either by pseudonym or numeric address.

**Feature** Voice Commands

**Mode** Dial Peer Configuration Mode

**Release** 4.3.1

**Options**

Option	Description	Range	Default Value
< registration_name >	The registration string used for registering and for outgoing calls.	It can be a string of alpha-numeric [a-zA-Z0-9] and special chars [-_+]. Max 255 characters	NA

**Note** Command is only supported for POTS dial peers when SIP call service is configured.

**Example** Refer to the following examples:

```
awplus#(config)# dial-peer voice 1 pots
awplus(config-dial-peer)# destination-pattern 201723239873
awplus(config-dial-peer)# registration-name MrBobBrown-Line1
```



**SESSION TARGET (CONFIG DIAL-PEER)**

**Syntax**            `session target <destination> {[port]} {[proxy]}`  
                      `no session target`

**Description**      This command is used to define sip server ip addresses for the additional voip dial peers. This command is used with [destination-pattern \(config-dial-peer\)](#) when defining each additional voip dial peer.

**Feature**            Voice Commands

**Mode**              Dial Peer Configuration Mode

**Release**           4.2

**Options**

Option	Description	Range	Default Value
destination	The ip address or hostname that is the contact point for the sip network.	NA	NA
port	The SIP destination port of the target host.	NA	5060
proxy	The domain port of the URI equals the SIP domain configuration.	NA	None

**Note**                NA

**Example**            Refer to the following commands:

```
awplus#(config)# dial-peer voice 4 voip
awplus(config-dial-peer)# destination-pattern 201723232151
awplus(config-dial-peer)# session target 172.32.3.215
awplus(config-dial-peer)# end
awplus# show dial-peer voice 4
```

```
VoiceOverIpPeer4
  peer type = voice
  Admin state is up
  tag = 4
  protocol is session protocol sipv2
  destination-pattern = '201723232151'
  domain = ''
  session target = '172.32.3.215:5060'
  session target is not a proxy
```

**SHOW DIAL-PEER VOICE**

**Syntax** show dial-peer [voice <number>]

**Description** This command displays the configuration of a dial peer.

Displays detailed information about all dial-peers configured on the system. If a dial-peer is identified - then only the details of that dial peer are displayed.

**Feature** Voice Commands

**Mode** Privileged Exec Mode, User Exec

**Release** 4.1

**Options**

Option	Description	Range	Default Value
<number>	The dial-peer instance to display	NA	NA

**Note** NA

**Example** Refer to the following commands:

```
awplus# show dial-peer
```

```
POTSPeer1
  peer type = voice
  Admin state is up
  tag = 1
  protocol is session protocol sipv2
  destination-pattern = '201723232141'
  voice-port = 'tel1'
  translate-outgoing = 0
  SIP authentication username = '201723232141'
  SIP registration username = 'MrBobBrown-Line1'
```

```
POTSPeer2
  peer type = voice
  Admin state is up
  tag = 2
  protocol is session protocol sipv2
  destination-pattern = '201723232142'
  voice-port = 'tel2'
  translate-outgoing = 0
  SIP authentication username = '201723232142'
  SIP registration username = 'MrBobBrown-Line2'
```

```
VoiceOverIpPeer3
  peer type = voice
  Admin state is up
  tag = 3
  protocol is session protocol sipv2
  destination-pattern =
  '[x*#].T|9xxxxxxxx|99x|777|800xxxx|8000xxxxxxxx|1xx|050xxxxxxxx|00xxxxxx.T|0[2-4]xxxxxxxx|0[6-7]xxxxxxxx|09xxxxxxxx|080[2-4]xxxxxxxx|080[6-9]xxxxxxxx|08050xxxxxxxx|0800xxx|8xxxxxx'
```

```
awplus#
```

**TRANSLATE-OUTGOING (CONFIG-DIAL-PEER)**

**Syntax**            `translate-outgoing <UINT:rule#>`  
                     `no translate-outgoing`

**Description**       This command configures the translation rule applied to dialed digits. It only applies to POTS dial-peers 1 and 2. The No form of this command deletes the domain entry.

**Feature**            Voice Commands

**Mode**              Dial-Peer Configuration Mode

**Release**            4.1

**Options**

Option	Description	Range	Default Value
rule	The translation rule identifier (integer 1...4294967295)	NA	NA

**Note**                The translation rule must be pre-configured using the voice translation-rule command. This is covered in 7.3.7 Configuring Voice Prefix Replacement (config-voi-trans-rule).

**Example**            Refer to the following commands:

```
awplus# configure terminal
awplus(config)# dial-peer voice 1 pots
awplus(config-dial-peer)# translate-outgoing 1
```

## 9. Using the GUI Application

### 9.1 Overview


#### 9.1.1 Introduction

The iMG GUI allows the administrator to perform many of the query/control tasks for the iMG in a non-command environment. Refer to [How to Access the Product](#) for the steps to bring up the GUI on your browser.

**Caution:** While configuration tasks can be done with the GUI, most should be done using the *AlliedView NMS* or CLI, since these allow more control and are done in the context of a larger task. Where appropriate, there is a reference to a previous section of this document or the *AlliedView NMS Administration Guide*.

The following figure shows the initial screen, which is the **Device Info -> Summary** menu item.

**Note:** The recommended browser is Internet Explorer 8 since it has been fully validated.



The screenshot shows the iMG GUI interface. On the left is a navigation menu with the following items: Device Info, Advanced Setup, Wireless, and Management. The main content area is titled "Device Info" and contains four tables of system information.

System Information	
Vendor:	Allied Telesis Holdings
URL:	<a href="http://www.alliedtelesis.com">http://www.alliedtelesis.com</a>
Mac Address:	00:0c:25:00:01:6d
System Name:	
System Location:	
System Contact:	
System Up Time:	00:05:51
Load inst. 96 / 1min / 5min / 15min:	0.99% / 0.92s / 0.74s / 0.35s
Ram Total/Free:	117300 kB / 34692 kB

System Additional Information	
Hardware Version:	IMG1425W A
Hardware Serial Number:	ATNLAB4040302291
Partition One:	AT-IMG1400-4.3_106
Running Software Version / Build Type:	AtiBcm-4.3_106 / ALPHA
Running Voip Software Version:	AtiVoip-2.3_34
Running Build Date (yyymmdd_hhmm):	130326_0009
Bootloader Version:	AtiUboot-1.0_23
Wireless Driver / Hostapd Version:	0.9.17.1 / v1.0

Power Status Management	
System Power Mgmt:	Enabled
Battery:	Missing
Supply:	On battery supply
Battery Capacity:	Less than 20%
Battery Status:	Self test failed

Status WAN connection	
WAN IPv4 Address:	192.168.1.24
Default Gateway:	brv1.1
Primary DNS Server:	192.168.1.1
Secondary DNS Server:	
WAN IPv6 Address:	
Default IPv6 Gateway:	

FIGURE 9-1 Initial Screen for iMG GUI

## 9.2 Menu Levels

The GUI is comprised of four main levels:

- Device Info
- Advanced Setup
- Wireless (only present on wireless-equipped models)
- Management

The following tables go down into these four main levels and describes the menu and submenu headings

Table 9-1: Device Info Main Menu Level - Attributes

Menu	Submenu/Property	Description	Reference
Summary	System Information	Includes MAC address and system uptime Always www.alliedtelesis.com (main website)	<a href="#">show system</a>
	Power Status Management	Includes whether there is a battery backup, if the battery is being used, and if so how much power is left.	<a href="#">show system</a>
	System Additional Information	Provides the software load configuration. Note that wireless driver & hostapd version information is only present on wireless-equipped models.	<a href="#">show system</a>
	Status WAN Connection	Lists the IP connections	
WAN	WAN Info	Provides the status of features specific to the WAN interface.	
Statistics	LAN	Provides packet counts both received and transmitted.	
	WAN Service	Provides packet counts both received and transmitted.'	
Route	Device Info - Route	Provides the IP configuration for the interfaces	<a href="#">ip route</a>
ARP	Device Info - ARP	Provides the Ip and MAC association	NA

Table 9-2: Advanced Setup - Attributes

Attribute	Submenu/Property	Description	Reference
Layer2 Interface	ETH WAN Interface Configuration	Used to add or remove the ETH WAN interface	<a href="#">switchport access vlan</a>
WAN Service	Wide Area Network (WAN) Service Setup	Allows the user to enable NAT Firewall IGMP Multicast	<a href="#">ip nat enable</a>
LAN	Local Area Network (LAN) Setup	Allows the user to enable/set the LAN IP address enable Firewall IGMP Multicast.	<a href="#">ip address dhcp</a> NA <a href="#">ip igmp snooping</a>

Table 9-2: Advanced Setup - Attributes

Attribute	Submenu/Property	Description	Reference
NAT	Virtual Servers	show the virtual servers setup	<a href="#">show ip nat</a>
	Port Triggering	Shows which ports can be opened for access by remote parties	NA
	DMZ Host	Allows the user to enter the DMZ Host IP Address	NA
Security	Outgoing IP Filtering Setup	Allows the user to set up filters to block outgoing traffic.	access-list (standard numbered)
	Incoming IP Filtering Setup	When the firewall is enabled on a WAN or LAN interface, all incoming IP traffic is BLOCKED. However, some IP traffic can be ACCEPTED by setting up filters.  When the firewall is NOT ENABLED on a WAN or LAN interface, all incoming IP traffic is ALLOWED. However, some IP traffic can be DENIED by setting up filters to restrict access.	NA
	MAC Filtering	MAC Filtering is only effective on ATM PVCs configured in Bridge mode. FORWARDED means that all MAC layer frames will be FORWARDED except those matching with any of the specified rules in the following table. BLOCKED means that all MAC layer frames will be BLOCKED except those matching with any of the specified rules in the following table.  MAC Filtering Policy For Each Interface:  WARNING: Changing from one policy to another of an interface will cause all defined rules for that interface to be REMOVED AUTOMATICALLY! You will need to create new rules for the new policy.	NA
Parental Control	Time Restriction	Allows the user to restrict Internet Access to a list of well know stations at specific time and days of the week.	NA
	URL Filter	Allows the user to block the access to a list of web URL addresses.	NA
QOS Classification	QoS -- Queue Management Configuration	Allows the user to enable QoS and select a default DSCP.	NA
	Queue Config	Allows the user to configure the queue.	NA
	QoS Classification	Allows user to set criteria for the classifiers.	NA
Routing	Default Gateway	Sets the default gateway interfaces	<a href="#">ip route</a>
	Static Route	Sets the fixed routes	<a href="#">ip route</a>
	Policy Routing	Creates the policy names for WAN routes	NA

Table 9-2: Advanced Setup - Attributes

Attribute	Submenu/Property	Description	Reference
DNS Proxy	DNS Proxy Configuration	Allows the user to set a proxy router	NA
VLAN Status	VLAN Status -- A maximum 32 entries can be configured		<a href="#">show vlan</a>
Multicast	IGMP Configuration	Sets the iGMP protocol fields	<a href="#">ip igmp limit</a> , <a href="#">ip igmp query-interval</a> <a href="#">ip igmp query-max-response-time</a>

Table 9-3: Wireless - Attributes

Attribute	Submenu/Property	Description	Reference
Basic		Configures basic wireless properties including: <ul style="list-style-type: none"> <li>• Enable/disable of wireless</li> <li>• Country (regulatory domain)</li> <li>• 802.11 standard (i.e. b, g, n)</li> <li>• Channel</li> <li>• SSID</li> </ul>	shutdown no shutdown
Security		Configures 802.11 encryption & authentication	NA
MAC Filter		Sets blacklist & whitelist MAC address filters	NA
Station Info		Lists wireless clients associated with this iMG	NA

Table 9-4: Management - Attributes

Attribute	Submenu/Property	Description	Reference
Settings	Backup	A <b>Backup Settings</b> button saves the device configuration to a .cfg file	<a href="#">copy running-config</a>
	Update	Allows the user to update settings with an existing file	<a href="#">swupdate</a>
	Save Config	Saves the current configuration	<a href="#">copy running-config</a>
	Select Config	Lists the available config files and allows user to select the one used for the next update	<a href="#">show running-config</a>
System Log	System Log	The System Log dialog allows you to view the System Log and configure the System Log options. Click "View System Log" to view the System Log. Click "Configure System Log" to configure the System Log options	<a href="#">log host</a>
Security Log		The Security Log dialog allows you to view the Security Log and configure the Security Log options. Click "View" to view the Security Log. Click "Reset" to clear and reset the Security Log. Right-click here to save Security Log to a file.	<a href="#">log host</a>
SNMP Agent	SNMP - Configuration	Allows the user to enable or disable the SNMP Agent. If enabled: Read Community: Set Community: System Name: System Location: System Contact: Trap Manager IP:	<a href="#">snmp-server ip</a>



Table 9-4: Management - Attributes

Attribute	Submenu/Property	Description	Reference
TR-069 Client	TR-069 Client Configuration	<p>Allows a Auto-Configuration Server (ACS) to perform auto-configuration, provision, collection, and diagnostics to this device.</p> <p>Select the desired values and click "Apply/Save" to configure the TR-069 client options:</p> <p>Inform - Disable or Enable</p> <p>Inform Interval: 300 seconds is the default</p> <p>ACS URL:</p> <p>ACS User Name:</p> <p>ACS Password:</p> <p>WAN Interface used by TR-069 client</p> <p>Display SOAP messages on serial console - Disable or Enable</p> <p>Connection Request Authentication - Select option</p> <p>GETRPCMethods:</p>	<a href="#">tr69-client acs-authentication</a>
Internet Time	Time Settings	Allows configuration for automatic synchronizing with external time servers.	<a href="#">ntp conf</a>
Password		Allows the user to change their password.	
Update Software	Tools - Selection of firmware image to boot	<p>Select partition 1 or 2 that will be updated</p> <p>Follow the steps to retrieve and update the Partition.</p>	<a href="#">boot system</a>
Reboot	Button to Reboot System	Click the Reboot button to reboot the system. While rebooting, the connection to the PC is lost and restored	<a href="#">boot system</a>

## 9.3 Split Management

The iMG GUI allows the system administrator to provide a limited set of configuration WEB pages to the end user.

To reduce the content of the WEB pages, it's sufficient to configure a new Login user with privileges 9 to 14.

For example:

```
awplus# configure
awplus(config)# username home-user privilege 9 password my-home-pwd
```

By default a web login is created with username "admin" and password "admin" and privileged level equals to 14.

The following WEB pages are available when Split Management is configured:

- Device Info --> Summary
- Device Info --> WAN Info
- Device Info --> Statistics LAN
- Device Info --> Statistic WAN
- Device Info --> Route

- Device Info --> Arp
- Device Info --> DHCP (if the DHCP server is managing clients)
- Advanced Setup --> LAN setup (DHCP server configuration)
- Advanced Setup --> NAT virtual server (reserved mapping configuration)
- Advanced Setup --> NAT DMZ network configuration
- Advanced Setup --> Security IP filtering
- Advanced Setup --> Security port triggering
- Advanced Setup --> Parental control time restriction
- Advanced Setup --> Parental control url filter
- Wireless (only for wireless devices) --> Basic
- Wireless (only for wireless devices) --> Security
- Wireless (only for wireless devices) --> MAC filter
- Wireless (only for wireless devices) --> Station info
- Management --> Password configuration
- Management --> Reboot

**Note:** Refer to Table 8-2 for a complete device description

## 10. AMF

The Network Management functions of the iMG include the following:

- [AMF Agent Support](#)

---

### 10.1 AMF Agent Support

#### 10.1.1 Introduction

AlliedWare+ devices support AMF - which is a management framework that allows the customer to manage their network. The AMF Agent enables this framework to be aware of devices connected to an AMF enabled network - and pre-provisioning per interface of a Firmware image and Base Configuration for devices that are to be plugged into that device.

For more details on AMF please see the AMF Feature Overview and configuration Guide on the Support Web Page.

The information provided to the AMF Network can be displayed on the Hosting AW+ device as follows:

```
master#show atmf links agent detail
Agentlink: port1.0.4 is Up
    State: Full
    MAC: 0:c:25:3:9a:5e
    IPv4 Address: 10.52.140.200
    IPv6 Address: ::
    Device Type: iMG1425
    Serial Number: ATNLAB4040301297 XX
    Firmware Name: AtiBcm-4.5_10
    Firmware Version: 170414_1308
    Config Name: atmf_02.cfg
    Config Version: not available
    Configured Firmware URL: abc123-/home/wilco/tango/foxtrot/img.bin
```

The information provided to the iMG by the AMF master is the "Firmware URL". This is how the AMF Master provides the location of the Firmware image and base that the iMG is to use. Both these values are encoded into the URL as follows:

```
<config URL>;<Application image URL>
```

**Note** The order actually is not critical. It is critical that the configuration file name end in ".cfg". The Application image has encoded information that the iMG uses to identify it as an application image and confirm that it is compatible with the device.

A key point for usage of this feature is that there must be an untagged vlan on the WAN interface of the iMG.

## 10.1.2 AMF Agent Command List

This chapter provides an alphabetical reference of configure and show commands related to AMF.

Table 10-1: AMF Commands

Commands
<code>atmf</code>
<code>show atmf</code>

**ATMF**

<i>Source</i>	atmf
<i>Description</i>	This command enables the AMF Agent functionality on the iMG
<i>Feature</i>	AMF Commands
<i>Mode</i>	Global Configuration Mode
<i>Release</i>	4.5
<i>Options</i>	N/A
<i>Note</i>	A key point for usage of this feature - is that there must be an untagged vlan on the WAN interface of the iMG.

**Example**

```
awplus> enable
awplus# configure terminal
Enter configuration commands, one per line.  End with CNTL/Z.
awplus(config)# atmf
```

**SHOW ATMF**

**Syntax**            show atmf

**Description**      This command shows the state of the agent - and URL data downloaded by the AMF Master

**Feature**            AMF Commands

**Mode**                Priviledged Exec Mode

**Release**            4.5

**Options**            N/A

**Example**

The information received, and parsed can be viewed on the iMG as follows:

```
awplus#> show atmf
```

```
ATMF Status        : Enabled
```

```
  Parsed URL [1]: tftp://10.52.140.4/adear/amf_on.cfg
```

```
  Parsed URL [2]: tftp://10.52.140.4/adear/art_1600.bin
```

```
  Received URL    : tftp://10.52.140.4/adear/amf_on.cfg;tftp://10.52.140.4/adear/
art_1600.bin
```

## 11. Sample Command Sequences

### 11.1 Introduction

The following sections give command sequences for provisioning the iMG, as follows:

- All basic features (except voice) - [11.1.1](#)
- Voice Service - SIP - [11.1.2](#)
- Voice Service - MGCP - [11.1.3](#)
- IPv6 Configuration - [11.1.4](#)

**Note:** For a complete example that includes provides step-by-step commands and outputs that match a customer configuration, refer to the *AT-iMG1000 and 2000 Series Multiservice Gateway Application Notes*.

#### 11.1.1 Configuring the iMG (except for Voice Service)

Table 11-1: Provisioning Sequence for iMG (except for Voice Service) - complete example

Task / Notes	Go to Level	Command Set
Configure VLAN	VLAN (config-vlan)	<pre>enable configure terminal vlan database vlan 8 name vlan_default vlan 205 name vlan_video vlan 3030 name vlan_internal vlan 204 name vlan_data vlan 202 name vlan_mgmt vlan 203 name vlan_voip exit do show vlan</pre>

Table II-I: Provisioning Sequence for iMG (except for Voice Service) - complete example

Task / Notes	Go to Level	Command Set
Configure WAN	Interface (config-if)	<pre> configure terminal interface port1.0.4,port1.0.5 switchport mode trunk switchport trunk allowed vlan add 203,202,204,205 switchport trunk native vlan none exit </pre>
Configure LAN Ports		<pre> configure terminal interface port1.0.3 switchport mode access switchport access vlan 3030 interface port1.0.1,port1.0.2 switchport mode access switchport access vlan 205 exit do show vlan </pre>
Configure IP Addressing	Interface (config-if)	<pre> configure interface vlan3030 ip address 192.168.1.1/24  interface vlan205 ip address 172.32.5.201/24 interface vlan203 ip address dhcp  interface vlan204 ip address dhcp ip dhcp client request 6 ip dhcp client request 3  interface vlan202 ip address dhcp exit do show ip interface </pre>
Set up Routes	Configure terminal (config)	<pre> configure ip route 172.30.1.199/32 172.32.2.1 ip route 172.30.1.228/32 172.32.3.1 ip route 172.30.1.229/32 172.32.2.1 ip route 10.17.90.64/32 172.32.2.1 ip route 10.17.90.66/32 172.32.3.1 ip route 172.30.1.0/28 172.32.3.1 ip route 172.30.1.112/28 172.32.3.1 exit do show ip route exit </pre>



Table 11-1: Provisioning Sequence for iMG (except for Voice Service) - complete example

Task / Notes	Go to Level	Command Set
Set up DHCP Server	Interface (config-if)	<pre> configure interface vlan3030 ip dhcp poolrange 192.168.1.200 192.168.1.210 subnet-mask 255.255.255.0 domain-name iMG1500 lease 0 1 0 exit exitip dhcp server interface 3030 exit </pre>
Set up SNMP	Configure Terminal (config)	<pre> configure snmp-server ip snmp-server host 172.30.1.199 snmp-server community friend rw snmp-server contact ATL-Milan Testing Team snmp-server location Aquarium@firstfloor hostname iMG2524-201 exit </pre>
Set up NTP		<pre> configure ntp conf polling-time 300 ntp conf time-out 3 ntp peer 10.17.90.68 ntp peer pc229.service.stre.com clock timezone CET plus 1 exit </pre>
Set up IGMP		<pre> configure ip igmp version 2 interface vlan205 ip igmp snooping exit </pre>
Set up NAT	Interface (config-if)	<pre> configure interface vlan204 ip nat enable exit </pre>
Set up TR69 Client	Configure Terminal (config)	<pre> configure tr69-client inform interval 300000 tr69-client acs-url http://10.17.90.64:9797/cwmp/ACS exit </pre>
Save configuration	Privileged Exec Mode	<pre> enable copy running-config myconfig.cfg </pre>

## 11.1.2 Configuring Voice Service (SIP)

Table 11-2: Provisioning Sequence for SIP - Example

Task / Notes	Go to Level	Command Set
Set up dhcp for VLAN	Configuration interface	<pre>awplus(config)# interface vlan20 awplus(config-if)# ip address dhc awplus(config-if)# exit awplus(config)# exit awplus&gt; enable</pre>
Associate vlan with server	sip (from Voice Service)	<pre>awplus(config)# voice service voip awplus(config-voi-srv)# sip awplus(config-serv-sip)# call service awplus(config-serv-sip)# bind source-interface vlan20 awplus(config-serv-sip)# localhost dns allied.voip.com awplus(config-serv-sip)# no hairpin</pre>
Set up cp tone	Voice service	<pre>awplus(config-voi-srv)# cptone US</pre>
set up sip servers	sip protocol	<pre>awplus(config-sip-ua)# registrar 10.52.18.88 awplus(config-sip-ua)# sip-server 10.52.18.88</pre>
set up signaling	Voice service	<pre>awplus(config)# voice service voip awplus(config-voi-srv)# ip signaling precedence 32 awplus(config-voi-srv)# ip rtp precedence 46</pre>
Configure Endpoint Repeat this sequence with tel2	Voice Port	<pre>awplus(config)# voice-port tel1 awplus(config-voiceport)# no shutdown awplus(config-voiceport)# timing hookflash-input 900 awplus(config-voiceport)# timing onhook 1000 awplus(config-voiceport)# caller-id awplus(config-voiceport)# caller-id standard Bellcore awplus(config-voiceport)# caller-id mode FSK awplus(config-voiceport)# mwi</pre>
Configure codecs Repeat this sequence with tel2	Voice Class Codec	<pre>awplus(config)# voice class codec tel1 awplus(config-voice-class)# codec preference 1 g711ulaw packetization period 20 awplus(config-voice-class)# codec preference 2 g729abr8 packetization period 20 awplus(config-voice-class)# no codec preference g711alaw awplus(config-voice-class)# no codec preference g726r32</pre>
Configure Call-On-Hold – Repeat this sequence with tel2	Supplementary Services on port	<pre>awplus(config)# voipapp supplementary-services awplus(config-voipapp-suppl-serv)# port tel1 awplus(config-voipapp-suppl-serv-port)# hold-resume</pre>

Table 11-2: Provisioning Sequence for SIP - Example (Continued)

Task / Notes	Go to Level	Command Set
Configure Call Waiting Supplementary Services – Repeat this sequence with tel2	Voice Applications (access codes)	<pre>awplus(config)# voipapp feature access-code awplus(config-voipapp-fac)# call-waiting *31 awplus(config-voipapp-fac)# call-waiting cancel *32 awplus(config-voipapp-fac)# per-call call-waiting *41 awplus(config-voipapp-fac)# per-call call-waiting cancel *42 awplus(config-voipapp-fac)# suffix #</pre>
Activate Call Waiting	Voice Port	<pre>awplus(config)# voice-port tel1 awplus(config-voiceport)# call-waiting</pre>
Configure Call Forwarding Supplementary Services Repeat this sequence with tel2	Voice Applications (access codes)	<pre>awplus(config)# voipapp feature access-code awplus(config-voipapp-fac)# call forward all *61 awplus(config-voipapp-fac)# call forward all cancel *62 awplus(config-voipapp-fac)# call forward busy *71 awplus(config-voipapp-fac)# call forward busy cancel *72 awplus(config-voipapp-fac)# call forward no-answer *81 awplus(config-voipapp-fac)# call forward no-answer cancel *82 awplus(config-voipapp-fac)# suffix #</pre>
Activate features	Voice Supplementary Services	<pre>awplus(config)# voipapp supplementary-services awplus(config-voipapp-suppl-serv)# port tel1  awplus(config-voipapp-suppl-serv-port)# call forward all awplus(config-voipapp-suppl-serv-port)# call forward busy awplus(config-voipapp-suppl-serv-port)# call forward noan</pre>
Configure the SIP User	Dial Peer	<pre>awplus(config)# dial-peer voice 1 pots awplus(config-dial-peer)# destination-pattern 201723232011 awplus(config-dial-peer)# authentication username 1723232011 password alliedtelesis.com awplus(config-dial-peer)# exit awplus(config)# dial-peer voice 2 pots awplus(config-dial-peer)# destination-pattern 201723232012 awplus(config-dial-peer)# authentication username 1723232012 password alliedtelesis.com</pre>

### 11.1.3 Configuring Voice Service (MGCP)

Table 11-3: Provisioning Sequence for MGCP - Example

Task / Notes	Go to Level	Command Set
Configure the MGCP Protocol – and associate it with the appropriate VLAN	mgcp	<pre>awplus(config)# voice service voip awplus(config-voi-srv)# mgcp awplus(config-serv-mgcp)# call service awplus(config-serv-mgcp)# bind source-interface vlan20</pre>

Table 11-3: Provisioning Sequence for MGCP - Example

Task / Notes	Go to Level	Command Set
Set up cptone	voice service voip	awplus(config-voi-srv)# cptone US
Set up call agent and signaling	mgcp	awplus(config)# mgcp awplus(config-mgcp)# call-agent 10.52.18.88 #awplus(config-mgcp)# call-agent 172.30.1.228 2727 service-type mgcp-ncs #awplus(config-mgcp)# package-capability lcs-package #awplus(config-mgcp)# rtp payload-type nte dynamic  awplus(config-mgcp)# domain [\$IP]  #awplus(config-mgcp)# behavior heartbeat RSIP-keepalive 5
Configure priority for voice traffic	voice service	awplus(config)# voice service voip awplus(config-voi-srv)# ip signaling precedence 32 awplus(config-voi-srv)# ip rtp precedence 46
Configure Endpoint – Repeat this sequence with tel2	Voice port	awplus(config)# voice-port tell awplus(config-voiceport)# no shutdown awplus(config-voiceport)# timing hookflash-input 900 awplus(config-voiceport)# timing onhook 1000 awplus(config-voiceport)# caller-id awplus(config-voiceport)# caller-id standard Bellcore awplus(config-voiceport)# caller-id mode FSK
Configure Codecs – Repeat this sequence with tel2	Voice Class codec	awplus(config)# voice class codec tell awplus(config-voice-class)# codec preference 1 g711ulaw packetization period 20 awplus(config-voice-class)# codec preference 2 g729abr8 packetization period 20 awplus(config-voice-class)# no codec preference g711alaw awplus(config-voice-class)# no codec preference g726r32

### 11.1.4 IPv6 Configuration

Table 11-4: Provisioning Sequence for IPv6

Task / Notes	Go to Level	Command Set
Enable IPv6 forwarding on the iMG	Configure terminal(config)	<pre>enable configure terminal ipv6 forwarding exit show ipv6 forwarding</pre>
Configure VLAN	VLAN (config-vlan)	<pre>enable configure terminal vlan database vlan 2 name ipv6_wan vlan 11 name ipv6_lan_1 vlan 22 name ipv6_lan_2 exit do show vlan</pre>
Configure WAN port	Interface (config-if)	<pre>interface port1.0.6 switchport mode trunk switchport trunk allowed vlan add 2 exit do show vlan</pre>
Configure LAN ports	Interface (config-if)	<pre>interface port1.0.1,port1.0.2 switchport mode access switchport access vlan 11 interface port1.0.3,port1.0.4 switchport mode access switchport access vlan 22 exit do show vlan</pre>
Configure WAN IPv6	Interface (config-if)	<pre>interface vlan2 ipv6 nd rs-interval 1 ipv6 nd rs-attempts 32 ipv6 dhcp client pd MyPrefix hint ::/63 ipv6 dhcp client request domain-name-servers ipv6 address dhcp default exit do show ipv6 interface verbose vlan2</pre>

Table 11-4: Provisioning Sequence for IPv6 (Continued)

Task / Notes	Go to Level	Command Set
Configure LAN IPv6 interfaces	Interface (config-if)	<pre> interface vlan11 ipv6 nd ra-interval 20 ipv6 nd other-config-flag no ipv6 nd suppress-ra ipv6 address MyPrefix 0:0:0:0::/64 eui-64  interface vlan22 ipv6 nd ra-interval 20 ipv6 nd other-config-flag no ipv6 nd suppress-ra ipv6 address MyPrefix 0:0:0:1::/64 eui-64  exit </pre>
Set up DHCPv6 server	Interface (config-if)	<pre> ipv6 dhcp pool 11 dns-server 2001:2:3::4 domain-name mydomain.com exit  ipv6 dhcp pool 22 dns-server 2001:2:3::4 domain-name mydomain.com exit  ipv6 dhcp server interface 11 ipv6 dhcp server interface 22 exit  show ipv6 interface verbose vlan11 show ipv6 interface verbose vlan22 </pre>
Verify prefix delegation is working	Privileged Exec Mode	<pre> show ipv6 general-prefix </pre>
Save Configuration	Privileged Exec Mode	<pre> copy running-config myconfig.cfg </pre>

## Appendix A: Command List

access-group	364
access-list	365
add provider	154
add url	155
atmf	625
authentication key-management	289
authentication method (config-sip-ua)	524
authentication open	290
authentication username (config-dial-peer)	608
backup-call-agent (config-mgcp)	508
behavior disable-url-matching	525
behavior heartbeat (config-mgcp)	510
behavior hook-flash (config-sip-ua)	526
behavior rsip-range (config-mgcp)	511
behavior softswitch (config-sip-ua)	528
bind (config-serv-mgcp)	496
bind (config-serv-sip)	501
boot config-file	74
boot default button	75
boot system recovery crc	77
boot system recovery filename	78
boot system recovery server	79
boot system	76
call forward all (config-voipapp-fac)	544
call forward all (config-voipapp-suppl-serv-port)	566
call forward all cancel (config-voipapp-fac)	545
call forward busy (config-voipapp-fac)	546
call forward busy (config-voipapp-suppl-serv-port)	567
call forward busy cancel (config-voipapp-fac)	547
call forward noan (config-voipapp-suppl-serv-port)	568
call forward no-answer (config-voipapp-fac)	548
call forward no-answer cancel (config-voipapp-fac)	549
call service (config-serv-mgcp)	498
call service (config-serv-sip)	503
call service restart (config-serv-mgcp)	497
call service restart (config-serv-sip)	502
call-agent (config-mgcp)	512
caller-id (config-voice-port)	579

---

caller-id alerting (config-voice-port) - - - - -	577
caller-id block (config-voice-port) - - - - -	578
caller-id block override off (config-voipapp-fac) - - - - -	552
caller-id block override on (config-voipapp-fac) - - - - -	553
caller-id mode (config-voice-port) - - - - -	580
caller-id signal (config-voice-port) - - - - -	581
caller-id standard (config-voice-port) - - - - -	582
call-waiting (config-voice-port) - - - - -	576
call-waiting (config-voipapp-fac) - - - - -	550
call-waiting cancel (config-voipapp-fac) - - - - -	551
channel - - - - -	291
clear hpna counters - - - - -	281
clear log - - - - -	122
clear mac address-table dynamic - - - - -	227
clear mac address-table static - - - - -	228
clear port counter - - - - -	229
clear port-security intrusion interface - - - - -	215
client-isolation - - - - -	292
clock set - - - - -	96
clock summer-time - - - - -	97
clock timezone - - - - -	98
codec preference (config-voice-class) - - - - -	602
conference (config-voipapp-fac) - - - - -	554
conference (config-voipapp-suppl-serv-port) - - - - -	569
config-reset - - - - -	293
configure terminal - - - - -	42
copy running-config - - - - -	81
copy startup-config - - - - -	82
copy - - - - -	80
cptone (config-voi-serv) - - - - -	484
debug access level - - - - -	367
debug sshd - - - - -	357
debug voip category (config) - - - - -	480
debug - - - - -	123
delete - - - - -	83
deny - - - - -	294
description - - - - -	230
destination-pattern (config-dial-peer) - - - - -	609
dial-peer (config-dial-peer) - - - - -	610
dial-type (config-voice-port) - - - - -	583
dir - - - - -	84
disable (Privileged Exec Mode) - - - - -	43
disconnect-supervision osi - - - - -	584
dns-server (ipv6)- - - - -	400
dns-server - - - - -	399

---



---

do	44
domain (config-dial-peer)	611
domain (config-mgcp)	513
domain-name (ipv6)	402
domain-name	401
dot11 ssid	295
dtmf-relay voip (config-voi-serv)	485
duplex	231
echo-cancel (config-voice-port)	585
egress-rate-limit	344
enable (Privileged Exec Mode)	45
enable default button configuration	85
enable password	52
end	46
endpoint offset (config-mgcp)	514
erase startup-config	86
exec-timeout	53
exit	47
fax protocolt38 (config-voi-serv)	486
filename	403
firewall enable (config-if)	368
flowcontrol	232
flowcontrol	345
guest-mode	296
hairpin (config-serv-sip)	504
help	48
hold-resume (config-voipapp-suppl-serv-port)	570
host	404
hostname	101
http	156
import dns-server (ipv6)	406
import domain-name (ipv6)	407
ingress-rate-limit	346
input gain (config-voice-port)	587
interface catv	133
interface dot11radio1.0.1	297
interface hpna1.0.1	280
interface port	131
interface vlan	134
ip address dhcp	405
ip address	157
ip ddns update hostname	158
ip ddns update method	159
ip dhcp client broadcast-flag	408
ip dhcp client class-id	409

---

---

ip dhcp client client-id - - - - -	410
ip dhcp client request - - - - -	411
ip dhcp pool- - - - -	412
ip dhcp server interface - - - - -	413
ip domain-name - - - - -	160
ip firewall trigger (config-if) - - - - -	369
ip igmp last-member-query-interval - - - - -	327
ip igmp limit- - - - -	328
ip igmp proxy-service (interface level)- - - - -	330
ip igmp proxy-service - - - - -	329
ip igmp query-interval - - - - -	331
ip igmp query-max-response-time - - - - -	332
ip igmp robustness-variable- - - - -	333
ip igmp snooping fast-leave - - - - -	335
ip igmp snooping- - - - -	334
ip igmp version - - - - -	336
ip name-server (config) - IPv6 - - - - -	186
ip name-server (IPv4)- - - - -	161
ip nat enable - - - - -	381
ip nat portmap - - - - -	382
ip route- - - - -	162
ip rtp precedence (config-voi-serv)- - - - -	487
ip signaling precedence (config-voi-serv) - - - - -	488
ip upnp local enable- - - - -	460
ip upnp network enable - - - - -	461
ipv6 access-list extended - - - - -	370
ipv6 address (config-if) - - - - -	183
ipv6 dhcp client pd - - - - -	414
ipv6 dhcp client request - - - - -	415
ipv6 dhcp pool - - - - -	416
ipv6 enable (config-if)- - - - -	184
ipv6 forwarding (config) - - - - -	185
ipv6 nd dad-attempts (config-if) - - - - -	187
ipv6 nd managed-config-flag (config-if)- - - - -	188
ipv6 nd minimum-ra-interval (config-if) - - - - -	189
ipv6 nd other-config-flag (config-if) - - - - -	190
ipv6 nd ra-interval (config-if) - - - - -	191
ipv6 nd rs-attempts (config-if) - - - - -	192
ipv6 nd rs-delay (config-if)- - - - -	193
ipv6 nd rs-interval (config-if) - - - - -	194
ipv6 nd suppress-ra (config-if) - - - - -	195
ipv6 route (config)- - - - -	196
ipv6 traffic-filter - - - - -	372
jumbo-frame - - - - -	233
lease - - - - -	417

---

---

listen-port (config-serv-mgcp) - - - - -	499
listen-port (config-serv-sip) - - - - -	505
localhost (config-serv-sip) - - - - -	506
log host- - - - -	124
logout - - - - -	49
loop-protection action link-down- - - - -	234
loop-protection loop-detect - - - - -	235
loop-protection timeout- - - - -	236
mac address-table acquire - - - - -	237
mac address-table ageing-time - - - - -	238
map alertinfo (config-sip-ua) - - - - -	529
map alertinfo (config-sip-ua) - - - - -	530
max-association - - - - -	298
mirror interface - - - - -	239
mls qos cos - - - - -	347
mls qos map cos-queue - - - - -	348
mls qos map premark-dscp to new-queue - - - - -	349
mls qos trust cos - - - - -	350
mls qos trust dscp- - - - -	351
move - - - - -	87
mwi (config-voice-port) - - - - -	586
network (DHCP) - - - - -	430
ntp conf - - - - -	389
ntp peer - - - - -	390
ntp sync - - - - -	391
option- - - - -	418
output attenuation (config-voice-port) - - - - -	588
package-capability lcs-package (config-mgcp) - - - - -	515
per-call call-waiting (config-voipapp-fac) - - - - -	555
per-call call-waiting cancel (config-voipapp-fac) - - - - -	556
permit- - - - -	299
persistent (config-mgcp) - - - - -	516
piggyback message (config-mgcp) - - - - -	517
ping (ipv4) - - - - -	163
ping ipv6 - - - - -	197
platform vlan-stacking-tpid - - - - -	240
playout-delay (config-voice-port) - - - - -	589
playout-delay mode (config-voice-port)- - - - -	590
ppp authentication - - - - -	272
ppp ipcp default route - - - - -	273
ppp ipcp dns request - - - - -	274
ppp sent-username - - - - -	275
pppoe enable - - - - -	276
prefix (config-voipapp-fac) - - - - -	557
protected - - - - -	373

---

---

protocol-family - - - - -	300
psu-management- - - - -	102
range - - - - -	419
registration-name (config-dial-peer) - - - - -	612
rel xx- - - - -	531
remove provider- - - - -	164
remove url- - - - -	165
request retries (config-mgcp) - - - - -	518
request timeout (config-mgcp)- - - - -	519
rtcp (config-voi-serv) - - - - -	491
rtp behavior discard-when-remote-unknown (config-voi-serv) - - - - -	489
rtp behavior discard-when-source-unknown (config-voi-serv) - - - - -	490
rtp payload-type (config-mgcp) - - - - -	520
rtp payload-type (config-voi-serv)- - - - -	492
rule - - - - -	540
service dhcp-server - - - - -	420
service http - - - - -	54
service ssh - - - - -	358
service ssh - - - - -	55
service telnet - - - - -	56
session target (config dial-peer) - - - - -	613
show access-group - - - - -	374
show access-list - - - - -	375
show atmf - - - - -	626
show boot - - - - -	88
show catv diagnostics - - - - -	136
show catv - - - - -	135
show clock - - - - -	103
show controllers dot11 radio - - - - -	301
show counter dhcp-client - - - - -	421
show counter dhcp-server - - - - -	422
show cpu- - - - -	104
show dhcp lease - - - - -	424
show dial-peer voice - - - - -	614
show dot11 associations - - - - -	302
show dot11 bssid - - - - -	303
show exec-timeout - - - - -	58
show file - - - - -	89
show history - - - - -	50
show hosts - - - - -	166
show hpna counters - - - - -	282
show hpna stations - - - - -	283
show http - - - - -	57
show interface brief- - - - -	140
show interface dot11 radio1.0.1 status- - - - -	305

---

---

show interface dot11radio1.0.1 - - - - -	304
show interface status - - - - -	141
show interface switchport - - - - -	142
show interface switchport - - - - -	241
show interface - - - - -	137
show ip ddns - - - - -	167
show ip dhcp binding - - - - -	425
show ip dhcp pool - - - - -	426
show ip dhcp server summary - - - - -	427
show ip domain-list - - - - -	168
show ip domain-name - - - - -	169
show ip firewall status <VLAN id> - - - - -	385
show ip firewall status - - - - -	376
show ip igmp groups - - - - -	339
show ip igmp - - - - -	337
show ip interface brief - - - - -	170
show ip name-server (ipv4) - - - - -	171
show ip name-server (ipv6) - - - - -	198
show ip nat - - - - -	383
show ip route - - - - -	172
show ip sockets - - - - -	173
show ip upnp - - - - -	462
show ipv6 access-list extended - - - - -	377
show ipv6 dhcp interface - - - - -	428
show ipv6 forwarding - - - - -	199
show ipv6 general-prefix - - - - -	200
show ipv6 interface brief - - - - -	201
show ipv6 interface verbose - - - - -	202
show ipv6 neighbors - - - - -	203
show ipv6 route - - - - -	204
show ipv6 traffic-filter - - - - -	378
show line - - - - -	59
show log config - - - - -	127
show log - - - - -	125
show loop-protection - - - - -	242
show mac address-table - - - - -	243
show memory shared - - - - -	106
show mgcp - - - - -	521
show mirror - - - - -	244
show mls qos interface - - - - -	352
show mls qos maps cos-queue - - - - -	353
show mls qos maps premark-dscp - - - - -	354
show ntp associations - - - - -	392
show ntp status - - - - -	393
show platform port counters - - - - -	246

---

show platform	245
show port-security interface	216
show port-security intrusion	217
show pppoe	277
show running-config snmp	440
show running-config	91
show security-password user	60
show sip service	532
show sip-ua map alertinfo	534
show sip-ua	533
show snmp-server community	442
show snmp-server traps	443
show snmp-server	441
show ssh server	359
show ssh server	62
show ssh	61
show startup-config	92
show storm-control	247
show swupdate	115
show system pluggable	109
show system psu	110
show system	108
show tech-support	111
show telnet	63
show test voice port	605
show test	284
show tr69-client	452
show version	93
show vlan	259
show voice port	591
show voice translation-rule	541
show voipapp	559
show wireless country supported	306
shutdown (config-if)	143
shutdown (config-if-catv)	144
shutdown (config-voi-serv)	493
shutdown	310
shutdown	593
sip-server (config-sip-ua)	535
snmp-server community	445
snmp-server contact	446
snmp-server enable traps link-status	447
snmp-server host	448
snmp-server ip	444
snmp-server location	449

---

---

snmp-server system-shutdown - - - - -	450
speed - - - - -	248
ssid-name - - - - -	311
storm-control - - - - -	249
subnet-mask- - - - -	429
subscribe message-summary - - - - -	536
suffix (config-voipapp-fac) - - - - -	560
switchport access vlan - - - - -	260
switchport block- - - - -	250
switchport mode access- - - - -	261
switchport mode trunk - - - - -	262
switchport port-security aging- - - - -	219
switchport port-security maximum - - - - -	220
switchport port-security violation - - - - -	221
switchport port-security - - - - -	218
switchport trunk allowed vlan - - - - -	263
switchport trunk native vlan - - - - -	265
switchport vlan-stacking (double tagging)- - - - -	266
swupdate now - - - - -	117
swupdate- - - - -	116
terminal length - - - - -	64
terminal monitor - - - - -	113
test interface hpna1.0.1 - - - - -	286
test voice port - - - - -	604
timeouts initial - - - - -	597
timeouts interdigit- - - - -	598
timeouts ringing - - - - -	599
timing hookflash-input - - - - -	594
timing offhook-input - - - - -	595
timing onhook-input - - - - -	596
tone incoming (config-voi-srv) - - - - -	494
tr69-client acs-authentication - - - - -	453
tr69-client acs-url - - - - -	454
tr69-client bind source-interface <if-name> - - - - -	455
tr69-client bind source-interface <VLAN:vlan>- - - - -	456
tr69-client inform - - - - -	457
tr69-client request-authentication - - - - -	458
traceroute ipv6- - - - -	205
traceroute - - - - -	174
transfer blind (config-voipapp-fac) - - - - -	561
transfer consult (config-voipapp-fac) - - - - -	562
transfer-mode (config-voipapp-suppl-serv-port) - - - - -	571
translate-outgoing (config-dial-peer) - - - - -	615
username - - - - -	65
vad (config-voice-port)- - - - -	600

---

---

vlan database - - - - -	268
vlan - - - - -	267
vlan - - - - -	312
voice translation-rule - - - - -	539
warmline (config-voipapp-fac) - - - - -	563
warmline (config-voipapp-suppl-serv-port) - - - - -	572
warmline cancel (config-voipapp-fac) - - - - -	564
warmline digits (config-voipapp-suppl-serv-port) - - - - -	573
warmline timeout (config-voipapp-suppl-serv-port) - - - - -	574
world-mode dot11d country-code - - - - -	313
wpa-psk - - - - -	314




## Appendix B: Windows 7, 8, and 10 Drivers

### B.1 Uninstalling the Existing Driver


Before proceeding with the installation and configuration of the Windows driver you must remove the association to the old ATI USB driver.

**Note:** Skip this section if the Allied Telesis USB driver has never been installed before.


1. From the **Start** menu, select **Devices and Printers**.
2. Under **Devices**, right-click on **USB Network Interface** and select **Properties**.




3. Select the **Hardware** tab.




4. Click **Properties**.



5. Click **Change Settings**.



6. Select the **Driver** tab.



7. Click **Uninstall**, then **OK** in the **Confirm Device Uninstall** window.




8. Close the **USB Remote NDIS Device Properties** window.
9. Disconnect the USB cable.


## B.2 Installing the Windows 7 (Or 8 or 10) Native Driver

This section describes the steps to instruct Windows 7 to use its universal NDIS driver to control the USB interface associated with the Allied Telesis iMG.


1. From the **Start** menu, select **Devices and Printers**.
2. Under **Unspecified**, right-click on **USB Network Interface** and select **Properties**.




3. Select the **Hardware** tab.




4. Select **Properties**.




5. Select **Change Settings**.




6. Select the **Driver** tab, then select **Update Driver**.




7. Select **Browse my computer for driver software**.




8. Select **Let me pick a list of device drivers on my computer.**



9. Select **Network Adapters**, then click **Next**.




10. Under **Manufacturer**, select **Microsoft Corporation**. Under **Network Adapter**, select **Remote NDIS Compatible Device**.




11. Click **Next**.
12. In the **Update Driver Warning** window, click **Yes**.






13. Wait for Windows to install the driver. Click **Close** when you receive the confirmation that the driver software has updated successfully.




14. The new USB device will be displayed in the Devices list




## B.3 Disabling IPv6 on the USB Interface

The final steps for Windows 7 to communicate to an iMG USB interface consist of disabling IPv6 support on the USB connection.


1. Open the **Control Panel**.
2. Select the **Network and Sharing Center**.




3. Select the **Local Area Connection** corresponding to the USB/iMG interface.



4. Select **Properties**.



5. Deselect **Internet Protocol Version 6 (TCP/IPv6)**, then click **OK**.



6. Unplug the USB cable and then plug it back again to get the valid IPv4 address.