

Mail (SMTP)

Feature Overview and Configuration Guide

Introduction

This guide describes how to configure and use the mail feature. The mail feature utilizes Simple Mail Transfer Protocol (SMTP) to transfer mail from an internal email client operating within the AlliedWare Plus device. This feature is typically used to email event notifications to an external email server from the AlliedWare Plus device.

What is SMTP?

SMTP is a TCP/IP protocol used to send mail. SMTP is limited in its ability to queue messages at the receiving end, so protocols POP3 or IMAP can be used to let the client (user) save messages to an email server. This allows a client to save messages in a server mailbox and download them periodically from the server. Typically a client uses a program that uses SMTP for sending an email and either POP3 or IMAP for receiving email.

SMTP sessions consist of commands originating from a sender (SMTP client). Each SMTP session has transactions that contain the email recipient, subject, and message body. The following default ports are used to send mail:

- SMTP clients use port 587
- SMTP servers use TCP port 25
- SMTP servers configured with TLS use:
 - port 465 with SMTPS
 - port 587 with STARTTLS

AlliedWare Plus devices are capable of acting as an SMTP client. To send mail, the receiving SMTP server must be configured. Once configured you can send mail either from the command line, or from a script, typically based on event notifications. The mail command is often used from a script which is connected to a trigger. For example, you can send an email if a connection to a particular device is down.

For more information about using log type triggers and email logging commands, see the [Logging Feature Overview and Configuration Guide](#).



Contents

Introduction	1
What is SMTP?.....	1
Products and software version that apply to this guide	3
How to configure mail	4
Set up your SMTP server.....	4
Optional SMTP server parameters (authentication and port)	5
Set up secure TLS	6
Set up your email address as the sender	7
Send your email	7
Monitor your mail	8
Delete mail from the queue.....	9
Debug mail.....	9
Email log	9
Configuration examples	12
Interactive message.....	12
Non interactive message	12
Non interactive message with authentication and port parameters	12
Interactive message with parameter substitutions	13
Non interactive message using a trigger script with parameter substitutions.....	13
Interactive message with TLS method using STARTTLS.....	14
Interactive message with TLS method using SMTPS.....	15
Non interactive message with a trigger script	16
Show commands	17

Products and software version that apply to this guide

This guide applies to all AlliedWare Plus™ products, running version **5.4.4** or later.

For more information, see the following documents:

- The [product's Datasheet](#)
- The product's [Command Reference](#)

These documents are available from the above links on our website at alliedtelesis.com.

Most features described in this document are supported from AlliedWare Plus 5.4.4 or later. These features are available in later releases:

- Version 5.4.8-1 and later support new features to configure optional authentication and port parameters for your SMTP server.
- Version 5.5.3-0.1 and later support TLS authentication in the mail client.

How to configure mail

The following steps must be carried out in order to send emails from your device:

- **Set up your SMTP server**
- **Optional SMTP server parameters (authentication and port)**
- **Set up secure TLS**
- **Set up your email address as the sender**
- **Send your email**
- **Monitor your mail**
- **Delete mail from the queue**
- **Debug mail**
- **Email log**

Set up your SMTP server

First specify the **<IP address>** or domain **<name>** of your SMTP email server that your device sends email to. From Global Configuration mode, use the **mail smtpserver** command as follows:

```
awplus(config)#mail smtpserver {<ip-address>|<name>}
```

If you specify this server by its domain **<name>**, you must also ensure that the DNS client on your device is enabled. It is enabled by default, but if it has been disabled, you can re-enable it by using the **ip domain-lookup** command.

Example To configure your SMTP server with the name “smtp.example.com”, use the command:

```
awplus(config)#mail smtpserver smtp.example.com
```

To remove the configured SMTP server, use the **no mail smtpserver** command.

Optional SMTP server parameters (authentication and port)

If you are configuring your SMTP server for a device from release 5.4.8-1, or later, you have options to configure authentication and port parameters, which may be required if the external email needs to perform authentication before accepting incoming emails from the email client, or if the email server uses a non-default port.

SMTP server authentication options

To configure your SMTP server with authentication options, use the **mail smtpserver authentication** command from Global Configuration mode:

```
awplus(config)#mail smtpserver authentication {crammd5|login|plain}
username <username> password [8] <password>
```

Authentication parameter options are:

Table 1: Authentication options

PARAMETER NAME	DESCRIPTION
crammd5	This is a Challenge Request Authentication Mechanism (CRAM-MD5) and is the most secure.
login	This is a base64 encryption mechanism.
plain	This is a base64 encryption mechanism.
<username>	Registered username.
8	The registered user password is presented in an already encrypted format. This is how the running configuration stores the plain text password and is not for general use.
<password>	Registered user password.

Each of these parameters requires a <username> and <password> that is registered on your SMTP server.

Example To configure an authentication login username 'person' and password 'uniquePassword', use the command:

```
awplus(config)#mail smtpserver authentication login username person
password uniquePassword
```

To remove the configured SMTP server authentication mechanism, use the **no mail smtpserver authentication** command.

Note: You cannot change the IP address or Domain Name of your SMTP server if authentication is configured. If you attempt to change it when authentication is configured, the following warning message is displayed:

```
% Error: authentication configuration still exists
```

SMTP server port options

To configure your SMTP server port, use the **mail smtpserver port** command from Global Configuration mode:

```
awplus(config)#mail smtpserver port <port>
```

Specify the SMTP client/server communication port from the range 1 to 65535.

Example To configure your mail client to perform server communication over port 587, use the command:

```
awplus(config)#mail smtpserver port 587
```

To set your SMTP client/server port back to the default port 25 (if TLS is not configured), use the **no mail smtpserver port** command.

Set up secure TLS

If you are configuring your SMTP server for a device from release 5.5.3-0.1 or later, you can send emails to SMTP servers over a TLS connection. This makes sending email from AlliedWare Plus devices more secure. It also allows people to use other SMTP servers that do not accept emails over clear-text connection.

A secure TCP connection is created after negotiation with the server, which involves choosing the encryption algorithm to use, STARTTLS or SMTPS.

STARTTLS

The connection starts as clear-text SMTP first and then the client establishes a TLS connection using the STARTTLS method. After that point, the SMTP authentication and email message are sent through the encrypted TLS connection.

To configure a TLS connection with STARTTLS, use the following commands:

```
awplus(config)#mail smtpserver smtp.example.com
awplus(config)#mail from example@example.com
awplus(config)#mail smtpserver tls starttls
awplus(config)#mail smtpserver authentication login username example
password uniquePassword
```

SMTPS

A secure connection is established at the beginning, and the whole SMTP communication is through the encrypted TLS connection.

To configure a TLS connection with SMTPS, use the following commands:

```
awplus(config)#mail smtpserver smtp.example.com
awplus(config)#mail from example@example.com
awplus(config)#mail smtpserver tls smtps
awplus(config)#mail smtpserver authentication login username example
password uniquePassword
```

Default SMTP server ports

If the SMTP server port is not configured, or reset by the command **no mail smtpserver port**, the default ports are:

- 25 if TLS is not configured
- 587 if TLS is configured for STARTTLS
- 465 if TLS is configured for SMTPS.

For full configuration examples, see ["Interactive message with TLS method using STARTTLS"](#) on page 14, and ["Interactive message with TLS method using SMTPS"](#) on page 15.

Set up your email address as the sender

Before sending an email, first you must specify your email address as the sender with the **<from>** parameter. From Global Configuration mode use the **mail from** command as follows:

```
awplus(config)#mail from <from>
```

Example To configure your email address as the sender "person@example.com", use the command:

```
awplus(config)#mail from person@example.com
```

To remove the sending email address, use the **no mail from** command.

Send your email

After you have configured your SMTP server and set your email address as the sender, you can then send your email. You can send your emails interactively via screen prompts for each parameter. This allows you to type your message body directly on your screen. Otherwise, you can send your email so that all parameters are specified in one line and the optional file parameter stores the message body.

Interactive message

This method allows you to send messages interactively via the CLI by being prompted for the parameters from the console. If you enter the **mail** command with no parameters specified, the email client interactively prompts you for a **<to>** address, a **<subject>** and message body. Press enter to end the message body, then press **ctrl-d**, to send your email.

From Privileged Exec mode, use the **mail** command as follows:

```
awplus#mail [to <to>] [subject <subject>] [file <filename>]
```

Non-interactive message

This method allows you to send a message in one line with all the parameters specified, including **<to>** address, a **<subject>** and **<filename>** (the file stores the message body).

From Privileged Exec mode, use the **mail** command as follows:

```
awplus#mail to <to> subject <subject> file <filename>
```

Parameter substitution

When you use the **mail** command you can use parameter substitutions in the subject field. The following table lists the parameters that can be substituted and their descriptions:

Table 2: Parameter substitution

PARAMETER NAME	DESCRIPTION
%N	When this parameter is specified, the %N is replaced by the hostname of your device.
%S	When this parameter is specified, the %S is replaced by the serial number of your device.
%T, %D, %L	When you use either of these parameters %T, %D, %L they will be replaced by the current date and time (local time) on your device.
%U	When you use this parameter, the %U is replaced by the current date and time (UTC time) on your device.

Any combination of %D, %T, %L, %U, %S, %N is substituted in the subject text. This includes multiple substitutions of the same parameter type.

Note: If no local time is configured, it uses UTC.

Example To send an email using parameter substitutions for the hostname, serial number and date, use the command:

```
awplus#mail to example@gmail.com subject "Sending email from Hostname:%N
Serial Number:%S Date:%T"
```

The recipient mail server will receive an email containing:

```
Received: by gmail.com (nbSMTP-1.00) for uid 0 example@gmail.com; Tue, 10 Apr
2018 03:45:02 +0000 (UTC)
To: <example@tb212.st.atlnz.lc>
From: <example@gmail.com>
Subject: "Sending email from Hostname:top Serial Number:A05049G154200043
Date:2018-04-10T03:45:01+0000"
```

Monitor your mail

From Privileged Exec mode, use the **show mail** command to display emails in the queue as follows:

```
awplus#show mail
```

From User Exec or Privileged Exec modes, use the **show counter mail** command to display the email counters as follows:

```
awplus#show counter mail
```

This command shows you the number of emails sent successfully since the last device restart, and the number of emails your device failed to send since the last device restart.

Delete mail from the queue

From Privileged Exec mode, use the **delete mail** command to delete emails in the queue as follows:

```
awplus#delete mail [mail-id <mail-id>|all]
```

You need the **<mail-id>** from the **show mail** command output to delete specific emails, or use the **<all>** parameter to clear all messages in the queue completely.

Example To delete the mail-id “20180501183635.16737” from the queue, use the command:

```
awplus#delete mail 20180501183635.1637
```

Debug mail

From Privileged Exec mode, to turn on debugging for sending emails, use the **debug mail** command as follows:

```
awplus#debug mail
```

From Privileged Exec mode, to turn off debugging for sending emails, you can use either the **no debug mail** command, or the **undebug mail** command as follows:

```
awplus#no debug mail
```

or

```
awplus#undebug mail
```

Email log

The following commands are available to use in conjunction with the mail feature, and are used to ensure logged events result in automatic email notifications. These commands are in the Logging Commands Chapter in the Setup and Troubleshooting section in the Command Reference manual:

- default log email
- log email
- log email (filter)
- log email exclude
- log email time
- show log config

You can configure your device to send log messages to an email address. By default no filters are defined for email log targets. Filters must be defined before messages will be sent.

From Global Configuration mode, use the command:

```
awplus(conf)#log email <email-address> [level <level>] [program <program-name>] [facility <facility>] [msgtext <text-string>]
```

Examples To create a filter to send all messages containing the text “Pool exhausted”, to the email address admin@example.com, use the following commands:

```
awplus#configure terminal
awplus(conf)#log email admin@example.com msgtext "Pool exhausted"
```

To create a filter to send messages with a severity level of “informational” and above to the email address “admin@example.com”, use the following commands:

```
awplus#configure terminal
awplus(conf)#log email admin@example.com level informational
```

To stop the device emailing log messages emailed to the email address admin@example.com, use the following commands:

```
awplus#configure terminal
awplus(conf)#no log email admin@example.com
```

To remove a filter that sends messages with a severity level of “informational” and above to the email address “admin@example.com”, use the following commands:

```
awplus#configure terminal
awplus(conf)#no log email admin@example.com level informational
```

Some example output from the **show log config** command follows:

```
Facility: default
PKI trustpoints: example_trustpoint

Buffered log:
Status ..... enabled
Maximum size ... 100kb
Filters:
*1 Level ..... notices
  Program ..... any
  Facility ..... any
  Message text . any
  2 Level ..... informational
    Program ..... auth
    Facility ..... daemon
    Message text . any
  Statistics ..... 1327 messages received, 821 accepted by filter (2016 Oct 11 10:36:16)
Permanent log:
Status ..... enabled
Maximum size ... 60kb
Filters:
  1 Level ..... error
    Program ..... any
    Facility ..... any
    Message text . any
  *2 Level ..... warnings
    Program ..... dhcp
    Facility ..... any
    Message text . "pool exhausted"
  Statistics ..... 1327 messages received, 12 accepted by filter (2016 Oct 11 10:36:16)
Host 10.32.16.21:
Time offset .... +2:00
Offset type .... UTC
Source ..... -
Secured ..... enabled
Filters:
  1 Level ..... critical
    Program ..... any
    Facility ..... any
    Message text . any
  Statistics ..... 1327 messages received, 1 accepted by filter (2016 Oct 11 10:36:16)
Email admin@example.com:
Time offset .... +0:00
Offset type .... Local
Filters:
  1 Level ..... emergencies
    Program ..... any
    Facility ..... any
    Message text . any
  Statistics ..... 1327 messages received, 0 accepted by filter (2016 Oct 11 10:36:16)
...
```

For more information about logging email, see your product's [Command Reference](#).

Configuration examples

Interactive message

This example shows an interactive message configuration, where the email client prompts you for each parameter. In this example below, the mail message body is manually typed via the command shell interactively. This interactive capability can be useful as a user aid when initially configuring and testing the mail feature for the first time.

```
awplus>en
awplus#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
awplus(config)#mail smtpserver smtp.example.com
awplus(config)#mail from example@example.com
awplus(config)#exit
awplus#mail
To: example1@example1.com
Subject:
The LAN interface is down

Type the message below and finish with a CTRL-d
The LAN interface is down
Sending 20180501183635.16737...
```

Non interactive message

This example shows all parameters specified in the configuration, including the message body. In this example below, the mail message body is that is stored in a file named message.txt.

```
awplus#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
awplus(config)#mail smtpserver 192.0.2.1
awplus(config)#mail from example@example.com
awplus(config)#exit
awplus#mail to example2@example2.com subject "The LAN interface is down" file
message.txt
Sending 20180501201513.22840...
```

Note: The named text file must already exist in the root directory of flash.

Non interactive message with authentication and port parameters

This example shows authentication and port parameters configured:

```
awplus#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
awplus(config)#mail smtpserver 192.0.2.1
awplus(config)#mail smtpserver authentication plain username example3 password
uniquePassword
awplus(config)#mail smtpserver port 587
awplus(config)#mail from example@example.com
awplus(config)#exit
awplus#mail to example3@example3.com subject "testing" file message.txt
Sending 20180501191513.23930...
```

Example show running-config:

```
mail smtpserver 192.0.2.1
mail smtpserver authentication plain username example3 password 8
xKnq11ClOgquJxt91cz04tCVBChLjkTPze+nk25MaxM=
mail smtpserver port 587
mail from example@example.com
```

Interactive message with parameter substitutions

This example shows parameter substitution in the mail subject text:

```
awplus#
awplus#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
awplus(config)#mail smtpserver smtp.example.com
awplus(config)#mail from example@example.com
awplus(config)#exit

awplus#mail to example4.net subject "Sending email from Hostname:%N Serial
Number:%S Date:%T"

Type the message below and finish with a CTRL-d
The WAN is down
Sending 20180411033215.26950... ok.
```

This example shows what the recipient will receive:

```
To: <smtp.example.net>
From: <example@example.com>
Subject: "Sending email from Hostname:CON Serial Number:V9128981EB6B9E38
Date:2018-04-11T03:32:07+0000"

The WAN is down
```

Non interactive message using a trigger script with parameter substitutions

This example shows a trigger script that uses parameter substitutions for the hostname, serial number and date in the mail subject text:

```
awplus#show file sendmail.scp
enable
mail to examplename@tb212.st.atlnz.lc subject "Sending email from Hostname:%N
Serial Number:%S Date:%T"

activate sendmail.scp
AlliedWare Plus (TM) 0.0.0 04/10/18 03:21:34

enable
mail to examplename@tb212.com subject "Sending email from Hostname:%N Serial
Number:%S Date:%T"

Type the message below and finish with a CTRL-d
Sending 20180410035746.2510...
exit
```

This example shows what the recipient will receive:

```
Received: by gmail.com (nbSMTP-1.00) for uid 0 exemplename@gmail.com; Tue, 10
Apr 2018 03:45:02 +0000 (UTC)
To: <exemplename@tb212.com>
From: <exemplename@gmail.com>
Subject: "Sending email from Hostname:top Serial Number:A05049G154200043
Date:2018-04-10T03:45:01+0000"
```

Interactive message with TLS method using STARTTLS

```
awplus(config)# mail smtpserver smtp.example.com
awplus(config)# mail from example@example.com
awplus(config)# mail smtpserver tls starttls
awplus(config)# mail smtpserver authentication login username example password
uniquePassword

awplus# show run | grep mail
mail smtpserver smtp.example.com
mail smtpserver authentication login username example password 8
+512Zartc7fV2r9cPTy1eJVREvdi+H66C6zFVBPJR+Q=
mail smtpserver tls starttls
mail from example@example.com

awplus# mail to example1@example.com subject mail1

Type the message below and finish with a CTRL-d
This is a message.
^D

awplus# show mail
Mail Settings
-----
State                               : Alive
SMTP Server                         : smtp.example.com
Host Name                           : example@example.com
Authentication                       : login
Username                            : example
Port                                 : 587
Use TLS                             : STARTTLS
Debug                               : Disabled

Messages
-----
To                                  : example1@example.com
Subject                             : mail1
Message-ID                          : 20221205123648.18627
```

Interactive message with TLS method using SMTPS

```
awplus(config)# mail smtpserver smtp.example.com
awplus(config)# mail from example@example.com
awplus(config)# mail smtpserver tls smtps
awplus(config)# mail smtpserver authentication login username example password
uniquePassword

awplus# show run | grep mail
mail smtpserver smtp.example.com
mail smtpserver authentication login username example password 8
+512Zartc7fV2r9cPTy1eJVREvdi+H66C6zFVBPJR+Q=
mail smtpserver tls smtps
mail from example@example.com

awplus# mail to example2@example.com subject mail2

Type the message below and finish with a CTRL-d
This is a message.
^D

awplus# show mail
Mail Settings
-----
State                               : Alive
SMTP Server                         : smtp.example.com
Host Name                           : example@example.com
Authentication                       : login
Username                            : example
Port                                 : 465
Use TLS                             : SMTPS
Debug                               : Disabled

Messages
-----
To                                   : example2@example.com
Subject                             : mail2
Message-ID                          : 20221205125307.10845
```

Non interactive message with a trigger script

This example shows how to automatically send a mail notification when memory usage exceeds 90 percent. In the example below, when memory usage exceeds the trigger threshold, a script is activated. This generates an automatic email notification of the event.

```
awplus>enable
awplus#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
awplus(config)#mail smtpserver example@example.com
awplus(config)#mail smtpserver authentication crammd5 username fred password uniquePassword
awplus(config)#mail from fred@example.com
awplus(config)#trigger 1
awplus(config-trigger)#type memory ?
<1-100> The percentage of memory usage at which to trigger

awplus(config-trigger)#type memory 90 ?
any    Activate when memory usage passes the specified level in either
        direction
down   Activate when memory usage drops below the specified level
up     Activate when memory usage exceeds the specified level
<cr>

awplus(config-trigger)#type memory 90 up
awplus(config-trigger)#active
awplus(config-trigger)#script ?
<1-5> The list position of the script

awplus(config-trigger)#script 1 ?
FILE   The file containing the script

awplus(config-trigger)#script 1 mem.scp
awplus(config-trigger)#active
awplus(config-trigger)#end
awplus#debug mail
awplus#term mon
03:11:51 awplus TRIGGER[3569]: Trigger 1 activated
03:11:51 awplus TRIGGER[3572]: Executing /flash/mem.scp
03:11:51 awplus IMISH[3576]: [SCRIPT]
03:11:51 awplus IMISH[391]: Last message '[SCRIPT]' repeated 5 times, suppressed by syslA
03:11:51 awplus IMISH[3576]: [SCRIPT]enable
03:11:51 awplus IMISH[3576]: [SCRIPT]mail to example@example.com subject "Host:awplus with
Serial: 012345678 memory utilization high at 2018-07-11T15:09:31+0000"
03:11:52 awplus nbSMTP[3593]: Creating connection to host (example@example.com:25)
03:11:53 awplus nbSMTP[3593]: Authentication succeeded [fred]
03:11:54 awplus nbSMTP[3593]: Recipient accepted [example@example.com]
03:11:55 awplus nbSMTP[3593]: Mail sent for example@example.com. Closing connection
03:11:55 awplus IMISH[3576]: [SCRIPT]exit
```

```
awplus#sh trigger
TR# Type & Details      Description          Ac Te Tr Repeat      #Scr Days/Date
-----
001 Memory (90% up)    Y N Y Continuous    1  smtwtfS
```

```
awplus#show trigger count
Trigger Module Counters
-----
Trigger activations                1
Last trigger activated             1
Time triggers activated today      0
Periodic triggers activated today  0
Interface triggers activated today  0
CPU triggers activated today       0
Memory triggers activated today    1
Reboot triggers activated today    0
Ping-poll triggers activated today  0
USB event triggers activated today  0
Stack master fail triggers activated today  0
Stack member triggers activated today  0
Stack link triggers activated today  0
ATMF node triggers activated today  0
Log triggers activated today       0
-----
```



```
Mail and trigger configuration is as follows:
```

```
!
trigger 1
  type memory 90 up
  script 1 mem.scp
!
mail smtpserver example@example.com
mail smtpserver authentication crammd5 username fred password 8
gkXRH5Dac4ERvttVu054mSCHVghVccV20c16OG6t97Q=
mail from fred@example.com
!
```

```
awplus#dir
 4096 drwx Jun 28 2018 20:58:16 log/
 1352 -rw- May 30 2018 02:10:51 default.cfg
   103 -rw- May 09 2018 06:33:45 mem.scp
43371435 -rw- Oct 26 2017 23:05:50 AR3050S-tb247.rel
```

```
awplus#show file mem.scp
enable
mail to fred@example.com subject "Host: %N with Serial: %S memory utilization high at %L"
```

Show commands

The **show mail** command displays emails in the SMTP server queue:

```
awplus#show mail
Mail Settings
-----
State                : Alive
SMTP Server          : example@example.com
Host Name             : fred@example.com
Authentication        : login
Username              : fred
Port                  : 587
Use TLS              : STARTTLS
Debug                 : Disabled

Messages
-----
To : fred@example.com
Subject : "Host:awplus with Serial: 012345678 memory utilization
high at 2018-07-11T15:09:31+0000"
Message-ID : 20180711150931.12139
```

This example shows the result after deleting message-ID “20180711150931.12139” from the queue. Use the **show mail** command to check it has been deleted:

```
awplus#delete mail mail-id 20180711150931.12139
awplus#show mail
Mail Settings
-----
State                : Alive
SMTP Server          : smtp.example.com
Host Name             : example@example.com
Debug                 : Disabled

Messages
-----
```

This example shows the output from the **show counter mail** command so you can check that your messages have been sent successfully:

```
awplus#show counter mail
Mail Client (SMTP) counters
Mails Sent           ..... 2
Mails Sent Fails     ..... 0
```

C613-22109-00 REV C



NETWORK SMARTER

North America Headquarters | 19800 North Creek Parkway | Suite 100 | Bothell | WA 98011 | USA | T: +1 800 424 4284 | F: +1 425 481 3895
Asia-Pacific Headquarters | 11 Tai Seng Link | Singapore | 534182 | T: +65 6383 3832 | F: +65 6383 3830
EMEA & CSA Operations | Incheonweg 7 | 1437 EK Rozenburg | The Netherlands | T: +31 20 7950020 | F: +31 20 7950021

alliedtelesis.com

© 2023 Allied Telesis, Inc. All rights reserved. Information in this document is subject to change without notice. All company names, logos, and product designs that are trademarks or registered trademarks are the property of their respective owners.